

# **CLARK**

## **OPERATORS MANUAL**

### **No. 2653**

### **Models 175B & 275B**

### **MICHIGAN**

### **Tractor Shovels**

**Information contained herein pertains  
to Machine Serial Numbers listed below:**

**175B G.M.            - 427A101 & →**  
**175B G.M.            - 427B101 & →**  
**175B CUMMINS - 438A101 & →**  
**175B CUMMINS - 438B101 & →**  
**275B CUMMINS - 425A101 & →**  
**275B CUMMINS - 425B101 & →**  
**275B CUMMINS - 425C101 & →**







# CLARK

## OPERATORS MANUAL

### No. 2653

### Models 175B & 275B

### MICHIGAN

### Tractor Shovels

Information contained herein pertains  
to Machine Serial Numbers listed below:

175B G.M.            – 427A101 & →  
175B G.M.            – 427B101 & →  
175B CUMMINS – 438A101 & →  
175B CUMMINS – 438B101 & →  
275B CUMMINS – 425A101 & →  
275B CUMMINS – 425B101 & →  
275B CUMMINS – 425C101 & →

Record Your Machine Serial Number and Engine  
Model Specification and Serial Number Here

Machine Serial \_\_\_\_\_

Engine Model \_\_\_\_\_

Engine Serial \_\_\_\_\_



## **TO OWNERS**

The purpose of this manual is to serve as a guide to the proper operation, lubrication and minor adjustment of the Clark Tractor Shovel. Study this manual carefully before starting or operating the machine the first time. Become familiar with all controls and procedures, and keep the manual on the machine for handy reference.

You have purchased this Clark Tractor Shovel with the expectation that it would give you long and faithful service. In its construction we have taken every precaution to see that you get an efficient, long lived, satisfactory machine. It is our sincere hope that you derive from its operation the full measure of value and utility which you looked forward to when purchasing it.

For these reasons, we take the liberty of suggesting that your Clark Tractor Shovel will always respond at its best with considerate treatment and care. The slight outlay in personal attention and cost required to give it regular and proper lubrication, inspection at stated intervals, and such adjustments as may be indicated, will repay you many times in low cost operation and trouble-free service.

Whenever repair or replacement of component parts is required, only Clark-approved parts as listed in the applicable parts manual should be used. Use of "will-fit" or non-approved parts may endanger proper operation and performance of the equipment. The Clark Equipment Company does not warrant repair or replacement parts, nor failures resulting from the use thereof, which are not supplied by or approved by the Clark Equipment Company.




## TABLE OF CONTENTS


<b>GENERAL DESCRIPTION</b> . . . . .	01-01-1	Tighten Wheel Nuts and Inspect Rims . . . . .	45-02-3
Data Plates . . . . .	01-01-1	Check Air Chambers and Lines for Leaks . . . . .	45-02-3
<b>PREPARATION FOR OPERATION</b> . . . . .	05-01-1	Clean Cylinder Rods . . . . .	45-02-3
<b>INSTRUMENTS AND OPERATING CONTROLS</b> . . . . .	10-01-1	<b>100 HOUR MAINTENANCE OPERATIONS</b> . . . . .	45-03-1
Instruments and Switches . . . . .	10-01-2	Engine Maintenance . . . . .	45-03-1
Operating Controls . . . . .	10-01-3	<b>250 HOUR MAINTENANCE OPERATIONS</b> . . . . .	45-04-1
<b>OPERATING INSTRUCTIONS</b> . . . . .	15-01-1	Engine Maintenance . . . . .	45-04-1
Safety Precautions . . . . .	15-01-1	Check Engine RPM . . . . .	45-04-1
<b>STARTING PROCEDURES</b> . . . . .	20-01-1	Adjust Bucket Leveler . . . . .	45-04-2
Pre-Starting Checks . . . . .	20-01-1	Adjust Service (Wheel) Brakes . . . . .	45-04-3
Cold Weather Starting . . . . .	20-01-1	Adjust Parking Brake . . . . .	45-04-4
Warm-Up Checks . . . . .	20-01-1	Adjust and Lubricate Operator's Seat . . . . .	45-04-5
Parking Area Checks . . . . .	20-01-2	Check and Adjust Lower Hinge Pin Bushing . . . . .	45-04-6
<b>G.M. DIESEL</b> . . . . .	25-01-1	Check Brake Disc Mounting Bolts . . . . .	45-04-7
<b>CUMMINS DIESEL</b> . . . . .	30-01-1	Service Reservoir Return Filter Assemblies . . . . .	45-04-8
<b>OPERATING TRACTOR SHOVEL</b> . . . . .	35-01-1	Clean Reservoir Suction Filter Assemblies . . . . .	45-04-8
Setting Machine in Motion . . . . .	35-01-1	<b>500 HOUR MAINTENANCE OPERATIONS</b> . . . . .	45-05-1
Loading the Bucket . . . . .	35-01-1	Engine Maintenance . . . . .	45-05-1
Transporting the Load . . . . .	35-01-1	Clean Radiator Core . . . . .	45-05-1
Dumping the Bucket . . . . .	35-01-1	Check and Adjust Transmission	
Backfilling and Spreading . . . . .	35-01-2	Shift Lever Linkage . . . . .	45-05-1
Traveling Without a Load in Bucket . . . . .	35-01-2	Check Transmission De-Clutch Valve . . . . .	45-05-2
Towing the Machine . . . . .	35-01-2	Check Converter Internal Pressure . . . . .	45-05-2
<b>LUBRICATION</b> . . . . .	40-01-1	Check Transmission Clutch, Lubricating	
Every 8 Operating Hours . . . . .	40-01-3	and Oil Cooler Pressures . . . . .	45-05-3
Every 50 Operating Hours . . . . .	40-02-1	Check Boom and Bucket Pressure . . . . .	45-05-4
Every 100 Operating Hours . . . . .	40-03-1	Check and Adjust Main Hydraulic Pump . . . . .	45-05-7
Every 250 Operating Hours . . . . .	40-04-1	Adjust Boom and Bucket Control Levers . . . . .	45-05-8
Every 500 Operating Hours . . . . .	40-05-1	Clean and Tighten Electrical Connections . . . . .	45-05-8
Every 1000 Operating Hours . . . . .	40-06-1	Clean Axle Breathers . . . . .	45-05-9
Chassis Lubrication Chart — 175B . . . . .	40-07-1	Check Steering Pressure . . . . .	45-05-9
Drive Line Lubrication Chart — 175B . . . . .	40-07-2	Check and Adjust Steering Pump . . . . .	45-05-10
Chassis Lubrication Chart — 275B . . . . .	40-08-1	Bleed Steering Relief Valve . . . . .	45-05-11
Drive Line Lubrication Chart — 275B . . . . .	40-08-2	Adjust Draglink Ball Joints . . . . .	45-05-11
<b>MAINTENANCE SCHEDULE</b> . . . . .	45-00-1	Steam Clean Machine . . . . .	45-05-11
<b>MAINTENANCE</b> . . . . .	45-01-1	Service Air Cleaner Element . . . . .	45-05-12
<b>DAILY OR SHIFT MAINTENANCE OPERATIONS</b> . . . . .	45-01-1	<b>1000 HOUR MAINTENANCE OPERATIONS</b> . . . . .	45-06-1
Engine Maintenance . . . . .	45-01-1	Engine Maintenance . . . . .	45-06-1
Check Air Cleaner Service Indicator . . . . .	45-01-1	Check Accumulator Pre-Charge . . . . .	45-06-1
Check Tire Pressure and Casings . . . . .	45-01-1	Radiator . . . . .	45-06-3
Inspect Brakes . . . . .	45-01-1	Check and Repair Bucket Cutting Edges . . . . .	45-06-3
Visually Inspect Machine . . . . .	45-01-1	Check Boom to Bucket Linkage . . . . .	45-06-5
<b>50 HOUR MAINTENANCE OPERATIONS</b> . . . . .	45-02-1	Inspect, Test and Lubricate Electrical Units . . . . .	45-06-5
Engine Maintenance . . . . .	45-02-1	Inspect Frame . . . . .	45-06-6
Check Cooling System for Leaks . . . . .	45-02-1	<b>BOLT TORQUE CHART</b> . . . . .	50-01-1
Drain Fuel Tank Sediment . . . . .	45-02-1	<b>CAPACITIES</b> . . . . .	55-01-1
Check Anti-Freeze Protection . . . . .	45-02-1	<b>ENGINE SPECIFICATIONS AND</b>	
Tighten Air Cleaner Connections . . . . .	45-02-1	<b>SERVICE DATA</b> . . . . .	60-01-1
Check and Adjust Belt Tension . . . . .	45-02-1	<b>TIRE DATA AND HYDROINFLATION</b> . . . . .	65-01-1
Check Hydraulic System for Leaks . . . . .	45-02-2	<b>WIRING DIAGRAM — 175B G.M.</b> . . . . .	70-01-1
Check Lights and Fuses . . . . .	45-02-3	<b>WIRING DIAGRAM — 175B &amp; 275B CUMMINS</b> . . . . .	70-02-1



**CLARK**



MODEL SHOWN WITH OPTIONAL EQUIPMENT.



MODEL SHOWN WITH OPTIONAL EQUIPMENT.



## GENERAL DESCRIPTION

CLARK Articulated Tractor Shovels are constructed for rugged heavy-duty industrial and commercial applications. They are specifically engineered for maximum ease of operation to move the greatest amount of material in the shortest possible time.

Drive power is from the engine through a Clark torque converter, to a Clark power shifted transmission, to Clark axle assemblies. Universal slip-joint drive shaft assemblies are used between power transfer units.

Axle assemblies are Clark all wheel drive, spiral bevel ring gear and pinion, with further gear reduction provided by planetary gear sets within the wheel hubs.

Constant four-wheel drive provides additional tractive effort and power for any operating condition. Effortless hydraulic power steering is provided, utilizing two double acting steering cylinders, one at each side between front and rear frames.

Service brakes provide braking effort on all four wheels, with a cable controlled mechanical parking brake mounted on the drive line.

Numerous quick-change attachments are available as optional accessory equipment, enabling one to increase the usefulness of the machine for a variety of different operations.

For more complete specifications refer to Specifications and Service Data in the rear of this manual.

### DATA PLATES

Data plates and decals used throughout the machine aid in its safe efficient operation; others give service instructions. Read all instruction plates before starting and operating the machine.

#### AREA WARNING DECAL

The warning decal as shown in Figure 1 is located on the surfaces of both fuel tank and hydraulic reservoir. Safety links should be attached between front and rear frames when servicing the




Fig. 1. Area Warning Decal

machine. Service personnel must stay out of these areas when the engine is running, or the machine is in motion, as there is not enough space for a man in the area when machine is turned.

#### MACHINE SERIAL NUMBER PLATE

The machine serial number plate gives model number and serial number of machine. See Figure 2. Serial number of machine also is stamped in one-half inch numerals beneath right hand upper pivot assembly, and on the rear beneath the wrap around.

IMPORTANT: ALWAYS GIVE SERIAL NUMBER OF MACHINE WHEN ORDERING PARTS.




Fig. 2. Machine Serial Number Plate

LUBRICATION INSTRUCTIONS						
ITEM	SHOVEL	DOZER	SCRAPER	CHECK	LUBRICATION OR CHANGE PERIOD	LUBRICANT KEY
AIR CLEANER(S)	X	X	X		SEE OPERATORS MANUAL FOR DETAILED INSTRUCTIONS.	
HYDRAULIC RESERVOIR	X	X	X	8 HRS.	1000 HRS.	HF
TORQUE CONVERTER & TRANSMISSION	X	X	X	8 HRS.	500 HRS.	HF
ALL GREASE FITTINGS EXCEPT: AUTOMATIC LUBE SYSTEM RESERVOIR** BOOM & BUCKET SEALED LINKAGE PINS** BRAKE CAMSHAFT FITTINGS PROPELLER SHAFT FITTINGS ELEVATOR MOTOR CIRCUIT SWIVEL JOINTS	X X X X —	X X — X —	X X — X X	— — — — —	8 HRS. 8 HRS. *100 HRS. 50 HRS. *100 HRS. 250 HRS.	LBG-1 LBG-2 LBG-1 LBG-1 LBG-1 LBG-1
FRONT AXLE DIFFERENTIAL	X	X	X	50 HRS.	1000 HRS. - 6 MO.	SAE 90 EPGL-1
REAR AXLE DIFFERENTIAL	X	X	—	50 HRS.	1000 HRS. - 6 MO.	SAE 90 EPGL-1
FRONT AXLE PLANETARY HUBS	X	X	X	50 HRS.	1000 HRS. - 6 MO.	SAE 90 EPGL-1
REAR AXLE PLANETARY HUBS	X	X	—	50 HRS.	1000 HRS. - 6 MO.	SAE 90 EPGL-1
REAR AXLE WHEEL BEARINGS	—	—	X	—	1000 HRS. - 6 MO.	WB
REAR AXLE WHEEL BEARINGS & CENTER STEER ARM BEARINGS (Non-Driving Axles)	X	—	—	—	1000 HRS. - 6 MO.	WB
STEERING GEAR**	X	X	X	50 HRS.	—	LBG-1
FAN DRIVE GEAR BOX**	—	X	—	50 HRS.	1000 HRS. - 6 MO.	SAE 90 GL
ELEVATOR GEARBOX	—	—	X	50 HRS.	1000 HRS. - 6 MO.	SAE 90 EPGL-2
MIDMOUNT BEARING ASSEMBLY: A — Equipped with level & drain plug B — Equipped with grease fittings (2)	X X	X X	— —	50 HRS. —	1000 HRS. - 6 MO. 100 HRS.	HF LBG-1
BRAKE MASTER CYLINDER (Hydraulic & Air Over Hydraulic Brakes)	X	—	X	50 HRS.	—	BF
BRAKE POWER CLUSTER AIR CHAMBER (Air Over Hydraulic Brakes)	X	—	X	—	1000 HRS.	HF
CAB PRESSURIZER FILTER**	X	X	X	REMOVE, CLEAN & REPLACE EVERY 8 HRS. OR OFTENER AS REQUIRED		
HYDRAULIC SYSTEM BREATHER	X	X	X	REMOVE, CLEAN & REPLACE EVERY 50 HRS.		
CONVERTER BREATHER	X	X	X	REMOVE, CLEAN & REPLACE EVERY 50 HRS.		
TRANSMISSION BREATHER	X	X	X	REMOVE, CLEAN & REPLACE EVERY 50 HRS.		
CONVERTER & TRANSMISSION OIL FILTERS	X	X	X	—	250 HRS.	—
STEERING SYSTEM OIL FILTERS	X	X	X	—	250 HRS.	—
BRAKE SYSTEM AIR DRYER CARTRIDGE**	X	X	X	*CHANGE CARTRIDGE EVERY 500 HRS.		
HYDRAULIC RESERVOIR SUCTION & RETURN FILTERS	X	X	X	CLEAN OR REPLACE EVERY 250 HRS.		
AXLE BREATHERS	X	X	X	REMOVE, CLEAN & REPLACE EVERY 500 HRS.		
ENGINE, FUEL & OIL FILTERS & ACCESSORIES				SEE ENGINE OPERATORS MANUAL FOR INSTRUCTIONS.		
*LUBRICATION OR CHANGE PERIOD IS AS INDICATED, EXCEPT WHEN DIFFERENT ON DECAL BELOW. **WHERE APPLICABLE.						
LUBRICANT KEY						
LBG-1	LITHIUM BASE MULTI-PURPOSE GREASE 0°F & ABOVE — GRADE 2 BELOW 0°F — GRADE 0	GL	STRAIGHT MINERAL OIL GEAR LUBE — API CLASS GL1			
		BF	SAE J1703 (70R-3) BRAKE FLUID			
LBG-2	LITHIUM BASE MULTI-PURPOSE GREASE 30°F (−1°C) & ABOVE — GRADE 0 −30°F (−34°C) TO 30°F (−1°C) — GRADE 00	WB	WHEEL BEARING GREASE — EP GRADE 1 (Lithium Soap or Lithium Lead Type — 40 lbs. Min. Lever Load, Timken Test)			
		HF	AMBIENT TEMP. RANGE		LUBRICANT TO BE USED	
ABOVE 0°F (−18°C)			SAE 10W Engine Oil, API Class SD or SE MIL-L-2104B or MIL-L-2104C. (For Optional Lubricants See Operators Manual).			
0°F (−18°C) & BELOW			See Operators Manual			
EPGL-1	EXTREME PRESSURE GEAR LUBE — SCL TYPE	HF				
EPGL-2	EXTREME PRESSURE GEAR LUBE — API CLASS GL4 (Military Spec. MIL-L-2105B)					
SEE APPLICABLE OPERATORS MANUAL FOR DETAILED INSTRUCTIONS.						
						TS-13907

Fig. 3. Lubrication Instruction Decal



## LUBRICATION INSTRUCTION DECAL

The lubrication instruction decal as shown in Figure 3 provides a list of items to be lubricated on specific models, intervals of lubrication, and types of lubricant to be used. However, in addition to the lubrication instruction decal, it will be necessary to refer to the Lubrication Section in applicable Operator's Manual for location of lubricating points and detailed instructions pertaining to lubrication.

## SAFETY WIRING DECAL

The safety wiring decal as shown in Figure 4 appears on machines equipped with an alternator having a negative grounded electrical system.

The alternator is a continuous output diode rectified alternating current (a.c.) generator that develops a continuous output of electrical energy at all engine operating speeds (high, low and idle). The trade name for this unit manufactured by Delco-Remy is "Delcotron". The output of the alternator is controlled by a transistorized voltage regulator.

*Note: To prevent serious injury to personnel or extreme damage to electrical system components, it should be noted that information contained in this manual pertaining to electrical system components will emphasize certain precautions that must be followed when servicing the "Delcotron" charging system.*




Fig. 4. Safety Wiring Decal




Fig. 5. Operating Precaution Plate

## OPERATING PRECAUTION PLATE

The operating precaution plate as shown in Figure 5 is located in the center of the steering wheel. This plate provides a few precautions to follow during machine operation, and also reminds the operator to refer to the Operator's Manual for additional information that is necessary for proper operation of the machine.

## TRANSMISSION OR TORQUE CONVERTER SERIAL NUMBER PLATE

The transmission serial number plate is located on the transmission. The torque converter serial number plate is located on the torque converter. Both plates are identical except for model number and serial number stamped on each plate to properly identify the units. Plate is shown in Figure 6.




Fig. 6. Torque Converter or Transmission Serial

## NOTICE

**SUBJECT: Spark Arresters  
All Models**

**Many states and other governmental entities have adopted laws and regulations which require Spark Arresters on machines operating on or near forest, brush or grass-covered lands within their jurisdiction. The Federal government also has regulations (Forest Services) which require Spark Arresters on machines operating on National lands.**

**Use of machines without Spark Arresters in areas where such use is prohibited by law or regulation can subject the owner or operator of the machine to penal fines or civil damages, including the costs of fire suppression.**

**Spark arresting equipment complying with the applicable laws and regulations must be installed on any machines which are likely to be operated in such areas. All machines which are converted for Woodland use (loggers, harvesters, etc.) should be installed with approved Spark Arresting Equipment.**

**Machines with turbo charged engines do not require additional Spark Arresting Equipment to comply with currently known laws and regulations.**



## PREPARATION FOR OPERATION

It is essential that the following points be checked with machine in a level position before operating this MICHIGAN Tractor Shovel.

Refer to the Lubrication Charts to locate items listed below.

1. Check entire machine for damage in transit or storage.
2. Check oil level in the following to specifications outlined in Lubrication Section.
  - a. Engine crankcase
  - b. Transmission case (with engine idling)
  - c. Front drive axle differential
  - d. Front drive axle planetary hubs
  - e. Rear drive axle differential
  - f. Rear drive axle planetary hubs
  - g. Hydraulic system reservoir
  - h. Midmount bearing
3. Check cooling system to make sure radiator is filled and that radiator drain cock and engine block drain cock are closed. When there is danger of water freezing in the cooling system, use a reliable brand of permanent type anti-freeze according to manufacturer's instructions. For further information, please refer to Operation and Maintenance Manual of engine manufacturer.
4. Check batteries that plates are covered with water. Add only clean distilled water. Do not overfill.
5. Check fuel level in tank. Handle fuel in clean containers. Use No. 2 Diesel fuel oil, Cetane 40 minimum.
6. Check that all drain plugs, drain cocks, filler openings, fuel lines, oil lines, hydraulic lines, cooling system and air cleaner connections are tight and do not leak.
7. Check tire pressures and hydroinflation. See Specifications and Service Data for air pressure and hydroinflation data. Be sure valve caps are in place to prevent dirt, moisture and foreign material from damaging valve core.
8. Grease all lubrication points of the entire unit. Refer to Lubrication Section as a guide for location and type of lubricant.

## INSTRUMENTS AND OPERATING CONTROLS

Before operating a machine of this type it is essential that the operator become thoroughly familiar with the location and function of the various controls and instruments. Reference to, and study of the illustrations of the operator's compartment, controls, and instruments, together with the following paragraphs will aid in acquiring this information.

The operator should work slowly and carefully until he has become thoroughly accustomed to the machine. Speed and skill will be attained much easier if the necessary time is spent to acquire complete familiarity with the machine and its operation.




Fig. 7. Instrument Panel

TS-13770

## INSTRUMENTS AND SWITCHES

All instruments and switches with the exception of the hourmeter and foot operated horn switch are conveniently located on instrument panel at left front side of operator's compartment. The hourmeter is mounted at the rear of the operator's compartment. The foot operated horn switch is located at left side of front floorboard.

It is good practice to observe gauges frequently while working the machine. Each gauge serves as an important check point for operating conditions of torque converter and transmission, and of the engine and accessories. Do not operate machine if gauges are not functioning properly.

Figures 7 and 8 give identification of instruments and switches.

## INSTRUMENT PANEL

**Engine Temperature Gauge** indicates temperature of engine coolant. Under normal operating conditions gauge should register between 165°F. and 185°F. If gauge indicates temperature to be at boiling point, idle engine, and add water to the system. When temperature lowers, shut down engine and troubleshoot cooling system for cause of overheating.

**Engine Oil Pressure Gauge** indicates oil pressure in engine lubricating system. Under normal operation, at idle and governed rpm, check gauge pressure. Refer to Specifications and Service Data for normal pressure readings under these conditions. If gauge fails to register within 10 to 15 seconds, stop engine immediately and determine cause.

**Dash Lamp** lights when light switch is pulled out to the first position.

**Air Pressure Gauge** indicates pressure in air reservoir for operating brakes. Never operate machine unless gauge indicates adequate pressure for actuating brakes. Refer to Specifications and Service Data for air pressure specifications.

**Torque Converter Temperature Gauge** indicates the temperature of fluid in torque converter




Fig. 8. Hourmeter

and transmission lubricating system. When temperature approaches 250°F. or red portion of gauge, shift to a lower operating speed range.

**Voltmeter** indicates the condition of the batteries. When the ignition switch is turned on, the voltmeter will indicate the voltage available from the batteries. A reading lower than rated system voltage would indicate low batteries. When the engine is running, a reading above rated system voltage indicates the batteries are charging.

**Ignition Switch** energizes all gauges and switches on instrument panel, and starting motor circuit. Turn switch to right for ON position.

**Light Switch** operates dash lamp, headlights, and tail lights in first position, with the addition of back-up lights in second position. Pull switch to operate.

**Starter Button** energizes cranking motor to start engine. Press to operate; release when engine starts. Do not crank engine continuously for more than 30 seconds to avoid damage to cranking motor. Pause a few minutes between cranking cycles, if difficulty is encountered to let windings cool. See Starting Procedure in rear of manual.

**Cigarette Lighter** is a push button type conveniently located on instrument panel. With ignition switch in the ON position, push lighter to operate.



## OPERATING CONTROLS

All controls are conveniently located to provide maximum ease of operation of the machine.

The operator's seat can be shifted forward or rearward to suit the individual by moving the lever on left side of seat forward and shifting the seat to desired position. The height and angle of the seat can also be adjusted by repositioning the seat in the adjusting holes in seat mounting brackets.

If enclosed parking is not available when shutting down machine at end of shift, tilt seat forward over steering wheel and spread tarpaulin over operator's compartment to give protection from inclement weather. A cab enclosure kit is available as optional accessory equipment.

Refer to Figure 9 for location and identification of operating controls.

**Directional Shift Lever** is the top lever on steering column. This lever provides three positions, FORWARD, NEUTRAL and REVERSE to control direction of machine travel. Pushing lever into forward position engages FORWARD travel. Pulling lever into rear position engages REVERSE travel. Lever is in NEUTRAL when in its central position.

When shifting from FORWARD into REVERSE or vice versa, always decrease engine rpm and stop machine momentarily while making the shift.

**Speed Range Lever** is the bottom lever on steering column. This lever controls the travel speed of the machine. Pushing the lever forward engages LO (First) speed range. Pulling the lever to the rear engages progressively higher speed ranges in consecutive order.

Observe torque converter temperature gauge when working machine. If gauge approaches 250°F., shift to a lower operating speed range.

Shifting from one speed range to another can be made at any time during the working cycle. Momentarily let up on accelerator pedal when shifting to a higher speed range, and accelerate slightly when shifting to a lower speed range.

It is not good driver practice to skip speed ranges when shifting, if machine is in motion. It is better to make progressive shifts engaging each speed range before proceeding to the next.

**Boom Control Lever** is the outer lever on right hand side of operator. This lever has four positions: RAISE, HOLD, DOWN PRESSURE and FLOAT to control boom operation. Of the four positions, RAISE, HOLD and FLOAT are detent located and can be distinctly felt by the operator. The DOWN PRESSURE position is not detent located and must be located by "feathering" the lever between the HOLD and FLOAT positions.

To raise boom and bucket, pull boom lever backward to the last detent position. Boom and bucket will raise in proportion to engine speed.

Push lever forward, one notch ahead of RAISE position to reach the HOLD (neutral) position. Placing boom control lever in this position will stop and hold boom and bucket at any height desired.

Push lever all the way forward to reach the FLOAT position. In this detent position, hydraulic oil will pass from the base end of the boom cylinders through the control valve and into the rod end of the cylinders, keeping them free of air. FLOAT position may be used for lowering the bucket or back dragging.


The DOWN PRESSURE position found between the HOLD and FLOAT positions by "feathering" the lever. This position may be used for lowering the boom and bucket or to provide penetration to dig below grade level.

Always place boom control lever in HOLD (neutral) position before starting or shutting down engine. This lever will lower boom and bucket even though engine has been shut down.

**Bucket Control Lever** is the inner lever on right hand side of operator. This lever has three positions: CLOSE, HOLD and DUMP to control bucket operation. Since lever is connected to a spring loaded plunger in the control valve, it returns to the HOLD position automatically when released.

To DUMP bucket, push lever forward. Release the lever and it will return to the HOLD (neutral) position, allowing the bucket to remain in the DUMP position.

To CLOSE bucket, pull lever backward. Release the lever and it will return to the HOLD (neutral) position when the bucket reaches a level attitude



**TRANSMISSION CONTROL LEVERS**

- Low
- Forward
- Neutral
- Reverse
- 2nd
- 3rd
- High

**HYDRAULIC CONTROL LEVERS**

- BUCKET**
- Dump
- Hold
- Close
- BOOM**
- Float - Detent
- Down
- Hold
- Raise - Detent

**PARKING BRAKE LEVER**

- Down - Release
- Up - Apply

- 1. Parking Brake Lever
- 2. Horn Switch
- 3. Brake Pedal (Declutch)
- 4. Directional Shift Lever
- 5. Speed Range Lever
- 6. Brake Pedal (Declutch By-Pass)
- 7. Accelerator Pedal
- 8. Boom Control Lever
- 9. Bucket Control Lever

**Fig. 9. Operating Controls**

as it is being rotated back from the DUMP position.

The bucket may be stopped and held at any position of its dumping arc by placing lever in the HOLD (neutral) position.

**Parking Brake Lever** applies mechanical brake on drive line. To set brake, pull up and back on lever. To release brake push lever forward and down.

**Brake Pedal** design permits brake application with either left or right foot of operator. Pedal actuates an air valve for applying brakes at all wheels. As pedal pressure increases, air valve opens wider, and brake application becomes more severe.

The left hand brake pedal also operates a de-clutch or shut-off valve in the transmission control cover which blocks off hydraulic pressure to the forward clutch in all speed ranges, thus disengaging the forward clutch and establishing a transmission neutral when the left hand brake pedal is applied. The reverse clutch is not affected.

The right hand brake pedal by-passes the de-clutch valve, making it possible to apply the service brakes without de-clutching if so desired. This permits inching the machine forward using service brakes and throttle.

The purpose of the de-clutching feature is to prevent the machine from creeping forward when loading or dumping the bucket, yet permits backing away if operating on a sloping grade. It also increases boom and bucket hydraulic system working power by blocking the power transmitted to the wheels.

**Circuit Breaker Reset Button** is located below or on right hand side of left hand instrument panel cavity. Press button and hold momentarily to reset

circuit breaker whenever circuit breaker has been tripped.

#### **175B S/N 427A141 and after only**

**Safety Brakes:** A safety feature has been incorporated in the air over hydraulic disc brake system on Model 175B Tractor Shovels. It consists of automatically applied, low pressure actuated, front and rear axle braking systems, with a manual control feature.

Each axle is equipped with independent components so that an application of the service brake pedal actuates both systems simultaneously. If air pressure is lost in either the front, rear or both systems, the safety brake for that system is automatically applied to bring the machine to a safe controlled stop.

Additional braking protection is provided by an emergency system, manually controlled by a hand valve located in the operator's compartment. A dash mounted light and buzzer warn the operator when air pressure reaches the minimum safe limit, see Figure 9A. If the operator does not stop, the brakes are automatically applied when air pressure drops below safe operating limit.

**CAUTION:** *When safety brakes are actuated, the machine must not be moved until air pressure is returned to safe operating level.*

The emergency brake button is located to the immediate left of the right hand instrument panel. It is a push-pull type control used to actuate the manually controlled emergency system. Pull button out to apply brakes, push in to release brakes.

**WARNING:** *The emergency brake is not to be used as a parking brake since air pressure in the emergency system bleeds down about 15 minutes after the engine has been shut down.*




## 275B S/N 425A361 and After only

**Safety Brakes:** A safety feature has been incorporated in the straight air brake system on Model 275B Tractor Shovels. It consists of automatically applied, low pressure actuated, front and rear axle braking systems, with a manual control feature.

Each axle is equipped with independent components so that an application of the service brake pedal actuates both front and rear systems simultaneously. If air pressure is lost in either the front, rear or both systems, the safety brake for that system is automatically applied to bring the machine to a safe controlled stop.

Additional braking protection is provided by an emergency system, manually controlled by a hand valve located in the operator's compartment. A dash mounted light and buzzer warn the operator when air pressure reaches the minimum safe limit, see Figure 9A. If the operator does not stop, the brakes are automatically applied when air pressure drops below safe operating limit.

**CAUTION:** *When safety brakes are actuated, the machine must not be moved until air pressure is returned to safe operating level.*



A. Brake Hand Valve      B. Warning Light

**Figure 9A. Brake Manual Control & Warning Light.**

The emergency brake button is located to the immediate left of the right hand instrument panel. It is a push-pull type control used to actuate the manually controlled emergency system. Pull button out to apply brakes, push in to release brakes.

**WARNING:** *The emergency brake is not to be used as a parking brake since air pressure in the emergency system bleeds down about 15 minutes after the engine has been shut down.*

## OPERATING INSTRUCTIONS

After the machine has been properly checked and the operator has familiarized himself with location and function of the various controls, the machine should be operated according to instructions given in the following safety precautions.

**Warning:** Use safety links when servicing machine. Do not stand or work in step area(s) when machine is running. There is no room in this area for a man when machine is turned.

The use of this machine is subject to certain hazards that cannot be met by mechanical means, but only by the exercise of intelligence, care and common sense.

### SAFETY PRECAUTIONS

#### I. Maintenance

1. Read and understand operator's manual and safety manual. Do not attempt to perform maintenance until all procedures have been read and understood.
2. Remove key from ignition switch, tag steering wheel and install steering lock bar or safety link before working on vehicle.
3. Block attachments and vehicle wheels before working on any part of the vehicle or attachments.
4. Lubricate implements only when lowered to ground. If other positions are required, block implements securely.
5. Always use handrails, ladders and hand holds when working around machine. Keep all these areas free from water, grease and mud.
6. Remove all pressure caps slowly and bleed all pressurized systems such as accumulators and alcohol injectors before attempting any repairs.
7. Remove all pressure caps slowly when attempting any fluid level checks. Do not check fluids for leaks with any kind of flame.
8. Use cold start aids sparingly. DO NOT burn or puncture container. DO NOT smoke when using.
9. When using jumper cables to aid starting, connect positive terminals to positive and negative to negative. Make sure contact is secure to prevent damage to battery posts.
10. DO NOT wear long hair, jewelry or loose clothing while working around machine.
11. Keep brakes properly adjusted and hydraulic brake lines free from air.
12. Inspect disc brake vehicles frequently for proper torque of brake disc retention bolts.

#### II. Before Starting Engine

1. Read and understand operator's manual and safety manual.
2. Make all of the following prestart checks at least daily.
  - A. Tire pressure.
  - B. Fluid levels.
  - C. Leaks.
  - D. Loose parts.
3. Make at least the following prestart checks every time vehicle is shut down.
  - A. Leaks.
  - B. Loose parts.
4. Check area all around vehicle before entering operator's compartment. Then sound horn before starting engine.

#### III. Starting

1. Mount vehicle carefully; normally from left hand side.
2. Fasten seat belt.
3. Warm up engine before applying full throttle.

4. Check all gauges and controls before moving machine. Pay particular attention to brakes and steering.
5. If any defects are noted, shut down machine immediately and report defects to your supervisor. Never assume corrections have been made until you personally recheck.

## IV. Operating Vehicle

1. Know vehicle capacity.
2. NEVER operate vehicle while wearing loose clothing or under the influence of drugs, alcohol or medicines.
3. Watch direction at all times. Pay particular attention to overhead dangers, buried power lines and look out for soft spots. Be considerate of ground crews and other vehicles.
4. Always maintain vehicle balance and stability; never transport load with bucket fully raised. Keep implements close to ground when traveling up steep grades. Travel in reverse when descending steep grades.
5. Never waste air by pumping brakes.
6. Match speed to work and select proper speed range.
7. Do not operate L-5 tires above 5 mph.
8. Never use implements as an emergency brake.
9. CAUTION! Emergency brake system will automatically apply if system air pressure drops

below 60 psi.

10. After an emergency brake application, set parking brake, lower implements to ground and block wheels immediately. Do not operate vehicle until repairs have been made and system functions properly.
11. NEVER climb on or off a machine that is in motion.
12. NEVER dismount machine without first shutting down engine and following all shut down instructions.

## V. Shut Down Instructions

1. Select level parking spot and set parking brake. **Caution:** *Do not use emergency hand valve located near right hand instrument panel to park machine. Doing so would allow air pressure to bleed away and leave vehicle without a parking brake.*
2. If parking area is not level, set parking brake and also block wheels.
3. Lower all implements to ground. Be certain that bucket cutting edge rests flat on ground.
4. Shut down engine.
5. Place all control levers in neutral position.
6. Remove any keys.
7. Be sure machine is safe to leave; then dismount carefully.

## STARTING PROCEDURES

Refer to starting instructions for make of engine involved located in next two sections.

### PRE-STARTING CHECKS

Before starting engine at beginning of work shift, or at any time machine has been shut down for adjustment or time-off period, perform the following checks.

1. Engine oil level.
2. Engine air cleaner.
3. Hydraulic system oil level.
4. Cooling system.
5. Fuel supply.
6. Transmission fluid.
7. Tire pressures.

Service units at this time if inspection indicates the necessity.

**Caution:** *Disconnect safety links before moving machine.*

### COLD WEATHER STARTING

MICHIGAN machines do not require extension preparation for cold weather operation beyond addition of a permanent type anti-freeze to the cooling system, and a change of engine oil to a viscosity suitable for anticipated temperatures in which the machine is to operate. At temperatures below 0°F. a change of oil in the main hydraulic system to the fluid recommended for this temperature, will aid starting by reduction of resistance in the main pump. Probably the most important item to insure prompt starting is proper maintenance of the electrical system, especially the batteries.

Batteries must be kept fully charged at all times, since in cold weather the capacity to deliver full power is greatly reduced. A fully charged battery at 15°F. is capable of delivering only 70% of its rated amperage, and at lower temperatures becomes even less efficient. Service batteries weekly as follows:

1. Add distilled water to cover plates and separators but do not overfill. Overfilling causes dilu-

tion of the electrolyte, and sputtering during the charging cycle. This may result in battery freezing and corroded terminals.

2. Keep terminals clean and tight. Dirty or loose connections offer high resistance.
3. Keep vent plugs in place, and tight to prevent entrance of foreign materials into cells.
4. Check specific gravity regularly with a hydrometer, and recharge or replace batteries that continually show a low reading.

Service other electrical components as follows:

1. Visually check all wiring for worn or cracked insulation and loose terminal connections.
2. Clean and tighten loose connections on cranking motor, alternator, voltage regulator, solenoid switch, relays and sender units.
3. Clean and tighten external ground straps, and replace if badly frayed or corroded.

To avoid unnecessary cranking because of air locks in cold fuel oil, change fuel oil only when engine is hot; then start and run engine after filter change, and check that there is no fuel restriction or leakage.

When not in use, machine should be parked or stored in a closed garage or building during cold weather to reduce cranking effort when starting a cold engine. It is particularly important in starting the engine that it is not accelerated to governed speed or a load applied until the oil has become warm enough to circulate to all bearing surfaces.

### WARM-UP CHECKS

Hold engine at idle speed for approximately two minutes after starting; then while engine continues to warm up for the next few minutes perform the following checks.

1. Engine oil pressure gauge.
2. Ammeter.
3. Air pressure gauge.
4. Engine temperature gauge.

5. Fuel gauge.
6. Torque converter temperature gauge.
7. Horn.
8. Lights.
9. Hydraulic system — boom and bucket control levers.

Visually check for leaks at drain and fill plugs in axle assemblies, torque converter and transmission, and at hose couplings and fittings in hydraulic, fuel, air intake, brake and cooling systems. Correct all leaking conditions, and repair or replace gauges that are not functioning before continuing operation of the machine.

## PARKING AREA CHECKS

As a final check before leaving the parking area, set machine into motion and test the following:

1. Steering gear.
2. Service brakes.
3. Parking brake.

Remember, the safety of the operator and other workmen, and the efficient operation of the machine depend upon the performance of all items in the check list above. Service units at this time if inspection indicates the necessity.



## G.M. DIESEL

### STARTING INSTRUCTIONS

#### NORMAL STARTING

**Caution:** Walk around machine. Make certain that no one is in "danger area" before entering the operator's compartment.

1. Set directional shift lever in NEUTRAL.
2. Depress and release accelerator to reset governor throttle control lever in IDLE position.
3. Turn ignition switch ON; press starter switch firmly, and very lightly depress accelerator to feed additional fuel. Operate cranking motor no more than 30 seconds at a time to avoid overheating motor.

**Caution:** If engine fails to start, wait until cranking motor stops rotating before repressing starter switch. Serious damage to the cranking motor may result if this precaution is not complied with.

If engine fails to start after four periods of cranking, refer to Operation and Maintenance Manual of engine manufacturer.

4. After engine starts, check oil pressure gauge. If no pressure is indicated within 15 seconds, shut down engine immediately and determine cause.
5. Allow engine to reach operating temperature before driving or operating machine.

#### COLD WEATHER STARTING (When Colder Than 40°F.)

G.M. Diesels are not equipped with cold weather starting aids. However, starting fluid (pressurized can type) sprayed into air cleaner intake is recommended as engine is being started.

Ether starting fluid is available in 16 ounce pressurized can from your authorized MICHIGAN Distributor under part number 945152.

A fluid starting aid (capsule form) can be installed by any authorized G.M. Diesel Distributor.

1. Set all control levers in NEUTRAL position and turn ignition switch ON.
2. Depress accelerator to full throttle position.

3. Press starter switch firmly and simultaneously use starting fluid directed into air cleaner intake.

Do not operate cranking motor for more than 30 seconds at a time to avoid overheating motor.

**Caution:** If engine fails to start, do not repress starter until cranking motor has stopped rotating. Serious damage to cranking motor may result if above procedure is not complied with.

4. After engine starts, check oil pressure gauge.

If no pressure is indicated within 15 seconds shut off engine and determine cause.

5. Allow engine to warm up for a few minutes before driving or operating machine.

### OPTIONAL

#### QUICK START COLD WEATHER STARTING AID

The "Quick Start" cold weather starting aid is controlled by a push button mounted on the left hand instrument panel. When the button is pushed, ether is injected into the engine's intake manifold to aid in cold weather starting.

**Caution:** Do not attempt to inject additional ether by pushing button after engine is running. This could result in detonation and severe damage to the engine.

Cold weather, below 50°F. (10°C.) may require use of the "Quick Start" starting aid. With control levers in the NEUTRAL position, proceed as follows:

1. Turn ignition switch ON, then push "Quick Start" button for one second and release.
2. Wait two seconds and engage starter.
3. Below 0°F. (-18°C.) repeat steps 1 & 2.

**CAUTION: USE ONLY FOR STARTING.**

### MAINTENANCE

- A. Periodically remove cylinder and oil valve.

1. Use care in wiping dirt from valve inlet when

- removing cylinder to prevent dirt from entering valve.
2. Check valve gasket for damage and replace if needed.
  3. With cylinder removed, actuate system to distribute lubricant.
- B. When replacing empty cylinder, follow steps 1, 2 & 3 in Instruction A.
- C. Periodically check all connections for leaks. Also check valve mounting bolts and cylinder studs for tightness.
- D. Periodically test unit for proper functioning. Disconnect tube from atomizer and remove atomizer. Reassemble atomizer to tube, then actuate the system. A fine mist-like spray should be emitted from each orifice of the atomizer.
- E. If system is subjected to moisture, spray valve with a plastic coating.

## INITIAL HOOK-UP OF CYLINDER

The ether cylinder is disconnected from the valve and the valve and cylinder end are capped as a safety precaution during shipment of tractor. It will be necessary to hook-up the cylinder in the following manner prior to initial use of the system.

1. Remove cap from valve and cap from end of cylinder.
2. Loosen cylinder mounting bracket and lower cylinder to valve.
3. Screw cylinder into valve and tighten cylinder mounting bracket.

## TROUBLE SHOOTING THE SYSTEM

If the system fails to function it may be necessary to trouble shoot the system as follows:

- A. Check the cylinder for tightness and fuel supply.
1. If cylinder is loose, it should be tightened finger tight.
  2. If the cylinder is not loose, it should be removed and weighed. (Empty cylinder weight is 17 ounces).

- B. If system still fails to function, remove tubing at valve and actuate valve.

1. If valve is not functioning, it must be replaced. See Parts Manual.
2. If valve is functioning remove tubing and clean thoroughly. Then reinstall tube at valve end and actuate valve.
3. If fuel is discharged from tube, remove and disassemble atomizer and clean screen and blow out orifices. Then connect tubing to atomizer and actuate valve. Fuel should be emitted from each orifice of atomizer. This indicates proper functioning of the system.
4. Disconnect tubing from atomizer and reinstall atomizer. Reconnect tubing to atomizer.

## SHUTTING DOWN ENGINE

It is important to idle an engine 3 to 5 minutes before shutting it down. This will allow lubricating oil and water to carry heat away from combustion chambers, cylinder head, bearings and shafts.

Residual heat can damage many parts ranging from valves to fuel pumps. The latter suffer from gums and deposits remaining after residual evaporation. In addition, the physical stresses from expansion and contraction can cause distortion, permanent warping and gasket failures. In some cases, oil seals and cylinder sleeve seals suffer badly, although the results may not appear until much later.

To shut down a G.M. Diesel, turn ignition switch OFF; then pull engine fuel shut-off control (forward T-handle) up and hold until engine stops rotating. After engine stops running, replace T-handle in its original position.

If after pulling fuel shut-off control, engine continues to operate, the engine emergency air shut-off control (rear T-handle) must be pulled to the up position. This T-handle will trip the latch assembly securing air shut-off valve inside air intake housing, thus starving the engine of air and preventing further combustion of fuel. Replace control T-handle in its original position and manually reset latch assembly at air intake housing before restarting engine.

**CUMMINS DIESEL****STARTING INSTRUCTIONS****NORMAL STARTING**

**Caution:** Walk around machine. Make certain that no one is in "danger area" before entering operator's compartment.

1. Set directional shift lever in NEUTRAL.
2. Turn ignition switch ON; and press starter switch firmly. Very lightly depress accelerator to feed additional fuel. Operate cranking motor no more than 30 seconds at a time to avoid overheating motor.

**Caution:** If engine fails to start within the first 30 seconds, wait two to five minutes before re-cranking.

If engine fails to start after four periods of cranking, refer to Operation and Maintenance Manual of engine manufacturer.

3. After engine starts, check oil pressure gauge. If no pressure is indicated within 15 seconds, shut off engine and determine cause.
4. Allow engine to reach operating temperature before driving machine.

**COLD WEATHER STARTING****(When Colder Than 50°F.)****(a) Use of Ether without Metering Equipment**

Cummins Diesels are not equipped with cold weather starting aids. However, two men can use the following procedure as a cold weather starting aid.

**Caution:** Ether is highly flammable. Do not use with preheater or near open flame. Do not breathe ether fumes.

1. Pour three tablespoonfuls of ether on a cloth; hold cloth close to air cleaner intake while second man cranks the engine.
2. As an alternate method, spray ether into air cleaner intake while second man cranks the engine.
3. Ether fumes will be drawn into the air intake manifold and the cold engine should start without difficulty.

**Caution:** Do not use excessive amounts of ether. Excessive amounts of ether will cause unusually high pressures and detonation.

**OPTIONAL****QUICK START COLD WEATHER STARTING AID**

The "Quick Start" cold weather starting aid is controlled by a push button mounted on the left hand instrument panel. When the button is pushed, ether is injected into the engine's intake manifold to aid in cold weather starting.

**Caution:** Do not attempt to inject additional ether by pushing button after engine is running. This could result in detonation and severe damage to the engine.

Cold weather, below 50°F. (10°C.) may require use of the "Quick Start" starting aid. With control levers in the NEUTRAL position, proceed as follows:

1. Turn ignition switch ON, then push "Quick Start" button for one second and release.
2. Wait two seconds and engage starter.
3. Below 0°F. (-18°C.) repeat steps 1 & 2.

**CAUTION: USE ONLY FOR STARTING.**

**MAINTENANCE**

- A. Periodically remove cylinder and oil valve.
  1. Use care in wiping dirt from valve inlet when removing cylinder to prevent dirt from entering valve.
  2. Check valve gasket for damage and replace if needed.
  3. With cylinder removed, actuate system to distribute lubricant.
- B. When replacing empty cylinder, follow steps 1, 2 & 3 in Instruction A.
- C. Periodically check all connections for leaks. Also check valve mounting bolts and cylinder studs for tightness.
- D. Periodically test unit for proper functioning. Disconnect tube from atomizer and remove atomizer. Reassemble atomizer to tube, then ac-

tuates the system. A fine mist-like spray should be emitted from each orifice of the atomizer.

- E. If system is subjected to moisture, spray valve with a plastic coating.

## INITIAL HOOK-UP OF CYLINDER

The ether cylinder is disconnected from the valve and the valve and cylinder end are capped as a safety precaution during shipment of tractor. It will be necessary to hook-up the cylinder in the following manner prior to initial use of the system.

1. Remove cap from valve and cap from end of cylinder.
2. Loosen cylinder mounting bracket and lower cylinder to valve.
3. Screw cylinder into valve and tighten cylinder mounting bracket.

## TROUBLE SHOOTING THE SYSTEM

If the system fails to function it may be necessary to trouble shoot the system as follows:

- A. Check the cylinder for tightness and fuel supply.
1. If cylinder is loose, it should be tightened finger tight.
  2. If the cylinder is not loose, it should be removed and weighed. (Empty cylinder weight is 17 ounces).
- B. If system still fails to function, remove tubing at valve and actuate valve.

1. If valve is not functioning, it must be replaced. See Parts Manual.
2. If valve is functioning remove tubing and clean thoroughly. Then reinstall tube at valve end and actuate valve.
3. If fuel is discharged from tube, remove and disassemble atomizer and clean screen and blow out orifices. Then connect tubing to atomizer and actuate valve. Fuel should be emitted from each orifice of atomizer. This indicates proper functioning of the system.
4. Disconnect tubing from atomizer and reinstall atomizer. Reconnect tubing to atomizer.

## SHUTTING DOWN ENGINE

It is important to idle an engine 3 to 5 minutes before shutting it down. This will allow lubricating oil and water to carry heat away from combustion chambers, cylinder head, bearings, and shafts.

Residual heat can damage many parts, ranging from valves to fuel pumps. The latter suffer from gums and deposits remaining after residual evaporation. In addition, the physical stresses from expansion and contraction can cause distortion, permanent warping, and gasket failures. In some cases, oil seals and cylinder sleeve seals suffer badly, although the results may not appear until much later.

IT IS GOOD PRACTICE TO IDLE ANY ENGINE LONG ENOUGH TO REDUCE EXTREME TEMPERATURES.

To shut down a Cummins Diesel, turn ignition switch off.

## **OPERATING TRACTOR SHOVEL**

### **SETTING MACHINE IN MOTION**

The following steps give proper procedure for setting the machine in motion. Refer to Operating Controls Diagram, Figure 9.

1. Raise boom and bucket approximately 15 inches above the ground by pulling backward on boom control lever. Then roll bucket back to afford maximum visibility.
2. Place directional shift lever in position for direction of travel desired. When shifting from forward into reverse, or vice versa, always decrease engine rpm and stop machine momentarily while making shift.
3. Select applicable speed range for operating machine. Speed range and directional shift levers are so positioned that it is convenient to load in low range forward, and back away from pile in high range reverse by gripping both levers at the same time.

High range should be used when traveling machine for comparatively long distances without a load.

A shift from a low speed range to a higher speed range can be made when machine is in motion, by momentarily letting up on accelerator, making the shift, and again depressing accelerator.

When making a down shift, accelerate engine to synchronize engine and drive shaft speeds when transmission clutch re-engages.

4. Release parking brake.
5. Gradually apply pressure on accelerator pedal until desired travel speed is reached.

### **LOADING THE BUCKET**

Place speed range lever in low, and directional lever in forward. With bucket control lever, adjust bucket to the level position.

When loading from a stockpile, drive into pile with cutting edge parallel to the ground, and push cutting edge into pile until bucket is nearly full. Then pull boom control lever back to raise bucket. As bucket raises, pull bucket lever back to tip bucket back against stops. Continue to raise bucket with boom lever until it breaks out of pile. Back

out of pile keeping load low, and deliver load to desired dumping position.

When grading or excavating, bucket should be in the level position. Feather boom control lever to the DOWN PRESSURE position to face bucket cutting edge against the ground as machine moves forward.

If cutting edge does not penetrate the ground immediately, use bucket control lever to incline the angle of the cutting edge slightly to give better penetration. When cutting edge penetrates, use bucket control lever to adjust bucket to level position to avoid excessive penetration. The operator may manipulate boom and bucket control levers slightly to maintain a good grade as machine moves forward.

When maintaining a grade, machine should be driven in low speed range at sufficient throttle to make an accurate cut. When the end of the cut is reached, pull backward on bucket control lever to tip bucket back against the stops, then raise boom so that bucket is approximately 15 inches off the ground for carrying to dumping position.

### **TRANSPORTING THE LOAD**

When transporting the load, travel speed of machine will depend upon the length of haul, and kind of surface over which the machine must pass. Rough terrain calls for a fairly slow speed. When the bucket is full, it should be carried approximately 15 inches off the ground. Never transport load with bucket fully raised. The nearer the ground the bucket is held, the better the stability, especially on slopes or when turning machine.

### **DUMPING THE BUCKET**

Approach truck, railroad car or hopper raising the boom until bucket safely clears top edge of unit. At proper clearance height, place boom control lever in HOLD (neutral) position. Move machine up to place bucket inside the dumping area, positioning Tractor Shovel perpendicular to side of unit to avoid spillage, and to distribute material evenly. Apply service brakes, which will automatically disengage transmission FORWARD clutch. This not only prevents machine from creeping forward when engine is accelerated, but also provides maximum hydraulic working power for bucket cylinders.



Push bucket control lever forward slowly to dump bucket. Control rate of material discharge with accelerator, and by manipulating control lever between DUMP and HOLD positions. Bucket can be maintained in full dump or partial dump position by returning control lever to HOLD position. Dumping load slowly will minimize shock loading of a truck body or other transporting vehicle.

When bucket is empty, pull backward on bucket control lever into detent located CLOSE position, and back away from loaded unit. Place boom control lever in DOWN PRESSURE or FLOAT position while returning for another load. Bucket will stop in a level position automatically. The bucket control lever automatically returns to the HOLD (neutral) position.

## BACKFILLING AND SPREADING

The bucket is used for backfilling and spreading operations. Lower the bucket in an attitude parallel to the surface of the ground and proceed forward in one of the lower speed ranges allowing the bucket to fill. The material will form its own dozer blade. Best results are obtained when a shallow bite is used. Caution must be used in controlling the depth of the bite as too deep a bite will cause wheel spin and an uneven working surface.

## TRAVELING WITHOUT A LOAD IN BUCKET

When driving machine from job to job, shift into high speed range. The bucket should be raised approximately 15 inches off the ground and tipped back to afford maximum visibility.

## TOWING THE MACHINE

If at anytime it is necessary to tow the machine any appreciable distance, observe the following precautions:

1. Set all control levers in NEUTRAL.
2. Remove the propeller shaft from the transmission to the rear axle assembly, and one of the propeller shafts from between the transmission and the front axle assembly.
3. Attach safety links.

**Important:** *Note correct assembly of propeller shafts before removing them. Reassemble them in the same position. The tubular end is always the driving end. Do not separate the two ends of the assembly due to wear pattern and balancing characteristics. Wire the spider and bearing assemblies to the prop shaft flanges and wrap the assemblies in lint free cloths.*

When the machine is being towed, the converter charging pump is not operating. There is danger of bearing or gear damage in the torque converter and transmission if propeller shafts are not removed.

When reinstalling propshaft assemblies use only the special heat treated nuts and bolts provided. Tighten attaching bolts to the torque specified on Bolt Torque Chart.

4. When towing an articulated machine it may be best to raise one end of machine with safety links attached since machine cannot be steered without engine operating.

## LUBRICATION AND MAINTENANCE

This section of the manual is divided into two major categories — LUBRICATION and MAINTENANCE. The LUBRICATION portion is to be used in conjunction with Chassis and Drive Line Lube Charts found in the rear of this section. This section contains the recommended intervals at which the machine should be serviced such as Daily or Shift, Weekly or 50 Operating Hours, up through a 1000 Operating Hour schedule.

Lubrication is maintenance, but the items described in the Lubrication portion are only those that pertain to the actual greasing or oiling of the machine, including the level checks and the drain and refill procedures.

The MAINTENANCE portion contains recommended checks and adjustments over and above those found in the LUBRICATION portion.

The maintenance schedule is based on hours of normal operation recorded on the hourmeter. A more practical schedule should be developed for each job application. Make changes in the basic schedule as required based on the type of work machine is doing, the rate at which it is worked, and how it is being worked.

### LUBRICATION

The importance of proper lubrication cannot be overemphasized. It is the most essential single factor in a well planned preventive maintenance program. Refer to lubrication charts to locate the various points to be serviced.

Before servicing machine always wipe dirt and foreign material from grease fittings, clips, plugs or covers to prevent dirt, grit or foreign material from entering into mechanisms. When checking various lubricant levels, machine must be level and areas around all fill and level plug openings cleaned. Systems requiring draining at specific intervals

when fluid is at operating temperature. Hot oil flows more freely and carries more foreign material with it.

Cleanliness of the oil used and of the system cannot be overemphasized. Oil added to the reservoir should be poured through a 100 mesh screen. Filters and breathers should be serviced regularly. should always be drained after working machine

Additions required to maintain fluid level in the system should be made with the same fluid as is in the system, however, on occasions may be made with another approved lubricant for a given temperature range. Preferably the lubricants being mixed should be from the same manufacturer. The original fluid should not be diluted more than 50% by adding another fluid. When these conditions cannot be met, the system should be completely drained and refilled.

Lubricant changes for the different prevailing ambient temperature ranges specified should be made by complete drainage and refill. Occasional startups in temperatures above or below the prevailing ambient temperature ranges specified, for a given lubricant, will not require a complete change of lubricant. When the temperature, however, at startup is consistently above or below the range specified for the lubricant in the system, a complete change of lubricant is required, using the lubricant specified for the prevailing temperature range.

The lubrication charts herein specify the recommended lubricants for the various points to be serviced. NOTE: Lubricant specified on lube charts for use in the Transmission/Converter and Main/Steering Hydraulic Systems are for use in prevailing ambient temperature ranges above 0°F. (−18°C.). For additional approved lubricants for use in various ambient temperature ranges refer to charts below.

#### A — TRANSMISSION & CONVERTER HYDRAULIC SYSTEM:

##### PREVAILING AMBIENT TEMPERATURE

30°F. (−1°C.) & Above

−10°F. (−23°C.) & Above

##### LUBRICANT TO BE USED

SAE 30 Engine Oil, API Class SD or SE, MIL-L-2104B or MIL-L-2104C.

1. SAE 10W Engine Oil, API Class SD or SE, MIL-L-2104B or MIL-L-2104C.
2. Type C-2 Hydraulic Transmission Fluid.

-30°F. (-34°C.) & Above

DEXRON\* Automatic Transmission Fluid –  
(This does not include fluids referred to as Dexron II).

\* \* \* \*

0°F. (-18°C.) & Below

See Section titled Optional Lubricants.

## B – MAIN/STEERING HYDRAULIC SYSTEM:

### PREVAILING AMBIENT TEMPERATURE

### LUBRICANT TO BE USED

Above 0°F. (-18°C.)

1. SAE 10W Engine Oil, API Class SD or SE, MIL-L-2104B or MIL-L-2104C.

-30°F. (-34°C.) & Above

2. See Section titled Optional Lubricants.

DEXRON\* Automatic Transmission Fluid –  
(This does not include fluids referred to as Dexron II) – See Sub-Note I.

\* \* \* \*

0°F. (-18°C.) & Below

See Section titled Optional Lubricants

**NOTE 1:** DEXRON\* Fluid is suitable for use only if it meets the following specifications:

- A) Contain the type and content of anti-wear compounding found in API Class SD or SE engine oils, or have passed pump tests similar to those used in developing anti-wear type hydraulic oils.
- B) Have sufficient chemical stability for mobile hydraulic system service.
- C) Meet the viscosity requirements of API Class SD or SE engine oils – Grade SAE 10W.

\*DEXRON is a registered trademark of General Motors Corporation.

## OPTIONAL LUBRICANTS:

The following optional lubricants, in addition to the standard recommendations given above, are approved for use in the Transmission/Converter Hydraulic System and/or Main/Steering Hydraulic System.

### PREVAILING AMBIENT TEMPERATURE

### LUBRICANT TO BE USED

0°F. (-18°C.) & Below

The following should be used as a guide in consultation with a reputable oil supplier. *Any lubricant may be used which meets the following requirements:*

- 1. Oil to be used must contain anti-wear properties and rust and oxidation inhibitors plus anti-foam agents equivalent to that found in API Class SD or SE engine oils or have passed pump tests similar to those used in developing anti-wear type hydraulic oils.
- 2. Oil must have a Saybolt Universal Viscosity of 145 to 225 seconds at 100°F. (38°C.), and a vis-

cosity of not less than 42 seconds at operating temperature. The oil selected should have a high shear stability to insure that the viscosity remains within recommended limits. Viscosity Index should not be less than 90.

3. Have a pour point of 20°F. (11°C.) below start-up temperature.
4. Diesel fuel, kerosene, transformer oil, etc., *must not be used* to dilute normal fluids.

**NOTE:** Lubricants to the above specification may be used in prevailing ambient temperature range of Above 0°F. (-18°C.) in the Main/Steering Hydraulic System ONLY.

\* \* \* \*

There are literally hundreds of commercial brands of oil marketed today. Obviously, it is not physically possible or practical to test and evaluate each one of these brands of oil. Satisfactory OIL QUALITY is the responsibility of the oil supplier, therefore, the selection of a suitable lubricant should be made in consultation with a reputable oil supplier. Strict observance of oil change recommendations and proper filter maintenance will provide the best assurance of satisfactory performance.

### **SERVICE DAILY (Every 8 Operating Hours)**

**Grease Fittings:** Lubricate all points indicated on Chassis Lubrication Chart for 8 hour intervals. Use grade of lubricant specified on lubrication charts according to ambient temperature.

**Engine and Accessories:** Refer to Operation and Maintenance Manual of engine manufacturer for lubrication instructions of engine and accessories.

**Fuel Tank:** Fill fuel tank with clean fuel handled in clean containers. Use a good brand of fuel procured from a reliable company.

**Diesel Engine:** For most operating conditions, a No. 2 Diesel Fuel Oil Cetane 40 minimum is recommended. For unusual operating conditions with regard to load, speed, idling time, or ambient air temperature, refer to fuel oil specifications recommended by engine manufacturer.

**Radiator:** Check daily and refill as required with clean, soft water. See "Every 1000 Operating Hours" for Drain and Refill.

**Torque Converter and Transmission:** Check fluid level daily observing the following conditions.

1. Machine must be LEVEL.

2. Fluid must be HOT (operating temperature of 180°F. to 200°F.) (82°C. to 94°C.).
3. Engine must be IDLING.
4. Area around transmission dipstick opening must be CLEAN.
5. Maintain fluid level to indicated FULL mark on dipstick.

Refill as necessary adding fluid through the transmission fill plug.

See "Every 250 Operating Hours" for Filter Change, and "Every 500 Operating Hours" for Drain and Refill.

**Hydraulic Reservoir:** Check oil level daily observing the following conditions:

1. Machine must be LEVEL.
2. Blade must be on GROUND.
3. Engine must be SHUT DOWN.
4. Area around reservoir cap must be CLEAN.

Loosen reservoir cap at right side of machine SLOWLY to relieve pressure in reservoir tank; then

# CLARK

remove cap. Remove reservoir dipstick located inside reservoir and wipe with clean lint-free cloth. Reinsert and remove to check oil level. Maintain oil level to FULL mark on dipstick.

Refill as necessary using only premium quality

fluid. Refer to Chassis Lubrication Chart for recommended hydraulic fluid.

See "250 Hour Maintenance Operations" for Filter Change and "Every 1000 Operating Hours" for Drain and Refill.

**SERVICE WEEKLY (Every 50 Operating Hours)**

**Grease Fittings:** Lubricate all points indicated on Chassis Lubrication Chart for 50 hour intervals. Use grade of lubricant specified on lubrication charts according to ambient temperature.

**Engine and Accessories:** Refer to Operation and Maintenance Manual of engine manufacturer for lubrication instructions of engine and accessories.

**Brake Master Cylinders:** On machines equipped with disc brakes, check and maintain fluid level to within  $\frac{1}{4}$  inch from top of master cylinder reservoir. See Specifications and Service Data for recommended brake fluid.

**Initial Filter Change:** Remove and replace all replaceable filter elements in the converter/transmission, main and steering hydraulic systems after the first 50 operating hours. Remove and clean hydraulic reservoir suction filter and converter cooler line strainer. Subsequent filter changes may then be made at regular prescribed intervals.

**Batteries:** Keep terminals clean and tight, and be sure that distilled water is added to cover plates and separators in each cell. Do not overfill.

**Front Axle Differential:** Check lubricant level each 50 operating hours at the differential level plug. Add lubricant until level with plug opening. See "Every 1000 Operating Hours" for Drain and Refill.

**Front Axle Planetary Hubs:** Check lubricant level each 50 operating hours. Rotate wheel until arrow on sun gear thrust cap points downward.

This will position plug slightly below centerline of hub. Remove plug and check level.

Add lubricant until level with plug opening. See "Every 1000 Operating Hours" for Drain and Refill.

**Rear Axle Differential:** Check lubricant level each 50 operating hours at the differential level plug. Add lubricant until level with plug opening. See "Every 1000 Operating Hours" for Drain and Refill.

**Rear Axle Planetary Hubs:** Check lubricant level each 50 operating hours. Rotate wheel until arrow on sun gear thrust cap points downward. This will position plug slightly below centerline of hub. Remove plug and check level.

Add lubricant until level with plug opening. See "Every 1000 Operating Hours" for Drain and Refill.

**Steering Gear:** Check lubricant level each 50 operating hours. Keep reservoir filled. When adding lubricant, use of hand pump or gun is recommended to force lubricant into housing and up through bearing, since weight of lubricant alone in filler extension is insufficient to raise level above bearing.

**Midmount Bearing:** Check oil level of mid-mount bearing assembly connecting prop shafts between the transmission and front axle every 50 operating hours. Keep reservoir full to level plug opening on front face of reservoir. Add lubricant as required through combination breather and filler plug opening located on top of mid-mount reservoir. See "Every 1000 Operating Hours" for Drain and Refill.

## SERVICE PERIODICALLY

Check and service the following items at intervals as specified.

### (Every 100 Operating Hours)

**Propeller Shafts:** There are four propeller shafts – one from torque converter to transmission, one from transmission to midmount bearing,

one from midmount bearing to front drive axle, and one from transmission to rear drive axle. Each shaft has 3 points of lubrication – one on each spider assembly, and one on each slip yoke assembly. Total 12 points. Use a hand gun and apply grease until it is visible at all four bearing caps on each spider and bearing assembly. The grade of lubricant specified is on Drive Line Lubrication Chart according to ambient temperature.



**(Every 250 Operating Hours)**

**Engine and Accessories:** Refer to Operation and Maintenance Manual of engine manufacturer for lubrication instructions of engine and accessories.

**Torque Converter and Transmission Filter:** The torque converter and transmission hydraulic system is protected by full flow replaceable element type filter assemblies.

All fluid leaving the converter pump first passes through the filters providing clean fluid to the torque converter and transmission.

Replace filter elements every 250 operating hours and whenever converter pump, transmission or torque converter is repaired or overhauled for any reason. Thoroughly clean filter cases and base castings before inserting new elements. Using new gasket in base castings, tighten center bolts to specified torque. See Bolt Torque Chart in rear of manual.

**Converter Cooler Line Strainer:** The converter

cooler line strainer is located on the cooler line between converter and radiator oil cooler. Remove screen from strainer and wash in hot soapy water, rinse in clean hot water and reinstall in strainer. Repeat strainer cleaning procedure every 250 operating hours.

Run engine 5 minutes at approximately 1500 rpm checking filter assemblies, hoses and connections for leaks. Recheck transmission fluid level when it is at operating temperature (180°F. to 200°F.) as described under "Service Daily".

**Note:** *Filter elements are especially designed to withstand pressure and flow rate requirements. Use only replacement filter elements called for in applicable parts manual. Use of "will-fit" or substitute elements will endanger proper operation of torque converter and transmission and could cause costly repairs and down time.*

**Hydraulic Reservoir Suction and Return Filters:** Hydraulic reservoir suction and return filters are to be serviced at this time. See 250 Hour Maintenance Operations for the detailed instructions.

## (Every 500 Operating Hours)

**Grease Fittings:** Lubricate all points indicated on Chassis and Drive Line Lubrication Charts for 500 hour intervals. Use grade of lubricant specified on lubrication charts according to ambient temperature.

**Engine and Accessories:** Refer to Operation and Maintenance Manual of engine manufacturer for lubrication instructions of engine and accessories.

**Torque Converter and Transmission:** Drain and refill torque converter and transmission every 500 operating hours and whenever converter pump, transmission or torque converter is repaired or overhauled for any reason.

1. Always drain system while fluid is at operating temperature (180°F. to 200°F.). Hot oil flows more freely and carries more foreign material with it.
2. Remove drain plug from transmission housing and drain thoroughly.
3. Clean magnetic drain plugs and reinstall.
4. Replace elements in transmission and torque converter filter assemblies. Thoroughly clean filter cases and base castings before inserting new elements. Using new gaskets in base castings, tighten center bolts to specified torque. See Bolt Torque Chart in rear of manual. Remove, clean and reinstall cooler line strainer screen.
5. Remove breather cap from top of torque converter housing. Clean parts in solvent, blow dry with compressed air and reassemble.
6. Refill torque converter and transmission with fluid through transmission filler extension. Refer to Drive Line Lubrication Chart for recommended fluid. Refer to Specifications and Service Data for capacity.
7. Disconnect return oil cooler hose from cooler line and direct open end into waste drum or on ground. Securely block wheels of machine and apply parking brake.
8. Start engine, shift speed range selector lever in HI speed range and directional shift lever in FORWARD and maintain idle speed to force trapped oil in torque converter and oil cooler out through open end of return oil cooler hose. Drain sufficient fluid to insure clean fluid flow; then shut down engine and reconnect return oil cooler hose.
9. Restart and run engine for 5 minutes at approximately 1500 rpm checking filters, drain plugs, hoses and connections for leaks.
10. Recheck transmission fluid level when it is at operating temperature (180°F. to 200°F.). Add transmission fluid as necessary to maintain FULL mark on dipstick. (This check is to be performed with engine idling).

NEVER UNDER ANY CIRCUMSTANCES USE ANY FLUSHING OIL OR COMPOUNDS FOR CLEANING SYSTEM.

## (Every 1000 Operating Hours)

**Radiator:** Twice a year, drain flush and refill cooling system. Add permanent anti-freeze according to manufacturer's instructions when air temperature is 32°F. or lower, or when there is danger of water freezing in the system. Always use a hydrometer to check freezing point of solution when it is at operating temperature.

Check for evidence of foreign material blocking radiator core and blow out with compressed air.

Refer to Specifications and Service Data for capacity.

**Hydraulic Reservoir:** Drain, clean and refill hydraulic oil system every 1000 hours of operation or oftener if required. When operating under severe dusty and dirty conditions, clean the system more often to prevent excessive wear or premature failure of valve, pump, or cylinder parts.

1. Always drain system after working machine, and while oil is at operating temperature. Hot oil flows more freely and carries more foreign material with it.
2. To thoroughly drain cylinders and hoses, raise boom and bucket to full height and extend bucket cylinders. *Securely block or chain boom and bucket in raised position.* Then shut down engine.
3. Loosen reservoir cap *slowly* to relieve pressure in hydraulic reservoir.
4. Remove drain plug in hand hole cover in bottom of reservoir and drain reservoir.
5. Disconnect boom and bucket cylinder hoses at lowest points to drain cylinders.
6. Remove and clean reservoir suction filter assembly as specified under "250 Maintenance Operations". Replace reservoir return filter assembly.
7. Remove hand hole cover from bottom of reservoir and clean all foreign material from bottom of tank. Remove magnet and clean thoroughly. Reinstall magnet; then reinstall hand hole cover and drain plug securely.

8. Reconnect all hoses and unions.
9. Refill reservoir to indicated FULL mark on dipstick. Reinsert dipstick and secure reservoir cap. Refer to Chassis Lubrication Chart for recommended fluids.

Refer to Specifications and Service Data for capacity.

10. Be sure all control levers are in NEUTRAL position. Start engine and run it at idle speed for a few minutes.
11. Place boom lever in RAISE position to pump oil into boom cylinders. Then remove blocks or chains securing boom and bucket. *Do not stand or work under boom and bucket after removing blocks or chains.*
12. Operate unit by raising, lowering, dumping, and closing bucket until oil ceases to foam. This will "bleed" the system, forcing trapped air to escape through reservoir drain hose.
13. After oil has ceased to aerate, add oil to reservoir to bring level to indicated FULL mark on dipstick. This will replace oil drawn into cylinders and hoses.
14. Check all connections for leaks and make certain reservoir cap is properly secured.

NEVER UNDER ANY CIRCUMSTANCES USE ANY FLUSHING OIL OR COMPOUNDS FOR CLEANING THE SYSTEM.

**Transmission Sump and Screen:** When servicing transmission at every 1000 operating hours remove transmission sump and screen. Wash in solvent, dry and reinstall using new gaskets.

**Front Axle Differential:** Drain differential every 1000 operating hours. Refill with lubricant recommended on Drive Line Lubrication Chart until level with plug opening at center of axle assembly.

Refer to Specifications and Service Data for capacity.

**Front Axle Planetary Hubs:** Drain planetary hubs every 1000 operating hours; then rotate wheel until arrow on sun gear thrust cap points downward.

Add lubricant recommended on Drive Line Lubrication Chart until level with plug opening slightly below centerline of hub.

Refer to Specifications and Service Data for capacity.

**Rear Axle Differential:** Drain differential every 1000 operating hours. Refill with lubricant recommended on lubrication chart until level with plug opening at center of axle assembly.

Refer to Specifications and Service Data for capacity.

**Rear Axle Planetary Hubs:** Drain planetary hubs every 1000 operating hours; then rotate wheel until arrow on sun gear thrust cap points downward.

Add lubricant recommended on Drive Line Lubrication Chart until level with plug opening slightly below centerline of hub.


Refer to Specifications and Service Data for capacity.

**Midmount Bearing:** Drain and refill every 1000 operating hours. Remove drain plug located in bottom of midmount bearing and allow all fluid to drain out. Reinstall drain plug. Remove check plug from side and breather fill cap from top of midmount bearing. Add fluid through breather-fill cap hole until level reaches check plug hole. Reinstall check plug. Wash breather-fill cap in solvent, dry and reinstall. See Drive Line Lubrication Chart for recommended fluid.

Refer to Specifications and Service Data for capacity.

# MICHIGAN

## CHASSIS LUBRICATION CHART



DESCRIPTION	HOURS					KEY
	500	250	100	50	∞	
2 Fittings PUSHROD TO BUCKET	X					LBG
2 Fittings PUSHROD TO BELL CRANK		X				LBG
2 Fittings BUCKET CYL TO BELL CRANK			X			LBG
2 Fittings BELL CRANK PIVOT				X		LBG
2 Fittings BOOM CYL TO BOOM				X		LBG
2 Fittings Each Side BOOM CYLINDER TO TRUNNION MOUNT				X		LBG
2 Fittings BOOM TO UPPER PIVOT				X		LBG
1 Fitting Each Pin TRACTOR PIVOT UPPER & LOWER HINGE PIN				X		LBG
(See Text) BATTERIES				X		
(See Text) FUEL TANK					X	
(See Text) TRANSMISSION & TORQUE CONVERTER SYSTEM FILTERS			X			
(See Text) AIR RESERVOIR				X		
(See Text) ENGINE & ACCESSORIES					X	
(See Text) TIRES-FRONT & REAR					X	
(See Text) RADIATOR					X	

KEY	
LBG	LITHIUM BASE MULTI-PURPOSE GREASE 0°F. & Above Grade 2 Below 0°F.
HF	LUBRICANT TO BE USED SAE 10W Engine Oil, API Class SD or SE MIL-L-2104B or MIL-L-2104C (For Optional Lubricants See Operators Manual Text)
BF	0°F. & BELOW (See Operator's Manual Text) SAE J1703 (70R-3) BRAKE FLUID

KEY	HOURS					DESCRIPTION
	∞	50	100	250	500	
LBG		X				BOOM TO BUCKET 1 Fitting Each Side
LBG	X					STEERING CYLINDERS 2 Fittings Each Cylinder
LBG	X					BUCKET CYLINDER TO FRAME 1 Fitting Each Cylinder
BF		X				BRAKE MASTER CYLINDER (See Text)
LBG		X				STEERING GEAR (See Text)
LBG	X					STEERING DRAGLINK 2 Fittings
BF		X				BRAKE MASTER CYLINDER (See Text)
				X		HYDRAULIC SYSTEM RETURN FILTER (See Text)
				X		HYDRAULIC SYSTEM SUCTION FILTER (See Text)
HF	X					HYDRAULIC SYSTEM OIL RESERVOIR (See Text)
	X					AIR CLEANER (See Text)
	X					AXLE CRADLE BUSHINGS 2 Fittings
LBG	X					TRANSMISSION & TORQUE (See Text) CONVERTER COOLER LINE STRAINER

### MODEL 175 Articulated Tractor Shovel

TS-13985

Chassis Lubrication Chart (175)


**MICHIGAN**  
DRIVE LINE LUBRICATION

KEY	HOURS					DESCRIPTION
	∞	50	100	500	1000	
	X			X		TRANSMISSION DIPSTICK (See Text)
LBG		X				PROP SHAFT 3 Fittings (See Text)
LBG			X			PROP SHAFT 3 Fittings (See Text)
				X		PLANETARY DRAIN PLUG (See Text)
EPGL-1	X				X	DIFFERENTIAL FILL & LEVEL PLUG (See Text)

KEY	
LBG	LITHIUM BASE MULTI-PURPOSE GREASE Above 0°F Below 0°F
EPGL-1	EXTREME PRESSURE GEAR LUBE - *SCL TYPE LUBRICANT TO BE USED
HF	SAE 10W Engine Oil, API Class SD or SE MIL-L-2104B or MIL-L-2104 C (For Optional Lubricants See Operators Manual Text)
	0°F & BELOW See Operators Manual Text

FRONT OF MACHINE →

\*SCL signifies sulfo-chloro-lead type. Factory fill is made with SCL type lube and it is recommended that same type be used when adding or refilling. Below 0°F, to minus 10°F, use SAE-80. Up to 100°F, use SAE-90. Above 100°F, consistently, use SAE-140. SAE-80 and SAE-140 should contain additives similar to SAE-90.



DESCRIPTION	HOURS					KEY
	000	000	50	∞		
TRANSMISSION & TORQUE CONVERTER FILL PLUG (See Text)	X			X		HF
PROP SHAFT 3 Fittings (See Text)		X				LBG
PLANETARY DRAIN PLUG (See Text)	X					
TRANSMISSION & TORQUE CONVERTER BREATHER (See Text)			X			
DIFFERENTIAL FILL & LEVEL PLUG (See Text)	X				X	EPGL-1

TS-13986						
				X		DIFFERENTIAL DRAIN PLUG (See Text)
EPGL-1	X					PLANETARY FILL & LEVEL PLUG (See Text)
HF	X					MIDMOUNT BEARING FILL PLUG (See Text)
				X		MIDMOUNT BEARING DRAIN PLUG (See Text)

**MODEL 175**  
**Articulated**  
**Tractor Shovel**

Drive Line Lubrication Chart (175)


# MICHIGAN

## CHASSIS LUBRICATION CHART

Chassis Lubrication Chart (275)

[ 40-08-1 ]

DESCRIPTION	HOURS				KEY
	500	250	100	50	
1 Fitting Each Side PUSHROD TO BUCKET				X	LBG
1 Fitting Each Side PUSHROD TO BELL CRANK				X	LBG
1 Fitting Each Side BUCKET CYL TO BELL CRANK				X	LBG
1 Fitting Each Side BELL CRANK PIVOT				X	LBG
1 Fitting Each Side BOOM CYLINDER TO BOOM				X	LBG
2 Fittings Each Side BOOM CYLINDER TO TRUNNION MOUNT				X	LBG
1 Fitting Each Side BOOM TO UPPER PIVOT				X	LBG
1 Fitting Each Pin TRACTOR HINGE PIVOT UPPER & LOWER PIN				X	LBG
(See Text) BATTERIES			X		
(See Text) FUEL TANK				X	
TRANSMISSION & TORQUE CONVERTER SYSTEM FILTERS (See Text)	X				
2 Fittings Each Side BRAKE CAMSHAFT			X		LBG
(See Text) ENGINE & ACCESSORIES				X	
(See Text) TIRES — FRONT & REAR				X	
(See Text) RADIATOR				X	



KEY	HOURS				DESCRIPTION
	8	50	100	500	
LBG	X				BOOM TO BUCKET 1 Fitting Each Side
LBG		X			BRAKE CAMSHAFT 2 Fittings Each Side
LBG	X				STEERING CYLINDERS 2 Fittings Each Cylinder
LBG	X				BUCKET CYLINDER TO FRAME 1 Fitting Each Cylinder
GL		X			STEERING GEAR (See Text)
LBG	X				STEERING DRAG LINK 2 Fittings
LBG	X				BUCKET CONTROL LEVER 1 Fitting
LBG	X				BOOM CONTROL LEVER 1 Fitting
				X	HYDRAULIC SYSTEM RETURN FILTER (See Text)
				X	HYDRAULIC SYSTEM SUCTION FILTER (See Text)
HF	X				HYDRAULIC SYSTEM OIL RESERVOIR (See Text)
	X				AIR CLEANER (See Text)
LBG	X				AXLE CRADLE BUSHINGS 2 Fittings
				X	TRANSMISSION & TORQUE CONVERTER COOLER LINE STRAINER (See Text)

### MODEL 275B Articulated Tractor Shovel

KEY	
LBG	LITHIUM BASE MULTI-PURPOSE GREASE Grade 2 0°F. & Above Below 0°F. Grade 0
GL	STRAIGHT MINERAL OIL GEAR LUBE — API CLASS GL1
HF	AMBIENT TEMP. RANGE ABOVE 0°F
	LUBRICANT TO BE USED
0°F & BELOW	1) SAE 10 W Engine Oil, API Class 5MS, DM, or MIL-L-2104 B.
	2) Automatic Transmission Fluids: Type A, Suffix A, or DEXRON. See Note Below.
	3) Hydraulic Transmission Fluid: Type C — See Note Below.
	Automatic Transmission Fluids: Type A, Suffix A, or DEXRON. See Note Below.

5 — Sequence Tested.

Note: Automatic Transmission Fluids, Type A, Suffix A, or DEXRON and Type C-2 Hydraulic Transmission Fluids must contain type and content of anti-wear compound found in API Class MS engine oils and meet viscosity requirements of Class MS engine oils — GRADE 10 W.

TS-10559




# MICHIGAN

## DRIVE LINE LUBRICATION

DESCRIPTION	HOURS					KEY
	1000	500	100	50	8	
TRANSMISSION & TORQUE CONVERTER FILL PLUG (See Text)	X				X	HF
TRANSMISSION BREATHER (See Text)				X		
3 Fittings PROP SHAFT (See Text)			X			LBG
PLANETARY DRAIN PLUG (See Text)	X					
TORQUE CONVERTER BREATHER (See Text)				X		

KEY		
LBG	LITHIUM BASE MULTI-PURPOSE GREASE 0°F. & Above: Grade 2 Below 0°F. Grade 0	
EPGL-1	EXTREME PRESSURE GEAR LUBE * SCL TYPE	
HF	AMBIENT TEMP. RANGE	
	ABOVE 0°F	1) SAE 10 W Engine Oil, API Class SMS, DM, or MIL-L-2104 B. 2) Automatic Transmission Fluids: Type A, Suffix A, or DEXRON. See Note Below. 3) Hydraulic Transmission Fluid: Type C - See Note Below.
	0°F & BELOW	Automatic Transmission Fluids: Type A, Suffix A, or DEXRON. See Note Below.

KEY	HOURS					DESCRIPTION
	8	50	100	500	1000	
	X			X		TRANSMISSION DIP STICK (See Text)
LBG			X			PROP SHAFT 3 Fittings (See Text)
LBG			X			PROP SHAFT 3 Fittings (See Text)
				X		PLANETARY DRAIN PLUG (See Text)
EPGL-1	X			X		DIFFERENTIAL FILL & LEVEL PLUG (See Text)



Note: Automatic Transmission Fluids, Type A, Suffix A, or DEXRON and Type C-2 Hydraulic Transmission Fluids must contain type and content of anti-wear compound found in API Class MS engine oils and meet viscosity requirements of Class MS engine oils - GRADE 10 W.

\*\* SCL signifies sulfo-chloro-load type. Factory fill is made with SCL type lube and it is recommended that same type be used when adding or refilling. Below 0°F. to minus 10°F. use SAE-80. Up to 100°F. use SAE-90. Above 100°F. consistently, use SAE-140. SAE-80 and SAE-140 should contain additives similar to SAE-90.

### MODEL 275B Articulated Tractor Shovel

TS-9813

DIFFERENTIAL FILL & LEVEL PLUG (See Text)	X		X		EPGL-1
DIFFERENTIAL DRAIN PLUG (See Text)	X				
PLANETARY FILL & LEVEL PLUG (See Text)	X		X		EPGL-1
3 Fittings PROP SHAFT (See Text)			X		LBG

				X		DIFFERENTIAL DRAIN PLUG (See Text)
EPGL-1	X		X			PLANETARY FILL & LEVEL PLUG (See Text)
HF	X		X			MIDMOUNT BEARING (See Text)
			X			TRANSMISSION & TORQUE CONVERTER DRAIN PLUG (See Text)

Drive Line Lubrication Chart (275)

[ 40-08-2 ]

## MAINTENANCE SCHEDULE

SYSTEM	OPERATION	DAILY or SHIFT	TIME INTERVAL (HOURS)				
			50	100	250	500	1000
<b>Engine, Controls, Cooling System and Accessories</b>	Engine Maintenance		See Engine Manufacturer's Manual				
	Check Air Cleaner Service Indicator	●	●	●	●	●	●
	Check Cooling System for Leaks		●	●	●	●	●
	Drain Fuel Tank Sediment		●	●	●	●	●
	Check Anti-Freeze Protection		●	●	●	●	●
	Tighten Air Cleaner Connections		●	●	●	●	●
	Check and Adjust Belt Tension		●	●	●	●	●
	Check Engine RPM				●	●	●
	Clean Radiator Core					●	●
Service Air Cleaner Element and Body					●	●	
<b>Torque Converter and Transmission System</b>	Check Hydraulic System for Leaks		●	●	●	●	●
	Clean Torque Converter and Transmission Breather			●	●	●	●
	Check and Adjust Transmission Shift Lever Linkage					●	●
	Check Transmission De-Clutch Valve					●	●
	Check Converter Internal Pressure					●	●
	Check Transmission Clutch, Lubricating and Oil Cooler Pressures					●	●
<b>Boom and Bucket System</b>	Check Hydraulic System for Leaks		●	●	●	●	●
	Clean Cylinder Rods		●	●	●	●	●
	Adjust Bucket Leveler				●	●	●
	Service Reservoir Return Filter Assembly				●	●	●
	Clean Reservoir Suction Filter Assembly				●	●	●
	Check Boom and Bucket Pressure					●	●
	Check and Adjust Main Hydraulic Pump					●	●
	Adjust Boom and Bucket Control Levers					●	●
	Check Accumulator Precharge						●
	Check and Repair Bucket Cutting Edge						●
Check Boom to Bucket Linkage						●	
<b>Electrical System</b>	Check Lights and Fuses		●	●	●	●	●
	Service Batteries		●	●	●	●	●
	Clean and Tighten Electrical Connections					●	●
	Inspect, Test and Lubricate Electrical Units						●
<b>Axles, Prop Shafts, Wheels and Tires</b>	Check Tire Pressure and Casings	●	●	●	●	●	●
	Tighten Wheel Nuts and Inspect Rims		●	●	●	●	●
	Clean Axle Breathers					●	●
<b>Steering System</b>	Check Hydraulic System for Leaks		●	●	●	●	●
	Clean Cylinder Rods		●	●	●	●	●
	Check Steering Pressure					●	●
	Check and Adjust Steering Pump					●	●
	Bleed Steering Relief Valve					●	●
	Adjust Drag Link Ball Joints					●	●
	Adjust Steering Gear						●
<b>Brake System</b>	Inspect Brakes	●	●	●	●	●	●
	Check Air Chamber and Lines for Leaks		●	●	●	●	●
	Tighten Brake Disc Mounting Bolts				●	●	●
	Adjust Service (Wheel) Brakes (Drum Type)				●	●	●
	Bleed Brake System (Disc Type)				●	●	●
	Adjust Parking Brake				●	●	●
<b>General Maintenance</b>	Visually Inspect Machine	●	●	●	●	●	●
	Adjust and Lubricate Operator's Seat				●	●	●
	Check and Adjust Lower Hinge Pin Bushing				●	●	●
	Tighten Mounting Bolts					●	●
	Steam Clean Machine					●	●
	Inspect Frame						●

## MAINTENANCE

The Maintenance Schedule lists checks or adjustments within machine systems or related components.


Procedure from each system listed at a specified interval are described in sequence. They should be performed at the same time as the lubrication intervals.

### DAILY OR SHIFT MAINTENANCE OPERATIONS

- ENGINE MAINTENANCE
- CHECK AIR CLEANER SERVICE INDICATOR
- CHECK TIRE PRESSURE AND CASINGS
- INSPECT BRAKES
- VISUALLY INSPECT MACHINE

**Engine Maintenance:** Refer to Operation and Maintenance Manual of engine manufacturer for maintenance instructions of engine and accessories.

**Check Air Cleaner Service Indicator:** Mounted on the air cleaner outlet to the engine, the service indicator is factory set to signal when servicing of the filter element is required. Refer to Figure 10.



1. Red Flag                      2. Reset Button

Fig. 10. Air Cleaner Service Indicator

Dirt trapped by the filter element gradually increases the pressure drop across the cleaner. As the resistance increases, the Red Flag of the indicator gradually rises in the window. When the flag reaches the top position it will lock in place regardless of whether or not the engine is running. Service filter element at this time.

**Check Tire Pressure and Casings:** Check air pressure in all tires. See Specifications and Service Data for recommended air pressure. Particular attention must be emphasized when checking hydro-inflated tires as there is less volume of air to provide cushioning. Be sure valve caps are in place to prevent dirt, moisture, and foreign material from damaging valve core.

**Inspect Brakes:** On machines equipped with disc brakes, visually inspect to insure that all bolts are tight and that boot deterioration or excessive lining wear has not occurred. Linings worn to  $\frac{1}{8}$ " thickness should be replaced. Discs worn to less than .450 inch should be replaced. Inspect brake hydraulic system to be certain that no leakage is evident.

**Visually Inspect Machine:** Visually inspect general condition of the machine, operating controls, instruments and switches, control rods, cable controls and linkage, fuel pump, filters and the radiator for any noticeable damage.

Special attention must be emphasized when inspecting components of the oil system, fuel system, and cooling system. If unusual, or unexplained traces of oil, fuel, or water are found on or below components of the respective systems locate and correct such leaks immediately.

Unexplained oil streaks on or below the engine, transmission, torque converter, or axle assemblies must be carefully investigated. Such indications may be evidence of cracks, loose mounting bolts, damaged seals or gaskets, which (if neglected) may result in complete failure and major damage to the engine and drive line.

## 50 HOUR MAINTENANCE OPERATIONS

- ENGINE MAINTENANCE
- CHECK COOLING SYSTEM FOR LEAKS
- DRAIN FUEL TANK SEDIMENT
- CHECK ANTI-FREEZE PROTECTION
- TIGHTEN AIR CLEANER CONNECTIONS
- CHECK AND ADJUST BELT TENSION
- CHECK HYDRAULIC SYSTEMS FOR LEAKS
- CLEAN TORQUE CONVERTER AND TRANSMISSION BREATHER
- CHECK LIGHTS AND FUSES
- SERVICE BATTERIES
- TIGHTEN WHEEL NUTS AND INSPECT RIMS
- CHECK AIR CHAMBERS AND LINES FOR LEAKS
- CLEAN CYLINDER RODS

**Engine Maintenance:** Refer to Operation and Maintenance Manual of engine manufacturer for maintenance instructions of engine and accessories.

**Check Cooling System for Leaks:** Check radiator, hoses, oil cooler, water pump and drain cocks for leaks and correct where necessary. Loss of coolant due to ruptured hoses, loose clamps, leaking pump or drain cocks can and will result in expensive repairs or replacement of engine components.

**Drain Fuel Tank Sediment:** Every 50 operating hours loosen drain plug in hand hole cover on bottom of fuel tank and drain off any accumulated water.

Check all fuel lines, fuel pump, filters, and shut-off cocks for leaks and correct where necessary. Open drain cock at bottom of filters, when provided, and drain off accumulated water and sediment.

**Check Anti-Freeze Protection:** At specified intervals, or whenever anticipating extremely cold weather, use a hydrometer to check freezing point of solution (permanent type anti-freeze) when it is at operating temperature. If necessary add additional anti-freeze according to manufacturer's

instructions to maintain a safe level beyond the freezing point.

**Tighten Air Cleaner Connections:** Tighten all hose clamps and air cleaner mounting bracket bolts. Check all hoses and pipes between air cleaner and engine for cracks or leaks, which will permit dust laden air to by-pass air cleaner entering directly into engine. Serious and costly damage to the engine will result. See "50 Hour Maintenance Operations" for servicing air cleaner filter element.

**Check and Adjust Belt Tension:** Each 50 operating hours inspect all drive belts for serviceable condition and proper tension. Neglect and improper tension often leads to inadequate cooling, bearing failure of the driven part and short belt life. Belts should be just tight enough to drive the moving parts without slipping.

*Note: Due to older belts having been stretched, through use, beyond their original length and preventing newer belts from carrying most of the load, it will be necessary to replace all belts as a matched set when one or two belts in the set are worn or damaged beyond serviceable condition.*


All new belts will loosen after operating for a day or two and must be rechecked and retensioned if necessary. At specified intervals check and retension fan belts as follows:

### G.M. ADJUSTMENT

1. Loosen the four mounting bolts securing the fan drive pulley bracket as shown in Figure 11.
2. Turn fan bracket adjusting bolt clockwise to raise fan drive pulley (increasing belt tension) or counterclockwise to lower fan drive pulley (decreasing belt tension) depending on the existing condition.
3. Turn the adjusting bolt so that  $\frac{3}{4}$  inch maximum deflection is obtained on the belts midway between the pulleys as shown in Figure 11.
4. When belts are properly adjusted, retighten the four mounting bolts securing the fan drive pulley.

### CUMMINS ADJUSTMENT

1. Loosen locknut securing fan drive pulley to




1. Mounting Bolts
2. Adjusting Bolt

**Fig. 11. Check Fan Belt Tension — G.M.**

bracket as shown in Figure 12.

2. Turn fan drive pulley adjusting bolt clockwise to raise fan drive pulley (increasing belt tension) or counterclockwise to lower fan drive pulley (decreasing belt tension) depending on the existing condition.
3. Turn the adjusting bolt so that  $\frac{3}{16}$  inch maximum deflection is obtained on the belts midway between the pulleys.
4. When belts are properly adjusted, retighten locknut to 400-500 ft.-lbs. torque. Rotate torque one more hex.
5. Back-off adjusting screw one-half turn.

Periodically belts should be cleaned to remove



1. Locknut
2. Adjusting Bolt

**Fig. 12. Check Fan Belt Tension — Cummins**

grease and glaze by wiping with a cloth saturated with brake fluid. This in most instances will eliminate squeak and extend the service life of the belts.

**Check Hydraulic System for Leaks:** Check oil reservoirs, valve, pumps, cylinders, all hydraulic hose lines and connections for leaks, correcting where necessary. Particular attention should be paid to hoses on the intake or suction side of the pumps. Hose clamps and connections employed must be securely tightened to prevent entrance of foreign material or air into the system. Air drawn into the system at this point will cause cavitation of the pump with resultant malfunctioning and early failure. All hoses should be checked for abrasions which could result in ruptures of same. Replace hoses found in this condition.

**Clean Torque Converter and Transmission Breather:** The torque converter and transmission system is equipped with a breather located on top of torque converter.

Each 50 operating hours unscrew breather, wash in solvent, blow dry with compressed air and reinstall.

**Check Lights and Fuses:** Two fuses provide protection for the electrical system, one in gauge circuit and one in light circuit. An additional self contained fuse which is part of the lighter base and cord assembly provides protection for the lighter element. All fuses are located behind the instrument panel as shown on the Wiring Diagram.


The light circuit fuse and gauge circuit fuse are contained in plastic connectors. Push and twist to open and lock plastic connectors for fuse replacement. The self contained lighter fuse is a screw on type fuse secured between the lighter base and cord assembly.

To replace fuses remove instrument panel mounting bolts and swing panel outward.

The circuits and fuse protection are:

- Gauge Circuit . . . . . AGC  $\frac{3}{4}$  Amp.
- Light Circuit . . . . . SFE 20 Amp.
- Lighter Circuit (self contained) . . 20 Amp.

(a) **Headlamps and Back-Up Lamps:** The machine is equipped with headlamps and back-up lamps mounted in shock resistant rubber retainers.




**Fig. 13. Replace Headlamps or Back-Up Lamps**

The headlamps and back-up lamps are floodlamps that disperse light in a horizontal pattern.

Headlamps are factory adjusted, but may be re-adjusted at the headlamp mounting bolts or nuts to obtain a desired light pattern.

If necessary to replace floodlamps, depress lamp and spread lip of rubber retainer outward forcing lamp out as shown in Figure 13, and disconnect terminals. Reconnect terminals on new lamp and reinstall in retainer.

(b) **Dash, Tail and Stop Lamps:** These lights are easily replaced by a push and a twist. To remove dash lamp reflector from dash lamp assembly pull out to remove and push on to retain. Reflectors for the tail and stop lights must be removed by removing three screws shown in Figure 14 and carefully forcing reflectors out. To reinstall reflec-



**Fig. 14. Remove Reflectors and Replace Tail or Stop Lamps**

tors carefully depress reflectors and fasten in place with retaining screws.

**Service Batteries:** Keep terminals clean and tight, and be sure distilled water is added to cover plates and separators in each cell. Do not overfill.

To prevent serious damage to electrical system components when recharging or replacing batteries in the "Delcotron" charging system.

**... REMEMBER ...**

1. When installing batteries, *make sure* batteries and "Delcotron" polarities are the same.
2. Booster batteries *must be* paralled.
3. Battery-charger and battery polarities *must agree*.
4. Before doing any welding, *disconnect ground cable from batteries and electrical lead from battery terminal on alternator*.

**Tighten Wheel Nuts and Inspect Rims:** Wheel nuts should be checked regularly and kept tight. Loose wheel nuts will cause undue tire wear, strain axle assemblies and affect steering and load distribution. Apply lubricant on threads of wheel studs only and tighten wheel nuts to torque specified on Bolt Torque Chart.

Check rims for bent or damaged flanges and repair or replace as needed.

**Check Air Chambers and Lines for Leaks:** Periodically check connecting lines and fittings to be sure they are air tight. Air chambers occasionally should be painted with soap solution to detect leakage. Tighten clamping ring bolts uniformly until leakage is eliminated, as no leakage is permissible.

Check and securely tighten air chamber to mounting bracket bolts and mounting bracket to axle bolts.

**Clean Cylinder Rods:** Wipe boom, bucket, and steering cylinder rods with clean cloth saturated in hydraulic oil. Check rods for nicks or burrs which would damage packings or seals. Remove such nicks or burrs with a fine grained hand stone or crocus cloth.

## 100 HOUR MAINTENANCE OPERATIONS

- **ENGINE MAINTENANCE**

**Engine Maintenance:** Refer to Operation and Maintenance Manual of engine manufacturer for maintenance instructions of engine and accessories.

## 250 HOUR MAINTENANCE OPERATIONS

- **ENGINE MAINTENANCE**
- **CHECK ENGINE RPM**
- **ADJUST BUCKET LEVELER**
- **ADJUST BOOM KICKOUT**
- **ADJUST SERVICE (WHEEL) BRAKES**
- **BLEED BRAKE SYSTEM (DISC BRAKES ONLY)**
- **ADJUST PARKING BRAKE**
- **ADJUST AND LUBRICATE OPERATOR'S SEAT**
- **CHECK AND ADJUST LOWER HINGE PIN BUSHING**
- **CHECK BRAKE DISC MOUNTING BOLTS**
- **SERVICE RESERVOIR RETURN FILTER ASSEMBLIES**
- **CLEAN HYDRAULIC RESERVOIR SUCTION FILTER ASSEMBLIES**

**Engine Maintenance:** Refer to Operation and Maintenance Manual of engine manufacturer for maintenance instructions of engine and accessories.

**Check Engine RPM:** Engine speeds should be checked regularly against specifications to determine engine efficiency and machine performance. Proper speeds insure safe operating limits for the engine and maintain correct operating speeds for torque converter and transmission.

(a) **Low Idle and High Idle RPM:** These speeds are the free operating limits of the engine under no load conditions. They are determined by the amount of the amount of fuel delivered to the engine. See Specifications and Service Data.

**Caution:** *Do not accelerate to maximum rpm until engine is at operating temperature.*

Check throttle linkage to insure wide open throttle when accelerator is fully depressed, also closed throttle when accelerator is fully released. Accelerator and linkage should operate freely in all positions.

Occasionally control rods, control levers or bell cranks loosen or become damaged, impairing the operating efficiency of the engine. Insufficient power is frequently caused by throttle linkage being out of adjustment. Adjust linkage if necessary.

Fuel controls are accurately calibrated at the factory to insure correct idle and high idle speeds.

**Adjust Throttle Linkage:** If throttle linkage requires adjustment, proceed as follows.

1. Unhook spring and disconnect ball joint assembly from throttle control lever.
2. Depress accelerator until it contacts stop on floorboard.
3. Rotate throttle control lever to the extreme full throttle position and adjust ball joint to obtain a slip fit on throttle control lever just before accelerator pedal bottoms.
4. Reinstall ball joint assembly and reconnect spring.
5. Depress and release accelerator, and check that accelerator control rods will properly rotate throttle control lever from idle to full throttle position with out interference.
6. Additional adjustments may be made at the other ball joint or at accelerator pedal.

Pressure required to depress accelerator is controlled by the spring on the throttle control lever. This spring also insures that the engine will return to idle speed when accelerator pedal is released.

(b) **Stall RPM:** The engine and torque converter act as a unit to deliver power to the transmission. A stall check should be performed to insure that the engine is developing rated power and that the torque converter is operating efficiently.

**Caution:** *Check stall rpm only when torque converter fluid is hot (180°F. to 200°F.), engine is at operating temperature, and boom and bucket relief valve setting is at proper specification.*

1. Install tachometer on engine.
2. Apply parking brake, block wheels, attach safety links, and place directional lever in NEUTRAL.
3. Start engine and raise bucket a few inches above the ground.
4. Shift levers into FORWARD, HI speed range, and accelerate engine. When engine reaches maximum rpm, pull back on bucket control lever to rotate bucket to full close position. When engine rpm drops off to lowest point read tachometer.

**DO NOT STALL CONVERTER MORE THAN 30 SECONDS AT ANY ONE TIME.**



If stall rpm is not within specifications, trouble shooting of engine or torque converter by a qualified mechanic is required. See Specifications and Service Data.

**Note:** Stall rpm specified in Specifications and Service Data at rear of this manual is applicable to altitude of 600 ft. and ambient temperature of 70°F. Do to many combinations of altitude and temperature possible in the field, space does not permit publishing here all the corrections necessary to the stall rpm indicated to accommodate such variations. It is suggested the engine manufacturer's distributor be contacted to determine the correction necessary for altitude and temperature in your application.

**Adjust Bucket Leveler:** There are two types of bucket levelers currently in use. Adjustment procedures for both are covered in the following paragraphs.

(a) **Air Actuated Bucket Leveler:** The bucket leveler mechanism mounted on the right hand bucket cylinder consists of a leveler cam and leveler valve with connecting piping from the air reservoir to the main control valve.

The roller arm of the bucket leveler valve rolls off the leveler cam as the bucket rotates back from the DUMP position. Air flow from the air reservoir to the bucket spool on the main control valve is interrupted, releasing the bucket lever from the detent located CLOSE position to the HOLD (neutral) position. This action returns bucket to a level position automatically.

Servicing and adjustment procedures are as follows, see Figure 15: **Leveler cam must be parallel to cylinder rod.**

1. Start engine and position level on ground; shut down engine and pull bucket lever into detent located CLOSE position.
2. Adjustment is provided at the leveler cam bracket. Elongated holes in the bracket, Figure 15 item 1, allow adjustment either in or out to maintain proper roller arm stroke,  $\frac{1}{8}$  inch to actuate.
3. Additional adjustment is provided at the roller arm, Figure 15 item 2. Loosen locknut and turn




Fig. 15. Adjust Bucket Leveler (Air)


adjusting screw until roller arm just contacts leveler cam. Bucket lever should be in HOLD (neutral) position. Tighten the locknut. Maximum stroke of roller arm is  $\frac{3}{16}$  inch.

4. Start engine. Raise boom to a number of different heights and cycle bucket slowly at each of these various heights to check proper operation. Each time bucket reaches a level position, the bucket control lever should automatically return to the HOLD position.

(b) **Electric Bucket Leveler:** The bucket leveler mechanism consists of a leveler cam and an electric switch mounted on the right hand bucket cylinder, and a solenoid operated air valve. The electric switch is wired to the solenoid operated air valve, which in turn is connected to the air tank and main hydraulic valve by piping.

The roller arm on the electric switch rolls off the leveler cam as the bucket is rotated back from the DUMP position. This action closes the electric switch and completes the circuit, sending a flow of electricity to the solenoid operated air valve. This releases a flow of air from the tank to the main control valve causing the bucket lever to move from the detent located CLOSE position to the HOLD (neutral) position. The bucket will then stop in a level position.

Servicing and adjustment procedures are as follows: Refer to Figure 16 for correct position of leveler cam in relation to roller on electric switch when bucket is in a level position.




**Fig. 16. Adjust Bucket Leveler (Electric)**

**Caution:** *Leveler cam must be parallel to bucket cylinder rod at all times.*

1. Start engine, position bucket level on ground, shut down engine and pull bucket lever into detent located CLOSE position.
2. Adjustment is provided at the leveler cam bracket. Elongated holes in the leveler cam bracket allow adjustment either in or out to maintain proper roller arm stroke,  $\frac{1}{8}$  inch to actuate. (Figure 16 Item 1).
3. The roller on the electric switch should be just off, but nearly touching the leveler cam when bucket is in a level position.
4. Additional adjustment is provided at the roller arm on the electric switch. Maximum stroke of roller arm is  $\frac{5}{16}$  inch.
5. Start engine. Raise bucket to a number of different heights and cycle bucket slowly at each of these various heights to check proper operation. Each time bucket is rotated back from the DUMP position, the bucket lever should return automatically to the HOLD (neutral) position.

**Adjust Boom Kickout:** The boom kickout mechanism consists of a boom cylinder mounted kickout cam, a frame mounted electric switch and solenoid mounted at the control valve boom spool.

To obtain maximum height kickout switch bracket should be installed in bottom slots of frame bracket. The roller on the electric switch should just contact cylinder mounted kickout cam. This will cause boom kickout to occur at approximately 1 foot (30,5 cm) from maximum height. Lower boom kickout positions may be obtained by raising switch bracket in mounting slots.



**Fig. 17. Adjust Brake Slack Adjuster**

**Adjust Service (Wheel) Brakes:** The following paragraphs cover adjustment procedures for shoe and drum type brakes, and bleeding procedures for disc type brakes.

(a) **Brake Slack Adjuster (Shoe and drum type only):** Slack adjusters are used between brake chambers and brake camshafts at all wheels. Slack adjusters permit a rotation of the camshaft from its original position sufficient to compensate for wear of brake linings.


See Figure 17. The adjustment is as follows:

1. Turn adjusting screw, Figure 17 item 1, to change position of lever in relation to brake camshaft. Turning screw clockwise will decrease clearance between brake lining and drum.
2. With maximum air pressure and with brakes fully activated and applied, adjust at slack adjuster to obtain 1 inch of travel on brake chamber push rod when brakes are released. Adjust all slack adjusters for the same travel distance.

(b) **Bleed Brake System (Disc Brakes Only):** Occasionally it may be necessary to bleed brake system to remove air trapped in the system due to a leak in the line or the installation of new parts in the system. Air trapped in the system will be indicated by a soft spongy brake pedal.

**Note:** *It is recommended to use a bleeder hose on bleeder valves when ever possible to keep fluid away from linings. Keep master cylinder(s) filled during bleeding process.*

1. Open bleeder valve, (See Item 1 Figure 18), and actuate brakes several times until fluid coming from bleeder valve is free of bubbles. Depress brake pedal and close bleeder valve, then release brake pedal.
2. Open second bleeder valve (See Item 2 Figure 18). Depress brake pedal several times until



TS-13477

**Fig. 18. Disc Brake Head (Exploded View)**

brake fluid coming from bleeder valve is free of bubbles. Depress brake pedal and close bleeder valve, then release brake pedal.

3. Actuate brakes several times.
4. Repeat steps 1 and 2, until no bubbles are observed in fluid from bleeder valves.
5. Repeat entire process at each brake head to finish bleeding system.


**Note:** Master cylinder(s) must be kept full at all times.

See Specifications and Service Data section in rear of this manual for recommended brake fluid.

**Adjust Parking Brake:** When slack develops in parking brake cable, perform the following adjustments.


1. With lever in released position, turn acorn on end of handle clockwise as shown in Figure 19.
2. Test for good resistance over center as handle is pulled up to applied position.

Further adjustment is provided by a clevis at the brake arm. See Figure 20. First be sure that acorn on lever is backed off, so that all slack can be taken up at the clevis. Brake lever should be in released position.



TS-11067

**Fig. 19. Adjust Parking Brake at Handle**




**Fig. 20. Adjust Parking Brake at Brake Arm**

1. Loosen locknut (Item 1 Figure 20), on brake cable.
2. Remove cotter and clevis pin (Item 2 Figure 20).
3. Turn clevis (Item 3 Figure 20) clockwise to tighten brake.
4. Reassemble and tighten locknut.
5. Test brake for proper application and release.


**Adjust Parking Brake:** The parking brake consists of a mechanical disc brake mounted on the front axle. Maintenance consists of occasional adjustment of the parking brake whenever linings become partially worn down or new pad and lining assemblies are installed.

To adjust parking brake, use a feeler gauge and tighten adjusting lever nut, see Figure 20A, until



- A. Adjusting Lever Nut      B. Return Spring  
C. Pad & Lining Assembly

**Fig. 20A. Parking Brake**



**Fig. 21. Adjust Operator's Seat**

.010 (0,3) clearance is obtained between disc and lining pad on one side only.


**Adjust and Lubricate Operator's Seat:** The operator's seat can be shifted forward or rearward to suit the individual by moving the lever, (Item 1 Figure 21), on left hand side of operator's seat forward and shifting seat to the desired position.

The seat can also be adjusted up and down by relocating the seat assembly in the adjusting holes, (Item 2 Figure 21), in the seat mounting brackets.


Oiling of release mechanism (Item 1 Figure 22) track assemblies and pivot points will keep them operating freely.

Tilt seat over steering wheel when shutting down machine at end of work shift.


**Check and Adjust Lower Hinge Pin Bushing:** The lower hinge pin bushing is constructed in a manner which allows for a clearance adjustment between the inner and outer roll. By removing shims under the bushing retaining cap, the clear-



**Fig. 22. Lubricate Operator's Seat**



**Fig. 23. Adjust Bushing — One Piece Shim**



**Fig. 24. Adjust Bushing — Split Shim**

ance between the inner and outer race can be adjusted to compensate for wear.

There are two types of adjustable lower hinge pin arrangements in use. Use procedure "A" for adjustment of lower hinge pins with doughnut shaped cover plate and one piece shims. Follow procedure "B" for adjustment of lower hinge pins without doughnut shaped cover plate and split shims.

Check Bushing Adjustment. See Figures 23 & 24.

1. Park machine on a level surface, attach safety links and lower bucket.
2. Check center bolt to be certain that it is tightened to specified torque. (See Bolt Torque Chart in rear of manual).
3. If it is necessary to retighten center bolt, check lower hinge pin bushing by alternately applying down pressure and raising boom at idle. Look for movement or change in distance between front and rear frame plates at center pivot. If any movement is detected, adjust bushing as follows.

**Adjust Bushing – Procedure "A".** See Figure 23.

1. Using a dial indicator measure the amount of "play" between front and rear frame plates at lower pivot and record measurement.
2. Remove doughnut shaped plate from center pivot, then remove cap.
3. Remove shims equal to above measurement.
4. Reinstall cap and tighten bolts to specified torque. Refer to Bolt Torque Chart in rear of manual.
5. Reinstall doughnut shaped plate and tighten mounting bolts. Retighten center bolt to specified torque.

Procedure "B" See Figure 24.

1. Using a dial indicator measure the amount of "play" between front and rear frame plates at lower pivot and record measurement.
2. Loosen cap bolts to gain access to shims.
3. Remove shims equal to the above measurement.
4. Retighten cap bolts to specified torque. Refer to Bolt Torque Chart in rear of manual.
5. Retighten center bolt to specified torque.

**Brake Disc Mounting Bolts: (175 B only)**  
Check brake disc mounting bolts after first 250 operating hours. If any bolts show evidence of loosening, all brake disc mounting bolts should be re-tightened as follows:

1. Tighten all brake disc mounting bolts to 159 to 175 ft. lbs.
2. Repeat entire procedure so that each individual bolt is checked twice. Subsequent checking should not be necessary until brake disc is replaced.

**Replacement of Brake Disc: (175 B only)** If at any time it is necessary to replace the brake disc, all mounting bolts should be tightened in the following manner:

1. Tighten all brake disc mounting bolts to 159-175 ft. lbs.
2. Repeat entire procedure so that each individual bolt is checked twice.
3. After first 250 operating hours on new disc, check brake disc mounting bolts. If any bolts show evidence of loosening, all brake disc mounting bolts should be retightened as described in Steps 1 and 2 above.

## Service Reservoir Return Filter Assemblies:

The hydraulic reservoir return filter assemblies installed inside the hydraulic reservoir consist of a head and handle assembly, o-ring, filter elements secured between a holder assembly with retaining plates (center and bottom), a spring and attaching hardware. The reservoir return filter assemblies are designed and installed in a manner that permits the filter assembly to act as a relief valve so that oil can be by-passed if the filter element becomes excessively plugged with foreign material.

During normal operation, hydraulic system oil flows through the return filter assemblies from inside to outside before entering the reservoir. However, when the filter elements become excessively plugged with foreign material or contaminants, a difference in pressure within the inner side of the filter elements and reservoir will be created. When the pressure differential reaches approximately 11 psi, the filter assembly is forced downward permitting the hydraulic oil to by-pass the plugged filter elements entering directly into the hydraulic reservoir.

Remove the hydraulic reservoir return filter assemblies and replace filter elements as follows, See Figure 25:

**Caution:** *Extreme care must be exercised when removing filter while oil is hot to prevent hands from getting burned.*

1. Remove filter assembly from hydraulic reservoir by removing mounting bolts and lockwashers holding cover plate in place.
2. Remove attaching hardware securing the bottom retaining plate and filter elements in the holder assembly. Discard the retaining plate sealing washer.
3. Remove filter elements and center retaining plate from holder assembly. Discard the filter elements.

**Note:** *Do not attempt to clean or re-use the dirty filter elements.*

4. Install new filter elements in holder assembly with the center retaining plate positioned between the top and bottom filter elements. Resecure the elements in the holder assembly with bottom retaining plate, using a new sealing washer, and attaching hardware.
5. Reinstall and secure the return filter assemblies in the hydraulic reservoir with coverplate, mounting bolts and lockwashers.




Fig. 25. Reservoir Return Filter Assembly

**Clean Hydraulic Reservoir Suction Filter Assemblies:** The hydraulic reservoir suction filter assemblies installed inside the hydraulic reservoir consist of a pleated metal filter element with sealing gaskets secured between a mounting base and cover type relief valve.

Recommended servicing procedures for cleaning the suction filter element are described below.

During normal operation, oil is drawn from the reservoir through the filter element under equal pressure by the main hydraulic pump before entering the hydraulic system. However, when the filter element becomes excessively plugged with foreign material or contaminants, a difference in pressure within the reservoir and the inner side of the filter element will be created. When the pressure difference reaches 2.4 psi, the cover type relief valve incorporated at the top of the filter





Fig. 26. Remove Reservoir Cap, Dipstick and Hand Hole Cover




TS-11085

**Fig. 27. Remove Filter Element**

assembly will open permitting the hydraulic oil to by-pass the plugged filter element entering directly into the hydraulic system.


1. Loosen reservoir cap slowly to relieve pressure in hydraulic reservoir. Remove reservoir cap, dipstick, and hand hole cover as shown in Figure 26.
2. Unscrew filter element from element mounting base and remove filter element as shown in Figure 27.
3. Immerse filter element in hot soapy water. Soak and intermittently agitate element and relief valve components for approximately 30 minutes to loosen dirt particles. Remove any remaining deposits between element pleats with a stiff bristled non-metallic brush as shown in Figure 28. Flush element and relief valve components with clean hot water until drain water is clear.
4. Air dry element and relief valve components



TS-11086

**Fig. 28. Clean Filter Element with Stiff Bristled Brush**

with filtered low pressure air as shown in Figure 29. Examine general condition of filter element checking for element cleanliness, or screen damage. If filter screen is damaged, replace with new element. Check relief valve components for any sign of damage replacing any component not in good serviceable condition.



TS-11087

**Fig. 29. Air Dry Filter Element and Inspect for Damage**



## 500 HOUR MAINTENANCE OPERATIONS


- ENGINE MAINTENANCE
- CLEAN RADIATOR CORE
- CHECK AND ADJUST TRANSMISSION SHIFT LEVER LINKAGE
- CHECK TRANSMISSION DE-CLUTCH VALVE
- CHECK CONVERTER INTERNAL PRESSURE
- CHECK TRANSMISSION CLUTCH, LUBRICATING AND OIL COOLER PRESSURES
- CHECK AND ADJUST BOOM AND BUCKET PRESSURES
- CHECK AND ADJUST MAIN HYDRAULIC PUMP
- ADJUST BOOM AND BUCKET CONTROL LEVERS
- CLEAN AND TIGHTEN ELECTRICAL CONNECTIONS
- CLEAN AXLE BREATHERS
- CHECK STEERING PRESSURE
- CHECK AND ADJUST STEERING PUMP
- ADJUST DRAGLINK BALL JOINTS
- TIGHTEN MOUNTING BOLTS
- STEAM CLEAN MACHINE
- SERVICE AIR CLEANER ELEMENT AND BODY

**Engine Maintenance:** Refer to Operation and Maintenance Manual of engine manufacturer for maintenance instructions of engine and accessories.

**Clean Radiator Core:** External surfaces of radiator core must be kept clean, straight, and unobstructed to prevent blocking the air flow and causing overheating.

Flying objects such as sand, dust, leaves, twigs, bugs or other debris that plug the core or adhere to water or oil streaks impair the cooling efficiency.

Use compressed air, steam, or a high pressure water stream and remove such objects opposite the



**Fig. 30. Adjust Directional and Speed Range Levers**

air flow through the core assembly. Oil streaks should be removed using a solvent non-harmful to hoses and wiring insulation. Straighten bent fins being careful not to puncture or enlarge the openings.

**Check and Adjust Transmission Shift Lever Linkage:** Inspect all mechanical control linkage to make sure all shift rods, bell cranks, ball joint assemblies and shift levers are in good serviceable condition and properly adjusted. Correct any questionable condition such as loose or bent linkage, worn pins or evidence of binding or rubbing of any of the shifting components.

The directional and speed range shift levers must be properly adjusted to insure full engagement into all detent positions without interference.

1. Check and tighten bolts securing the shift levers, shift quadrant, and steering column so that bolts are snug.
2. Place speed range lever in LO (first) and directional lever in NEUTRAL.
3. Loosen jam nut, (Item 1 Figure 30), on shift rod, (Item 2 Figure 30), and remove locknut, (Item 3 Figure 30) securing ball joint assembly (Item 4 Figure 30), to shift lever arm, (Item 5 Figure 30).
4. Adjust ball joint assembly as necessary to correct existing condition, then check lever alignment on shift quadrant in operator's compartment. If sufficient adjustment is not available, adjust ball joint assembly at opposite end of shift rod (bell crank end).

5. Reinstall ball joint assembly in lever arm and secure with locknut, then tighten jam nut on shift rod.
6. Check that levers will shift into all detent positions without interference from the steering column, bell cranks, bell crank mounting support or transmission control cover and valve housing.

**Check Transmission De-Clutch Valve:** The transmission de-clutch valve is an air operated valve consisting of a piston, piston stop plug, and the necessary o-rings to provide an air tight body. This valve is installed in a housing bore containing a shut-off valve spool located in the transmission control cover and connected to the brake valve by a hose line.

The function of the de-clutch valve is to automatically establish a transmission neutral using air pressure from the brake system when the left brake pedal is applied.

When the left brake pedal is applied, the brake valve releases air pressure from the brake system into the de-clutch valve forcing the de-clutch valve piston to contact the shut-off valve spool inside the transmission control cover. This forces the shut-off valve spool to shift into a position that prevents oil flow to the forward clutch, disengaging the clutch and establishing a transmission neutral. *The reverse clutch is not affected.*

This arrangement prevents the machine from creeping forward when loading or dumping the bucket; yet permits backing away if operating on a sloping grade. It also increases the boom and bucket hydraulic system working power by utilizing the power contained at the transmission, which is normally used for engaging the forward clutch to drive the wheels.

Maintenance consists of periodically checking the de-clutch valve or proper operation as described below:

1. Place directional shift lever in NEUTRAL position and start engine.
2. Accelerate engine to approximately half throttle, lightly apply left brake pedal and shift directional shift lever to FORWARD position. There should be no clutch engagement (causing the machine to move forward) or drop in engine

rpm as would be noticed when shifting lever into REVERSE position. A steady rpm will give a more pronounced indication. However, if forward movement of the machine does occur, this is an indication that the de-clutch valve is not functioning properly and must be replaced.


3. Shut down engine and remove and replace de-clutch valve.
4. Recheck valve operation as described in Steps 1 and 2.

**Check Converter Internal Pressure:** The torque converter internal pressure must be maintained within the specified limits listed below to insure proper operation of the torque converter and converter regulator valve assembly.

Periodically check the converter internal pressure when fluid is at operating temperature (180°F. to 200°F.) and engine operating at maximum rpm.

1. Shut down engine and remove pipe plug from converter regulator valve assembly.
2. Install an accurate gauge (0 to 100 psi capacity) in regulator valve pressure port as shown in Figure 31, Item 1.
3. Place directional lever in NEUTRAL and apply parking brake.
4. Start engine and accelerate to maximum rpm. Gauge reading should be between a maximum of 60 psi and a minimum of 30 psi.

If pressure is not within the specified limits, further trouble shooting of the torque converter,



**Fig. 31. Check Converter Internal Pressure**

transmission and allied hydraulic system by a qualified mechanic will be required.

**Check Transmission Clutch, Lubricating, and Oil Cooler Pressures:** Check transmission clutch, transmission lubricating and oil cooler pressures at specified intervals, or whenever machine evidences overheating or no power in any speed range in forward or reverse direction.

Pressure checks must be taken with fluid hot (180°F. to 200°F.).


(a) **Transmission Clutch Pressure:** Pressure check should be made in all speed ranges in both forward and reverse directions. Wheels of machine should be securely blocked and parking brake applied.

1. Remove filler plate and seat base assemblies.
2. Install an accurate gauge (0 to 400 psi capacity) in the pressure regulator valve port on transmission control cover as shown in Figure 32, Item 1.
3. Check pressure with engine at IDLE.
4. Read gauge in NEUTRAL; then engage clutches one at a time. Minimum pressure reading should be as specified in Specifications and Service Data section at rear of manual.

If pressure is not as specified, further trouble shooting of the transmission, torque converter and allied hydraulic system by a qualified mechanic is required.

(b) **Transmission Lubricating Pressure:** The transmission lubricating manifold insures proper lubrication of the transmission clutches, bearings and shafts. Periodically, lubricating pressure should be checked when fluid is at operating temperature (180°F. to 200°F.) and engine operating at maximum rpm.

1. Shut down engine and remove pipe plug from transmission lubricating manifold. Install an accurate gauge (0 to 100 psi capacity) as shown in Figure 32, Item 2.
2. Place directional shift lever in NEUTRAL and apply parking brake.
3. Start engine and accelerate to maximum rpm. Gauge reading must not exceed the pressure



**Fig. 32. Transmission Clutch and Lubricating Pressure**


given in Specifications and Service Data section at rear of this manual.

If pressure is not as specified, further trouble shooting of torque converter and transmission by a qualified mechanic will be required.

(c) **Oil Cooler Pressure:** The drop in pressure across the oil cooler at bottom of radiator will indicate whether oil cooler has or is becoming plugged with foreign material causing overheating.


Pressure check must be made with fluid hot (180°F. to 200°F.) using accurate gauges (0 to 100 psi capacity) at 2000 rpm.

1. Install tachometer on engine. Install gauges at cooler IN and cooler OUT pressure ports as shown in Figures 33 and 34.
2. Attach safety links, apply parking brake and shift directional lever into NEUTRAL position.



**1. Pressure Port**

**Fig. 33. Check Pressure - Oil Cooler IN**



1. Pressure Port

**Fig. 34. Check Pressure - Oil Cooler OUT**


3. With the aid of a helper, read gauges at steady 2000 rpm, and subtract oil cooler OUT pressure from oil cooler IN pressure to get pressure drop. Pressure drop should be between 10 psi and 30 psi.

If pressure difference equals or exceeds 30 psi it will be necessary to thoroughly clean or replace the oil cooler and/or the radiator assembly.

**Check Boom and Bucket Pressure:** (175 All S/N and 275 S/N 425A101 thru 425A317, and 425A319 thru 425A336) The boom and bucket hydraulic pump is coupled to the drive line and operates as soon as the engine starts. The pump draws fluid from the reservoir and forces it under pressure into the main hydraulic valve, from which a small supply of fluid is directed to the pilot valve, routing the fluid back to the main valve, operating the desired circuit in the main valve, supplying the flow of fluid to the cylinders. Preset overload relief cartridges on the pilot valve protect the system and components.

Maintenance consists of periodically checking the pressure in the system. All pressure checks are to be made with fluids at operating temperature. (150° F. minimum).

1. Attach safety links and block wheels.
2. Use a hydraulic test gauge of at least 3000 psi capacity. With engine shut down, loosen cap on hydraulic reservoir until pressure escapes, to minimize oil loss while attaching gauge, then retighten cap.
3. Remove pipe plug from pressure port on main pressure tube, and attach gauge. Refer to Fig-




1. Pipe Plug

**Fig. 35. Main Hydraulic Pressure Gauge Port**

ure 35 for typical gauge installation.

4. Place transmission directional shift lever in NEUTRAL, start engine and apply parking brake.
5. If it is necessary during any of the following steps to replace any of the relief valve cartridges on the pilot valve, remove seat and seat support plate to gain access to pilot valve.
6. With transmission directional and speed range levers in FORWARD, and HI, actuate bucket control lever to ull ROLLBACK position and accelerate engine to maximum rpm. Record gauge reading and proceed to Step 7.
7. With transmission directional and speed range levers in FORWARD, and HI, actuate boom control lever to the full RAISE position and accelerate engine to maximum rpm. Record gauge reading and proceed to Step 8.



**Fig. 36. Pressure Relief Settings - Pilot Valve**

8. If bucket ROLLBACK and boom RAISE are not the same within 50 psi, the circuit with the lower reading must have the relief valve cartridge on the pilot valve changed. Figure 36 Item 1 is bucket rollback cartridge Item 2 is boom raise cartridge.
9. After either relief cartridge is changed, repeat Steps 6, 7, 8 and 9 until recorded pressure readings for bucket ROLLBACK and boom RAISE are the same within 50 psi.
10. If gauge pressure readings or bucket ROLLBACK and boom RAISE are the same within 50 psi, but not to specification of  $2200 \pm 50$  psi, the main relief valve, (located in the main control valve assembly) must be adjusted. See Steps 11 thru 13 for procedure.
11. Remove eight bolts retaining cover (Figure 37, Item A) and remove cover. Refer to Figure 38 and remove spring (Item 2) and main relief valve assembly (Item 1), which protrude from face of main control valve after cover is removed. Refer to Figure 38 and loosen hex locknut portion (Item 4) of relief valve and turn adjusting screw (Item 3) clockwise to increase pressure or counter-clockwise to decrease pressure. Each complete turn of adjusting screw changes setting approximately 1600 psi. Example: If pressure reading recorded in Step 9 was 1400 psi,  $\frac{1}{2}$  turn (clockwise) of adjusting screw would raise relief valve pressure to 2200 psi. After adjusting, tighten locknut.
12. Reinstall relief valve assembly and spring in position in main valve assembly.

*portion of relief valve must be toward outside of valve.*

**IMPORTANT:** *Adjusting screw and locknut*

13. Reinstall cover using two bolts in diagonally opposite holes in cover. Springs under cover must be compressed to start bolts into hole threads. Turn bolts finger tight. Install remaining bolts finger tight. Using a torque wrench with adapter for  $\frac{3}{8}$  inch Allen wrench, torque all bolts to 60-75 ft. lbs.
14. Place transmission directional and speed range levers in FORWARD, HI, actuate bucket control lever to full ROLLBACK position and accelerate to maximum rpm. Gauge should read  $2200 \pm 50$  psi.





Fig. 37. Remove Cover - Main Relief

15. With transmission directional lever in NEUTRAL, feather boom control lever to the DOWN PRESSURE position, maintaining low idle rpm. Gauge should read 1750 to 2200 psi. If reading is not as specified, replace down pressure relief valve cartridge (Item 3 Figure 36).



- |                       |                    |
|-----------------------|--------------------|
| 1. Relief Valve Assy. | 3. Adjusting Screw |
| 2. Spring             | 4. Locknut         |

Fig. 38. Main Relief Valve

16. With transmission directional lever in NEUTRAL, actuate bucket control lever to the full DUMP position, maintaining low idle rpm. Gauge should read 1750 to 2200 psi. If reading is not as specified, replace bucket dump relief valve cartridge (Item 4 Figure 36).

**IMPORTANT: OVERLOAD RELIEF VALVES ARE PRESET AND SEALED AT THE FACTORY. DO NOT BREAK THE SEAL. IF THE SEAL IS BROKEN, REPLACE RELIEF VALVE CARTRIDGE IMMEDIATELY. ADJUSTMENTS ARE TO BE MADE ONLY AT THE MAIN RELIEF.**

**Check Boom and Bucket Hydraulic Pressure:** (275, 425A318, 425A337 and after) The boom and bucket hydraulic pumps are coupled to the drive line and operate as soon as the engine starts. The pumps draw fluid from the reservoir and force it under pressure into the main hydraulic valve, from which a small supply of fluid is directed to the pilot valve, rerouting the fluid back to the main valve operating the desired circuit in the main valve, supplying the flow of fluid to the cylinders. A hydraulic accumulator is incorporated in the boom and bucket circuit to improve hydraulic stability and absorb possible shock loads within the main control valve. Preset relief cartridges on the pilot valve protect the system and components.

Maintenance consists of periodically checking the pressure in the system. All pressure checks should be made with fluid at operating temperature. (150°F. minimum)

1. Attach safety links and block wheels.
2. Position bucket and boom mechanism so that bucket is level on ground and shut down engine.
3. Loosen hydraulic reservoir cap slowly to relieve pressure in reservoir.
4. Actuate boom and bucket control levers both fore and aft, holding levers in both fore and aft positions for several seconds. Repeat this operation several times. Retighten reservoir cap.

**Caution:** *This is a gas pressurized hydraulic system. It is extremely hazardous to attempt to disconnect any part of the hydraulic system without first bleeding off this pressure as described in Steps 2, 3 and 4 above.*

5. Use a hydraulic test gauge of at least 3000 psi capacity. Remove pipe plug from pressure port on main pressure tube, see Figure 35 for loca-

tion, and attach gauge.

6. Place transmission directional shift lever in NEUTRAL, start engine and apply parking brake.
7. If it is necessary during the following steps to replace any of the relief valve cartridges on the pilot valve, remove seat and seat support plate to gain access to pilot valve.
8. With transmission directional and speed range levers in FORWARD, and HI, actuate bucket control lever to the full ROLLBACK position and accelerate engine to maximum rpm. Record gauge reading and proceed to Step 9.
9. With transmission directional and speed range levers in FORWARD, and HI, actuate boom control lever to the full RAISE position and accelerate to maximum rpm. Record gauge reading and proceed to Step 10.
10. If bucket ROLLBACK and boom RAISE are not the same within 50 psi, the circuit with the lower pressure reading must have the relief valve cartridge on the pilot valve changed. Figure 36. Item 1 is bucket rollback cartridge, Item 2 is boom raise cartridge.
11. After either relief cartridge is changed, repeat Steps 8, 9, 10, and 11 until recorded pressure readings for bucket ROLLBACK and boom RAISE are the same within 50 psi.
12. If gauge pressure readings for bucket ROLLBACK and boom RAISE are the same within 50 psi, but not to specification of 2200 psi, the main relief valve (located in the main control valve assembly) must be adjusted. See Steps 13 thru 15 for procedure.
13. Remove 8 bolts retaining cover (Figure 37, Item A) and remove cover. Refer to Figure 38 and remove spring and relief valve assembly which protrude from front face of main control valve after cover is removed. See Figure 38. Loosen hex locknut portion of relief valve and turn adjusting screw clockwise to increase pressure or counter-clockwise to decrease pressure. Each complete turn of adjusting screw changes setting approximately 1600 psi. Example: If pressure reading recorded in Step 9 was 1400 psi, ½ turn (clockwise) of adjusting screw would raise relief valve pressure to 2200 psi. After adjusting, tighten locknut.


14. Reinstall relief valve assembly and spring in position in main valve assembly. **IMPORTANT:** *Adjusting screw and locknut portion of relief valve must be toward outside of valve.*
15. Reinstall cover using two bolts in diagonally opposite holes in cover. Springs under cover must be compressed to start bolts into hole threads. Turn bolts finger tight. Using a torque wrench with adapter for  $\frac{3}{8}$  inch Allen wrench, tighten all bolts to 60-75 ft. lbs. torque.
16. Place transmission directional and speed range levers in FORWARD, HI, actuate bucket control lever to full ROLLBACK position and accelerate to maximum rpm. Gauge should read 2200 psi.
17. With transmission directional lever in NEUTRAL, feather boom control lever to the DOWN PRESSURE position, maintaining low idle rpm. Gauge should read 1750 to 2200 psi. If reading is not as specified, replace down pressure relief valve cartridge. (Item 3 Figure 36).
18. With transmission directional lever in NEUTRAL, actuate bucket control lever to the full DUMP position, maintaining low idle rpm. Gauge should read 1750 to 2200 psi. If reading is not as specified, replace bucket dump relief valve cartridge. (Item 4 Figure 36).

**IMPORTANT:** OVERLOAD RELIEF VALVES ARE PRESET AND SEALED AT THE FACTORY. DO NOT BREAK THE SEAL. IF THE SEAL IS BROKEN, REPLACE RELIEF VALVE CARTRIDGE IMMEDIATELY. ADJUSTMENTS ARE TO BE MADE ONLY ON THE MAIN RELIEF.

**Caution:** *This is a gas pressurized hydraulic system. It is extremely hazardous to attempt to remove gauge and reinstall pipe plug without first bleeding off this pressure as described in Steps 2, 3, and 4.*

**Check and Adjust Main Hydraulic Pump:** The main hydraulic pump is a double pump, consisting of a primary section and a secondary section. At lower pressures, up to by-pass pressure setting, both sections supply the main hydraulic system. From by-pass pressure setting up to system relief, the pressure sensitive valve attached to the pump causes the secondary section to unload by-passing back to the suction side, leaving the primary section to supply the system.


Maintenance consists of periodically checking, and adjusting if necessary, the pressure at which the secondary section of the pump unloads and



1. Primary Port                      2. Secondary port

**Fig. 39. Main Hydraulic Pump Pressure Port by-passes.**

1. Attach safety links and apply parking brake.
2. Install two 3000 psi capacity gauges, one at the primary pressure port and one at the pressure port on the secondary section of the main pump as shown in Figure 39, Items 1 & 2.
3. With transmission directional shift lever in neutral, start engine and follow normal warm up procedure.
4. Actuate boom control lever to the lift position, maintaining low idle rpm. Raise boom to stop, feathering lever as boom approaches stop. Observe both gauges. As pressure increases, the gauge attached to the secondary section of the pump will indicate a sudden drop-off in pressure. The highest pressure indicated is the unloading pressure.



1. Acorn Nut

**Fig. 40. Main Hydraulic Pump Adjustment**

5. Observe the indicated pressure on the gauge attached to the main hydraulic pressure port. When the unloading pressure is reached, this gauge should read as specified in Specifications and Service Data section at rear of manual.


If the secondary pump section does not unload at specified pressure, it will be necessary to adjust the pressure sensing valve on the main pump. Proceed with valve adjustment as follows:

1. Remove acorn nut and o-ring covering adjusting screw on pressure sensing valve. See Figure 40.
2. Actuate boom control lever to the raise position maintaining low idle rpm. Feather the lever as boom approaches stop, observing the pressure at which the secondary section unloads, then return lever to the neutral position.
3. Turn pressure adjusting screw in increments of  $\frac{1}{4}$  turn, clockwise to increase or counter-clockwise to decrease unloading pressure. Recheck unloading pressure as described in Step 2. Repeat this procedure until secondary section of main pump unloads at specified pressure.
4. Reinstall acorn nut and o-ring, then recheck the unloading pressure to be certain pressure setting was not disturbed while installing acorn nut and o-ring.
5. Shut down engine, remove gauges, reinstall pipe plugs and detach safety links.

**Adjust Boom and Bucket Control Levers:** The control levers are properly set at the factory. An adjustment is provided by clevises connected directly to the levers to permit changing angle of levers if desired and to insure that spools shift into all positions.

With engine shut down, and bucket on the ground, place levers in HOLD (neutral) position. The adjustment can be made as follows: See Figure 41.

1. Loosen locknut (Item 1 Figure 41) on control rod.



**Fig. 41. Adjust Boom and Bucket Control Levers**

2. Remove cotter and clevis pin (Item 2 Figure 41).
3. Turn clevis clockwise to move lever toward the rear; counter-clockwise to move lever forward.
4. When lever is set where desired, attach clevis with pin and cotter and tighten locknut securely.
5. Check that levers shift into all positions without interference.

**Clean and Tighten Electrical Connections:** Periodically inspect and check all wiring and connections on electrical components such as the batteries, cranking motor, voltage regulator, alternator, solenoid switch, relays, instruments and switches for worn, cracked, broken or frayed insulation and loose terminal connections. Check for frayed or corroded external ground straps and corrosion on battery terminal ports.

Where inspection reveals dirt, looseness or damage; clean, tighten and adjust or replace as necessary depending on existing conditions.

**Note:** Maintenance personnel must observe the following precautions to prevent the possibility of serious injury or excessive damage to electrical system components when servicing the "Delcotron" charging system.

1. WHEN INSTALLING BATTERIES, MAKE SURE BATTERIES AND "DELCO TRON" POLARITIES ARE THE SAME—



When installing a battery, always make absolutely sure the ground polarity of the battery and the ground polarity of the "Delcotron" are the same. If a battery of the wrong polarity is connected into the charging system or if a battery is reversed when installing it, the battery is directly shorted through the diodes. Consequently the diodes and machine wiring are endangered by high current flow. Burned wiring harness and burned "open" diodes probably will result.

## 2. BOOSTER BATTERIES MUST BE PARALLELED—

When connecting a booster or "slave" battery, make certain to connect the negative terminals together and the positive terminals together. Failure to observe this precaution will result in the same damage as described above.

## 3. BATTERY CHARGER AND BATTERY POLARITIES MUST AGREE—

When connecting a charger to the battery, connect the charger positive lead to the battery positive terminal and the charger negative lead to the battery negative terminal. Failure to follow this procedure will result in the same damage as described in the first caution.

## 4. NEVER OPERATE "DELCOTRON" ON OPEN CIRCUIT—

Never operate the "Delcotron" on open circuit. With no battery or electric load in the circuit (open circuit), the "Delcotron" can build up high voltages which could be extremely dangerous to anyone who might accidentally touch the "Delcotron" battery terminal. Before making tests or "on the machine" checks, it is prudent to make sure all connections in the circuit are tight and secure.

## 5. DO NOT SHORT ACROSS OR GROUND ANY TERMINALS OF THE "DELCOTRON" OR REGULATOR—

Do not short across or ground any of the terminals on the "Delcotron" or regulator. Any artificial circuit set up by purposely grounding or shorting any of the "Delcotron" or regulator terminals can cause serious electrical malfunctions that might endanger components of the electrical system.

## 6. DO NOT POLARIZE THE "DELCOTRON"—

Do not attempt to polarize the "Delcotron". Polarizing the d.c. type of generator is necessary to insure that generator and battery polarity are the same. "Delcotron" polarizing however is not

necessary since the voltage developed within the "Delcotron" is of both polarities and the diode rectifier automatically controls the direction of current flow. It is of vital importance as discussed in the first precaution that the battery ground and the "Delcotron" ground be of the same polarity for diode protection.

## 7. BEFORE DOING ANY WELDING, DISCONNECT GROUND CABLE FROM BATTERY AND ELECTRICAL LEAD FROM BATTERY TERMINAL ON ALTERNATOR—

Before doing any welding on machines equipped with an alternator, disconnect the ground cable from the battery and the electrical lead from the battery terminal on the alternator.

**Clean Axle Breathers:** Each 500 operating hours inspect breathers on front and rear axle housings. Housing breathers have a loose fitting cap that should be rotated.

Oil leakage past breathers, thrust caps, carrier housing or pinion cap seals indicates that breathers may be clogged. Unscrew breathers, wash in solvent, dry and reinstall.

**Check Steering Pressure:** The steering hydraulic pump is coupled to the drive line and operates as soon as the engine is started. The pump draws fluid from the reservoir and forces it under pressure into the control valve mounted at the base of the steering gear.

Maintenance consists of periodically checking the pressure in the system.

**Note:** Remove safety links, if attached between front and rear frames.




Fig. 42. Steering Relief Pressure Port

**Warning:** Do not stand or work in step area(s) when machine is running — No room for a man in this area when machine is turned.

1. Use hydraulic pressure gauge of at least 3000 psi capacity. With engine shut down, remove pipe plug in steering tube at left side of machine and install gauge as shown in Figure 42, Item 1.
2. Start engine and accelerate to maximum rpm; then turn tractor to the right and hold against stops.
3. With the aid of a helper read gauge. Pressure reading should be as specified in Specifications and Service Data section at rear of this manual.


If pressure reading is not as specified, shut down engine, and inspect and check for collapsed or ruptured hoses, proper function of steering cylinder packing glands, defective steering pump or steering control valve.

If the above items are in satisfactory operating condition it will be necessary to adjust the steering pressure at the steering control valve.

1. Loosen locknut on steering control valve adjusting screw.
2. Turn tractor to extreme right or left and hold against stops.
3. With transmission in neutral, accelerate to maximum rpm.
4. Turn adjusting screw in increments of  $\frac{1}{4}$  revolution or less, clockwise to increase pressure or counter-clockwise to decrease pressure.
5. When pressure reading on gauge reaches that specified in Specifications and Service Data section at rear of this manual, tighten locknut, release throttle and steering wheel, shut down engine, remove gauge and reinstall pipe plug.

**Check and Adjust Steering Pump:** The steering pump is a double pump consisting of a primary section and a secondary section. From low idle to approximately 1600 rpm, both primary and secondary sections are supplying the steering system. From approximately 1600 to maximum rpm, the primary section continues to supply the steering system, but the secondary section by-passes.

Maintenance consists of periodically checking, and adjusting if necessary, the rpm at which the



1. Primary Port
2. Secondary Port
3. Acorn Nut

**Fig. 43. Steering Pump Pressure Port and Adjustment**

secondary steering pump section by-passes.

1. Install tachometer on engine.
2. Install two 3000 psi capacity gauges, one at the steering pump primary section port, and one at the secondary section port. See Figure 43.
3. Remove safety links if attached between frames.
4. Start engine and maintain low idle rpm, turn steering against stops and hold. At this point, both gauges should read steering relief pressure or slightly below.
5. Accelerate engine rpm observing gauges and tachometer. Note the rpm at which the gauge attached to the secondary port indicates a large pressure drop off. At this point, tachometer should read approximately 1600 rpm.

**WARNING:** Do not stand or work in stop area(s) when engine is running. No room for a man in this area when machine is turned.

6. Accelerate to maximum rpm with steering held against stops. The gauge attached to the primary port should read system relief pressure while the gauge attached to the secondary port indicates very little pressure.

If secondary pump section does not show a pressure drop-off at approximately 1600 rpm, it will be necessary to adjust the valve on the steering pump. Proceed with valve adjustment as follows.


1. Turn steering to extreme right on left and hold against stops. Accelerate to maximum rpm. The attached to the primary section pressure port should read system relief pressure.
2. If gauge reading is not as specified, adjust main steering relief valve located at base of steering gear as described under 500 HOUR MAINTENANCE OPERATIONS.
3. With steering against stops, increase engine rpm slowly starting at low idle.
4. Carefully watching tachometer and pressure gauge attached to steer pump secondary pressure port, note the rpm at which pressure drop-off occurs.
5. Remove acorn nut and o-ring on steer pump valve. See Figure 43.
6. Turn adjusting screw clockwise to increase or counter-clockwise to decrease pressure drop-off rpm.
7. After correct setting has been obtained, reinstall acorn nut and o-ring. Recheck pressure drop-off rpm to be certain adjustment was not disturbed while installing acorn nut and o-ring.
8. Shut down engine, remove gauges and tachometer and reinstall pipe plugs.

**Bleed Steering Relief Valve:** Whenever steering pressure is checked or if chattering occurs in the steering valve, the steering relief valve must be bled to remove air trapped in the valve. To bleed relief valve, open bleed screw and turn steering wheel until a solid stream of oil flows from the bleed screw. Then close bleed screw.

**Adjust Draglink Ball Joints:** Adjust front and rear ball joints on drag link whenever excessive play develops. This condition will be indicated by an increase of free play at the steering wheel before tractor responds to turning action.

Remove cotter (Item 1) and turn slotted adjusting plug (Item 2) to remove all slack in ball joints at each end of drag link as shown in Figure 44.

**Tighten Mounting Bolts:** Mounting bolts on such components as engine, torque converter, transmission, steering gear, axles and prop shafts will occasionally work loose and cause supports and



**Fig. 44. Adjust Draglink Ball Joints**

brackets to wear rapidly. Alignment difficulty may also develop.

Inspect all mounting bolts for evidence of looseness, stripped threads, cracked or broken heads or any other signs of damage.

**Note:** Where spring bolts are used on engine mounts, bolts should be tightened to compress spring, and then backed-off two full turns.


Remove and replace damaged or missing mounting bolts and tighten all loose mounting bolts as necessary. Refer to Bolt Torque Chart.

**Steam Clean Machine:** Periodically or whenever working machine in muddy or swampy areas or when machine begins to cake up with excessive dirt, the entire machine should be steam cleaned. If allowed to accumulate, dirt will find its way into the various systems when plugs, covers or caps are removed or during unit replacement eventually cause serious damage and down time.

Dirt packed on or around the axle, transmission, torque converter and engine breathers will cause oil losses.


Steam is the most effective and recommended method of cleaning a dirty machine. If unavailable use a spray of mineral spirits or a similar solvent non-harmful to exposed hoses, lines and electrical wiring.

**Note:** Prior to steam cleaning, cover all alternator and cranking motor openings to protect them from the force of the steam jet.



TS-8009

**Fig. 45. Air Cleaner Assembly**



TS-8012

**Fig. 46. Remove Dust Cup and Element**

**Service Air Cleaner Element:** Recommended servicing procedures and intervals for replacing the air cleaner filter element are described below, but it should be understood that no set rule can be established for replacing the filter element because the replacement interval is automatically established by a service indicator installed on the air cleaner outlet to the engine. The service indicator insures maximum engine efficiency by providing the operator with a fast, safe and efficient method of determining when the filter element should be replaced. This is accomplished by a WARNING SIGNAL (red band) which is actuated by the pressure drop across the air cleaner.

Dirt trapped by the filter element gradually increases the pressure drop across the air cleaner. As the resistance increases, a WARNING SIGNAL (red band) inside the indicator will become visible in the indicator window. This indicates the life reserve of the filter element. When restriction of the air flow through the filter reaches the upper limit for efficient filter element performance, the WARNING SIGNAL (red band) will lock and remain in a position visible to the operator regardless of whether or not the engine is running. This is an indication that the filter must be serviced.

**Note:** *Extended operation of machine without replacing filter element when indicated by the service indicator will create excessive restriction resulting in high fuel consumption, excessive smoke, lower horsepower and poor acceleration.*

Figures 45 thru 47 illustrate the removal and cleaning procedure of the air cleaner element.

Loosen clamp assembly, (Item 1 Figure 45), and remove dust cup, (Item 2 Figure 45). Unscrew the wing nut, (Item 3 Figure 45), and remove element, (Item 4 Figure 45). Pat sides of element with palm of hand to remove dust trapped in the pleats. Tapping element against hard surface or with hard objects may dent or break the element end cap seals (Figure 46 Item 1). This would affect improper sealing when the element is reassembled and result in rapid engine wear. Using low pressure air (see Figure 47 Item A), not over 100 psi, blow out remaining dust from inside out, opposite normal air flow through the element.


**Caution:** *Be careful not to rupture filter element. Maintain a reasonable distance between air nozzle and filter element when directing air up and down the clean air side of the element pleats.*

Extremely dirty element can be cleaned in warm water (120°F. to 140°F.) using a nonsudsing detergent such as SOILAX. Soak element until dirt particles are loosened (approximately 15 minutes); then brush lightly with a non metallic brush or agitate element in cleaning solution to remove dirt particles, (see Figure 47 Item B). Flush with clean water from a hose (maximum pressure 40 psi). Air dry element completely before using.

After element has been dried, check top sealing gasket for looseness or damage. A loose gasket may be recemented. Inspect the element for damage by placing a bright light inside element, (see Figure 47 Item C). Thin spots, pin holes, or the slightest rupture will render the element unfit for use. DISCARD ANY DAMAGED ELEMENT.

Clean the fins and inside of air cleaner body with a dry lint-free cloth and reassemble air cleaner. The wing nut retaining the element must always have the gasket washer around its shank.

**Caution:** *Do not use oil in dust cup.*



**Fig. 47. Clean and Inspect Filter Element**

## 1000 HOUR MAINTENANCE OPERATIONS

- ENGINE MAINTENANCE
- CHECK ACCUMULATOR PRE-CHARGE
- CHECK AND REPAIR BUCKET CUTTING EDGE
- CHECK BOOM TO BUCKET LINKAGE
- INSPECT, TEST AND LUBRICATE ELECTRICAL UNITS
- ADJUST STEERING GEAR
- INSPECT FRAME

**Engine Maintenance:** Refer to Operation and Maintenance Manual of engine manufacturer for maintenance instructions of engine and accessories.

**Check Accumulator Precharge:** (275, 425A318, 425A337 and after) Periodically it is necessary to check the accumulator precharge pressure and recharge if necessary. This operation should be performed every 1000 operating hours or at six (6) month intervals, whichever occurs first.


**Caution:** The accumulator should only be recharged with dry nitrogen gas. Do not use gases of a combustible nature such as acetylene, hydrogen etc.

The accumulator may be recharged on the machine or it may be removed and transported to a location where dry nitrogen gas is available.

**Caution:** Before removing or recharging accumulator, it is absolutely necessary that the pressure in the hydraulic system be bled off or relieved.

### Relieving Hydraulic System Pressure:

1. Position boom and bucket mechanism so that bucket is on ground. Shut down engine.
2. Loosen hydraulic reservoir cap slowly to relieve pressure in reservoir.
3. Actuate boom and bucket control levers both fore and aft, holding levers in fore and aft positions for several seconds. Repeat this operation several times. Retighten reservoir cap.



1. Accumulator
2. Gas Check
3. Hose Assembly

4. Regulator
5. Regulator Gauge
6. Cylinder Pressure Gauge

7. Cylinder Valve
8. Nitrogen Cylinder
9. Gas Valve

Fig. 48. Accumulator Checking and Charging Device

## Checking and Recharging Accumulator:

A. When checking and recharging equipment is available proceed as outlined below. This equipment consists of a regulator valve, regulator valve pressure gauge and cylinder pressure gauge assembly, a hose and gas chuck, plus a cylinder of dry nitrogen gas. Refer to Figure 48.

1. Relieve hydraulic system pressure as described above.
2. Remove gas valve protector plate and valve cap from accumulator.
3. Turn handle on regulator valve in a counter-clockwise direction until all tension on regulator diaphragm is relieved.
4. Turn T-handle on gas chuck all the way out by turning in a counter-clockwise direction.
5. Attach gas chuck to accumulator using wrench to tighten swivel nut.
6. Turn T-handle on gas chuck all the way in by turning in a clockwise direction to depress valve core in gas valve of accumulator. The reading obtained on regulator gauge indicates accumulator precharge gas pressure. This should be  $1100 \pm 100$  psi (at  $60^{\circ}\text{F.}$ ).

The above pressure applies at  $60^{\circ}\text{F.}$  Check precharge of accumulator when its temperature is equal to ambient temperature. If there is a noticeable temperature difference, delay pressure check until temperatures are more nearly alike.

For each  $10^{\circ}\text{F.}$  difference in ambient temperature from  $60^{\circ}\text{F.}$ , precharge pressure will rise or fall 6 psi from pressure specification given above.

7. If precharge pressure is satisfactory, turn T-handle on gas chuck all the way out by turning in a counter-clockwise direction. Loosen swivel nut on gas chuck and remove from accumulator.

Valve cap should be wrench tight to insure a positive seal.

8. If precharge pressure is not to specifications, open valve on nitrogen cylinder which will allow gas to flow as far as the regulator valve. Turn handle on regulator valve slowly in clockwise

direction until the desired charging pressure is reached on the regulator gauge. When required pressure is reached, close valve on dry nitrogen cylinder. Turn T-handle on gas chuck all the way out by turning in a counter-clockwise direction. Loosen swivel nut on gas chuck and remove from the accumulator. Reinstall gas valve protective cap and plate on accumulator. Valve cap should be wrench tight to insure a positive seal.

- B. When checking and recharging equipment is not available, it will be necessary to remove the accumulator, after relieving the hydraulic system pressure, and transport it to a local welding supply house or bottled gas distributor for checking and recharging to  $1100 \pm 100$  psi (at  $60^{\circ}\text{F.}$ ).

Due to the relatively small volume capacity (10 cu. in.) of this type of accumulator, it is not possible to use a checking device only, consisting of a gauge, hose of any appreciable length and gas chuck, to check the precharge pressure.

This is due to the fact that, with the device attached, when the gas chuck is opened, the volume of gas escaping from the accumulator to fill the hose reduces the volume and pressure within the accumulator to a point where the pressure will be below specifications when the gas chuck is closed and removed.

It is therefore recommended that a spare accumulator (precharged to the above pressure specifications) be stocked for use at periods when pressure check and recharging is required. This will permit recharging the removed accumulator at a more convenient time.

## OBSERVE THE FOLLOWING PRECAUTIONS AT ALL TIMES:

- A. Do not attempt to disconnect or service any part of the boom and bucket hydraulic system or to remove the accumulator without first relieving the hydraulic system pressure.
- B. When using checking and recharging devices with nitrogen cylinder, observe the following:
  1. Do not attach the device to either the nitrogen cylinder or accumulator without first turning handle of regulator in counter-clockwise direction until all tension on regulator diaphragm is relieved and turning T-handle

on gas chuck all the way out by turning in a counter-clockwise direction.

2. Do not loosen swivel nut attaching gas chuck to accumulator without first backing T-handle on gas chuck all the way out by turning in a counter-clockwise direction.
3. Do not attempt to remove regulator valve from nitrogen cylinder without first closing nitrogen cylinder valve.

**Radiator:** Twice a year, drain, flush and refill cooling system. Refill with equal amounts of permanent type anti-freeze plus clean water to bring coolant level to fill neck.

Check freezing point of solution when air temperature is 32°F. or below or whenever there is danger of water freezing in the system. The recommended solution of permanent type anti-freeze to an approximately equal volume of water provides protection against freezing to approximately -35°F.

Always use a hydrometer to check freezing point of coolant with engine at operating temperature.

**Check and Repair Bucket Cutting Edge:** The bucket should be periodically checked for badly ripped, cracked, chipped or worn-out cutting edges (bottom and sides).

If at any time it becomes necessary to replace the bucket cutting edge (bottom and or sides) replacement parts can be ordered separately. Refer to Parts Manual for applicable part numbers.

To replace bucket cutting edges, follow the procedure outlined below and refer to Figure 49.

### (a) Bottom Cutting Edge

1. Scarf out front and rear welds Item 17 securing bottom cutting edge to top cutting edge as shown in view "D". Grind rough edges smooth.
2. Align and clamp bottom cutting edge and tack weld in place. See view "D".
3. Finish welding bottom cutting edge to top cutting edge. Front weld is a continuous  $\frac{3}{8}$  inch fillet weld along entire edge. Rear weld is a  $\frac{3}{8}$  inch intermittent fillet weld consisting of a series of 3 inch welds equally spaced on 10 inch centers.




Fig. 49. Repair Bucket Cutting Edge



**Note:** Use a  $\frac{3}{16}$  diameter low hydrogen electrode equivalent to AWS-E-10016.

4. Grind front weld to present a smooth surface for entry of material.

**(b) Top, Bottom, and Side Cutting Edges**


1. Align and clamp straight edge so that back edge will line up with front edge of bucket sheet as shown in view "B".
2. Measure up on each side cutting edge the length of the line segment (2) from top cutting edge and scribe lines (1) as shown in view "A".
3. Guide cutting torch through scribe lines (1) and down rear of side cutting edges to top cutting edge as shown in view "A"; then continue cutting along back side of straight edge(s) as shown in view "B". Remove and discard cutout section from bucket. Grind all rough edges on bucket smooth.
4. Equally space three flat plates on bucket sheet and tack weld in three places as shown in view "C".
5. Position and align new cutting edge assembly

flush against bucket sheet and flat plates and secure in place with clamps as shown in view "C".

6. Alternately tack weld cutting edge to bucket sheet on top.
7. Remove flat plates and continuously weld cutting edge to bucket sheet on top, as shown in views "C" and "D". Top weld (12) is a  $\frac{3}{16}$  inch flush bevel groove weld.
8. Clamp side cutting edges flush against bucket end plate, bucket sheet and top cutting edge and weld, (9 & 10) view "C", securely. Welds to bucket end plate are  $\frac{1}{4}$  inch convex bevel groove weld inside and  $\frac{3}{8}$  inch fillet weld outside. Welds to cutting edge and bucket sheet are  $\frac{3}{4}$  inch fillet weld inside and  $\frac{5}{8}$  inch flush bevel groove weld outside. Where the side cutting edge overlaps the bucket sheet on the outside a  $\frac{3}{8}$  inch fillet weld should be made.

**Note:** Use a  $\frac{3}{16}$  inch diameter low hydrogen electrode equivalent to AWS-E-10016.

9. Grind all welds inside bucket to present a smooth surface for entry of material; grind the residue of the tack welds from bucket sheet.



TS-13682

**Fig. 50. Check and Adjust Boom to Bucket Linkage**

[ 45-06-4 ]

**Check Boom to Bucket Linkage:** Boom to bucket linkage should be checked periodically and adjusted whenever inspection indicates or whenever new boom to bucket linkage parts are installed.

Pushrod length, measured from pin holes, center-to-center should be checked out first. The pushrods should not vary more than one turn on any machine. Nominal pushrod length is 64½ inches for Model 275, and 56¾ inches for Model 175.

Refer to Figure 50, position "A" and raise boom to full up position, shut off engine and free fall bucket until bucket stop or stops contact boom. Adjust bucket stops to no more than ¼ inch space, one stop to the other by grinding or welding on bucket stops.

Lower boom until bucket hinge pin is just far enough off ground to clear bucket cutting edge in the full dump position. Rotate bucket to the full dump position, then raise boom until one bellcrank contacts boomstop. Refer to position "B" and observe stop on opposite bellcrank. Maximum gap allowable at this point is ⅛ inch. If gap exceeds ⅛ inch, grind on stop making contact until this tolerance is met.

With boom in full up position, refer to Figure 50 position "B" and free fall bucket with engine shut off. In this position, bellcrank to boom stop spacing should be a nominal ½ inch. A maximum of ⅛ inch difference side to side is allowable with a maximum ⅝ inch spacing and a minimum ⅜ inch spacing. To obtain the correct spacing, adjust both pushrods the same amount.

Under no circumstances should the pushrods vary in length more than one full turn.

**Inspect, Test and Lubricate Electrical Units:** Maintenance performed on the various electrical components usually consists of cleaning, lubricating, minor testing and adjusting, and replacing defective or worn out parts.

At specified intervals lubricate alternator and cranking motor sparingly. Excessive lubrication can result in premature failure.

Check cranking motor operation with a substitute battery source known to be fully charged and in good condition.

In general, proper function of the alternator and voltage regulator can usually be determined by the following conditions: (1) if batteries are kept fully charged, except when under unusually sever loads, and (2) if no more than the usual of water is required to keep them filled.

When testing alternator for charging rate use accurate test meters.

Inspect wires, cables and terminals for tight connections, cleanliness and evidence of deterioration or corrosion.

Blow out accumulated dust and dirt, and clean exterior surfaces of all electrical units.


Complete service facilities for electrical system components are available at any authorized Delco-Remy or United Motors sales and service outlet.

**Adjust Steering Gear:** The steering gear assembly consists of a manual gear of the recirculating ball type with a hydraulic control valve mounted at the base.

The manual gear requires two adjustments to maintain proper operation: (1) worn bearing adjustment, (2) overcenter or pitman shaft adjustment. The worn bearing adjustment is performed only at the time the control valve is assembled to the gear. The adjusting nut is securely staked in place and does not require further attention.

The overcenter or pitman shaft adjustment, however, should be periodically checked and adjusted to remove lash between pitman shaft gear and the worm gear ball nut. Adjustment is indicated by too much free play at steering wheel before wheels respond to turning action. Adjustment is as follows with the engine shut off.

1. Disconnect steering drag link from pitman arm.
2. Turn steering wheel gently from one stop all the way to the other stop, carefully counting the




1. Locknut                      2. Adjusting Screw

**Fig. 51. Adjust Steering Gear**

total number of turns. Then turn wheel back exactly half way to the center position. Mark wheel at top or bottom center with piece of tape.

3. Measure the pull at the rim of the steering wheel required to keep the wheel in motion. Take the highest reading of the spring scale as the wheel is pulled through the center position. This pull can be measured by attaching a spring scale to the rim of the wheel with a piece of cord, then pulling on the spring scale to turn the wheel. The line of the scale should be kept tangent to the rim of the wheel. The proper pull at the wheel rim under these conditions should be 1½ to 2 lbs.
4. Loosen locknut and turn adjusting screw clockwise to increase pull at the wheel and counter clockwise to decrease the pull. See Figure 51. Reset locknut and recheck pull as it must be within the specified limits after the locknut is tightened.



**Fig. 52. Check Safety Links**

5. Reassemble drag link to pitman arm and adjust drag link ball joints.

**Inspect Frame:** The frame is the basic backbone of the entire machine that provides structural support directly or indirectly for completely mounting all assemblies, sub-assemblies and individual components necessary for machine construction and operation. The frame structure and all supporting assemblies such as cradle, boom and bucket, bellcranks, pushrods, upper and lower pivots, cross members, reinforcing gussets and brackets should be periodically inspected for cracks, bends, broken welds, warping or any other signs of damage that would endanger proper operation.

Frame damage should be immediately repaired or corrected as necessary to maintain the frame assembly in good serviceable condition.

**Note:** Repair or replace safety links that do not connect properly or have been damaged. See Figure 52.

**BOLT TORQUE CHART**

Location	175B		275B	
	Thread	Torque Ft. Lbs.	Thread	Torque Ft. Lbs.
Axle Mounting Bolts	1¼"-12	1500	1½"-12	2000
Bucket Cylinder Cap	¾"-16	320	----	505
Converter Drive Gear Mounting	¾"-16	45	¾"-16	45
Converter Filter Cartridge – A.C. Units	----	50±5	----	50±5
Converter Housing Mounting	⅞"-14	23	⅞"-14	23
Engine Support to Flywheel Housing	⅝"-11	67	⅝"-11	67
Engine Support to Frame	¾"-16	320	¾"-16	320
Engine Trunnion Mounting	⅝"-18	105	⅝"-18	105
Lower Pivot Hinge Cap Bolts	----	200	----	275
Prop Shaft – Upper	⅜"-24	50	⅞"-20	75
Prop Shaft – Lower	⅞"-20	75	½"-20	120
Suction Filter	3" NPTF	50	3" NPTF	50
Tractor Pivot	1¼"-12	1500	1½"-12	2000
Transmission Bracket to Frame	¾"-16	320	1"-14	790
Transmission to Bracket	⅞"-14	505	1"-14	790
Wheel Nuts – Oiled Threads	¾"-16	320	⅞"-14	400

Bolts not listed are to be drawn up tight in a manner constant with good workmanship.

<b>MODEL</b>	<b>175B G.M.</b>	<b>175B Cummins</b>	<b>275B Cummins</b>
<b>CAPACITIES (Approximate)</b>			
<b>U.S. MEASURE</b>			
Engine Crankcase and System .....	6.5 gal.	12 gal.	12 gal.
Cooling System .....	18 gal.	18 gal.	18 gal.
Front Drive Axle Differential .....	5 gal.	5 gal.	13.25 gal.
Front Drive Axle Planetary Hubs (Ea.) .....	2 gal.	2 gal.	3.25 gal.
Fuel Tank .....	116 gal.	116 gal.	165 gal.
Hydraulic System .....	115 gal.	115 gal.	165 gal.
Rear Drive Axle Differential .....	5 gal.	5 gal.	13.25 gal.
Rear Drive Axle Planetary Hubs (Ea.) .....	2 gal.	2 gal.	3.25 gal.
Torque Converter and Transmission .....	11 gal.	11 gal.	12 gal.
Midmount Bearing .....	2 qts.	2 qts.	5 qts.
<b>METRIC MEASURE (Liters)</b>			
Engine Crankcase and System .....	24.6	45.4	45.4
Cooling System .....	68.0	68.0	68.0
Front Drive Axle Differential .....	18.9	18.9	50.2
Front Drive Axle Planetary Hubs (Ea.) .....	7.6	7.6	12.3
Fuel Tank .....	439.1	439.1	624.5
Hydraulic System .....	435.3	435.3	624.5
Rear Drive Axle Differential .....	18.9	18.9	50.2
Rear Drive Axle Planetary Hubs (Ea.) .....	7.6	7.6	12.3
Torque Converter and Transmission .....	41.6	41.6	45.4
Midmount Bearing .....	1.9	1.9	4.7
<b>IMPERIAL MEASURE</b>			
Engine Crankcase and System .....	5.4 gal.	10 gal.	10 gal.
Cooling System .....	15 gal.	15 gal.	15 gal.
Front Drive Axle Differential .....	4.2 gal.	4.2 gal.	11.0 gal.
Front Drive Axle Planetary Hubs (Ea.) .....	1.7 gal.	1.7 gal.	2.7 gal.
Fuel Tank .....	96.6 gal.	96.6 gal.	153.9 gal.
Hydraulic System .....	95.8 gal.	95.8 gal.	153.9 gal.
Rear Drive Axle Differential .....	4.2 gal.	4.2 gal.	11.0 gal.
Rear Drive Axle Planetary Hubs (Ea.) .....	1.7 gal.	1.7 gal.	2.7 gal.
Torque Converter and Transmission .....	9.1 gal.	9.1 gal.	10 gal.
Midmount Bearing .....	1.7 qts.	1.7 gal.	4.2 gal.

## ENGINE SPECIFICATIONS AND SERVICE DATA

ENGINE	175B	175B	275B	275B
Make .....	G.M.	Cummins	Cummins	Cummins
Model .....	8V71N	NT-855-C	NTA-855-C360	NTA-855-C380
No. of Cyls. ....	8	6	6	6
Bore (in.) .....	4.25	5.50	5.50	5.50
Stroke (in.) .....	5.00	6.00	6.00	6.00
Displacement (cu. in.) .....	567.4	855	855	855
Max. Torque (ft. lbs.) .....	805	780	960	960
@ RPM .....	1200	1550	1650	1650
Flywheel Horsepower .....	261	251	324	342
Governed RPM .....	2100	2100	2100	2300
Low Idle RPM .....	650-750	650-750	550-600	650-750
High Idle RPM .....	2200-2300	2200-2300	2200-2300	2400-2500
*Stall RPM .....	1850-1950	1850-1950	1700-1800	2000-2100

\*Note: Stall rpm is the maximum obtainable rpm with oil at operating temperature (180°F. to 200°F.), parking brake applied, wheels blocked, directional and speed range levers in FORWARD — 4th (HI), and bucket held in full close position. Stall rpm is applicable to altitude of 600 ft. and ambient temperature of 70°F. Due to the many combinations of altitude and temperature possible in the field, space does not permit publishing here all the corrections necessary to the stall rpm indicated to accommodate such variations. It is suggested the engine manufacturer's distributor be contacted to determine the correction necessary for altitude and temperature in your application.

MODEL	175B	175B	275B	275B
ELECTRICAL SYSTEM	G.M.	Cummins	Cummins	Cummins
Fuses:				
Gauge Circuit .....	AGC ¾ Amp.	AGC ¾ Amp.	AGC ¾ Amp.	AGC ¾ Amp.
Light Circuit .....	SFE 20 Amp.	SFE 20 Amp.	SFE 20 Amp.	SFE 20 Amp.
Lighter (self contained) ..	20 Amp.	20 Amp.	20 Amp.	20 Amp.
Instruments:				
Panel Gauges .....	12 Volt	12 Volt	12 Volt	12 Volt
Sender Units .....	12 Volt	12 Volt	12 Volt	12 Volt
Lamps:				
Back-Up .....	24 Volt, 60 Watt	24 Volt, 60 Watt	24 Volt, 60 Watt	24 Volt, 60 Watt
Dash .....	24 Volt, 6 C.P.	24 Volt, 6 C.P.	24 Volt, 6 C.P.	24 Volt, 6 C.P.
Tail & Stop .....	24 Volt, 32/6 C.P.	24 Volt, 32/6 C.P.	24 Volt, 32/6 C.P.	24 Volt, 32/6 C.P.
Head .....	24 Volt, 60 Watt	24 Volt, 60 Watt	24 Volt, 60 Watt	24 Volt, 60 Watt
Alternator .....	24V - 35A	24V - 35A	24V - 35A	24V - 75A
Voltage Regulator .....	24 Volt	24 Volt	24 Volt	24 Volt
Starting Motor .....	24 Volt	24 Volt	24 Volt	24 Volt
Batteries:				
Clark Part No. ....	1310121	1310121	1671369	1671369
No. & Voltage .....	2 x 12V	2 x 12V	2 x 12V	2 x 12V
System .....	24 Volt	24 Volt	24 Volt	24 Volt
Ground .....	Negative	Negative	Negative	Negative
Specific Gravity .....	1.230-1.260	1.230-1.260	1.230-1.260	1.230-1.260

MODEL	175B G.M.	175B Cummins	275B Cummins
<b>*PRESSURES —</b>			
Engine Oil:			
Low Idle (minimum) .....	12 psi	12 psi	12 psi
Gov. RPM (approximate) .....	45 psi	40 psi	40 psi
Air Compressor .....	95-110 psi	95-110 psi	95-120 psi
Main Hydraulic System — (At engine stall rpm with one set of cylinders against stops.) .....	2200 psi	2200 psi	2200 psi
Main Hydraulic Pump — (Secondary section by- pass pressure.) .....	1700 psi	1700 psi	1800 psi
Steering Hydraulic Pressure — (At maximum rpm with tractor halves against stops.) .....	1800±50 psi	1800±50 psi	1800±50 psi
Steering Hydraulic Pump — (Secondary section by-pass rpm.) .....	1600 rpm	1600 rpm	1600 rpm
Transmission Clutches — (At idle rpm in all speed ranges, both forward and reverse.) ...	240 min./ 280 max. psi	240 min./ 280 max. psi	180 min./ 220 max. psi
Transmission Lubricating — (Maximum at max- imum rpm.) .....	25 psi	25 psi	25 psi

\*Note: All hydraulic pressure checks should be made with converter oil at operating temperature, approximately 180°F. to 200°F, and hydraulic system oil at 150°F. minimum.

### FUEL SPECS — (All Models)

Fuel Oil ..... No. 2 Diesel, Cetane 40 minimum.

### BRAKE FLUID SPECS — (All Models)

SAE J-1703 (70 R3) ..... Clark 850487.

## TIRE DATA AND HYDROINFLATION

### TIRE DATA

<u>MODEL</u>	<u>SIZE</u>	<u>PLY RATING</u>	<u>INFLATION PSI</u>		<u>TYPE</u>
			<u>FRONT</u>	<u>REAR</u>	
175	26.5-25	16	40	40	Rock
275	29.5-29	22	55	55	Rock

Note: Other tire options available.

### HYDROINFLATION DATA


The following table indicates the amount of calcium chloride and water which may be added to tires where increased weight and tractive ability are desired.

<u>TIRE SIZE</u>	<u>USE CaCl<sub>2</sub> (POUNDS)</u>	<u>DISSOLVE IN WATER (GALLONS)</u>	<u>TOTAL GALLONS SOLUTION</u>	<u>WEIGHT INCREASE EACH TIRE (POUNDS)</u>
26.5-25	428	123	143	1450
29.5-29	675	194	226	2300

The solution indicated above, when using a commercial calcium chloride flake of 77-80%, should protect the tire against freezing down to 30°F. below zero. Solution strength can be tested with a battery hydrometer. Reading at 60°F. should be 1218.

It is recommended that the rear tires be hydro-inflated to the above table if optional counterweight is not used. It is not permissible to use both hydroinflation and optional counterweight.






WIRING DIAGRAM

WIRING DIAGRAM 175 B G.M. (427A101 thru 427A140)

TS-10848

**WIRING DIAGRAM COLOR CODE CHART FOR USE WITH TS-10848**

<b>Ref. No.</b>	<b>Color</b>	<b>Color Code</b>
1.	Tan	Stoplights to Stoplight Switch
2.	Yellow	Tail Lights to Instrument Panel Plug (Pink)
3.	Dark Blue	Rear Floodlamps to Light Switch
4.	Brown	Engine Temp. Sender to Engine Temp. Gauge
5.	Red & White	Ignition Switch to Hourmeter, Relay & Switches
6.	Dark Green	Engine Oil Press. Sender to Oil Press. Gauge
7.	Light Green	Air Press. Sender to Air Press. Gauge
8.	White	Starter Button to Neutral Start Switch to Relay
9.	Red	Ignition Switch to Starter Solenoid
10.	Grey	Converter Temp. Sender to Converter Temp Gauge
11.	Orange	Battery to Lighter
12.	Black	Ignition Switch to Starter Button
13.	Purple & White	Ignition Switch to Voltmeter
14.	Purple	Ignition Switch to Fuse to Gauges
15.	Violet	Ignition Switch to Fuse to Light Switch
16.	Light Blue	Horn Switch to Horn
17.	Pink	Light Switch to Front Floodlamps
18.	Brown & White	F-2 Alternator Terminal to Voltage Regulator
19.	Lt. Blue & White	F-1 Alternator Terminal to Voltage Regulator
20.	Red	Battery to Hourmeter Relay
21.	Red & Black	Battery Alternator Terminal to Battery
22.	Black	Ignition Switch to Brake Low Press. Sender



TS-11523 B


WIRING DIAGRAM — G.M. 175B (427A141 & After)

## COLOR CODE REFERENCE CHART FOR USE WITH TS-11523-B

Ref. No.	Color	Color Code
1.	Tan	Stop Lights to Stop Light Switch
2.	Yellow	Tail Lights to Instrument Panel Plug (Joins Pink)
3.	Dark Blue	Back-Up Lights to Light Switch
4.	Brown	Engine Temp. Sender to Engine Temp. Gauge
5.	Red & White	Ignition Switch to Hourmeter Relay, Hourmeter & Switches
6.	Dark Green	Engine Oil Press. Sender to Engine Oil Press. Gauge
7.	Light Green	Air Press. Sender to Air Press. Gauge
8.	White	Starter Button to Neutral Start Switch to Starter Relay
9.	Red	Ignition Switch to Circuit Breaker to Starter Solenoid
10.	Grey	Converter Temp. Sender to Converter Temp. Gauge
11.	Orange	Battery to Lighter
12.	Black	Ignition Switch to Starter Button
13.	Purple & White	Ignition Switch to Voltmeter
14.	Purple	Ignition Switch to Resistor to Fuse to Gauges
15.	Violet	Ignition Switch to Fuse to Light Switch
16.	Light Blue	Horn Switch to Horn
17.	Pink	Light Switch
18.	Brown & White	F-2 Alternator Terminal to Voltage Regulator
19.	Lt. Blue & White	F-1 Alternator Terminal to Voltage Regulator
20.	Red & Black	Battery Alternator Terminal Splice to Red
21.	Black	Ignition Switch to Brake Low Press. Sender

### 175B — G.M.

A — Stop & Tail Lamps	M — Air Pressure Gauge	Y — 20 Amp Fuse
B — Back-up Lamps	N — Engine Oil Pressure Gauge	Z — ¾ Amp Fuse
C — Alternator	O — Dash Lamp	AA — Neutral Start Switch
D — Engine Oil Pressure Sender	P — Lighter	BB — Low Pressure Sender
E — Engine Temperature Sender	Q — Starter Button	CC — Warning Light
F — Converter Temperature Sender	R — Stop Light Switch	DD — Buzzer
G — Hourmeter Relay	S — Horn Switch	EE — Batteries
H — Hourmeter	T — Heater Connector	FF — Starter Solenoid
I — Converter Temperature Gauge	U — Head Lamps	GG — Starter
J — Engine Temperature Gauge	V — Air Pressure Sender	HH — Starter Relay
K — Voltmeter	W — Horn	JJ — Resistor
L — Ignition Switch	X — Light Switch	KK — Circuit Breaker
		LL — Voltage Regulator



TS-13206


WIRING DIAGRAM — G.M. S/N 427B101 & AFTER

## COLOR CODE REFERENCE CHART FOR USE WITH TS-13206

Ref. No.	Color	Color Code
1.	Tan	Stop Lights to Stop Light Switch
2.	Yellow	Tail Lights to Instrument Panel Plug (Joins Pink)
3.	Dark Blue	Back-Up Lights to Light Switch
4.	Brown	Engine Temp. Sender to Engine Temp. Gauge
5.	Red & White	Ignition Switch to Hourmeter Relay, Hourmeter & Switches
6.	Dark Green	Engine Oil Press. Sender to Engine Oil Press. Gauge
7.	Light Green	Air Press. Sender to Air Press. Gauge
8.	White	Starter Button to Neutral Start Switch to Starter Relay
9.	Red	Ignition Switch to Circuit Breaker to Starter Solenoid
10.	Grey	Converter Temp. Sender to Converter Temp. Gauge
11.	Orange	Battery to Lighter
12.	Black	Ignition Switch to Starter Button
13.	Purple & White	Ignition Switch to Voltmeter
14.	Purple	Ignition Switch to Resistor to Fuse to Gauges
15.	Violet	Ignition Switch to Fuse to Light Switch
16.	Light Blue	Horn Switch to Horn
17.	Pink	Light Switch to Head Lamps
18.	Brown & White	F-2 Alternator Terminal to Voltage Regulator
19.	Lt. Blue & White	F-1 Alternator Terminal to Voltage Regulator
20.	Red & Black	Battery Alternator Terminal Spliced to Red
21.	Black	Ignition Switch to Brake Low Press. Sender

### 175 B — G.M.

A — Stop & Tail Lamps	N — Engine Oil Press. Gauge	AA — Neutral Start Switch
B — Back-Up Lamps	O — Dash Lamp	BB — Low Press. Sender
C — Alternator	P — Lighter	CC — Warning Light
D — Engine Oil Press. Sender	Q — Starter Button	DD — Buzzer
E — Engine Temp. Sender	R — Stop Light Switch	EE — Batteries
F — Converter Temp. Sender	S — Horn Switch	FF — Starter Solenoid
G — Hourmeter Relay	T — Heater Connector	GG — Starter
H — Hourmeter	U — Head Lamps	HH — Starter Relay
I — Converter Temp. Gauge	V — Air Press. Sender	JJ — Resistor
J — Engine Temp. Gauge	W — Horn	KK — Circuit Breaker
K — Voltmeter	X — Light Switch	LL — Voltage Regulator
L — Ignition Switch	Y — 20 Amp. Fuse	
M — Air Press. Gauge	Z — ¾ Amp. Fuse	




TS-10552

WIRING DIAGRAM — 275B CUMMINS (425A101 thru 425A360)

**WIRING DIAGRAM COLOR CODE CHART FOR USE WITH TS-10552**

<b>Ref. No.</b>	<b>Color</b>	<b>Color Code</b>
1.	Tan	Stoplights to Brake Light Switch
2.	Yellow	Tail Lights to Instrument Panel Plug (Pink)
3.	Dark Blue	Rear Floodlamps to Light Switch
4.	Brown	Engine Temp. Sender to Engine Temp. Gauge
5.	Red & White	Ignition Switch to Hourmeter & Switches
6.	Dark Green	Engine Oil Press. Sender to Oil Press. Gauge
7.	Light Green	Air Press. Sender to Air Press. Gauge
8.	White	Starter Button to Neutral Start Switch to Relay
9.	Red	Ignition Switch to Starter Solenoid
10.	Grey	Converter Temp. Sender to Converter Temp. Gauge
11.	Orange	Battery to Lighter
12.	Black	Ignition Switch to Starter Button
13.	Purple & White	Ignition Switch to Voltmeter
14.	Purple	Ignition Switch to Resistor to Fuse to Gauges
15.	Violet	Ignition Switch to Fuse to Light Switch
16.	Light Blue	Horn Switch to Horn
17.	Pink	Light Switch to Front Floodlamps





WIRING DIAGRAM — 175B CUMMINS (438A101 and After)  
— 275B CUMMINS (425A361 thru 425A999)  
(425B101 thru 425B429, 425B434)

TS-11508 B


## COLOR CODE REFERENCE CHART FOR USE WITH TS-11508-B

Ref. No.	Color	Color Code
1.	Tan	Stop Lights to Stop Light Switch
2.	Yellow	Tail Lights to Instrument Panel Plug (Joins Pink)
3.	Dark Blue	Back-Up Lights to Light Switch
4.	Brown	Engine Temp. Sender to Engine Temp. Gauge
5.	Red & White	Ignition Switch to Hourmeter, Relay & Switches
6.	Dark Green	Engine Oil Press. Sender to Engine Oil Press. Gauge
7.	Light Green	Air Press. Sender to Air Press. Gauge
8.	White	Starter Button to Neutral Start Switch to Starter Relay
9.	Red	Ignition Switch to Circuit Breaker to Starter Solenoid
10.	Grey	Converter Temp. Sender to Converter Temp. Gauge
11.	Orange	Battery to Lighter
12.	Black	Ignition Switch to Starter Button
13.	Purple & White	Ignition Switch to Voltmeter
14.	Purple	Ignition Switch to Resistor to Fuse to Gauges
15.	Violet	Ignition Switch to Fuse to Light Switch
16.	Light Blue	Horn Switch to Horn
17.	Pink	Light Switch to Headlamps
18.	Black	Ignition Switch to Low Pressure Sender

### 175B & 275B – Cummins

A – Stop & Tail Lamps	M – Air Pressure Gauge	Y – 20 Amp Fuse
B – Back-up Lamps	N – Engine Oil Pressure Gauge	Z – ¾ Amp Fuse
C – Alternator	O – Dash Lamp	AA – Neutral Start Switch
D – Engine Oil Pressure Sender	P – Lighter	BB – Low Pressure Sender
E – Engine Temperature Sender	Q – Starter Button	CC – Warning Light
F – Converter Temperature Sender	R – Stop Light Switch	DD – Buzzer
G – Fuel Solenoid	S – Horn Switch	EE – Batteries
H – Hourmeter	T – Heater Connector	FF – Starter Solenoid
I – Converter Temperature Gauge	U – Headlamps	GG – Starter
J – Engine Temperature Gauge	V – Air Pressure Sender	HH – Starter Relay
K – Voltmeter	W – Horn	JJ – Resistor
L – Ignition Switch	X – Light Switch	KK – Circuit Breaker

WIRING DIAGRAM 175B CUMMINS 438B101 & After




## COLOR CODE REFERENCE CHART FOR USE WITH TS-13352

Ref. No.	Color	Color Code
1.	Tan	Stop Lights to Stop Light Switch
2.	Yellow	Tail Lights to Instrument Panel Plug (Joins Pink)
3.	Dark Blue	Back-Up Lights to Light Switch
4.	Brown	Engine Temp. Sender to Engine Temp. Gauge
5.	Red & White	Ignition Switch to Hourmeter, Relay & Switches
6.	Dark Green	Engine Oil Press. Sender to Engine Oil Press. Gauge
7.	Light Green	Air Press. Sender to Air Press. Gauge
8.	White	Starter Button to Neutral Start Switch to Starter Relay
9.	Red	Ignition Switch to 50 Amp. Circuit Breaker to Starter Solenoid
10.	Grey	Converter Temp. Sender to Converter Temp. Gauge
11.	Orange	Battery to Lighter
12.	Black	Ignition Switch to Starter Button
13.	Purple & White	Ignition Switch to Voltmeter
14.	Purple	Ignition Switch to Resistor to Fuse to Gauges
15.	Violet	Ignition Switch to Fuse to Light Switch
16.	Light Blue	Horn Switch to Horn
17.	Pink	Light Switch to Headlamps
18.	Black	Ignition Switch to Low Pressure Sender

### 175B Cummins

A — Stop & Tail Lamps	M — Air Pressure Gauge	Y — 20 Amp Fuse
B — Back-up Lamps	N — Engine Oil Pressure Gauge	Z — ¼ Amp Fuse
C — Alternator	O — Dash Lamp	AA — Neutral Start Switch
D — Engine Oil Pressure Sender	P — Lighter	BB — Low Pressure Sender
E — Engine Temperature Sender	Q — Starter Button	CC — Warning Light
F — Converter Temperature Sender	R — Stop Light Switch	DD — Buzzer
G — Fuel Solenoid	S — Horn Switch	EE — Batteries
H — Hourmeter	T — Heater Connector	FF — Starter Solenoid
I — Converter Temperature Gauge	U — Headlamps	GG — Starter
J — Engine Temperature Gauge	V — Air Pressure Sender	HH — Starter Relay
K — Voltmeter	W — Horn	JJ — Resistor
L — Ignition Switch	X — Light Switch	KK — Circuit Breaker



WIRING DIAGRAM — 275B CUMMINS 425B430 thru 425B435 & AFTER

TS-13728

## COLOR CODE REFERENCE CHART FOR USE WITH TS-13728

Ref. No.	Color	Color Code
1.	Tan	Stop Lights to Stop Light Switch
2.	Yellow	Tail Lights to Instrument Panel Plug (Joins Pink)
3.	Dark Blue	Back-Up Lights to Light Switch
4.	Brown	Engine Temp. Sender to Engine Temp. Gauge
5.	Red & White	Ignition Switch to Hourmeter, Ether Injector & Switches
6.	Dark Green	Engine Oil Press. Sender to Engine Oil Press. Gauge
7.	Light Green	Air Press. Sender to Air Press. Gauge
8.	White	Starter Button to Neutral Start Switch to Starter Relay
9.	Red	Ignition Switch to Circuit Breaker to Starter Solenoid
10.	Grey	Converter Temp. Sender to Converter Temp. Gauge
11.	Orange	Battery to Lighter
12.	Black	Ignition Switch to Starter Button
13.	Purple & White	Ignition Switch to Voltmeter
14.	Purple	Resistor to Fuse to Gauges
15.	Violet	Ignition Switch to Fuse to Light Switch
16.	Light Blue	Horn Switch to Horn
17.	Pink	Light Switch to Headlamps
18.	Black	Ignition Switch to Low Pressure Sender
19.	Optional	Limit Switch to Solenoid (Boom Kickout & Bucket Leveler)
20.	Black	Heater Connector to Solenoid (Boom Kickout & Bucket Leveler)
21.	Brown & White	Quick Start Button to Ether Injector

### 275 B CUMMINS

A — Back-Up Lights	P — Heater Connector	EE — Starter Button
B — Stop & Tail Lights	Q — Limit Switch Boom Kickout	FF — Lighter
C — Alternator	R — Limit Switch Bucket Leveler	GG — Air Press. Gauge
D — Hourmeter	S — Horn Switch	HH — Ignition Switch
E — Batteries	T — Air Press. Sender	II — Engine Temp. Gauge
F — Neutral Start Switch	U — Stop Light Switch	JJ — Voltmeter
G — Converter Temp. Sender	V — Headlamp	KK — ¾ Amp. Fuse
H — Engine Oil Press. Gauge	W — Circuit Breaker	LL — Ether Injector
I — Dash Lamp	X — Emergency Brake Warning Light	MM — 15 Amp. Fuse
J — Horn	Y — Low Press. Sender	NN — Engine Temp. Sender
K — Headlamp Connector	Z — Buzzer	OO — Fuel Solenoid
L — Solenoid Bucket Leveler	AA — Light Switch	PP — Engine Oil Press. Sender
M — Solenoid Boom Kickout	BB — 20 Amp Fuse	QQ — Converter Temp. Sender
N — 6 Amp Fuse	CC — Quick Start Button	RR — Starter
O — 6 Amp Fuse	DD — Resistor	SS — Starter Solenoid
		TT — Starter Relay

**MICHIGAN**

## 275B TRACTOR SHOVEL

# OPERATORS MANUAL SUPPLEMENT

No. 2879-R1



**SUBJECT:** Revised Stall Speed Specifications.

This Supplement covers revised stall speed specifications for Model 275B Tractor Shovels equipped with Clark C-8502-11 Torque Converters effective on machines shipped from the factory with serial numbers:

425B106 & After  
425B101 FSC & After  
425B101 ENC & After



**\*Old Stall Speed Specification:** 1700-1800 RPM with transmission in FORWARD — 4th (HI) and bucket in full CLOSE position.

**\*New Stall Speed Specification:** 1950-2050 RPM with transmission in FORWARD — 4th (HI) and bucket in full CLOSE position.


**\*Note:** All stall speed checks should be made with converter oil at operating temperature, approximately 180°F. to 200°F. (82°C. to 94°C.) and hydraulic system oil 150°F. (65°C.) minimum. Stall RPM is applicable to altitude of 600 ft. (183 m.) and ambient temperature of 70°F. (21°C.). Contact engine manufacturer's distributor to determine the correction necessary for altitude and temperature in your application.



**Use this Supplement with Operators Manual No. 2653-R1**



## CLARK EQUIPMENT COMPANY





**MICHIGAN**

**175 B TRACTOR SHOVEL**  
**OPERATORS MANUAL SUPPLEMENT**

**No. 2913**

★

This Supplement covers Model 175 B Tractor Shovels with revised electrical systems featuring relocation of the main circuit breaker from instrument panel to rear frame next to starting motor, effective on machines shipped from the factory with serial numbers:

G. M. — 427 B101 and After  
CUMMINS — 438 B101 and After


★

Use this Supplement with Operators Manual No. 2653-R1 and existing supplements

★

**CLARK EQUIPMENT COMPANY**

TS-13206



WIRING DIAGRAM — G.M. S/N 427B101 & AFTER



**CONSTRUCTION MACHINERY DIVISION  
COLOR CODE REFERENCE CHART FOR USE WITH TS-13206**


Ref. No.	Color	Color Code
1.	Tan	Stop Lights to Stop Light Switch
2.	Yellow	Tail Lights to Instrument Panel Plug (Joins Pink)
3.	Dark Blue	Back-Up Lights to Light Switch
4.	Brown	Engine Temp. Sender to Engine Temp. Gauge
5.	Red & White	Ignition Switch to Hourmeter Relay, Hourmeter & Switches
6.	Dark Green	Engine Oil Press. Sender to Engine Oil Press. Gauge
7.	Light Green	Air Press. Sender to Air Press. Gauge
8.	White	Starter Button to Neutral Start Switch to Starter Relay
9.	Red	Ignition Switch to Circuit Breaker to Starter Solenoid
10.	Grey	Converter Temp. Sender to Converter Temp. Gauge
11.	Orange	Battery to Lighter
12.	Black	Ignition Switch to Starter Button
13.	Purple & White	Ignition Switch to Voltmeter
14.	Purple	Ignition Switch to Resistor to Fuse to Gauges
15.	Violet	Ignition Switch to Fuse to Light Switch
16.	Light Blue	Horn Switch to Horn
17.	Pink	Light Switch to Head Lamps
18.	Brown & White	F-2 Alternator Terminal to Voltage Regulator
19.	Lt. Blue & White	F-1 Alternator Terminal to Voltage Regulator
20.	Red & Black	Battery Alternator Terminal Spliced to Red
21.	Black	Ignition Switch to Brake Low Press. Sender

**175 B – G.M.**

A – Stop & Tail Lamps	N – Engine Oil Press. Gauge	AA – Neutral Start Switch
B – Back-Up Lamps	O – Dash Lamp	BB – Low Press. Sender
C – Alternator	P – Lighter	CC – Warning Light
D – Engine Oil Press. Sender	Q – Starter Button	DD – Buzzer
E – Engine Temp. Sender	R – Stop Light Switch	EE – Batteries
F – Converter Temp. Sender	S – Horn Switch	FF – Starter Solenoid
G – Hourmeter Relay	T – Heater Connector	GG – Starter
H – Hourmeter	U – Head Lamps	HH – Starter Relay
I – Converter Temp. Gauge	V – Air Press. Sender	JJ – Resistor
J – Engine Temp. Gauge	W – Horn	KK – Circuit Breaker
K – Voltmeter	X – Light Switch	LL – Voltage Regulator
L – Ignition Switch	Y – 20 Amp. Fuse	
M – Air Press. Gauge	Z – ¼ Amp. Fuse	



TS-13276



WIRING DIAGRAM — CUMMINS S/N 438B101 & AFTER

**COLOR CODE REFERENCE CHART FOR USE WITH TS-13276**

Ref. No.	Color	Color Code
1.	Tan	Stop Lights to Stop Light Switch
2.	Yellow	Tail Lights to Instrument Panel Plug (Joins Pink)
3.	Dark Blue	Back-Up Lights to Light Switch
4.	Brown	Engine Temp. Sender to Engine Temp. Gauge
5.	Red & White	Ignition Switch to Hourmeter Relay, Hourmeter & Switches
6.	Dark Green	Engine Oil Press. Sender to Engine Oil Press. Gauge
7.	Light Green	Air Press. Sender to Air Press. Gauge
8.	White	Starter Button to Neutral Start Switch to Starter Relay
9.	Red	Ignition Switch to Circuit Breaker to Starter Solenoid
10.	Grey	Converter Temp. Sender to Converter Temp. Gauge
11.	Orange	Battery to Lighter
12.	Black	Ignition Switch to Starter Button
13.	Purple & White	Ignition Switch to Voltmeter
14.	Purple	Ignition Switch to Resistor to Fuse to Gauges
15.	Violet	Ignition Switch to Fuse to Light Switch
16.	Light Blue	Horn Switch to Horn
17.	Pink	Light Switch to Head Lamps
18.	Brown & White	F-2 Alternator Terminal to Voltage Regulator
19.	Lt. Blue & White	F-1 Alternator Terminal to Voltage Regulator
20.	Red & Black	Battery Alternator Terminal Spliced to Red
21.	Black	Ignition Switch to Brake Low Press. Sender

**175 B – G.M.**

A – Stop & Tail Lamps	N – Engine Oil Press. Gauge	AA – Neutral Start Switch
B – Back-Up Lamps	O – Dash Lamp	BB – Low Press. Sender
C – Alternator	P – Lighter	CC – Warning Light
D – Engine Oil Press. Sender	Q – Starter Button	DD – Buzzer
E – Engine Temp. Sender	R – Stop Light Switch	EE – Batteries
F – Converter Temp. Sender	S – Horn Switch	FF – Starter Solenoid
G – Hourmeter Relay	T – Heater Connector	GG – Starter
H – Hourmeter	U – Head Lamps	HH – Starter Relay
I – Converter Temp. Gauge	V – Air Press. Sender	JJ – Resistor
J – Engine Temp. Gauge	W – Horn	KK – Circuit Breaker
K – Voltmeter	X – Light Switch	LL – Voltage Regulator
L – Ignition Switch	Y – 20 Amp. Fuse	
M – Air Press. Gauge	Z – ¾ Amp. Fuse	



**MICHIGAN**

# 175B TRACTOR SHOVEL

# OPERATORS MANUAL SUPPLEMENT

No. 2923

★

This Supplement covers Model 175B Tractor Shovels equipped with G.M. and Cummins engines and Clark 4421-2 Transmissions, effective on machines shipped from the factory with the following serial numbers:

G.M. — 427B171 and After

427B101FSC and After

427B101ENC and After

Cummins — 438B101FSC and After

438B101ENC and After

★

Use this Supplement with Operators Manual No. 2653-R1  
and existing supplements

★

**CLARK EQUIPMENT COMPANY**

**ENGINE SPECIFICATIONS AND SERVICE DATA**

<b>ENGINE</b>	<b>175B</b>	<b>175B</b>	<b>275B</b>
Make .....	G.M.	Cummins	Cummins
Model .....	8V71N	NT-855-C	NTA-855-C
No. of Cyls. ....	8	6	6
Bore (in.) .....	4.25	5.50	5.50
Stroke (in.) .....	5.00	6.00	6.00
Displacement (cu. in.) .....	567.4	855	855
Max. Torque (ft. lbs.) .....	805	780	960
@ RPM .....	1200	1550	1650
Flywheel Horsepower .....	273	279	324
Governed RPM .....	2100	2100	2100
Low Idle RPM .....	650-750	650-750	550-600
High Idle RPM .....	2200-2300	2200-2300	2200-2300
*Stall RPM .....	1850-1950	1850-1950	1700-1800

\*Note: Stall rpm is the maximum obtainable rpm with oil at operating temperature (180°F. to 200°F.), parking brake applied, wheels blocked, directional and speed range levers in FORWARD — 4th (HI), and bucket held in full close position. Stall rpm is applicable to altitude of 600 ft. and ambient temperature of 70°F. Due to the many combinations of altitude and temperature possible in the field, space does not permit publishing here all the corrections necessary to the stall rpm indicated to accommodate such variations. It is suggested the engine manufacturer's distributor be contacted to determine the correction necessary for altitude and temperature in your application.

<b>MODEL ELECTRICAL SYSTEM</b>	<b>175B G.M.</b>	<b>175B Cummins</b>	<b>275B Cummins</b>
<b>Fuses:</b>			
Gauge Circuit .....	AGC ¾ Amp.	AGC ¾ Amp.	AGC ¾ Amp.
Light Circuit .....	SFE 20 Amp.	SFE 20 Amp.	SFE 20 Amp.
Lighter (self contained) .....	20 Amp.	20 Amp.	20 Amp.
<b>Instruments:</b>			
Panel Gauges .....	12 Volt	12 Volt	12 Volt
Sender Units .....	12 Volt	12 Volt	12 Volt
<b>Lamps:</b>			
Back-Up .....	24 Volt, 60 Watt	24 Volt, 60 Watt	24 Volt, 60 Watt
Dash .....	24 Volt, 6 C.P.	24 Volt, 6 C.P.	24 Volt, 6 C.P.
Tail & Stop .....	24 Volt, 32/6 C.P.	24 Volt, 32/6 C.P.	24 Volt, 32/6 C.P.
Head .....	24 Volt, 60 Watt	24 Volt, 60 Watt	24 Volt, 60 Watt
Alternator .....	24V - 35A	24V - 50A	24V - 50A
Voltage Regulator .....	24 Volt	24 Volt	24 Volt
Starting Motor .....	24 Volt	24 Volt	24 Volt
<b>Batteries:</b>			
Clark Part No. ....	1310121	1310121	1671369
No. & Voltage .....	2 x 12V	.2 x 12V	2 x 12V
System .....	24 Volt	24 Volt	24 Volt
Ground .....	Negative	Negative	Negative
Specific Gravity .....	1.230-1.260	1.230-1.260	1.230-1.260



**MODEL**

**\*PRESSURES —**

	<b>175B G.M.</b>	<b>175B Cummins</b>	<b>275B Cummins</b>
Engine Oil:			
Low Idle (minimum) .....	12 psi	12 psi	12 psi
Gov. RPM (approximate) .....	45 psi	40 psi	40 psi
Air Compressor .....	95-110 psi	95-110 psi	80-105 psi
Main Hydraulic System — (At engine stall rpm with one set of cylinders against stops.) .....	2200 psi	2200 psi	2200 psi
Main Hydraulic Pump — (Secondary section by- pass pressure.) .....	1700 psi	1700 psi	1500 psi
**Steering Hydraulic Pressure — (At maximum rpm with tractor halves against stops.) .....	1800±50 psi	1800±50 psi	1800±50 psi
Steering Hydraulic Pump — (Secondary section by-pass rpm.) .....	1600 rpm	1600 rpm	1600 rpm
Transmission Clutches — (At idle rpm in all speed ranges, both forward and reverse.) ...	240 min./ 280 max. psi	240 min./ 280 max. psi	180 min./ 220 max. psi
Transmission Lubricating — (Maximum at max- imum rpm.) .....	25 psi	25 psi	25 psi

\*Note: All hydraulic pressure checks should be made with converter oil at operating temperature, approximately 180°F. to 200°F., and hydraulic system oil at 150°F. minimum.

\*\*S/N 437A369 & After 175B, 425B244 & After 275B.

**FUEL SPECS — (All Models)**

Fuel Oil ..... No.2 Diesel, Cetane 40 minimum.

**BRAKE FLUID SPECS — (All Models)**

SAE J-1703 (70 R3) ..... Clark 850487.



## 275B TRACTOR SHOVEL

**MICHIGAN**

# OPERATORS MANUAL SUPPLEMENT

No. 2978

★

This Supplement covers Model 275B Tractor Shovels equipped with Cummins NTA-855-C380 engines using the Turner "Quick Start" cold weather starting aid, effective on machines shipped from the factory with serial numbers:

425B430 thru 425B433,  
425B435 and After

★

Information contained in Operators Manual No. 2653-R1 and existing supplements will apply to these machines except for the differences covered in this Supplement.

★

Use this Supplement with Operators Manual No. 2653-R1 and existing Supplements.

★

**CLARK EQUIPMENT COMPANY**

**QUICK START COLD WEATHER STARTING AID**

Model 275B Tractor Shovels with serial numbers 425B430 thru 425B433 and 425B435 & after are equipped with "Quick Start" cold weather starting aids. The "Quick Start" cold weather starting aid is controlled by a push button mounted on the left hand instrument panel as shown in Figure 1. When the button is pushed, ether is injected into the engine's intake manifold to aid in cold weather starting.

**CAUTION:** Do not attempt to inject additional ether by pushing button after engine is running. This could result in detonation and severe damage to the engine.

Cold weather, below 50°F. (10°C.) may require use of the "Quick Start" starting aid. With control levers in the NEUTRAL position, proceed as follows:




Fig. 1. Instrument Panel



1. Turn ignition switch ON, then push "Quick Start" button for one second and release.
2. Wait two seconds and engage starter.
3. Below 0°F. (-18°C.) repeat steps 1 & 2.

3. Screw cylinder into valve and tighten cylinder mounting bracket.

**CAUTION: USE ONLY FOR STARTING.**

**MAINTENANCE**

- A. Periodically remove cylinder and oil valve.
  1. Use care in wiping dirt from valve inlet when removing cylinder to prevent dirt from entering valve.
  2. Check valve gasket for damage and replace if needed.
  3. With cylinder removed, actuate system to distribute lubricant.
- B. When replacing empty cylinder, follow steps 1, 2 & 3 in Instruction A.
- C. Periodically check all connections for leaks. Also check valve mounting bolts and cylinder studs for tightness.
- D. Periodically test unit for proper functioning. Disconnect tube from atomizer and remove atomizer. Reassemble atomizer to tube, then actuate the system. A fine mist-like spray should be emitted from each orifice of the atomizer.
- E. If system is subjected to moisture, spray valve with a plastic coating.

**TROUBLE SHOOTING THE SYSTEM**

If the system fails to function it may be necessary to trouble shoot the system as follows:

- A. Check the cylinder for tightness and fuel supply.
  1. If cylinder is loose, it should be tightened finger tight.
  2. If the cylinder is not loose, it should be removed and weighed. (Empty cylinder weight is 17 ounces).
- B. If system still fails to function, remove tubing at valve and actuate valve.
  1. If valve is not functioning, it must be replaced. See Parts Manual.
  2. If valve is functioning remove tubing and clean thoroughly. Then reinstall tube at valve end and actuate valve.
  3. If fuel is discharged from tube, remove and disassemble atomizer and clean screen and blow out orifices. Then connect tubing to atomizer and actuate valve. Fuel should be emitted from each orifice of atomizer. This indicates proper functioning of the system.
  4. Disconnect tubing from atomizer and reinstall atomizer. Reconnect tubing to atomizer.

**INITIAL HOOK-UP OF CYLINDER**


The ether cylinder is disconnected from the valve and the valve and cylinder end are capped as a safety precaution during shipment of tractor. It will be necessary to hook-up the cylinder in the following manner prior to initial use of the system.

1. Remove cap from valve and cap from end of cylinder.
2. Loosen cylinder mounting bracket and lower cylinder to valve.

**SPECIFICATIONS AND SERVICE DATA  
ENGINE**

Cummins .....	NTA-855-C380
Flywheel Horsepower .....	342
Low Idle RPM .....	650-750
Stall RPM .....	2000-2100
Alternator .....	24 Volt, 75 Amp.
Air Compressor .....	95-120 psi





TS-13728

WIRING DIAGRAM — CUMMINS 425B430 thru 425B435 & AFTER

**COLOR CODE REFERENCE CHART FOR USE WITH TS-13728**

Ref. No.	Color	Color Code
1.	Tan	Stop Lights to Stop Light Switch
2.	Yellow	Tail Lights to Instrument Panel Plug (Joins Pink)
3.	Dark Blue	Back-Up Lights to Light Switch
4.	Brown	Engine Temp. Sender to Engine Temp. Gauge
5.	Red & White	Ignition Switch to Hourmeter, Ether Injector & Switches
6.	Dark Green	Engine Oil Press. Sender to Engine Oil Press. Gauge
7.	Light Green	Air Press. Sender to Air Press. Gauge
8.	White	Starter Button to Neutral Start Switch to Starter Relay
9.	Red	Ignition Switch to Circuit Breaker to Starter Solenoid
10.	Grey	Converter Temp. Sender to Converter Temp. Gauge
11.	Orange	Battery to Lighter
12.	Black	Ignition Switch to Starter Button
13.	Purple & White	Ignition Switch to Voltmeter
14.	Purple	Resistor to Fuse to Gauges
15.	Violet	Ignition Switch to Fuse to Light Switch
16.	Light Blue	Horn Switch to Horn
17.	Pink	Light Switch to Headlamps
18.	Black	Ignition Switch to Low Pressure Sender
19.	Optional	Limit Switch to Solenoid (Boom Kickout & Bucket Leveler)
20.	Black	Heater Connector to Solenoid (Boom Kickout & Bucket Leveler)
21.	Brown & White	Quick Start Button to Ether Injector

**275 B CUMMINS**

A — Back-Up Lights  
 B — Stop & Tail Lights  
 C — Alternator  
 D — Hourmeter  
 E — Batteries  
 F — Neutral Start Switch  
 G — Converter Temp. Sender  
 H — Engine Oil Press. Gauge  
 I — Dash Lamp  
 J — Horn  
 K — Headlamp Connector  
 L — Solenoid Bucket Leveler  
 M — Solenoid Boom Kickout  
 N — 6 Amp Fuse  
 O — 6 Amp Fuse

P — Heater Connector  
 Q — Limit Switch Boom Kickout  
 R — Limit Switch Bucket Leveler  
 S — Horn Switch  
 T — Air Press. Sender  
 U — Stop Light Switch  
 V — Headlamp  
 W — Circuit Breaker  
 X — Emergency Brake Warning Light  
 Y — Low Press. Sender  
 Z — Buzzer  
 AA — Light Switch  
 BB — 20 Amp Fuse  
 CC — Quick Start Button  
 DD — Resistor

EE — Starter Button  
 FF — Lighter  
 GG — Air Press. Gauge  
 HH — Ignition Switch  
 II — Engine Temp. Gauge  
 JJ — Voltmeter  
 KK — ¼ Amp. Fuse  
 LL — Ether Injector  
 MM — 15 Amp. Fuse  
 NN — Engine Temp. Sender  
 OO — Fuel Solenoid  
 PP — Engine Oil Press. Sender  
 QQ — Converter Temp. Sender  
 RR — Starter  
 SS — Starter Solenoid  
 TT — Starter Relay





275B TRACTOR SHOVEL

**MICHIGAN**

# **OPERATORS MANUAL SUPPLEMENT**

No. 2985

★

This Supplement covers Model 275 B Tractor Shovels equipped with new sealed bucket pivot & linkage pins & bushings, and revisions to main & steering hydraulic systems, effective on machines shipped from the factory with serial numbers:

425C101 and After

★

Information contained in Operators Manual No. 2653-R1 and existing supplements will apply to these machines except for the differences covered in this Supplement.

★

Use this Supplement with Operators Manual No. 2653-R1 and existing supplements.

★

**CLARK EQUIPMENT COMPANY**




**MICHIGAN**

CHASSIS LUBRICATION CHART

DESCRIPTION	HOURS					KEY
	500	250	100	50	∞	
1 Fitting Each Side PUSHROD TO BUCKET	X					LBG
1 Fitting Each Side PUSHROD TO BELL CRANK				X		LBG
1 Fitting Each Side BUCKET CYL TO BELL CRANK				X		LBG
1 Fitting Each Side BELL CRANK PIVOT				X		LBG
1 Fitting Each Side BOOM CYLINDER TO BOOM				X		LBG
2 Fittings Each Side BOOM CYLINDER TO TRUNNION MOUNT				X		LBG
1 Fitting Each Side BOOM TO UPPER PIVOT				X		LBG
1 Fitting Each Pin TRACTOR HINGE PIVOT UPPER & LOWER PIN				X		LBG
(See Text) BATTERIES				X		
(See Text) FUEL TANK				X		
TRANSMISSION & TORQUE CONVERTER (See Text)		X				
SYSTEM FILTERS						
2 Fittings Each Side BRAKE CAMSHAFT			X			LBG
(See Text) ENGINE & ACCESSORIES				X		
(See Text) TIRES — FRONT & REAR				X		
(See Text) RADIATOR				X		

KEY	HOURS					DESCRIPTION
	∞	50	100	250	500	
LBG		X				BOOM TO BUCKET 1 Fitting Each Side
LBG		X				BRAKE CAMSHAFT 2 Fittings Each Side
LBG	X					STEERING CYLINDERS 2 Fittings Each Cylinder
LBG	X					BUCKET CYLINDER TO FRAME 1 Fitting Each Cylinder
LBG		X				STEERING GEAR (See Text)
LBG		X				STEERING DRAG LINK 2 Fittings
LBG		X				BUCKET CONTROL LEVER 1 Fitting
LBG		X				BOOM CONTROL LEVER 1 Fitting
					X	HYDRAULIC SYSTEM RETURN FILTER
					X	HYDRAULIC SYSTEM SUCTION FILTER (See Text)
HF		X				HYDRAULIC SYSTEM OIL RESERVOIR (See Text)
LBG		X				AIR CLEANER (See Text)
LBG	X					AXLE CRADLE BUSHINGS 2 Fittings
					X	TRANSMISSION & TORQUE CONVERTER COOLER LINE STRAINER (See Text)



**MODEL 275  
articulated  
Tractor Shovel**

TS-13871


KEY	
LBG	LITHIUM BASE MULTI-PURPOSE GREASE 0°F. & Above Below 0°F. Grade 2 Grade 0 LUBRICANT TO BE USED
HF	SAE 10W Engine Oil, API Class SD or SE MIL-L-2104B or MIL-L-2104C (For Optional Lubricants See Operators Manual Text)
	0°F. & BELOW See Operators Manual Text



**MICHIGAN**  
**DRIVE LINE LUBRICATION**

KEY	
LBG	LITHIUM BASE MULTI-PURPOSE GREASE 0°F. & Above Grade 2 Below 0°F.
EPGL-1	EXTREME PRESSURE GEAR LUBE - "SCL" TYPE LUBRICANT TO BE USED AMBIENT TEMP. RANGE ABOVE 0°F. SAE 10W Engine Oil, API Class SD or SE MIL-L-2104B or MIL-L-2104C (For Optional Lubricants See Operators Manual Text)
HF	0°F. & BELOW See Operators Manual Text

DESCRIPTION	HOURS					KEY
	0001	0005	0010	0050	∞	
TRANSMISSION & TORQUE CONVERTER FILL PLUG (See Text)	X					HF
TRANSMISSION BREATHER (See Text)		X				
3 Fittings PROP SHAFT (See Text)			X			LBG
PLANETARY DRAIN PLUG (See Text)				X		
TORQUE CONVERTER BREATHER (See Text)					X	




**MODEL 275  
TRACTOR SHOVEL**

KEY	HOURS					DESCRIPTION
	∞	50	100	500	1000	
	X			X		TRANSMISSION DIP STICK (See Text)
LBG		X				PROP SHAFT (See Text) 3 Fittings
LBG		X				PROP SHAFT (See Text) 3 Fittings
				X		PLANETARY DRAIN PLUG (See Text)
EPGL-1			X			DIFFERENTIAL FILL & LEVEL PLUG (See Text)


\* "SCL" signifies Sulfo-Chloro-Lead Type. Factory fill is made with SCL type lube and it is recommended that same type be used when adding or refilling. Below 0 minus 10°F., use SAE-80. Up to 100°F., use SAE-90. Above 100°F., consistently use SAE-140.

TS-13873						
				X		DIFFERENTIAL DRAIN PLUG (See Text)
EPGL-1		X				PLANETARY FILL & LEVEL PLUG (See Text)
HF		X				MIDMOUNT BEARING (See Text)
				X		TRANSMISSION & TORQUE CONVERTER DRAIN PLUG (See Text)





**Fig. 1. Pressure Relief Settings — Pilot Valve**




**Fig. 2. Remove Cover — Main Relief**

**Check Boom and Bucket Pressure:** The boom and bucket hydraulic pump is coupled to the drive line and operates as soon as the engine starts. The pump draws fluid from the reservoir and forces it under pressure into the main hydraulic valve, from which a small supply of fluid is directed to the pilot valve, routing the fluid back to the main valve, operating the desired circuit in the main valve, supplying the flow of fluid to the cylinders. Preset overload relief cartridges on the pilot valve protect the system and components.

Maintenance consists of periodically checking the pressure in the system. All pressure checks are to be made with fluids at operating temperature. (150°F. minimum).

1. Attach safety links and block wheels.
2. Position bucket and boom mechanism so that bucket is level on ground and shut down engine.
3. Loosen hydraulic reservoir cap slowly to relieve pressure in reservoir.
4. Actuate boom and bucket control levers both fore and aft, holding levers in both fore and aft positions for several seconds. Repeat this operation several times. Retighten reservoir cap.
5. Use a hydraulic test gauge of at least 3000 psi capacity. Remove cover from pressure port on primary section of main pump and attach gauge.
6. Place transmission directional shift lever in NEUTRAL, start engine and apply parking brake.
7. If it is necessary during the following steps to replace any of the relief valve cartridges on the pilot valve, remove seat and seat support plate to gain access to pilot valve.
8. With transmission directional and speed range levers in FORWARD, and HI, actuate bucket control lever to the full ROLLBACK position and accelerate engine to maximum rpm. Record gauge reading and proceed to Step 9.
9. With transmission directional and speed range levers in FORWARD, and HI, actuate boom control lever to the full RAISE position and accelerate to maximum rpm. Record gauge reading and proceed to Step 10.
10. If bucket ROLLBACK and boom RAISE are not the same within 50 psi, the circuit with the lower pressure reading must have the relief valve cartridge on the pilot valve changed. Figure 1. Item 1 is bucket rollback cartridge, Item 2 is boom raise cartridge.
11. After either relief cartridge is changed, repeat Steps 8, 9, 10, and 11 until recorded pressure readings for bucket ROLLBACK and boom RAISE are the same within 50 psi.
12. If gauge pressure readings for bucket ROLLBACK and boom RAISE are the same within 50 psi, but not to specification of 2200 psi, the main relief valve (located in the main control valve assembly) must be adjusted. See Steps 13 thru 15 for procedure.
13. Remove 8 bolts retaining cover (Figure 2, Item A, and remove cover. Refer to Figure 3 and





- |                       |                    |
|-----------------------|--------------------|
| 1. Relief Valve Assy. | 3. Adjusting Screw |
| 2. Spring             | 4. Locknut         |

**Fig. 3. Main Relief Valve**

remove spring and relief valve assembly which protrude from front face of main control valve after cover is removed. See Figure 3. Loosen hex locknut portion of relief valve and turn adjusting screw clockwise to increase pressure or counter-clockwise to decrease pressure. Each complete turn of adjusting screw changes setting approximately 1600 psi. Example: If pressure reading recorded in Step 9 was 1400 psi, 1/2 turn (clockwise) of adjusting screw would raise relief valve pressure to 2200 psi. After adjusting, tighten locknut.


14. Reinstall relief valve assembly and spring in position in main valve assembly. **IMPORTANT:** Adjusting screw and locknut portion of relief valve must be toward outside of valve.
15. Reinstall cover using two bolts in diagonally opposite holes in cover. Springs under cover must be compressed to start bolts into hole threads. Turn bolts finger tight. Using a torque wrench with adapter for 3/8 inch Allen wrench, tighten all bolts to 60-75 ft. lbs. torque.

16. Place transmission directional and speed range levers in FORWARD, HI, actuate bucket control lever to full ROLLBACK position and accelerate to maximum rpm. Gauge should read 2200 psi.
17. With transmission directional lever in NEUTRAL, feather boom control lever to the DOWN PRESSURE position, maintaining low idle rpm. Gauge should read 1750 to 2200 psi. If reading is not as specified, replace down pressure relief valve cartridge. (Item 3 Figure 1).
18. With transmission directional lever in NEUTRAL, actuate bucket control lever to the full DUMP position, maintaining low idle rpm. Gauge should read 1750 to 2200 psi. If reading is not as specified, replace bucket dump relief valve cartridge. (Item 4 Figure 1).

**IMPORTANT: OVERLOAD RELIEF VALVES ARE PRESET AND SEALED AT THE FACTORY. DO NOT BREAK THE SEAL. IF THE SEAL IS BROKEN, REPLACE RELIEF VALVE CARTRIDGE IMMEDIATELY. ADJUSTMENTS ARE TO BE MADE ONLY ON THE MAIN RELIEF.**


**Check and Adjust Main Hydraulic Pump:** The main hydraulic pump is a double pump, consisting of a primary section and a secondary section. At lower pressures, up to by-pass pressure setting, both sections supply the main hydraulic system. From by-pass pressure setting up to system relief, the pressure sensitive valve attached to the pump causes the secondary section to unload by-passing back to the suction side, leaving the primary section to supply the system.

Maintenance consists of periodically checking, and adjusting if necessary, the pressure at which the secondary section of the pump unloads and by-passes.



- |                 |                   |
|-----------------|-------------------|
| 1. Primary Port | 2. Secondary Port |
|-----------------|-------------------|
- Fig. 4. Main Hydraulic Pump Pressure Ports**





1. Acorn Nut

**Fig. 5. Main Hydraulic Pump Adjustment**

1. Attach safety links and apply parking brake.
2. Install two 3000 psi capacity gauges, one at the pressure port on the primary section and one at the pressure port on the secondary section of the main pump as shown in Figure 4, Items 1 & 2.
3. With transmission directional shift lever in neutral, start engine and follow normal warm up procedure.
4. Actuate boom control lever to the lift position, maintaining low idle rpm. Raise boom to stop, feathering lever as boom approaches stop. Observe both gauges. As pressure increases, the gauge attached to the secondary section of the pump will indicate a sudden drop-off in pressure. The highest pressure indicated is the unloading pressure.
5. Observe the indicated pressure on the gauge attached to the main hydraulic pressure port. When the unloading pressure is reached, this gauge should read as specified in Specifications and Service Data section at rear of manual.

If the secondary pump section does not unload at specified pressure, it will be necessary to adjust the pressure sensing valve on the main pump. Proceed with valve adjustment as follows:

1. Remove acorn nut and o-ring covering adjusting screw on pressure sensing valve. See Figure 5.
2. Actuate boom control lever to the raise position maintaining low idle rpm. Feather the lever as boom approaches stop, observing the pressure at which the secondary section unloads, then return lever to the neutral position.

3. Turn pressure adjusting screw in increments of  $\frac{1}{4}$  turn, clockwise to increase or counter-clockwise to decrease unloading pressure. Recheck unloading pressure as described in Step 2. Repeat this procedure until secondary section of main pump unloads at specified pressure.
4. Reinstall acorn nut and o-ring, then recheck the unloading pressure to be certain pressure setting was not disturbed while installing acorn nut and o-ring.
5. Shut down engine, remove gauges and detach safety links.

**Check Steering Pressure:** The steering hydraulic pump is coupled to the drive line and operates as soon as the engine is started. The pump draws fluid from the reservoir and forces it under pressure into the control valve mounted at the base of the steering gear.

Maintenance consists of periodically checking the pressure in the system.

**Note:** Remove safety links, if attached between front and rear frames.

**Warning:** Do not stand or work in step area(s) when machine is running — No room for a man in this area when machine is turned.

1. Use hydraulic pressure gauge of at least 3000 psi capacity. With engine shut down, install gauge line on quick release fitting on steer pump as shown in Figure 6, Item 1.
2. Start engine and accelerate to maximum rpm; then turn tractor to the right and hold against stops.
3. With the aid of a helper read gauge. Pressure reading should be as specified in Specifications and Service Data section at rear of this manual.

If pressure reading is not as specified, shut down engine, and inspect and check for collapsed or ruptured hoses, proper function of steering cylinder packing glands, defective steering pump or steering control valve.

If the above items are in satisfactory operating condition it will be necessary to adjust the steering pressure at the steering control valve.

1. Loosen locknut on steering control valve adjusting screw.



2. Turn tractor to extreme right or left and hold against stops.
3. With transmission in neutral, accelerate to maximum rpm.
4. Turn adjusting screw in increments of  $\frac{1}{4}$  revolution or less, clockwise to increase pressure or counter-clockwise to decrease pressure.
5. When pressure reading on gauge reaches that specified in Specifications and Service Data section at rear of this manual, tighten locknut, release throttle and steering wheel, shut down engine, remove gauge.


**Check and Adjust Steering Pump:** The steering pump is a double pump consisting of a primary section and a secondary section. From low idle to approximately 1600 rpm, both primary and secondary sections are supplying the steering system. From approximately 1600 to maximum rpm, the primary section continues to supply the steering system, but the secondary section by-passes.

Maintenance consists of periodically checking, and adjusting if necessary, the rpm at which the secondary steering pump section by-passes.

1. Install tachometer on engine.
2. Install two 3000 psi capacity gauges, one at the steering pump primary section port, and one at the secondary section port. See Figure 6.
3. Remove safety links if attached between frames.

**WARNING:** Do not stand or work in stop area(s) when engine is running. No room for a man in this area when machine is turned.

4. Start engine and maintain low idle rpm, turn steering against stops and hold. At this point, both gauges should read steering relief pressure or slightly below.
5. Accelerate engine rpm observing gauges and tachometer. Note the rpm at which the gauge attached to the secondary port indicates a large pressure drop off. At this point, tachometer should read approximately 1600 rpm.
6. Accelerate to maximum rpm with steering held against stops. The gauge attached to the primary port should read system relief pressure while the gauge attached to the secondary port indicates very little pressure.



1. Primary Port
2. Secondary Port
3. Acorn Nut

**Fig. 6. Steering Pump Pressure Port and Adjustment**

If secondary pump section does not show a pressure drop-off at approximately 1600 rpm, it will be necessary to adjust the valve on the steering pump. Proceed with valve adjustment as follows.

1. Turn steering to extreme right or left and hold against stops. Accelerate to maximum rpm. The gauge attached to the primary section pressure port should read system relief pressure.
2. If gauge reading is not as specified, adjust main steering relief valve located at base of steering gear as described under 500 HOUR MAINTENANCE OPERATIONS.
3. With steering against stops, increase engine rpm slowly starting at low idle.
4. Carefully watching tachometer and pressure gauge attached to steer pump secondary pressure port, note the rpm at which pressure drop-off occurs.
5. Remove acorn nut and o-ring on steer pump valve. See Figure 6.
6. Turn adjusting screw clockwise to increase or counter-clockwise to decrease pressure drop-off rpm.
7. After correct setting has been obtained, reinstall acorn nut and o-ring. Recheck pressure drop-off rpm to be certain adjustment was not disturbed while installing acorn nut and o-ring.
8. Shut down engine, remove gauges and tachometer.





CONSTRUCTION MACHINERY DIVISION



MODEL	175B G.M.	175B Cummins	275B Cummins
<b>*PRESSURES —</b>			
Engine Oil:			
Low Idle (minimum) .....	12 psi	12 psi	12 psi
Gov. RPM (approximate) .....	45 psi	40 psi	40 psi
Air Compressor .....	95-110 psi	95-110 psi	120 psi
Main Hydraulic System — (At engine stall rpm with one set of cylinders against stops.) .....	2200 psi	2200 psi	2200 psi
Main Hydraulic Pump — (Secondary section by- pass pressure.) .....	1700 psi	1700 psi	1800 psi
Steering Hydraulic Pressure — (At maximum rpm with tractor halves against stops.) .....	1650 psi	1650 psi	1800 psi
Steering Hydraulic Pump — (Secondary section by-pass rpm.) .....	1600 rpm	1600 rpm	1600 rpm
Transmission Clutches — (At idle rpm in all speed ranges, both forward and reverse.) ...	180 min./ 220 max. psi	180 min./ 220 max. psi	180 min./ 220 max. psi
Transmission Lubricating — (Maximum at max- imum rpm.) .....	25 psi	25 psi	25 psi

\*Note: All hydraulic pressure checks should be made with converter oil at operating temperature, approximately 180°F. to 200°F, and hydraulic system oil at 150°F. minimum.

**FUEL SPECS — (All Models)**

Fuel Oil ..... No. 2 Diesel, Cetane 40 minimum.

# CLARK

## OPERATORS MANUAL SUPPLEMENT

No. 3135

*Applicable to all Models Equipped with Aerofiner and Air Line Filter*

**SUBJECT:** Service Instructions for Aerofiner and Air Line Filter Assembly

**(A) AEROFINER OPERATION:**

In normal operation, air passes through the space between the desiccant canister and the outer shell, cooling in the process. The water and oil droplets that condense, drop to the bottom sump of the container as the air makes a 180° turn. The air then passes through the oil separator which removes dirt particles, oil and water mist. The air continues upward through the desiccant bed where it is exposed to the immense surface area of the desiccant which has a tremendous attraction for water molecules. Moisture is removed from the air without the need for further condensation. As the air continues to pass through the drying bed it is exposed to drier desiccant and its moisture content is reduced until the air is almost without moisture.

At the top of the unit, the air flows through the outlet and discharge line into the air reservoir. At this point, the air is so dry that its temperature can drop considerably before condensation can occur. See Figure 1 for air flow diagram, and Figure 2 for purge valve operation.



**COMPRESSOR LOADED**




Figure 1.

When the system reaches governor cutout pressure, air pressure from the unloader line enters the expulsion valve and moves the plunger off its seat. The sudden opening of the valve permits the pressurized air in the drier and connecting lines to flow through the desiccant in a reverse direction.

**COMPRESSOR UNLOADED**





Figure 2.

The sudden decompression of the drying bed removes moisture from the pores of the desiccant. By this rapid decompression, oil, particles and moisture are exhausted from the sump through the purge valve. The pressurized air is very efficient in removing water on its reverse flow through the desiccant bed. If the purge cycle continues beyond the time required to decompress, no further action takes place. When air compression resumes, the unloader line is exhausted, the purge valve plunger reseats, and the drying process is resumed.




## (B) AEROFINER SERVICE INSTRUCTIONS:

NOTE: Before servicing, bleed air system to zero psi.  
EVERY 1000 OPERATING HOURS




**2510803  
DESICCANT  
REFILL KIT**



### STEP 1


To remove the cap, first release the pressure from the unit by loosening the hose fitting from the port adapter at the inlet or outlet. Then remove the top retaining nuts with a  $\frac{1}{8}$ " end wrench. Next, remove the cap and bypass spring.



### STEP 2

Using the bail, remove the canister from the Aerofiner housing. It may be necessary to loosen the canister from the housing by using a twisting back and forth motion while pulling upwards.

NOTE: During reassembly, rotate the canister while inserting and make sure the canister O-ring seats below the housing shoulder.




### STEP 3

**CAUTION — DO NOT REMOVE TOP SCREEN**

Invert the canister and, with a small screwdriver, release and remove the retaining ring. Then while the canister is still inverted, remove screen number one and the oil separator.

NOTE: During reassembly, make sure the oil separator pad is pushed below the snap ring groove.




### STEP 4

Using a small screwdriver, release and remove the next retaining ring from the center post.

**CAUTION:** Screen is under spring tension. Hold screen down with vise grips or a similar tool, clamping on the outer canister wall in the vertical position while depressing the screen.


### STEP 5

Remove number two screen and desiccant retaining spring.




### STEP 6

Tip canister over a receptacle and remove screen number three, allowing desiccant to flow out.




### STEP 7

Clean all components before reassembly. Then pour new pre-measured desiccant into canister. Jar desiccant canister to settle the desiccant. Reassemble in reverse order, replacing all O-rings with the new O-rings included in the replacement kit. Lubricate all O-rings before inserting canister in housing.




### 961419 Canister Replacement Kit

For large volume users, a complete canister kit is available as a spare. Follow steps 1 and 2 as described above and install in the body in reverse order. Retrieved container can be recharged using Kit Number 2510803 and following all steps described above. If the recharged canister is to be stored it should be sealed from the atmosphere in a plastic bag.





# Purge Valve Service Instructions



- A. Included in 2510803
- B. Included in 2510803
- C. 25K-30018
- D. 961488
- E. 25K-20112
- F. 961425
- G. 961489
- H. 961423

- Gasket
- O-Ring
- O-Ring
- O-Ring
- O-Ring
- Spring
- "U" Cup
- Valve

1. Follow Step 1 and 2 from the basic Aerofiner Service Instructions on the preceding page.



2. To remove the center post assembly, turn the center post assembly counter-clockwise using a 5/8" box wrench. Care must be taken not to bend the shaft assembly from improper prying with the wrench.



3. Remove the purge valve and valve spring. Insert a screwdriver into the purge hole at the bottom center of the housing and push up. This will free the valve and valve spring. Remove the "U" cup seal from the valve body.

4. (Re-assembly) The inside of the valve body must be cleaned and free from scratches or burrs prior to re-assembly. Lubricate the new O-Ring and "U" cup. Place the "U" cup seal into the valve body with the "U" facing downward. Install O-Ring into the new valve and insert valve, stem down, into the valve body. Place the new spring on top of the valve.

5. (Re-assembly) Replace the two O-Rings, one on each end of the shaft assembly, and the gasket seal with the new ones. Insert shaft assembly into housing and thread together. Shaft is to be tightened wrench tight.

**CAUTION:** The housing is aluminum. Care must be taken not to cross thread the shaft assembly into the housing.



## (C) TROUBLESHOOTING:

PROBLEM	CAUSE	REMEDY
1. Purge air continually blows out the purge port while compressor is pumping.	1. Purge valve sticking open due to ice on valve seat (below freezing)	1. Warm purge valve to melt ice. If condition continues install heater.
	2. Purge valve held open by foreign particles on valve seat.	2. Insert screwdriver in ejector valve hole on bottom and lift valve to purge foreign article or dismantle and clean.
	3. Faulty governor.	3. Disconnect pilot line from governor. If leak stops and air is being expelled from governor line, problem is the governor.
	4. Damaged purge valve in Aerofiner or valve spring has taken set.	4. Disconnect purge valve line from governor. If leak continues, replace purge valve and spring in Aerofiner.
2. Leakage occurs while compressor is unloaded.		
	a) Continuous leakage.	1. Clean or replace check valve.
b) Pulsating leakage.	2. Governor malfunction.	2. Clean, rebuild or replace governor.
3. Continual on-off purge cycle.	1. No check valve at air reservoir inlet (#1 tank).	1. Install check valve.
	2. Air reservoir check valve faulty.	2. Replace check valve.
	3. Air reservoir drain cock open.	3. Close drain cock.
	4. Governor malfunction.	4. Check for continuous air leaks around compressor unloader valve with air system at maximum pressure. If cycling occurred when compressor was unloaded, check unloader valve for bypass leakage. Also check governor for hi-low limits.

PROBLEM	CAUSE	REMEDY
3. Continual on-off purge cycle (continued).	5. Unloader valve (on compressor).	5. Check for continuous air leaks around compressor unloader valve with air system at maximum pressure.
4. Aerofiner not purging or cycling.	1. Faulty governor.  2. Aerofiner purge valve line hooked up to wrong port on governor or on Aerofiner.  3. Purge line plugged.	1. If below freezing, governor may be frozen. Warm governor to melt ice.  2. Check piping. Purge valve line must go from the "air" port on the Aerofiner to an "unloaded" port on the governor. (See governor data sheet attached).  3. Remove purge line and inspect for blockage.
5. Large amount of water in air reservoir (#1 tank).	1. Aerofiner in by-pass mode due to: a) Road shock.  b) Canister and desiccant plugged.  Desiccant saturated with water.	a) Remove Aerofiner cap. Check to see if canister "O" ring is above housing seat. Reseat canister and re-install cap. If unit does not have canister brace, install brace before replacing cap. b) Disassemble canister, clean and re-charge with desiccant replacement kit, or replace canister with new canister.  Not enough cooling of air — use longer line between compressor and Aerofiner.



## (D) AIR LINE FILTER SERVICE INSTRUCTIONS:

### EVERY 10 OPERATING HOURS

Before each work shift, check the air line filter service indicator, see Figure 3. Located on top of the filter unit, a yellow caution signal pops into view when the filter element is plugged. This signal remains up even when the air supply is turned off. Reset the caution signal after servicing the filter element.

1. Bleed off all air pressure.
2. Loosen bayonet type clamp ring.
3. Remove bowl.
4. Remove bronze filter element.
5. Clean filter element and bowl in solvent, air dry and reinstall.
6. Re-set service indicator.




Figure 3.

**CLARK**

**OPERATORS MANUAL SUPPLEMENT**

**No. 3199**

**MODEL 275B  
TRACTOR SHOVEL**


**FOR MACHINE SERIAL NUMBERS**

**G.M. — 479A**

**CUMMINS — 425D**

**Use this Supplement with Operators Manual No. 2653  
and existing supplements.**





TS-20258

Fig. 1. Left Hand Instrument Panel



## INSTRUMENTS AND SWITCHES

Instruments and switches are located on the left hand and right hand instrument panels, except the foot operated horn switch. The horn switch is located on the left side of the front floorboard.

Watch the gauges and warning lights while you operate the machine. Do not operate the machine if gauges and warning lights do not work correctly.

### LEFT HAND INSTRUMENT PANEL

**Air Pressure Gauge:** Indicates pressure in air reservoir for brake operation. The gauge should indicate in the green area when the machine is in operation. When gauge indicates in the green area, 95 to 120 psi is available for brake operation.

**Water Temperature Gauge:** Indicates temperature of the engine coolant. Under normal operating conditions, the gauge will indicate in the green area. An indication in the red area is a warning that the coolant is at or near the boiling point. When this happens, reduce engine speed to low idle rpm and carefully add water to the cooling system. As the temperature lowers, shut down the engine and find the cause of the overheating.

**Voltmeter:** Indicates the condition of the batteries. When the ignition switch is in the ON position, the voltmeter will indicate the voltage available from the batteries. A reading in the black and white area indicates the battery voltage is low. A reading in the green area indicates that the batteries are fully charged. When the engine is running, a reading in the red area indicates overcharging. Follow normal procedure for electrical troubleshooting of the voltage regulator.

**Engine Oil Pressure Gauge:** Indicates oil pressure in the engine lubrication system. A reading in the green area indicates normal oil pressure. A reading in the red area is a warning of low oil pressure. Find the cause of low oil pressure immediately. If the gauge does not show oil pressure within 10 to 15 seconds of the time that the engine is started, stop the engine and find the cause.

**Converter Oil Temperature Gauge:** Indicates the temperature of the fluid in the converter. When the indicator reaches the red part of the gauge, shift to a lower speed range. During normal operation, the indicator will be in the green area of the gauge.

**Hourmeter:** Indicates the total hours of machine operation. The hourmeter keeps a record of operating hours for preventive maintenance.

**Air Pressure Warning Light:** Becomes illuminated when the air pressure is low. Check the system for the cause of low oil pressure.

**Parking Brake Warning Light:** Becomes illuminated when the parking brake is engaged and the ignition switch is in the ON position. Release the parking brake before you move the machine.

**Test Switch:** Checks the operation of the warning lights. With the ignition switch in the ON position, push the button of the switch to check the warning lights.

**Ether Start Button:** When the temperature is below 50°F. (10°C), use the ether start button when you start a cold engine. With all control levers in the NEUTRAL position, do the following:

1. Turn the key in the ignition switch to the ON position.
2. Push the ether start button for one second and release.
3. Wait two seconds and turn the key to the START position. When the engine starts, release the key.
4. Below 0°F. (-18°C), repeat steps 1 & 2.

**CAUTION: USE ONLY FOR STARTING.**

**Boom Detent Switch:** Controls the operation of the solenoid for the boom kickout. Push the switch to the ON position to activate the solenoid for the boom kickout. Push the switch to the OFF position to deactivate the solenoid.



## RIGHT HAND INSTRUMENT PANEL


**Ignition Switch:** Energizes the gauges, switches and starting motor. Actuates starting motor when key is turned all the way to the right.

**Light Switch:** Pull switch out to the first position to operate headlamps and tail lights. Pull the switch out to the second position to operate the back-up lights.

**Circuit Breakers:** Give protection for the electrical circuits. To reset a circuit breaker, push the button. The following circuit breakers are used.

Main .....	70 A
Windshield Wiper .....	10 A
Lights .....	10 A
Tractor Electrical System .....	10 A
Warning Lights and Gauges .....	2 A
Bucket Leveler .....	1 A

If a circuit breaker is activated each time you use that circuit, check that circuit immediately.




TS-20259

Fig. 2. Right Hand Instrument Panel




## SERVICE DAILY (Every 8 Operating Hours)



**Fig. 3. Remote Grease Fittings for Axle Cradle Bushings and Rear Steering Cylinder Bushings**

Add lubricant to axle cradle bushings and rear steering cylinder bushings. Use the remote grease fittings shown in Figure 3.




**Fig. 4. Hydraulic Reservoir Sight Glass**

Check the oil level daily or before each work shift. Make sure you follow this procedure.

1. Machine must be LEVEL.
2. Bucket must be on GROUND.
3. Engine must be STOPPED.
4. Check the oil level at the SIGHT GLASS. Add oil as needed.


Make sure that the area around the filler cap for the reservoir is clean before you remove the cap.

## EVERY 500 OPERATING HOURS



**Fig. 5. Cooler IN and Cooler OUT Pressure Ports**

**Check Cooler IN and Cooler OUT Pressures:** Check the pressure at 2000 rpm. Subtract the cooler OUT pressure from the cooler IN pressure. If the difference between cooler IN and cooler OUT pressures is more than 30 psi (2,1 kg/cm<sup>2</sup>) or (294,2 kPa), the cooler has a restriction. If the cooler has a restriction, the cooler must be cleaned or replaced immediately.



**Fig. 6. Main Hydraulic, Transmission Clutch and Steering Pressure Ports**


**Check the Transmission Clutch Pressure:** Make sure that the fluid is at operating temperature, 180-200°F. (82-94°C).

Put blocks in front of and behind the wheels. Engage the parking brake.

1. Check the clutch pressure at low idle in all speed ranges in FORWARD and REVERSE.
2. The clutch pressure specification is 180-220 psi (1241-1517 kPa) or (12,7-15,5 kg/cm<sup>2</sup>).
3. Maximum clutch pressure variation is 5 psi (49 kPa) or (0,4 kg/cm<sup>2</sup>).



## EVERY 500 OPERATING HOURS



**Fig. 7. Main Hydraulic Transmission Clutch and Steering Pressure Ports**

**Check the Main Hydraulic Pressure:** Make sure that the torque converter oil temperature is 180-200°F. (82-94°C), and the main hydraulic oil temperature is approximately 150°F. (66°C).

Check the main hydraulic pressure under the following conditions.

1. Transmission FORWARD and REVERSE control lever in NEUTRAL position.
2. Engine at maximum rpm.

3. Put the bucket control lever in the full ROLLBACK position.
4. When the engine rpm decreases to its lowest point, check your gauge.
5. Main hydraulic pressure specification is 2200 ± 50 psi (154 ± 3,5 kg/cm<sup>2</sup>) or (15167 ± 345 kPa).
6. If the pressure is not within specifications, adjust the main relief valve.

**Check the Steering Hydraulic Pressure:** Make sure that the torque converter oil temperature is 180-200°F. (82-94°C), and the main hydraulic oil temperature is approximately 150°F. (66°C).

Check the steering hydraulic pressure under the following conditions:

1. Safety link disconnected.
2. Transmission FORWARD and REVERSE control lever in NEUTRAL position.
3. Engine at low idle rpm.
4. Tractor sections turned against the stops.
5. Steering hydraulic pressure specification is 1600 psi (112 kg/cm<sup>2</sup>) or (15691 kPa).
6. If the pressure is not within specification, adjust the steering relief valve.


## ENGINE AND ELECTRICAL SPECIFICATIONS

ENGINE	275B	275B
Make .....	G.M.	Cummins
Model .....	8V-92T	NTA-855-C
Number of cylinders .....	8	6
Bore in inches (mm) .....	4.84 (123)	5.50 (140)
Stroke in inches (mm) .....	5.00 (127)	6.00 (152)
Displacement in cubic inches (L) .....	736 (12)	855 (14)
Maximum Torque in pound force feet (N·m) .....	1060 (1437)	960 (1302)
@ RPM .....	1400	1650
Net Horsepower (kW) .....	344 (257)	342 (255)
Governed RPM .....	2300	2300
Low Idle RPM .....	650-750	650-750
High Idle RPM .....	2400-2500	2400-2500
*Stall RPM .....	2000	2000

\*Note: Stall rpm is the maximum rpm with converter oil temperature 180-200°F. (82-94°C), the parking brake actuated, the transmission control levers in FORWARD and FOURTH (HI), and the bucket in the full ROLLBACK position. The stall rpm shown is for 600 ft. (182.9 m) above sea level and a temperature of 70°F. (21°C). Check with the distributor of the engine manufacturer for corrections to the stall rpm needed for altitude and temperature in your application.

MODEL ELECTRICAL SYSTEM	275B G.M.	275B Cummins
<b>Circuit Breakers</b>		
Main .....	70 A	70 A
Windshield Wiper .....	10 A	10 A
Lights .....	10 A	10 A
Tractor Electrical System .....	10 A	10 A
Warning Lights and Gauges .....	2 A	2 A
Bucket Leveler .....	1 A	1 A
<b>Instruments</b>		
Gauges .....	12V	12V
Sender Units .....	12V	12V
<b>Lamps</b>		
Back Up .....	24V, 60 W	24V, 60 W
Tail and Stop .....	24V, 32/6 Cd	24V, 32/6 Cd
Head .....	24V, 60 W	24V, 60 W
Alternator .....	24V, 50 A	24V, 75 A
Starting Motor .....	24V	24V
<b>Batteries:</b>		
Clark Part No. ....	1671369	1671369
Number and Voltage .....	2 x 24V	2 x 24V
System Voltage .....	24V	24V
Ground .....	Negative	Negative
Specific Gravity .....	1.230-1.260	1.230-1.260





# **CLARK**

## **≡≡≡ OPERATORS MANUAL SUPPLEMENT ≡≡≡**

**No. 3204**

### **MODEL 275B TRACTOR SHOVEL**

**FOR MACHINE SERIAL NUMBERS**

**CUMMINS — 482A**

**Use this Supplement with Operators Manual No. 2653  
and existing supplements.**



## RIGHT HAND INSTRUMENT PANEL


**Ignition Switch:** Energizes the gauges, switches and starting motor. The ignition switch actuates the starting motor when the key is turned all the way to the right.

**Light Switch:** Pull the switch handle out to operate the headlamps and tail lights. Pull the switch out to the second position to operate the back-up lights.

**Circuit Breakers:** Give protection for the electrical circuits. To reset a circuit breaker, push the button. The following circuit breakers are used.

Main .....	70A
Windshield Wiper .....	20A
Lights .....	20A
Tractor Electrical System .....	10A
Warning Lights, Gauges and Bucket Leveler .....	2A

If a circuit breaker is activated each time that you use the circuit, check that circuit for the cause immediately.



TS-20288

Figure 1. Right Hand Instrument Panel

**FLUID CAPACITY SPECIFICATIONS****MODEL  
CAPACITIES (Approximate)****275B  
Cummins**

## U.S. MEASURE (Gallons)

Engine Crankcase and System .....	11
Cooling System .....	21
Axle Differential (Each) .....	9
Planetary Hubs (Each) .....	3
Fuel Tank .....	165
Hydraulic System .....	192
Torque Converter and Transmission .....	15.5
Midmount Bearing .....	1.4

## METRIC MEASURE (Liters)

Engine Crankcase and System .....	41,6
Cooling System .....	79,5
Axle Differential (Each) .....	34,1
Planetary Hubs (Each) .....	11,6
Fuel Tank .....	624,5
Hydraulic System .....	728,0
Torque Converter and Transmission .....	58,7
Midmount Bearing .....	4,2

**FUEL SPECIFICATIONS**

Fuel Oil ..... No. 2 Diesel, Cetane 40 minimum.



**BOLT TORQUE SPECIFICATIONS**

<b>LOCATION</b>	<b>Thread Diameter</b>	<b>lbf·ft</b>	<b>Torque N·m</b>	<b>kgf·m</b>
Axle Mounting Bolts	1.500	2200	2983	304
Bucket Cylinder Cap	.875	475—525	644—712	66—73
Converter Drive Gear	.375	45	61	6
Converter Filter Cartridge — AC Units		45—55	61—75	6—8
Converter Housing Mounting	.4375	40—45	54—61	5—6
Engine Support to Flywheel Housing	.625	125—140	169—190	17—19
Engine Support to Frame	.625	115—145	156—197	16—20
Engine Trunnion Mounting	.625	115—145	156—197	16—20
Prop Shaft — Upper	.500	90—100	122—136	12—14
Prop Shaft — Lower Rear	.500	65—75	88—102	9—10
Prop Shaft — Lower Center & Front	.500	65—75	88—102	9—10
Tractor Pivot	1.500	2200	2983	304
Transmission Bracket to Frame	1.000	228—285	309—386	32—39
Transmission to Bracket	1.000	725—800	983—1085	100—111
Wheel Nuts (Wet)	.875	425—525	576—712	59—73

**ENGINE AND ELECTRICAL SPECIFICATIONS**

**ENGINE**

**275B**

Make .....	Cummins
Model .....	KT-1150-C
Number of cylinders .....	6
Bore in inches (mm) .....	6.25 (158,8)
Stroke in inches (mm) .....	6.25 (158,8)
Displacement in cubic inches (L) .....	1150 (18,6)
Maximum torque in pounds force feet (N•m) .....	1350 (1830)
@ RPM .....	1500
Net Horsepower (kW) .....	360 (268)
Governed RPM .....	2100
Low Idle RPM .....	700±50
High Idle RPM .....	2310
*Stall RPM .....	2000

\*Note: Stall rpm is the maximum rpm with torque converter oil temperature 180-200°F. (82-94°C), the parking brake actuated, the transmission control levers in FORWARD and FOURTH (HI) and the bucket in the full ROLLBACK position. The stall rpm shown is for 600 ft. (182,9 m) above sea level and a temperature of 70°F. (21°C). Check with the distributor of the engine manufacturer for corrections to the stall rpm needed for altitude and temperature in your area of operation.

**MODEL**

**275B  
Cummins**

**ELECTRICAL SYSTEM**

**Circuit Breakers:**

Main .....	70A
Windshield Wiper .....	20A
Lights .....	20A
Tractor Electrical System .....	10A
Warning Lights, Gauges and Bucket Leveler .....	2A

**Instruments:**

Gauges .....	12V
Sender Units .....	12V

**Lamps:**

Back Up .....	24V, 60W
Tail and Stop .....	24V, 32/6 Cd
Head .....	24V, 60W
Alternator .....	24V, 75A
Starting Motor .....	24V

**Batteries:**

Clark Part No. ....	1671369
Number and Voltage .....	2 x 24V
System Voltage .....	24V
Ground .....	Negative
Specific Gravity .....	1.230-1.260



**PRESSURE SPECIFICATIONS**

<b>MODEL</b>	<b>275B Cummins</b>	
<b>*PRESSURES —</b>		
Engine Oil At 1000 RPM .....	PSI 12	kPa 82
Main Hydraulic System — At maximum rpm with one set of cylinders against stops .....	2125-2325	14651-16030
Steering Hydraulic System — At low idle rpm with tractor halves against stops .....	1800±50	12410±345
Transmission Clutches — At low idle rpm in all speed ranges, both forward and reverse. No more than 5 PSI (34 kPa) difference from one clutch to another .....	180-220	1241-1517
Transmission Lubrication — At maximum RPM .....	25	172
Main Hydraulic Pump — Secondary section by-pass pressure .....	1800±50	12410±345
Steering Hydraulic Pump — Secondary section by-pass rpm .....	1600	11032
Air Compressor .....	120	827

**TIRE SPECIFICATIONS**


MODEL	SIZE	PLY RATING	INFLATION		TYPE
			PSI	kPa	
275B	29.5-29	22	55	379	L-2
275B	29.5-29	22	55	379	L-3
275B	29.5-29	22	55	379	L-4
275B	29.5-29	22	55	379	L-5

★                      ★                      ★                      ★

**LIQUID BALLAST (HYDROINFLATION) SPECIFICATIONS**

TIRE SIZE	CALCIUM CHLORIDE		WATER		TOTAL SOLUTION		WEIGHT INCREASE EACH TIRE	
	POUNDS	KILOGRAMS	GALLONS	LITERS	GALLONS	LITERS	POUNDS	KILOGRAMS
29.5-29	675	306	194	734	226	856	2300	1043

The solution shown in the table above gives protection against freezing at temperatures of  $-30^{\circ}\text{F}$ . ( $-35^{\circ}\text{C}$ ) and above. Use a battery hydrometer to check the solution. At a temperature of  $60^{\circ}\text{F}$ . ( $15^{\circ}\text{C}$ ) the hydrometer reading will be 1218. If you do not use the optional counterweight, use liquid ballast in the rear tires.



# CLARK

## OPERATORS MANUAL SUPPLEMENT

No. 3219

This Supplement Voids OMS 2991 and OMS 3205.

SUBJECT: Service Interval for Main Hydraulic System.

Applicable to: All models of tractor shovels and dozers.

**First filter change for all new machines: Replace the filter assembly after the first 50 Hours of operation.**

Service Interval for Machines with 15 Micron Filter Assemblies:  
Replace filter assembly every 250 hours. Drain, clean and refill the main hydraulic system every 1000 operating hours.

**Service Interval for Machines with 10 Micron filter Assemblies:  
Replace filter assembly every 500 hours. Drain, clean and refill the main hydraulic system every 2000 operating hours.\***

\*NOTE: The oil change interval may be more than 2000 operating hours if indicated by analysis of a regular oil sampling program conducted by a reputable oil company or an independent laboratory.



# CLARK

The 10 micron return filter assemblies were installed on machines shipped from the factory with the following serial numbers:

55B — 433B585FSC & after, 433B801CAC & after, 416C245FSC & after, and 416C1086CAC & after.

75B — 447C115CB & after, 447C112FSC & after, 447C277CAC & after, 443C113CB & after, 443C160FSC & after, and 443C166CAC & after.

125B — 441B335CB & after, 441B101FSC & after, 441266CAC & after, 439B322CB & after, 439B171FSC & after, and 439B195CAC & after.

175B — 438C316C & after, 438C156FSC & after, 438C256CAC & after, 427C308C & after, 427C115FSC & after, and 427C236CAC & after.

275B — 425C514C & after, 425C223FSC & after, and 425C521CAC & after.

475B — 421H224C & after, and 421J128CAC & after.

675B — All.

280-IIIA — 460C143C & after, 460B117FSC & after, and 546B174C & after.

380-IIIA — 434B112K & after, and 418E128K & after.

## IDENTIFICATION OF FILTER ASSEMBLIES:

You can identify a 10 micron filter assembly (Part Number 2515079) from a 15 micron filter assembly (Part Number 1530600). See Figure 1 for identification.




Figure 1. End View of Filter Assembly

Refer to CLARK MICHIGAN Service Gram SG-750 for information on installing the 10 micron filter on machines prior to the above serial numbers.

# **CLARK**

## **OPERATORS MANUAL SUPPLEMENT**

**No. 3247**

**SUBJECT: Aerofiner Air Dryer Service Instructions  
(Optional Equipment)**

**Models 45B, 55B, 75B, 125B and 175B Tractor Shovels**


This supplement gives servicing instructions for machines listed above using the Aerofiner Air Dryer.

Follow the service procedure on page 2 every 500 operating hours.

**CLARK EQUIPMENT COMPANY**




## Service Instructions



**2510803  
DESICCANT  
REFILL KIT**

### STEP 5

Remove number two screen and desiccant retaining spring.





### STEP 6

Tip canister over a receptacle and remove screen number three, allowing desiccant to flow out.




### STEP 7

Clean all components before reassembly. Then pour new pre-measured desiccant into canister. Jar desiccant canister to settle the desiccant. Reassemble in reverse order, replacing all O-rings with the new O-rings included in the replacement kit. Lubricate all O-rings before inserting canister in housing.



### STEP 1


To remove the cap, first release the pressure from the unit by loosening the hose fitting from the port adapter at the inlet or outlet. Then remove the top retaining nuts with a  $\frac{1}{8}$ " end wrench. Next, remove the cap and bypass spring.



### STEP 2

Using the bail, remove the canister from the Aerofiner housing. It may be necessary to loosen the canister from the housing by using a twisting back and forth motion while pulling upwards.

Note: During reassembly, rotate the canister while inserting and make sure the canister O-ring seats below the housing shoulder.



### STEP 3

#### CAUTION — DO NOT REMOVE TOP SCREEN

Invert the canister and, with a small screwdriver, release and remove the retaining ring. Then while the canister is still inverted, remove screen number one and the oil separator.


Note: During reassembly, make sure the oil separator pad is pushed below the snap ring groove.



### STEP 4

Using a small screwdriver, release and remove the next retaining ring from the center post.

Caution: Screen is under spring tension. Hold screen down with vise grips or a similar tool, clamping on the outer canister wall in the vertical position while depressing the screen.



### 961419 Canister Replacement Kit

For large volume users, a complete canister kit is available as a spare. Follow steps 1 and 2 as described above and install in the body in reverse order. Retrieved container can be recharged using Kit Number 2510803 and following all steps described above. If the recharged canister is to be stored it should be sealed from the atmosphere in a plastic bag.

# CLARK

## OPERATORS MANUAL SUPPLEMENT

No. 3270

★

**SUBJECT: Hydraulic System Hose Maintenance  
All Models of Wheel Loaders and Dozers**

★

**Proper hydraulic system hose installation and maintenance is very important for safe machine operation.**

**Follow the correct inspection and installation procedure of the hydraulic system hoses as shown on page 2 of this supplement.**

**CLARK EQUIPMENT COMPANY**



## HYDRAULIC HOSE MAINTENANCE



**WARNING:** Improper selection, installation, or maintenance may result in premature failures, bodily injury, or property damage.

Hose (also includes hose assemblies) has a finite life and there are a number of factors which will reduce its life.

**INSPECTION:** Inspect all hose daily. Any of the following conditions requires replacement of the hose:

1. Leaks at fitting or in hose (leaking fluid is a fire hazard)
2. Damaged, cut or abraded cover (any reinforcement exposed)
3. Kinked, crushed, flattened, or twisted hose
4. Hard, stiff, heat cracked, or charred hose
5. Blistered, soft, degraded, or loose cover
6. Cracked, damaged, or badly corroded fittings
7. Fitting slippage on hose

The following items must be tightened, repaired, or replaced as required:

1. Leaking port conditions
2. Clamps, guards, shields
3. Remove excessive dirt buildup.
4. System fluid level, fluid type, and any air entrapment

Every 2000 hours or yearly, clean hose completely and inspect and replace as listed above.

**INSTALLATION:** Use only CLARK - approved parts as listed in the applicable Parts Manual. Use of "will-fit" or non approved parts may cause premature failures, bodily injury, or property damage.

Use proper hose; install so that relative motion of machine components produces bending rather than twisting. Replace all clamps and other restraints used on previous installation. Install port connection so that no twist or torque is put into the hose. Correct or eliminate all tensile loads, side loads, kinking, flattening, potential abrasion, thread damage, or damage to sealing surfaces.

After completing the installation, all air entrapment must be eliminated and the system pressurized to the maximum pressure and checked for proper function and freedom from leaks.



**WARNING:** Avoid potential hazardous areas while testing.

**REPLACEMENT:** Specific replacement intervals must be considered based on previous service life or when failures could result in downtime, damage, or injury risk.

---

**CLARK**

**OPERATORS**  
**MANUAL**  
**SUPPLEMENT**

---

**PUBLICATION**  
**NO. 3312**

**SUBJECT:** REVISED Service Intervals

**APPLICABLE TO:** ALL Wheel Loaders



	Old Interval	New Interval
<b>ENGINE</b>		
Check Air Cleaner Connections	50	250
Check Belts (tightness condition) (added: Check tightness of new belts at 5 and 10 hours of operation)	50	250
Check Engine R.P.M.	250	1000
Change Coolant ,Flush System (added: and check coolant Protection)	1000	yearly
Check Air Cleaner Service Indicator	10	no change
Service Air Cleaner	as required	no change
Steam Clean Radiator	500	500 or as required
Check Oil Level	10	no change
Check Coolant Level	10	no change
Check Throttle Adjustment	250	removed
Adjust Throttle Linkage	as required	removed
Check Coolant Protection	250	removed
Check Fuel Shut Off Control	500	removed
Check Emergency (Air) Shut Off Control (if used)	500	no change
<b>TRANSMISSION AND TORQUE CONVERTER</b>		
Added: Clean Transmission Sump Screen	--	1000
Change Filter Elements	1st 50,1st 100,500	no change
Clean Cooler Line Strainer	1st 50,1st 100,500	no change
Check Transmission Control Lever Adjustment	500	removed
Adjust Transmission Control Levers	as required	removed
Clean Breathers	250	500
Change Fluid	1000	no change
Check Fluid Level	10	no change
Check Clutch, Lube, Converter In and Out, and Cooler In and Out Pressures	500	no change
<b>MID - MOUNT BEARING</b>		
Check Fluid Level	50	1000
Clean Breather	250	500
Change Fluid	1000	2000
<b>AXLES</b>		
Check Lube Levels	50	500
Clean Breather	250	500
Change Lube (Differential and Planetary)	1000	yearly
<b>FUEL SYSTEM</b>		
Check Fuel Level (Shown in Operators Manual only)	10	10
Drain Sediment from Tank	50	yearly
<b>ELECTRICAL</b>		
Added: Check Battery Cables and Connections	--	10
Check Electical Connections	10	yearly
Check Battery Electrolyte Level, (added: If Applicable)	50	250
Check Battery Specific Gravity (change Specific Gravity to Condition)	50	250



## HYDRAULIC SYSTEM

	Old Interval	New Interval
Check Fluid Level	10	no change
Clean and Check Cylinder Rods	50	removed
Change Fluid	2000	no change
Change Hydraulic Return Filter Elements (10 Micron Filters)	1st 50,500	1st 50,1000 (C Series) no change (A Series)
Check Control Valve Lever Adjustment	500	removed
Adjust Control Levers	as required	removed
Check Pressure	500	yearly
Check Hoses for Damage	10	no change
Clean and Completely Check Hoses	2000	no change
Clean Hydraulic Suction Filters, (added: If Applicable)	250	500
Check Cylinder Packing Glands	500	removed
Adjust Cylinder Packing Glands	as required	removed

## STEERING

Check Steering Gear Lube	250	yearly
Adjust Steering Gear	1000	yearly
Check Pressure	500	yearly
Adjust Pressure	as required	removed
Check Draglink Ball Joint Adjustment	500	1000
Adjust Draglink Ball Joints	as required	1000

## BRAKES

Check all Air Lines and Connections (changed to: check all Brake Lines, Connections and Components for Damage and Leaks)	10	no change
Check all Brakes for Proper Operation (Added: Adjust if required)	10	no change
Drain Water and Sediment from Tanks	50	10
Check Brake Linings (added: and Adjustment)	250	1st 100,500
Adjust Brakes	as required	removed
Check Brake Adjustment	1st 100,500	removed
Disassemble and Clean Air Dryer and Unloader Valve	500	250
Service Drain Valve on Air Tank (Service change to Check)	as required	500
Check Alcohol Level in Injector below 40 degrees F.	250	10
Check Parking Brake Adjustment	as required	removed
Check Brake Components for Leaks and Damage	10	removed
Added: Thorough Brake System Check	--	yearly

## WHEELS AND TIRES

Check Wheels and Tires for Damage (added: looseness and missing studs)	50	10
Tighten Lug Nuts (added: to correct torque. After wheel removal, check torque of lug nuts at 5 and 10 hours of operation)	50	500
Check Tire Pressure	10	50



	Old Interval	New Interval
<b>LUBRICATION</b>		
All Linkage Lube Points	--	no change
Propshafts	100	2000
Brake Anchor Pins	50	100
Brake Camshafts	50	100
Operators Seat Tracks	250	removed
Check Lube Level in Automatic Lube System	10	no change
Brake Pedal Pivot and Roller (changed to: Clean and Lube Brake Pedal Pivot and Roller)	100	no change
<b>GENERAL</b>		
Steam Clean Machine	500	yearly
Check Wiper Blade Condition	10	1000
Check Windshield Washer Fluid Level	10	as required
Check Cab Air Filter (changed to Check and Clean)	10	no change
Clean or Replace Cab Air Filter (removed: Clean or)	as required	no change
Check Rear ROPS Cab Mounting (change to Check ROPS and ROPS mounting)	250	1000
Added: Check Frame, C-Frame and Blade Linkage for Damage or wear	--	yearly
Check C-Frame and Linkage for Damage	10	removed
Tighten Engine, Transmission, Axle, etc. mounting bolts (added: Tank and Cockpit Mounting Bolts to Correct Torque)	250	1000
Check Hinge Bearing Clearance (changed to: Check Upper and Lower Hinge Bearings and Clearance)	250	no change
Adjust Hinge Bearing Clearance	as required	removed
Check all Instruments, Horn, Back-up Alarm, Lights, Neutral Start Switch, Secondary Steering, Heater and Air Conditioning	10	no change
Added: Check Steering Frame Lock for damage or wear	--	yearly
Added: Check Fan Shroud and Fan Guard for Damage	--	500
Added: Check Seat Belt and Seat Belt Mounts for Damage or Wear	--	yearly
Added: Recharge Accumulator	--	yearly

# CLARK

# OPERATORS MANUAL SUPPLEMENT

## PUBLICATION NO. 3292 (Supersedes No. 2938-R1)

**SUBJECT:** REVISED Lubricant Recommendations for  
Transmission & Converter Hydraulic System and  
Main & Steering Hydraulic System.

**APPLICABLE TO:** ALL Models of Wheel Loaders, Dozers &  
Scrapers

**NOTE:** The revised lubricant recommendations outlined  
herein supersede and replace all previous  
recommendations contained in Operators  
Manuals, Lube Charts, Operators Manual  
Supplements and Service Bulletins.



Hydraulic fluid that is clean and of the correct type is very important for efficient machine operation.

Cleanliness of the oil used and of the system cannot be overemphasized. Filters and breathers should be serviced regularly.

Lubricant changes for the different prevailing ambient temperature ranges specified should be made by complete drainage and refill.

Follow both fluid changes and filter service recommendations for the best performance and service.

**DO NOT USE FIRE RESISTANT FLUIDS IN ANY SYSTEM UNLESS YOU HAVE SPECIAL APPROVAL FROM CLARK ENGINEERING.**

**Main and Steering Hydraulic System:**

Ambient Temperature	Lubricant
0°F (-18°C) and Above	(1) Engine Oil - SD,SE,CC,CD (MIL-L-2104C or MIL-L-46152B) 10W
0°F (-18°C) and Below	(2) Conoco Polar Start DN-600 Fluid  Automatic Transmission Fluid (can be used only if it meets the following specifications:  (A) Contains the types and contents of anti-wear compounding found in API Class SD,SE,CC or CD engine oils or have passed pump tests similar to those used in developing anti-wear type hydraulic oils.  (B) Have enough chemical stability for mobile hydraulic system service.  (C) Meet the viscosity requirements of API Class SD,SE,CC or CD engine oil - Grade SAE 10W.
-30°F (-34°C) and Below	See Section titled Optional Lubricants

## OPTIONAL LUBRICANTS

The following optional lubricants, in addition to the standard recommendations given, are approved for use in the Main/Steering Hydraulic System.

### PREVAILING AMBIENT TEMPERATURE

-30°F (-34°C) and Below

### LUBRICANT TO BE USED

The following should be used as a guide in consultation with a reputable oil supplier. *Any lubricant may be used which meets the following requirements:*

1. Oil to be used must contain anti-wear properties and rust and oxidation inhibitors plus anti-foam agents equal to that found in API Class SD,SE,CC or CD engine oils or have passed pump tests similar to those used in developing anti-wear type hydraulic oils.
2. Oil must have a Saybolt Universal Viscosity of 145 to 225 seconds at 100°F (38°C) and a viscosity of not less than 42 seconds at operating temperature. The oil selected should have a high shear stability to insure that the viscosity remains within recommended limits. Viscosity Index should not be less than 90.
3. Have a pour point of 20°F (11°C) below start-up temperature.
4. Diesel fuel, kerosene, transformer oil, etc., *must not be used* to dilute normal fluids.

**NOTE:** *Lubricants to the above specifications may be used in prevailing ambient temperature range of -30°F (-34°C) and below in the Main/Steering Hydraulic System ONLY.*

Satisfactory OIL QUALITY is the responsibility of the oil supplier, therefore, the selection of a suitable lubricant should be made in consultation with a reputable oil supplier. **Strict observance of oil change recommendations and proper filter maintenance will provide the best assurance of satisfactory performance.**

### RECOMMENDED TRANSMISSION AND TORQUE CONVERTER FLUID CHANGE:

**CHECKING INTERVAL:** Check the fluid level DAILY with the engine operating at Low Idle RPM and fluid temperature at 180°F to 200°F (82°C to 93°C). Keep the fluid level at the FULL mark.

**\*DRAIN INTERVAL:** Change the filter element(s) every 500 hours. Drain and refill the system every 1000 hours.

- (1) Drain the transmission and remove the sump screen. Clean the screen thoroughly and replace it, using new gaskets.
- (2) Drain the oil filters, remove and discard the filter elements. Clean the filter element housings and install new elements.
- (3) Refill the transmission to the FULL mark on the dipstick or sight glass.
- (4) Start and operate the engine at Low Idle RPM to prime the converter and the lines.
- (5) Check the fluid level with the engine operating at Low Idle RPM and add fluid to bring the level to the FULL mark on the dipstick or sight glass. When the fluid temperature is 180°F to 200°F (82°C to 93°C) check the fluid level again to make sure it is still full.

See chart on next page for recommended fluids.

\*Interval change



LUBRICATION SPECIFICATIONS - TRANSMISSIONS AND TORQUE CONVERTERS

Ambient Temp	Non-Modulated Transmissions and Torque Converters	* Modulated 4000, 5000 and 8000 Series Transmissions	* Modulated 18000 and 28000 Series Transmissions
30 °F (- 1 °C) and Above	C-3 grade 30 Transmission Fluid	C-3 Grade 30 Transmission Fluid (Use when addition of fluid is necessary or for regular fluid changes)	C-3 Grade 30 Transmission Fluid
- 10 °F (- 23 °C) and Above	(1) Engine Oil - 10W CC, SD, SE, CD, (MIL-L-2104C or MIL-L-46152B) (2) Transmission Fluid (C-2 or C-3 Grade 10W)	C-3 Grade 10 Transmission Fluid Use when addition of fluid is necessary or for regular fluid changes)	C-3 Grade 10 Transmission Fluid
- 30 °F (- 34 °C) and Above	Automatic Transmission Fluid (can be used only if it meets the following specifications: (A) Contains the types and content of Anti-wear compounding found in API Class SD, SE, CC or CD engine oils, or have passed pump tests similar to those used in developing anti-wear type hydraulic oils. (B) Have enough chemical stability for mobile hydraulic system service. (C) Meet the viscosity requirements of API Class SD, SE, CC or CD engine oil Grade SAE 10W. (1) Clark Transmission and Converter Fluid Part Number 962669 (5 Gallon (19,0L) Can) or 962672 (55 Gallon (208,2L) Drum). (TEXACO 8570) ** (2) Clark Transmission and Converter Fluid Part Number 941615 (1 Gallon (3,8L) Can). (DEXRON 11D†)	Clark Transmission and Converter Fluid Part Number 962669 (5 Gallon (19,0L) Can) or 962672 (55 Gallon (208,2L) Drum). (TEXACO 8570)	(1) Clark Transmission and Converter Fluid Part Number 962669 (5 Gallon (19,0L) Can) or 962672 (55 Gallon (208,2L) Drum). (TEXACO 8570)  (2) Clark Transmission and Converter Fluid Part Number 941615 (1 Gallon (3,8L) Can). (DEXRON IID †)
- 30 °F (- 34 °C) and Below	Conoco Polar Star DN-600 Fluid	Contact: Clark Equipment Company Construction Machinery Div. Service Department	Contact: Clark Equipment Company Construction Machinery Div. Service Department

\* For initial fill after a transmission rebuild, Clark Equipment Company recommends the use of Clark Transmission and Converter Fluid part number 962672 (55 Gallon (208,2L) Drum. (TEXACO 8570)

\*\* Not for use in 3000, 4000, 5000, 8000 or 16000 Series Transmissions.

† DEXRON is a registered trademark of General Motors Corporation