

680E Loader Backhoe

Parts Catalog

C1224

Reprinted

CASE

REVISION RECORD LOG

REVISION NO.	DATE INSERTED
1.	
2.	
3.	
4.	
5.	


TS/6-6-76

680E CK LOADER BACKHOE

S/N 9114101 AND AFTER

Parts Catalog C1224

**Note: This parts catalog replaces
the previous issue - B1224 -
which is obsolete and
should be discarded.**



Service Parts Supply

700 State Street
Racine, Wisconsin 53404

Printed in U.S.A.

740041 A

GENERAL INFORMATION

Indexes

This parts catalog is arranged for easy identification of parts. The Alphabetical Index at the front of the catalog gives location of major groups and assemblies. The Numerical Index at the rear of the catalog gives part numbers and the page on which they are listed.

Abbreviations and Terms

HHCS - Hex head capscrew.

NSS - Not sold separately.

REF - Reference. Used to clarify drawing.

RESERVED - No item listed.

UAR - Use as required.

Changes

When changes are made to the machine, revised pages for this catalog will be issued. These pages must be inserted into your catalog as soon as they are received. Failure to keep your catalog up to date will result in confusion and may cause you to order wrong parts.

Description, Quantity, and Machinery Items

All parts are briefly described under DESCRIPTION. The quantity used is listed under REQ'D. Notice in the example below that the description of some items is moved in (indented) from the left-hand margin. An indented item is part of the item under which it is indented. The example shows that six track roller assemblies are used on the machine. Each track roller contains two nuts, two washers, two block and retainers, two O-rings, and two face seal assemblies (indented items 1 thru 5). The face seal assemblies are further divided to show individual parts (items 6, 7, and 8).

Machinery items (Mach. Item) must be ordered from the Machinery Price List. See item 9 in the example.

REF.	PART NO.	DESCRIPTION	REQ'D.
	R 27948	ROLLER ASSEMBLY - track, single flange	6
1	131- 737	NUT - hex., lock (3/4" - 10 NC)	2
2	R 29429	WASHER - hardened, 1/2" thick	2
3	R 27951	BLOCK AND RETAINER - seal	2
4	A 7156	O-RING	2
5	D 35267	SEAL - face	2
6	NSS	BODY - seal, split	1
	D 36826	KIT - repair	1
7	NSS	SEAL - rubber	2
8	NSS	RETAINER - plastic	1
9	Mach. Item	FRAME - mounting (See page 2 or 3 for ordering)	1
10	D 48297	HOSE - lube, 30" (762 mm) long	1
11	13- 728	HHCS - 7/16" - 14 NC x 1-3/4"	2
12	D 51263	HHCS - M20 x 2.5 x 80 (8.8)	2

Orders

Orders should specify correct part number, full description, quantity required, machine and engine model, machine and engine serial numbers, method of shipment and shipping address.

Right-Hand and Left-Hand Sides

The terms right-hand and left-hand (abbreviated to L. H. and R. H.) as used in this catalog indicate the right and left sides of the machine as viewed from the operator's seat for proper operation of the machine or attachment.

U.S. and Metric Units

Sizes, lengths, and dimensions are given in U.S. units followed by its equivalent in metric units. See item 10 below. Sizes of hardware (bolts, nuts, etc.) are given according to hardware type---in inches for U.S. hardware; in millimeters for metric hardware. See items 2, 11 and 12.

PARTS ORDERING INFORMATION FOR FRENCH, GERMAN, ITALIAN AND SWEDISH SPEAKING COUNTRIES

3

COMMANDE DE PIÈCES DE RECHANGE

Ce catalogue Pièces Rechange est conçu pour une identification facile de toutes les pièces CASE d'origine. Situé au début du catalogue, un répertoire permet de localiser rapidement les principaux groupes ou montages. A la fin du catalogue, un index numérique de pièces de rechange précise la page sur laquelle chacune des pièces est décrite.

Les pièces sont mentionnées par ordre du numéro de référence suivies du numéro de la pièce, de la description et de la quantité nécessaire. Les quantités mentionnées sous la rubrique « Quantité » correspondent à la quantité nécessaire pour former des assemblages ou des sous-ensembles.

Toutes les pièces sont illustrées sur des dessins éclatés montrant les pièces individuellement les unes par rapport aux autres. Les numéros de référence correspondent aux numéros des pièces sur les vues éclatées. Ces chiffres se rapportent à ceux de la rubrique « Chiffre de référence » qui sont suivis par le numéro de la pièce et sa description.

Toutes les commandes doivent spécifier exactement le numéro correct de la pièce, sa description, la quantité nécessaire, le type et le NUMERO DU MATERIEL, le mode d'expédition et l'adresse du destinataire.

Pour être sûr que votre commande de pièces correspond à vos besoins, vérifier l'illustration et la description dans le catalogue avec la pièce à commander.

BESTELLUNG VON ERSATZTEILEN

Diese Ersatzteilliste ist so zusammengestellt, dass alle Original—CASE—Ersatzteile leicht identifiziert werden können. Vorn ist ein Inhaltsverzeichnis nach Baugruppen und Bauteilen angeordnet, welches das Auffinden der Teile erleichtert. Hinten am Schluss der Liste befindet sich ein fortlaufendes Verzeichnis der Ersatzteilnummern, in dem der betreffenden Ersatzteilnummer jeweils die Seitennummer gegenübersteht, auf der das Teil verzeichnet ist.

Im Ersatzteilverzeichnis befindet sich vor der Ersatzteilnummer eine laufende Nummer, die auch auf der Abbildung wiederholt wird, daneben die Ersatzteilnummer, die Bezeichnung des Teils und die davon benötigte Stückzahl für die betreffende Baugruppe.

Alle Teile sind in Zerlegt-Darstellung so abgebildet, dass sie in ihrem natürlichen Zusammenhang mit den anderen Teilen erkennbar sind, und werden mit der « laufenden Nummer » des Ersatzteilverzeichnisses bezeichnet, um ihre Auffindung zu erleichtern.

Alle Ersatzteil-Aufträge müssen deutlich die richtige Ersatzteilnummer, die genaue Beschreibung, die benötigte Anzahl von Teilen, Modell und NUMMER des traktors, die gewünschte Versandart und die Versandadresse enthalten.

Das benötigte Teil muss sorgfältig mit der Abbildung und der Beschreibung verglichen werden, damit die in Auftrag gegebenen Teile auch richtig bestellt sind.

ORDINI DI PEZZI

Questo libro di pezzi è disposto in modo da permettere facilmente una identificazione di tutti gli Autentici Pezzi CASE Impiegati. Un indice è fornito sulla facciata del catalogo dei pezzi per individuare i principali gruppi o montaggi. Un indice numerico alla fine del catalogo dei pezzi indica la pagina in cui ciascun pezzo numerato è descritto.

I pezzi sono elencati in ordine di numero di riferimento seguito dal numero del pozzo, descrizione, e quantitativo richiesto. I quantitativi indicati nella colonna « Quantitativo richiesto » rappresentano il numero di pezzi richiesto per comporre uno dei precedenti Montaggi o Sotto-Montaggi.

Tutti i pezzi sono illustrati in « Prospetti Sviluppati » che mostrano i singoli pezzi e la loro relazione normale tra di loro. I numeri di riferimento sono indicati nella illustrazione. Questi numeri corrispondono a quelli nella colonna « Numero di Riferimento » e sono seguiti dal numero del pezzo e la descrizione.

Tutti gli ordini devono specificare chiaramente il preciso numero del pezzo, completa descrizione, quantitativo richiesto, modello e NUMERO DELLA SERIE della trattore, metodo di spedizione e indirizzo della spedizione.

Controllate l'illustrazione e la descrizione con il pezzo richiesto, per assicurarvi che i pezzi ordinati sono giusti.

BESTÄLLNING AV RESERVDELAR

Denna reservdelkatalog har getts en speciell uppställningsform för att förenkla identifieringen av alla äkta CASE reservdelar. Ett register finns i början av katalogen upptagande de olika större grupperna och enheterna. En reservdelnsnummervärteckning i slutet av katalogen anger vilken sida de olika detaljerna förekomma på.

De olika reservdelarna anges i referensnummerordning atföljda av serservdelnsnumret, beskrivning och antal. Antalet, som anges i kolumnen « Quantity Required », är det antal som ingår i enheten i fråga.


Alla reservdelaravbildas i sprängbilder i sina inbördes lägen. Referensnumraten anges på sprängbilderna. De framgå också av kolumnen « Reference Number » där de atföljas av beskrivning och reservdelnsnummer.

Reservdelbeställningar skall upptaga korrekt reservdelnsnummer, beskrivning, beställt antal, modell och serienummer på maskinen, transportsätt och mottagarens adress.

Kontrollera noga att bild och beskrivning motsvara den önskade detaljen så att misstag undvikas.

720143

**MODEL 680E CONSTRUCTION KING LOADER BACKHOE
SERIAL NUMBER LOCATION**



ALPHABETICAL INDEX

A

Air Cleaner	57
Air Compressor & Brake Circuit	221-263
Alarm - backup	113, 115
Alternator	53, 55
Anti-Rollback - Loader Bucket	389
Axle - Front	131-133
Axle - Rear	177-219

B

Backhoe	
Buckets	415-421
Controls	391-401
Frame	403
Hydraulic Circuits (See hydraulic circuits)	
Stabilizers	403
Tower Boom And Dipper	405-413
Backup Alarm	113, 115
Balancer - engine	27
Batteries and Cables	83
Belts - alternator, fan and compressor	55
Belts - seat	433
Block - engine	19
Brake System	
Air System and Controls	221-263
Shoes, Linings and Adjusters	205-219
Buckets	
Backhoe	415-421
Loader	377, 379

C

Cab - operator's	439-455
Camshaft - engine	17
Canopy - ROPS	453
Chassis - Tractor	423
Clutch Cutout	231, 233, 253, 255
Clutches - transmission	151, 153
Cold Start System	61, 63
Compressor - Air	239-247
Connecting Rods - engine	25
Controls	
Backhoe	391-401
Brake	235, 251
Clutch Cutout	231, 253, 255
Engine Shut-Off	73
Engine Throttle	71, 73
Loader	381-389
Transmission	173-175
Converter - torque	143-149
Cooler - hydraulic oil	265
Cooling System - transmission	165

C

Crankshaft - engine	21
Cylinders - equipment hydraulic	337-371
Cylinders - steering	129, 129B
Cylinder Head - engine	13
Cylinder Sleeves - engine	25

D

Decals	13, 379, 401, 411, 413, 463, 465
Defroster	89-93, 97
Differential	189-203
Dipsticks	19, 159, 163
Driveshaft	139, 141

E

Electrical System	75-115, 385, 387
Engine	
Balancer and Oil Pump	27
Crankshaft and Flywheel	21, 23
Cylinder Block	19
Cylinder Head and Cover	13
Fuel Injection Filter System	39
Fuel Injection Nozzles	45
Fuel Injection Pump and Drive	35, 41, 43
Fuel Injection System	37
Gasket Kit	33
Manifolds	11
Oil Filter and Cooler	31
Oil Pan	29
Pistons and Connecting Rods	25
Timing Gear Cover	35
Valve Mechanism and Camshaft	15, 17
Water Manifold and Thermostat	9
Water Pump	9
Engine and Transmission Mounting	55, 139

F

Fan	
Defroster	97
Engine Cooling	55
Heater	95
Fenders - rear wheels	425
Filters	
Air	57
Engine Oil	31
Fuel	39
Hydraulic Oil	423
Floor Plates	433, 435
Flywheel - engine	21, 23

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

ALPHABETICAL INDEX

F

- Frost Point - backhoe 409
 Fuel Injection System 35-45, 65-69
 Fuel Tank and Lines 65

G

- Gasket Kits - engine 33
 Gauges 57, 79, 81, 423
 Governor - air compressor 249
 Grille 431

H

- Head - cylinder, engine 13
 Heat Exchanger, engine oil cooler 31
 Heater
 Cab 89-95
 Engine block 19
 Hood - tractor 429
 Horn - electric 111
 Hose and Fitting Conversion Part
 Numbers 466

Hydraulic Circuits

- Backhoe Boom 289
 Backhoe Dipper and Bucket 291, 293
 Backhoe Extendable Dipper 295-297D
 Backhoe Stabilizer 285
 Backhoe Swing 287
 Equipment Primary 265-277
 Loader Bucket Tilt 281
 Loader Clam Bucket 283
 Loader Lift 279
 Steering 117-123
 Transmission Cooling 165

I

- Injection System and Parts - fuel 37-45
 Instrument Panel 79, 81

L

- Levers - control (See Controls)
 Lights 101-107
 Loader
 Buckets 377-379
 Controls 381-389
 Lift Frame 373-375
 Lockup Parts 459

M

- Manifolds - intake and exhaust 11
 Muffler 59

N

- Noise Control Pads 457
 Nozzles - fuel injection 45

P

- Parking Brake 235, 237
 Pedals (See Controls)
 Pistons - compressor 239-247
 Pistons - engine 25
 Pistons - hydraulic cylinder (See Cylinder)
 Pulleys
 Air compressor 221, 223
 Alternator 53, 55
 Fan Drive 9, 21
 Pumps
 Electric Fuel 69
 Fuel Injection 41, 43
 Oil - engine 27
 Oil - hydraulic 335
 Oil - torque converter charging 143, 147
 Water 9

R

- Radiator - cooling 55
 Return-To-Dig Parts - Loader 385, 387
 Rims - wheels 135, 137
 Rings - piston, engine 25
 Rocker Arms - engine 15
 Rods - connecting 25
 Rods - push 15
 Rods - tie 131, 133

S

- Screens
 Engine Oil 27
 Fuel 41, 43
 Hydraulic Oil 423
 Transmission Oil 143
 Seat - operators 433
 Sending Units - instruments 75, 77

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

7

ALPHABETICAL INDEX

S

Sleves - engine	25
Slow Moving Vehicle Emblem	461
Spindles - front axle	131
Starter and Solenoid - engine	47-51
Steering Wheel	117
Steps	423

T


Tanks	
Air	221-227
Fuel	65
Hydraulic	423
Teeth - bucket and digging	377, 379, 409, 415-421
Thermostat - coolant temperature	9
Throttle (See Conrols)	
Timing Gear Cover	35
Tool Box	433
Torque Converter	143-149
Transmission	143-175
Treadle - brake	225-233, 251
Turn Signals	109

V

Valves	
Backhoe Conrol	315
Brake Control	225, 251
Clutch Cutout	253, 255
Engine	15
Flow Control	331
Loader Control	299, 301
Pressure Protection	225
Relief	333
Relief - swing cylinder	355
Stabilizer - backhoe	313
Steering	125, 127, 127B
Transmission Control	155, 157

W

Water Pump	9
Wheel - steering	117
Wheels and Tires	135, 137
Windshield Wipers	99, 443-447, 451, 453





WATER MANIFOLD AND THERMOSTAT
336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 58735	MANIFOLD - water	1
2	A 58637	GASKET - water manifold	2
3	13- 624	BOLT - manifold (3/8 x 1-1/2" N.C. hex.)	2
3	13- 632	BOLT - manifold (3/8 x 2" N.C. hex.)	2
4	193- 10	WASHER - 3/8" ext. skpf	4
5	195- 25	WASHER - 3/8 x 13/16 x 1/16"	4
6	L 56217	UNIT - sending, engine temperature	1
7	193- 1000	NUT - unit terminal (#10 N.F. hex., brass)	1
10	A 58736	HOUSING - thermostat	1
11	G 46907	GASKET - housing to manifold	1
12	A 57641	THERMOSTAT	1
13	13- 614	BOLT - housing (3/8 x 7/8" N.C. hex.)	2
14	193- 10	WASHER - 3/8" ext. skpf	2
15	A 58737	HOSE - manifold to pump (1-1/4" I.D. x 5")	1
16	214- 256	CLAMP - hose (1-3/16" to 1-3/4")	2

WATER PUMP

20	A 62974	PUMP ASSY. - water	1
21	A 58646	GASKET - pump to body	1
22	A 62234	STUD - pump to body (3/8" N.C. x 1-5/16")	4
23	193- 30	WASHER - 3/8" int. skpf	4
24	25- 146	NUT - 3/8" N.C. hex., jam	4
28	A 138498	BODY ASSY. - water pump (for 1/2" P.T. connector) (See Ref. 30)	1
29	A 58568	PLUG - (1-3/8" cup type)	1
28	A 59220	BODY ASSY. - water pump (for 3/4" P.T. connector) (See Ref. 30)	1
29	A 58568	PLUG - (1-3/8" cup type)	1
30	217- 153	CONNECTOR - hose (1/2" P.T.)(Used w/A138498 body)	1
30	217- 381	CONNECTOR - hose (3/4" P.T.)(Used w/A59220 body)	1
31	221- 1092	BUSHING - reducer (3/4" to 3/8")	1
32	A 16764	VALVE ASSY. - shut-off	1
33	A 58649	GASKET - body to block	1
34	13- 620	BOLT - body (3/8 x 1-1/4" N.C. hex.)	2
35	G 11204	STUD - body (3/8" N.C. x 1-7/16")	2
36	92- 6	WASHER - 3/8" lock	4
37	25- 106	NUT - 3/8" N.C. hex	2
40	A 58650	PULLEY - fan	1
41	126- 116	KEY - pulley (#9 Woodruff)	1
42	A 58651	WASHER - (1/2 x 1 x 3/32")	1
43	131- 1106	NUT - 1/2" N.F., crown lock	1





MANIFOLDS
336BD DIESEL ENGINE
INTAKE MANIFOLD

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 140120	MANIFOLD - intake (aluminum)	1
2	A 59225	MANIFOLD ASSY. - intake (cast iron)	1
3	41- 1042	PLUG - (2-5/8" cup type)	1
4	221- 1011	PLUG - (1/8" P.T., sq. hd.)	1
5	A 58662	GASKET - intake manifold	4
6	A 59077	STUD - intake manifold (3/8" N.C. x 1-13/16")	8
7	92- 6	WASHER - 3/8" lock	8
8	195- 25	WASHER - 3/8 x 13/16 x 1/16" (Used w/A140120 manifold)	8
9	25- 166	NUT - 3/8" N.C. hex	8
10	A 20917	PLUG - heater hole	1
11	A 20916	GASKET - plug	1

EXHAUST MANIFOLD

	A 65272	MANIFOLD ASSY. - exhaust	1
15	NSS	MANIFOLD - exhaust	1
16	A 58750	PLUG - (3-1/4" cup type)	1
17	A 58665	PLATE - outlet cover	1
18	13- 616	BOLT - plate to manifold (3/8 x 1" N.C. hex.)	4
19	92- 6	WASHER - 3/8" lock	4
20	A 58666	GASKET - exhaust manifold	4
21	A 59077	STUD - exhaust manifold (3/8" N.C. x 1-13/16")	8
22	92- 6	WASHER - 3/8" lock	8
23	131- 903	NUT - 3/8" N.C. hex., Seez-Pruf	8




(37)

ENGINE DATA		DECAL NO. 321
MODEL		
FULL LOAD R.P.M.		
NO LOAD R.P.M.		
VALVE TAPPET CLEARANCE	INTAKE	COLD
	EXHAUST	COLD
FUEL PUMP TIMING		B.T.C
NOZZLE OPENING PRESS		P.S.I

CYLINDER HEAD AND COVER
336BD DIESEL ENGINE


REF.	PART NO.	DESCRIPTION	REQ'D
1	A 58929	COVER ASSEMBLY - cylinder head	2
2	131- 114	NUT - 1/4" NC Tinnerman	1
3	A 65734	GASKET - cover	2
4	A 64994	TUBE - breather	1
5	13- 440	BOLT - tube to cover (1/4 x 2-1/2" NC hex)	2
6	A 34133	GASKET - tube, upper	2
7	A 58635	GASKET - tube, lower	2
8	D 34033	CLAMP - breather tube (to flywheel housing)	1
15	A 66709	HEAD ASSEMBLY - cylinder (Replaces A60558)	2
16	A 41783	GUIDE - intake and exhaust valves	4
17	A 60557	INSERT - exhaust valve seat	2
18	A 66192	INSERT - intake valve seat	2
19	A 34124	PLUG - 1-3/8" (41.3 mm) cup type	2
20	A 58620	PLUG - 3/4" (19.1 mm) cup type	3
21	221- 843	PLUG - cylinder head (3/8" PT, hex socket head)	4
22	REF	GASKET - cylinder head (See Page 33)	2
23	A 62732	BOLT - cylinder head (5/8 x 5-5/8" NC hex)	20
24	A 58629	WASHER - cylinder head bolt	20
25	A 67121	STUD - cylinder head cover and rocker arm bracket (7/16" NC x 6-7/16")	4
26	A 23684	GASKET - cover	4
27	A 23683	WASHER - cover (dished)	4
28	25- 107	NUT - 7/16" NC hex	2
29	A 60567	EYE - engine lifting	2
37	321- 2644	DECAL - engine data (on cover)	1
40	221- 158	NIPPLE - (3/8" PT x 1")	1
41	221- 337	COUPLING - nipple to valve	1
42	A 16764	VALVE ASSEMBLY - shut-off	1



VALVE MECHANISM


336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 58655	ARM - rocker, exhaust valve, 1st and 3rd cyl	2
2	A 58656	ARM - rocker, exhaust valve, 2nd and 4th cyl	2
3	A 58654	ARM - rocker, intake valve	4
4	A 21105	SCREW - adjusting, rocker arm	8
5	25- 156	NUT - lock, adj. screw (3/8" N.F. hex., jam)	8
6	A 57532	SHAFT - rocker arm	2
7	A 27877	SPRING - rocker shaft	2
8	A 27878	WASHER - rocker shaft (29/32 x 1-5/16 x 1/32")	UAR
9	B 18206	RING - snap, rocker shaft	4
10	A 58657	TUBE - oil, rocker shaft	2
11	A 27880	O-RING - oil tube (3/16 x 5/16 x 1/16")	2
12	A 61128	BRACKET - rocker arm shaft	4
13	A 67121	STUD - bracket (7/16" N.C. x 6-7/16")	4
14	A 58659	STUD - bracket (7/16" N.C. x 4-5/16")	4
15	195- 29	WASHER - (15/32 x 15/16 x 1/16")	8
16	25- 107	NUT - 7/16" N.C. hex	4
17	A 141841	ROD ASSY. - push (Replaces A58596)	8
18	NSS	LIFTER - push rod (Order Ref. 40)	8
25	NSS	VALVE - exhaust (Order Ref. 41)	4
26	NSS	INSERT - exhaust valve seat (Order Ref. 42)	4
27	NSS	GUIDE - intake and exhaust valves (Order Ref. 43)	8
28	NSS	VALVE - intake (Order Ref. 44)	4
29	NSS	INSERT - intake valve seat (Order Ref. 45)	4
30	A 58628	SEAL - valve stem	8
31	A 66328	SEAT - valve springs	8
32	NSS	SPRING - valves (Order Ref. 46)	8
33	NSS	ROTO CAP - exhaust valve (Order Ref. 47)	4
34	NSS	RETAINER - intake valve (Order Ref. 48)	4
35	NSS	LOCK - valve springs (Order Ref. 49)	16
40	A 21653	LIFTER KIT - push rod (Set of 4)(Standard)(0.810" O.D.)	2
40	A 22463	LIFTER KIT - push rod (Set of 4)(Oversize)(0.819" O.D.)	2
41	A 41753	VALVE KIT - exhaust (Set of 2)	2
42	A 44576	INSERT KIT - exhaust valve seat (Set of 2)	2
43	A 41781	GUIDE KIT - intake and exhaust valves (Set of 2)	4
44	A 41754	VALVE KIT - intake (Set of 2)	2
45	A 42259	INSERT KIT - intake valve seat (Set of 2)	2
46	A 42895	SPRING KIT - valves (Set of 4)	2
47	A 44658	ROTO CAP KIT - exhaust valves (Set of 2)	2
48	A 44645	RETAINER KIT - intake valves (Set of 2 w/locks)	4
49	A 40352	LOCK KIT - valve spring keepers (Set of 8)	2



CAMSHAFT
336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 66742	CAMSHAFT - (Replaces A62733)	1
	A 23577	BUSHING KIT - camshaft (Set of 4)	1
3	NSS	BUSHING - rear (1-5/32" wide)	1
4	NSS	BUSHING - intermediate (1-7/16" wide)	2
5	NSS	BUSHING - front (1-21/32" wide)	1
6	A 21017	WASHER - thrust (2-1/4 x 3-1/4 x 1/8")	1
7	A 58592	GEAR - camshaft	1
8	A 58593	GEAR - idler drive	1
9	126- 227	KEY - (Hi-Pro type)	1
11	A 31038	WASHER - camshaft nut (1-3/8 x 2-1/4 x 5/32") (Replaces tab washer A58594)	1
12	A 58595	NUT - camshaft	1
13	A 27853	SPRING - plunger, camshaft bumper	1
14	A 27852	PLUNGER - thrust, camshaft	1




CYLINDER BLOCK

336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
	A 44056	BLOCK ASSY. - short (Incl. stripped block, camshaft, connecting rods and brgs., piston assy., crankshaft and brgs. and timing gears)	1
2	A 44057	BLOCK ASSY. - stripped (Casting No. A58504)	1
3	221- 1849	PLUG - oil gallery (1/8" P.T., sckt. hex. hd.)	4
4	221- 1843	PLUG - oil gallery (3/8" P.T., hex. sckt. hd.)	4
5	A 58568	PLUG - water gallery (1-3/8" cup type)	2
6	A 58569	PLUG - heater hole (2" cup type)	1
7	A 24361	PLUG - camshaft hole (2-3/8" cup type)	1
8	A 23577	BUSHING KIT - camshaft	1
9	A 34540	TUBE - oil filler and dipstick	1
10	A 58783	CAP - main bearing, front and rear (wide)	2
11	A 58784	CAP - main bearing, intermediate (narrow)	2
12	A 58785	CAP - main bearing, thrust, center (wide)	1
13	A 58566	BOLT - bearing caps (5/8 x 4-1/2" N.C. spec.)	10
18	221- 845	PLUG - (3/4" P.T., hex. sckt. hd.)	1
19	A 138330	DIPSTICK - oil level (Replaces A20739)	1
20	A 34266	DRIVE ASSY. - tachometer	1
21	41- 1052	COVER - pump mtg. hole (3-1/2" cup type plug)	1
25	A 66737	SWITCH - oil pressure	1

BLOCK HEATER

28	A 44812	HEATER ASSY. - block	1
29	NSS	ELEMENT - heater	1
30	A 7156	O-RING - element (1-3/4 x 2 x 1/8")	1
31	A 44713	CORD - heater	1




CRANKSHAFT AND FLYWHEEL

336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 58889	CRANKSHAFT	1
2	A 148425	GEAR - balancer drive (Replaces A62450)	1
3	A 8134	PIN - balancer gear locating (3/8 x 3/4")	1
4	A 146984	SCREW - (3/8 x 7/8" N.F. flat sckt. hd.)(Rpl. A23583)	4
5	193- 56	WASHER - 3/8" ext. skpf	4
6	A 58783	CAP - main bearing, front and rear (wide)	2
7	A 58784	CAP - main bearing, intermediate (narrow)	2
8	A 58785	CAP - main bearing, thrust, center (wide)	1
9	A 62573	WASHER - thrust, center bearing (Standard)(0.185")	2
9	A 42932	WASHER - thrust, center bearing (Oversize)(0.191")	2
12	A 43163	LINER SET - main brg., wide (Std.)(Set of 2)	3
12	A 43164	LINER SET - main brg., wide (-.002")(Set of 2)	3
12	A 43165	LINER SET - main brg., wide (-.010")(Set of 2)	3
12	A 43166	LINER SET - main brg., wide (-.020")(Set of 2)	3
12	A 43167	LINER SET - main brg., wide (-.030")(Set of 2)	3
13	A 43158	LINER SET - main brg., narrow (Std.)(Set of 2)	2
13	A 43159	LINER SET - main brg., narrow (-.002")(Set of 2)	2
13	A 43160	LINER SET - main brg., narrow (-.010")(Set of 2)	2
13	A 43161	LINER SET - main brg., narrow (-.020")(Set of 2)	2
13	A 43162	LINER SET - main brg., narrow (-.030")(Set of 2)	2
16	A 66404	GEAR - crankshaft	1
17	A 62049	SEAL - oil, front (2-5/8 x 3-5/8 x 1/2")	1
18	126- 129	KEY - gear and pulley (#C Woodruff)	2
19	A 66621	PULLEY - fan drive	1
20	A 28028	BOLT - pulley (5/8 x 1-1/2" N.F. hex., sckt. hd.)	1
21	92- 10	WASHER - 5/8" lock	1
22	A 27903	WASHER - pulley (21/32 x 2-1/8 x 1/4")	1
25	A 62050	SEAL - oil, rear (4-3/4 x 5-3/4 x 1/2")(See Ref. 38)	1
26	A 57457	RETAINER - rear oil seal	1
27	A 32830	GASKET - rear oil seal retainer	1
28	13- 620	BOLT - retainer (3/8 x 1-1/4" N.C. hex.)	6
29	92- 6	WASHER - 3/8" lock	6
32	A 66388	FLYWHEEL ASSY	1
33	'A 27920	GEAR - ring, starter	1
34	28- 1024	BOLT - flywheel to crankshaft (5/8 x 1-1/2" N.F. hex.)	6







WEAR SEAL KIT

38	A 43194	WEAR SEAL KIT - oil, crankshaft, rear	1
39	NSS	SEAL - oil, rear (4-7/8 x 5-3/4 x 1/2")	1
40	NSS	SLEEVE - wear (4-3/4 x 4-7/8 x 9/16")	1



FLYWHEEL HOUSING
336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 150268	HOUSING - flywheel (Replaces A9397)	1
2	A 61041	BOLT - dowel (1/2 x 2-7/16" N.C. hex.)	1
2	A 61040	BOLT - dowel (1/2 x 3" N.C. hex.)	1
3	13- 826	BOLT - (1/2 x 1-5/8" N.C. hex.)	3
3	13- 836	BOLT - (1/2 x 2-1/4" N.C. hex.)	3
4	92- 8	WASHER - 1/2" lock	8
5	25- 108	NUT - 1/2" N.C. hex	5
6	166- 138	SCREW - (3/4 x 3" N.C. 12 pt. hd.)	2
7	92- 12	WASHER - 3/4" lock	2
8	25- 1012	NUT - 3/4" N.C. hex	2
12	A 58931	SHIELD - dust, flywheel	1
13	13- 812	BOLT - (1/2 x 3/4" N.C. hex.)	2
13	13- 824	BOLT - (1/2 x 1-1/2" N.C. hex.)	2
14	92- 8	WASHER - 1/2" lock	4









**PISTONS AND SLEEVES
WITH 5.189" TO 5.194" FIRE DAM DIAMETER SLEEVE
336BD DIESEL ENGINES**

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 156931	PISTON AND SLEEVE ASSEMBLY - engine (Set of 2)	2
2	A 66531	PISTON - cylinder	2
3	NSS	RING - compression (1st groove)(Order Ref. 11)	2
4	NSS	RING - compression (2nd groove)(Order Ref. 11)	2
5	NSS	RING - oil control (3rd groove)(Order Ref. 11)	2
6	A 140607	PIN - piston	2
7	D 27833	RING - snap, piston pin retaining	4
8	A 153638	SLEEVE - cylinders, (With 3 grooves)	2
	NSS	SLEEVE - cylinder (2 groove) Order 3 groove sleeve A153638	2
9	A 144667	O-RING - sleeve	6
11	A 44060	RING SET - piston re-ring (Set of 1)	4
14	A 148553	SHIM - sleeve, 0.010" (0.254 mm)(Repairs Only)	UAR
14	A 148554	SHIM - sleeve, 0.005" (0.127 mm)(Repairs Only)	UAR
15	A 150327	BUSHING - sleeve (Repairs Only)	UAR
	A 150328	LOCTITE - tube (Not Shown)	UAR

CONNECTING RODS

18	A 62954	ROD ASSEMBLY - connecting	4
19	A 61241	BUSHING - piston pin	1
20	A 65757	BOLT - connecting rod bearing cap	2
22	A 43173	INSERT - connecting rod bearing, (Standard)(Set of 2)	4
22	A 43174	INSERT - connecting rod bearing, 0.002" (0.051 mm) undersize (Set of 2) .	4
22	A 43175	INSERT - connecting rod bearing, 0.010" (0.254 mm) undersize (Set of 2) .	4
22	A 43176	INSERT - connecting rod bearing, 0.020" (0.508 mm) undersize (Set of 2) .	4
22	A 43177	INSERT - connecting rod bearing, 0.030" (0.762 mm) undersize (Set of 2) .	4

25A





PISTONS AND SLEEVES
WITH 5.092" TO 5.097" FIRE DAM DIAMETER SLEEVE
336BD DIESEL ENGINES

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 66531	PISTON - cylinder	4
3	NSS	RING - compression (1st groove)(Order Ref. 11)	4
4	NSS	RING - compression (2nd groove)(Order Ref. 11)	4
5	NSS	RING - oil control (3rd groove)(Order Ref. 11)	4
6	A 140607	PIN - piston	4
7	D 27833	RING - snap, piston pin retaining	8
8	A 140216	SLEEVE - cylinders, (With 2 grooves)	4
9	A 146616	O-RING - sleeve	8
11	A 44060	RING SET - piston re-ring (Set of 1)	4
14	A 148553	SHIM - sleeve, 0.010" (0.254 mm)(Repairs Only)	UAR
14	A 148554	SHIM - sleeve, 0.005" (0.127 mm)(Repairs Only)	UAR
15	A 150327	BUSHING - sleeve (Repairs Only)	UAR
	A 150328	LOCTITE - tube (Not Shown)	UAR



CONNECTING RODS

18	A 62954	ROD ASSEMBLY - connecting	4
19	A 61241	BUSHING - piston pin	1
20	A 65757	BOLT - connecting rod bearing cap	2
22	A 43173	INSERT - connecting rod bearing, (Standard)(Set of 2)	4
22	A 43174	INSERT - connecting rod bearing, 0.002" (0.051 mm) undersize (Set of 2) .	4
22	A 43175	INSERT - connecting rod bearing, 0.010" (0.254 mm) undersize (Set of 2) .	4
22	A 43176	INSERT - connecting rod bearing, 0.020" (0.508 mm) undersize (Set of 2) .	4
22	A 43177	INSERT - connecting rod bearing, 0.030" (0.762 mm) undersize (Set of 2) .	4




BALANCER AND OIL PUMP
336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 66168	BALANCER ASSY. - engine	1
2	181- 675	SCREW - set (1/2 x 1-1/4" N.C. sq. hd., dog pt.)	4
3	A 61129	COVER - oil pump	1
4	A 65083	VALVE - oil pump relief	1
5	A 59111	SPRING - relief valve (2-1/16" free length)	1
6	41- 1011	PLUG - relief valve (11/16" cup type)	1
7	132- 32	PIN - cotter (3/32 x 1-1/2")	1
8	13- 514	BOLT - (5/16 x 7/8" N.C. hex.)	3
8	13- 522	BOLT - (5/16 x 1-3/8" N.C. hex.)	1
9	92- 5	WASHER - 5/16" lock	4
10	A 8134	PIN - dowel, balancer locating	2
11	222- 1012	CONNECTOR - manifold	4
15	A 62002	MANIFOLD - balancer oil supply	1
16	222- 1012	CONNECTOR - manifold inlet	1
17	G 49401	SHIM - mounting (.005")	UAR
17	G 49402	SHIM - mounting (.010")	UAR
18	13- 840	BOLT - balancer mtg. (1/2 x 2-1/2" N.C. hex.)	2
18	13- 852	BOLT - balancer mtg. (1/2 x 3-1/4" N.C. hex.)	2
19	A 150672	WASHER - 1/2 x 7/8 x 1/8"	4
20	A 61130	TUBE - pump to block	1
21	A 64436	O-RING - tube (9/16 x 3/4 x 3/32")	1
22	222- 31	CONNECTOR ASSY	1
23	222- 106	SLEEVE - (for 5/8" tube)	1
24	222- 116	NUT - (for 5/8" tube)	1
25	A 21235	ADAPTER - screen to balancer	1
26	A 22590	SCREEN ASSY. - oil inlet	1





**OIL PAN
336BD DIESEL ENGINE**

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 62711	PAN ASSY. - oil	1
2	221- 664	PLUG - (1/2" P.T., hex. hd.)	1
3	A 34826	PLUG - drain, oil pan	1
4	A 27968	GASKET - drain plug (7/8 x 1-1/8 x 1/16" copper)	1
5	A 58932	STRAP - reinforcing	1
6	13- 614	BOLT - (3/8 x 7/8" N.C. hex.)	24
6	193- 528	BOLT - breather tube brkt. (3/8 x 1-1/2" N.C. hex., sems)	2
7	92- 6	WASHER - 3/8" lock	24
8	195- 25	WASHER - (3/8 x 13/16 x 1/16")	32
9	NSS	GASKET - oil pan (See Page 33)	1



OIL FILTER AND COOLER
336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 58752	BASE ASSY. - oil filter and cooler	1
2	A 58754	VALVE - relief	1
3	A 58755	SPRING - relief valve	1
4	41- 1016	PLUG - relief valve (1" cup type)	1
5	A 58756	GASKET - filter base to block	1
6	13- 828	BOLT - base to block (1/2 x 1-3/4" N.C. hex.)	2
7	92- 8	WASHER - 1/2" lock	2
10	A 66295	COOLER - oil	1
11	217- 107	DRAINCOCK - cooler (discard 1/8" pipe plug in cooler)	1
12	A 66410	SEAL - oil, cooler to base (2-5/8 x 3 x 3/16" sq.)	1
13	A 75294	FILTER - oil (with 1"-12 N.F. threads) (1st used eng. ser. no. 10018987)	1
14	A 66992	ADAPTER - A75294 filter to A58757 adapter (1" - 12 N.F. threads and 3/4"-16 N.F. threads)	1
15	A 58757	ADAPTER - A66992 adapter to A66295 cooler (3/4"-16 N.F. threads and 3/4"-10 N.C. threads)	1
16	A 58758	FILTER - oil (with 3/4"-16" N.F. threads) (Used prior to eng. ser. no. 10018987)	1
17	A 66296	ADAPTER - A58757 filter to A66295 cooler (3/4"-16 N.F. threads and 3/4"-10 N.C. threads)	1
20	NSS	HOSE - water inlet (43" long)(Order A42610)	1
21	NSS	HOSE - water outlet (25" long)(Order A42610)	1
	A 42610	HOSE - (5/8" I.D. x 1" O.D. x 50 ft.)(Cut to length req.)	1
22	214- 335	CLAMP - hose (1/2" to 5/8")	4
23	L 11541	STRAP - hose tie	1
24	A 59718	CLAMP - hose	1
25	217- 134	CONNECTOR - hose (90°)	1
26	221- 60	REDUCER - (in block)(3/4" to 1/2")	1
27	217- 153	CONNECTOR - hose (to water pump)(1/2" P.T.) (Used w/A138498 water pump body)(See Page 9)	1
27	217- 381	CONNECTOR - hose, (to water pump)(3/4" P.T.) (Used w/A59220 water pump body)(See Page 9)	1



ENGINE GASKET KITS
336BD DIESEL ENGINE
VALVE GRIND KIT

USED WITH 5.189" TO 5.194" FIRE DAM DIAMETER SLEEVE

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 46367	GASKET KIT - valve grind (See Note)	1
2	A 138397	GASKET - cylinder head	2
3	A 65734	GASKET - cylinder head cover	2
4	A 58637	GASKET - water manifold	2
5	G 46907	GASKET - thermostat housing	1
6	A 58662	GASKET - intake manifold	4
7	A 58895	GASKET - exhaust manifold (Metal faced)(336BDT)	4
7	A 58666	GASKET - exhaust manifold (Asbestos faced)(336BD)	4
8	A 41403	WASHER - injector nozzle body	4
9	A 41402	SEAL - injector nozzle carbon stop	4
10	A 58635	GASKET - breather tube, lower	2
11	A 34133	GASKET - breather tube, upper	2
12	A 23684	GASKET - cover studs	4
13	A 27880	O-RING - rocker shaft oil tube	2
14	A 58628	SEAL - valve stem	8
15	A 58892	GASKET - turbocharger oil drain tube	1
16	A 58910	GASKET - turbocharger air intake elbow	1
17	A 58899	GASKET - turbocharger	2

NOTE: FOR COMPLETE ENGINE OVERHAUL ORDER 1-A46367, 1-A44075
AND 1-A42221.



VALVE GRIND KIT

USED WITH 5.092" TO 5.097" FIRE DAM DIAMETER SLEEVE

20	A 44086	GASKET KIT - valve grind (See Note)	1
21	A 142481	GASKET - cylinder head	2
22	A 65734	GASKET - cylinder head cover	2
23	A 58637	GASKET - water manifold	2
24	G 46907	GASKET - thermostat housing	1
25	A 58662	GASKET - intake manifold	4
26	A 58895	GASKET - exhaust manifold (Metal faced)(336BDT)	4
26	A 58666	GASKET - exhaust manifold (Asbestos faced)(336BD)	4
27	A 41403	WASHER - injector nozzle body	4
28	A 41402	SEAL - injector nozzle carbon stop	4
29	A 58635	GASKET - breather tube, lower	2
30	A 34133	GASKET - breather tube, upper	2
31	A 23684	GASKET - cover studs	4
32	A 27880	O-RING - rocker shaft oil tube	2
33	A 58628	SEAL - valve stem	8
34	A 58892	GASKET - turbocharger oil drain tube (Not Used)	1
35	A 58910	GASKET - turbocharger air intake elbow (Not Used)	1
36	A 58899	GASKET - turbocharger (Not Used)	2

NOTE: FOR COMPLETE ENGINE OVERHAUL ORDER 1-A44086, 1-A44075
AND 1-A42221.

33A



ENGINE GASKET KITS
336BD DIESEL ENGINES
CYLINDER BLOCK KIT


REF.	PART NO.	DESCRIPTION	REQ'D
1	A 44075	GASKET KIT - cylinder block (See Note)	1
2	A 58612	GASKET - timing gear cover	1
3	A 32830	GASKET - rear seal retainer	1
4	A 62049	SEAL - oil, crankshaft, front 2-5/8 x 3-5/8 x 1/2"	1
5	A 62050	SEAL - oil, crankshaft, rear 4-3/4 x 5-3/4 x 1/2"	1
6	A 58615	GASKET - fuel pump cover	1
7	A 58756	GASKET - oil filter base	1
8	A 58646	GASKET - water pump to body	1
9	A 58649	GASKET - water pump body to block	1
10	A 58613	GASKET - timing window plug	1
11	A 64434	O-RING - oil filter base (Not used this application)	3
12	A 58617	GASKET - (Not used this application)	1
13	A 58670	GASKET - (Not used this application)	1
14	A 76656	GASKET - (Not used this application)	1
15	A 58680	GASKET - (Not used this application)	1

OIL PAN KIT

18	A 42221	GASKET KIT - oil pan (See Note)	1
19	NSS	GASKET - oil pan	1
20	A 27968	GASKET - drain plug (Copper)	1
25	M 20614	SEAL KIT - valves (Incl. 4 seals and installation sleeve)	UAR

NOTE: FOR COMPLETE ENGINE OVERHAUL WITH 5.189" TO 5.194" FIRE DAM DIAMETER SLEEVES ORDER 1-A46367, 1-A44075 AND 1-A42221.

NOTE: FOR COMPLETE ENGINE OVERHAUL WITH 5.092" TO 5.097" FIRE DAM DIAMETER SLEEVES ORDER 1-A44086, 1-A44075 AND 1-A42221.




TIMING GEAR COVER
336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 58609	COVER ASSY. - timing gears	1
2	A 58611	DOWEL - cover locating	2
3	A 62049	SEAL - oil, crankshaft, front (2-5/8 x 3-5/8 x 1/2")	1
4	A 58612	GASKET - cover to block	1
5	A 18550	PLUG - timing window	1
6	221- 843	PLUG - (3/8" P.T., hex. sckt. hd.)	1
7	A 58613	GASKET - plug (1 x 1-1/4 x 1/16" nylon)	1
8	13- 616	BOLT - cover (3/8 x 1" N.C. hex.)	4
9	13- 640	BOLT - cover (3/8 x 2-1/2" N.C. hex.)	2
10	13- 656	BOLT - cover (3/8 x 3-1/2" N.C. hex.)	1
11	13- 660	BOLT - cover (3/8 x 3-3/4" N.C. hex.)	2
12	195- 25	WASHER - cover bolts (3/8 x 13/16 x 1/16")	2
13	92- 6	WASHER - 3/8" lock	9
14	25- 106	NUT - 3/8" N.C. hex	2
15	A 19774	SPACER - alternator pry point	1
20	A 61053	COVER - fuel pump gears	1
21	A 58615	GASKET - cover	1
22	13- 656	BOLT - cover (3/8 x 3-1/2" N.C. hex.)	2
23	A 150118	BOLT - cover (3/8 x 1-1/2" N.C. hex.) (Head drilled for anti-tamper wire)	2
24	92- 6	WASHER - 3/8" lock	4
25	13- 514	BOLT - cover (5/16 x 7/8" N.C. hex.)	1
26	92- 5	WASHER - 5/16" lock	1


INJECTION PUMP DRIVE

36	REF.	PUMP ASSY. - fuel injection (See Pages 41 and 43)	1
37	A 58689	STUD - pump mounting (3/8" N.C. x 1-7/8")	3
37	A 142092	STUD - pump mounting (3/8" N.C. x 1-7/8") (Drilled for anti-tamper wire)	1
38	A 57470	WASHER - 3/8 x 11/16 x 16 ga	4
39	193- 30	WASHER - 3/8" int. skpf	4
40	25- 106	NUT - 3/8" N.C. hex. (Used w/A58689 stud)	3
40	25- 126	NUT - 3/8" N.C. hex. sltd. (Used w/A142092 stud)	1
41	A 58693	GEAR - injection pump drive	1
42	13- 616	BOLT - drive gear to hub (3/8 x 1" N.C. hex.)	3
43	92- 6	WASHER - 3/8" lock	3
44	A 62542	GEAR ASSY. - idler, w/bushing	1
45	A 58690	SHAFT - idler	1
46	A 58691	WASHER - thrust, idler gear	1
47	A 58692	PLATE - thrust, idler shaft	1
48	13- 868	BOLT - idler shaft (1/2 x 4-1/4" N.C. hex.)	1




**FUEL INJECTION SYSTEM
336BD DIESEL ENGINE**

REF.	PART NO.	DESCRIPTION	REQ'D
1	REF.	PUMP ASSY. - fuel injection (See Pages 41 & 43)	1
2	A 58702	TUBE ASSY. - fuel injection, #1 cylinder	1
3	A 58703	TUBE ASSY. - fuel injection, #2 cylinder	1
4	A 58704	TUBE ASSY. - fuel injection, #3 cylinder	1
5	A 58705	TUBE ASSY. - fuel injection, #4 cylinder	1
6	A 58709	CLAMP - injection tubes	8
7	A 58710	PLATE - clamp support	1
8	163- 19	SCREW - clamps (#10 x 1" N.C. std. hex. hd.)	4
9	131- 612	NUT - #10 Tinnerman	4
15	REF.	NOZZLE ASSY. - fuel injector (See Page 45)	4
16	A 58695	CLAMP ASSY. - nozzle hold down	4
17	A 58696	SPACER - nozzle clamp	4
18	A 58960	TEE - inj. nozzles & leak-off lines	4
19	A 58962	GROMMET - inj. nozzle to tee	4
20	A 58961	NUT - inj. nozzle to tee	4
24	A 58965	TUBE - fuel leak-off (4-5/8" long)	2
25	A 58964	TUBE - fuel leak-off (5-5/8" long)	1
26	222- 102	SLEEVE - (for 1/4" tube)	8
27	222- 112	NUT - (for 1/4" tube)	8
28	A 58963	TUBE - fuel leak-off (#1 cyl. to check valve)	1
29	A 28098	VALVE ASSY. - check (one way valve)	1
30	222- 102	SLEEVE - (for 1/4" tube)	1
31	222- 112	NUT - (for 1/4" tube)	1




FUEL FILTER SYSTEM
336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
	A 62347	FILTER ASSY. - fuel	1
1	A 62339	HEAD ASSY. - fuel filters	1
2	221- 1849	PLUG - (1/8" P.T., sckt. hex. hd.)	1
	A 41745	ELEMENT KIT - fuel filters	1
4	NSS	FILTER ASSY. - 1st stage	1
5	G 49080	PLUG - filter drain (3/8" P.T., 12 pt. hd.)	1
6	A 28090	O-RING - drain plug (3/8" x 9/16 x 3/32")	1
7	NSS	FILTER ASSY. - 2nd stage	1
8	A 42315	GASKET - filter to head	1
9	A 20663	SCREW - bleed (#10-32 x 5/16" fill. hd.)	2
10	A 146368	WASHER - bleed screw (3/16 x 3/8 x 1/16" aluminum)	2
11	13- 620	BOLT - head to block (3/8 x 1-1/4" N.C. hex.)	2
12	92- 6	WASHER - 3/8" lock	2
15	222- 45	ELBOW ASSY. - fuel line	2
16	222- 103	SLEEVE - (for 5/16" tube)	1
17	222- 113	NUT - (for 5/16" tube)	1
18	A 62341	TUBE - pump to 1st stage filter	1
19	A 58774	HOSE - 2nd stage filter to pump	1
20	A 20539	UNION - (in pump)	2
21	221- 1011	PLUG - (1/8" P.T., sq. hd.)	1



**A138012 INJECTION PUMP
336BD DIESEL ENGINE
WITH LUBE TUBE ON OUTSIDE OF PUMP**



REF.	PART NO.	DESCRIPTION	REQ'D
1	A 138012	PUMP ASSY. - fuel injection	1
2	A 41853	HUB - pump drive	1
3	A 41855	SPACER - hub	2
4	A 42312	WASHER - lock, hub nut	1
5	A 42313	NUT - hub retaining	1
6	A 20933	KEY - hub to shaft	1
7	A 41854	POINTER - hub timing	1
8	A 41856	O-RING - (2-15/16 x 3-3/16 x 1/8")	1
12	A 43347	BOWL - filter (glass)	1
13	A 43346	GASKET - filter bowl	1
14	A 43350	BAIL - bowl hanger	1
15	A 43348	BAILNUT - bowl hanger	1
16	A 43349	STUD - bailnut lock & adjustment	1
17	A 43344	ELEMENT - filter	1
18	A 43345	SPRING - element	1
19	A 43343	PRIMER ASSY. - hand pump	1
20	A 45342	GASKET - hand pump	1
21	A 43351	SEAL - hand pump (copper)	1
25	222- 42	ELBOW ASSY. - (at pump)	1
26	222- 102	SLEEVE - (for 1/4" tube)	1
27	222- 112	NUT - (for 1/4" tube)	1
28	A 136902	TUBE - pump to oil filter	1
29	222- 23	CONNECTOR ASSY. - (at oil filter base)	1
30	222- 102	SLEEVE - (for 1/4" tube)	1
31	222- 112	NUT - (for 1/4" tube)	1
32	221- 86	BUSHING - reducing (1/4" P.T. to 3/8" P.T.)	1



**A64993 INJECTION PUMP
336BD DIESEL ENGINE
WITH LUBE TUBE ON ENGINE SIDE OF PUMP**

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 64993	PUMP ASSY. - fuel injection (See Note)	1
2	A 41853	HUB - pump drive	1
3	A 20933	KEY - hub to shaft	1
4	A 42312	WASHER - lock, hub	1
5	A 42313	NUT - hub retaining	1
6	A 41856	O-RING - pump sealing (2-15/16 x 3-3/16 x 1/8")	1
7	A 41854	POINTER - hub adjustment	1
8	A 41855	SPACER - pointer	2
9	A 25192	BOLT - oil tube fitting	1
10	A 22381	WASHER - banjo fitting (copper)	2
11	A 25191	FITTING - banjo, oil tube	1
12	A 25190	SPRING - oil tube fitting	1
14	A 43347	BOWL - filter (glass)	1
15	A 43346	GASKET - bowl	1
16	A 43350	BAIL - bowl	1
17	A 43348	BAILNUT - bowl retaining	1
18	A 43349	STUD - bailnut lock	1
19	A 43344	ELEMENT - filter	1
20	A 43345	SPRING - element tension	1
21	A 43351	SEAL - port (copper)	1
22	A 43343	PRIMER ASSY. - hand pump	1
23	A 45342	GASKET - hand primer (Replaces A44761)	1
28	A 58775	TUBE - oil filter to injection pump	1
29	222- 102	SLEEVE - (for 1/4" tube)	1
30	222- 112	NUT - (for 1/4" tube)	1
31	222- 23	CONNECTOR ASSY. - oil tube (at oil filter base)	1
32	222- 102	SLEEVE - (for 1/4" tube)	1
33	222- 112	NUT - (for 1/4" tube)	1
34	221- 86	BUSHING - reducer (3/8" P.T. to 1/4" P.T.)	1


NOTE: PRIOR TO ENGINE SERIAL NO. 2569948 FUEL INJECTION PUMPS
DID NOT HAVE A HAND PRIMER. USE A64993 FOR REPAIRS.



INJECTOR NOZZLES
336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 140830	NOZZLE ASSY. - injector (See Note) (Stamped 20669 on body)(Blue & Yellow color code) (1st used eng. ser. no. 2581421)	4
1	A 64439	NOZZLE ASSY. - injector (Order A140830) (Stamped 20346 on body)(Yellow & Blue color code) (Used prior to eng. ser. no. 2581421)	4
2	NSS	BODY - nozzle	1
3	A 43599	SCREW - lift adjusting	1
4	A 43602	NUT - lock, lift adjusting screw	1
5	A 43600	SCREW - pressure adjusting	1
6	A 42424	NUT - lock, pressure adjusting screw	1
7	A 44369	SEAT - spring	1
8	A 43733	SPRING - pressure adj. (9/16" free length)(Red color code)	1
9	NSS	VALVE - nozzle	1
10	A 41768	PLATE - nozzle locating	1
11	A 41403	WASHER - nozzle (3/8 x 9/16 x 1/16")	1
12	A 41402	SEAL - carbon stop (5/16 x 3/8 x 1/8")	1


NOTE: WHENEVER NOZZLE IS REMOVED FROM HEAD, A41402 SEAL & A41403 WASHER MUST BE REPLACED BEFORE NOZZLE IS INSTALLED BACK IN HEAD.



**R26136 STARTER
336BD DIESEL ENGINE**


REF.	PART NO.	DESCRIPTION	REQ'D
	R 26136	STARTER ASSY. - (Delco-Remy #1113403)	1
2	A 43861	FRAME ASSY. - commutator end	1
3	A 42323	BUSHING - shaft (9/16 x 11/16 x 25/32")	1
4	R 15023	WICK - oil	1
5	221- 1849	PLUG - (1/8" P.T., sckt. hd.)	1
6	114- 1	BOLT - (1/4 x 1" N.F. hex.)	4
7	192- 19	WASHER - 1/4" lock	4
8	R 21590	HOLDER - brush, insulated	2
9	A 40217	HOLDER - brush, grounded	2
10	R 15024	BRUSH	4
11	D 32481	SCREW - brush (#8-32 x 13/16" self tapping)	4
12	R 15025	SPRING - brush tension	2
13	R 15029	BRUSH SUPPORT KIT	2
14	NSS	SUPPORT - (Order R15029)	1
15	175- 449	SCREW - support (#10 x 3/4" N.F., truss hd.)	2
16	192- 18	WASHER - #10 lock	2
17	129- 17	NUT - #10 N.F. hex. (Replaces R15032)	2
18	R 15035	PIN - brush holder	1
19	R 15030	LEAD - brush	1
20	A 40909	ARMATURE	1
22	A 41917	WASHER - thrust, comm. end (9/16 x 1 x 1/16")	1
23	A 43860	COIL ASSY. - field	1
24	A 40896	STUD - field terminal	1
	A 41925	BUSHING ASSY. - inner, terminal insulating	1
25	NSS	INSULATOR - field coil stud, inner	1
26	NSS	SUPPORT - stud insulator	1
27	A 41977	INSULATOR - field coil	1
28	R 15115	SHOE - pole	4
29	A 42127	SCREW - pole shoes (3/8 x 5/8" N.F., flat sltd. hd)	8
30	A 40894	CONNECTOR - field terminal to solenoid	1
32	D 30005	INSULATOR - field stud, outer (1/2 x 1 x 3/32")	2
33	D 30006	WASHER - terminal stud (1/2 x 7/8 x 1/32")	1
34	129- 145	NUT - terminal stud (1/2" N.C. hex.)	2
35	192- 113	WASHER - 1/2" lock	1

CONTINUED ON PAGE 49




**R26136 STARTER
336BD DIESEL ENGINE**

REF.	PART NO.	DESCRIPTION	REQ'D
	R 26136	STARTER ASSY. - (Continued from Page 47)	1
40	R 21579	HOUSING ASSY. - shift lever	1
41	R 15023	WICK - oil	1
42	221- 1041	PLUG - (1/8" P.T., sltd. hd.)	1
43	R 21580	BUSHING - (13/16 x 1 x 1-1/4")	1
44	R 21582	SEAL - oil (13/16 x 1-3/8 x 3/8")	1
45	R 15145	WASHER - brake (7/16 x 1-7/8 x 3/16")	1
46	A 40892	WASHER - thrust, drive end (7/16 x 1-3/4 x 3/16")	1
47	R 21587	PLUG - housing	1
48	A 41924	GASKET - plug	1
49	114- 1	BOLT - housing to frame (1/4 x 1" N.F. hex.)	5
50	192- 19	WASHER - 1/4" lock	5
51	A 42397	DRIVE ASSY. - starter pinion	1
52	R 21562	GASKET - drive housing to drive end	1
55	A 44340	HOUSING ASSY. - drive end	1
56	A 40893	BUSHING - (5/8 x 3/4 x 3/4")	1
57	R 15023	WICK - oil	1
58	221- 1041	PLUG - (1/8" P.T., sltd. hd.)	1
59	D 32488	SCREW - housing (5/16 x 1-1/2" N.C., sckt. hd.)	1
60	D 32489	SCREW - housing (5/16 x 7/8" N.C., sckt. hd.)	1
62	D 32547	LEVER - shift control	1
63	A 42199	SHAFT - pivot, shift lever	1
64	R 21574	O-RING - shaft (1/4 x 3/8 x 1/16")	1
65	R 21573	O-RING - shaft (3/8 x 1/2 x 1/16")	1
66	G 46146	RING - snap, shaft retaining	1
67	A 42309	PLUNGER - solenoid	1
68	A 42308	BOOT - plunger (rubber)	1
69	A 41242	SPRING - plunger return	1
70	A 41922	WASHER - spring seat (13/16 x 1-3/8 x 1/32")	1
71	A 43380	RETAINER - plunger spring, inner (1-3/16" hole)	1
72	A 43419	RETAINER - plunger spring, outer (3/8" hole)	1
73	G 46146	RING - snap, retainer to plunger	1
74	A 43856	NUT - plunger to lever (5/16" N.F. special)	1
75	A 42376	SOLENOID ASSY. - (See Page 51)	1
76	R 15159	SCREW - solenoid mtg. (1/4 x 3/8" N.F. hex.)	4




A42376 SOLENOID
336BD DIESEL ENGINE

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 42376	SOLENOID ASSY. - (Delco-Remy #1119848)	1
2	NSS	CASE ASSY. - w/coil	1
3	A 42407	CLAMP - terminal	1
4	D 32502	SCREW - terminal clamp	2
5	D 32500	NUT ASSY. - w/skpf. washer	4
7	D 32498	DISC ASSY. - contact	1
8	A 42411	SPRING - return, contact disc	1
	A 42412	PLATE ASSY.	1
10	A 42410	PLATE - terminals & case cover	1
11	A 42260	GASKET - terminal plate to case	1
12	D 32507	INSULATOR - terminal plate	1
13	A 42413	STUD - battery term. (1-21/32" thread length)	1
14	D 32506	STUD - starter term. (1-13/16" thread length)	1
15	D 29910	TERMINAL - coil lead (Replaces A42406)	1
16	175- 56	SCREW - coil lead (#6-32 x 3/16" truss hd.)	1
17	D 32510	BUSHING - terminal plate insulators	2
18	A 43701	BUSHING - terminal studs insulators (Replaces A42409)	2
19	D 30004	WASHER - insulating, terminal studs (1/2 x 1-3/16" x 3/32")	2
20	129- 145	NUT - terminal studs (1/2" N.C. hex., jam)	2
21	192- 113	WASHER - terminal studs (1/2" lock)	4
22	129- 105	NUT - terminal studs (1/2" N.C. hex)	2




ALTERNATOR

REF.	PART NO.	DESCRIPTION	REQ'D
L	74747	ALTERNATOR ASSY. - (Production only)(24 volt) Motorola #8HC3006F) (Order 1-A44798 alternator, 1-A41361 pulley and 1 vol. regulator from Page 77)	1
1	A 44798	ALTERNATOR ASSY. - (Repairs Only)	1
2	A 44774	HOUSING - front	1
3	A 42075	BEARING - housing, front (1 x 2 x 9/16")	1
4	A 41052	SLEEVE - bearing pilot	1
5	A 43280	RETAINER - front bearing	1
6	169- 146	SCREW - front retainer (#8-32 x 3/8" std. hd.)	3
7	192- 16	WASHER - #8 lock	3
8	A 44775	ROTOR	1
9	A 44672	STATOR	1
10	A 44776	HOUSING - rear	1
11	A 42810	BEARING - housing, rear	1
12	A 44581	RING - slip (Order A44580)	1
13	163- 4	SCREW - slip ring (1 x 5/8" 12 pt. sckt. hd.)	1
14	192- 18	WASHER - #10 lock	1
15	A 44788	WASHER - slip ring	1
16	A 42806	O-RING - rear brg. retainer (1-1/2 x 1-3/4 x 1/8")	1
17	A 44777	DIODE ASSY. - negative	1
18	A 44778	DIODE ASSY. - positive	1
19	A 45253	DIODE ASSY. - trio	1
20	A 45254	SPACER - trio diode	1
21	A 41436	STUD - (#10 x 1-1/2" N.C., carr. hd.)	1
22	A 41041	INSULATOR - diode stud	1
23	A 44771	SLEEVE - insulator (1/4 x 5/16 x 1/2")	1
23	A 44782	SLEEVE - insulator (3/16 x 1/4 x 3/8")	2
24	A 44763	WASHER - insulating (1/4 x 3/4 x 1/16")	2
24	A 41038	WASHER - insulating (3/16 x 3/4 x 1/16")	4
25	A 44789	WASHER - 3/8 x 3/16"	4
26	A 41060	NUT - #10-24 hex., w/skpf. washer	4
32	A 44423	BOLT - thru (#10 N.F. x 3-1/8")	4
33	A 44779	BRUSH ASSY. - w/holder	1
34	A 44781	GASKET - brush cover (felt)	1
35	A 44785	COVER - brush	1
36	A 44784	SPACER - brush cover (3/16 x 9/32 x 1/16")	2
37	182- 519	SCREW - brush holder	2
38	187- 1089	SCREW - regulator (#8-32 x 3/4" std. hd.)	1
39	A 42431	FAN	1
40	126- 111	KEY - fan and pulley (#5 Woodruff)	1
41	A 42432	SPACER - fan (5/8 x 1-3/8 x 11/32")	1
42	192- 25	WASHER - 5/8" lock	1
43	A 41035	NUT - pulley retaining (5/8" N.F. hex.)	1
44	A 44770	CAPACITOR - (condenser)	1
46	A 41361	PULLEY - alternator	1
47	REF.	REGULATOR ASSY. - voltage (See Page 77)	1
48	A 62429	STRAP - alternator adjusting	1
49	A 38492	BRACKET - alternator mounting	1
50	13- 616	BOLT - brkt. and strap (3/8 x 1" N.C. hex.)	3
51	13- 652	BOLT - alt. to brkt. (3/8 x 3-1/4" N.C. hex.)	1
52	92- 6	WASHER - 3/8" lock	4
53	25- 106	NUT - 3/8" N.C. hex	1



RADIATOR, ENGINE AND RELATED PARTS

REF.	PART NO.	DESCRIPTION	REQ'D
1	D 25826	CAP - radiator, 7 PSI (48 kPa)	1
2	L 72507	RADIATOR - engine and hydraulic oil cooling, includes item 6	1
3	214- 262	CLAMP - radiator hose	4
4	L 55764	HOSE - radiator, lower	1
5	L 55524	HOSE - radiator, upper	1
6	A 23655	VALVE - radiator drain, included in L 72507 radiator	1
7	13- 628	HHCS - 3/8" - 16 NC x 1-3/4"	4
8	92- 6	WASHER - lock, 3/8"	4
9	A 61283	SPACER - fan	1
10		RESERVED	
11	A 15519	FAN - suction	1
11	L 73972	FAN - pusher, not shown	1
12	13- 1248	HHCS - 3/4" - 10 NC x 3"	4
13	L 50435	BRACKET - engine, order L78158 bracket, includes item 18	1
13A	L 78158	BRACKET - engine, includes item 18	1
14	92- 12	WASHER - lock, 3/4"	4
15	25- 1012	NUT - hex, 3/4" - 10 NC	4
16	139- 64	PIN - taper, #5 x 1-1/2"	2
17	13- 1264	HHCS - 3/4" - 10 NC x 4"	1
18	L 79179	CUSHION - rubber mount	1
19	L 74506	WASHER - flat, 3/4", hardened	1
19A	A 19068	WASHER - special, 3/4"	2
20	131- 1205	NUT - hex, lock, 3/4" - 10 NC	1
21	A 59296	BELTS - matched set, fan and alternator drive	1
22	L 55580	BELT - brake air compressor drive, before tractor sn. 9121647	1
22	L 72739	BELT - brake air compressor drive, tractor sn. 9121647 and after	1
23	13- 512	HHCS - 5/16" - 18 NC x 3/4", adjusting strap	1
24	92- 5	WASHER - lock, 5/16"	1
25	A 62429	STRAP - alternator belt adjusting	1
26	13- 616	HHCS - 3/8" - 16 NC x 1", strap mounting	1
27	92- 6	WASHER - lock, 3/8"	1
28	REF.	ALTERNATOR - electrical, parts list page 53	1
29	A 41361	PULLEY - alternator	1
30	13- 652	HHCS- 3/8" - 16 NC x 3-1/4"	1
31	A 38492	BRACKET - alternator mounting	1
31A	13- 616	HHCS-3/8"-16NCx1"	2
32	92- 6	WASHER - lock, 3/8"	3
33	25- 106	NUT - hex, 3/8" - 16 NC	1
34	13- 848	HHCS - 1/2" - 13 NC x 3"	1
35	13- 824	HHCS - 1/2" - 13 NC x 1-1/2"	2
36	92- 8	WASHER - lock, 1/2"	3
37	R 24323	WASHER - special, starter mounting	3
38	REF.	STARTER - electrical, parts list page 47- 51	1
39		RESERVED	
40	REF.	ENGINE - tractor, parts list pages 9 thru 45	1




AIR CLEANER AND MUFFLER

REF.	PART NO.	DESCRIPTION	REQ'D
1	L 55408	AIR CLEANER - dry type, not illustrated assembled	1
2	NSS	BODY - air cleaner	1
3	L 35975	ELEMENT - air cleaner	1
4	E 73655	BOLT - retainer, element	1
4A	L 36187	WASHER - sealing, retainer bolt	1
5	L 35976	COVER - air cleaner element	1
6	D 71455	VALVE - vacuator	1
7	70973	BAND - mounting, air cleaner	2
8	13- 512	HHCS - 5/16" - 18 NC x 3/4"	4
9	95- 5	WASHER - flat, 5/16"	4
10	92- 5	WASHER - lock, 5/16"	4
11	25- 105	NUT - hex, 5/16" - 18 NC	4
12	L 55258	ADAPTER - air cleaner to manifold, used before tractor sn. 9121647	1
12	L 73780	ADAPTER - air cleaner to manifold, used on tractor sn. 9121647 and after ..	1
13	A 58910	GASKET - adapter to manifold	2
14	13- 628	HHCS - 3/8" - 16 NC x 1-3/4"	4
15	92- 6	WASHER - lock, 3/8"	4
16	25- 106	NUT - hex, 3/8" - 16 NC	4
17	*L 55254	HOSE - air cleaner	1-2
18	214- 264	CLAMP - hose	2-3
19	D 36264	FITTING - special, filter type	1
19A	222- 681	FITTING ASSEMBLY - tube, for service order 222-5131 connector	2
20	NSS	FITTING - body	1
21	222- 650	SLEEVE - compression	1
22	222- 660	NUT - tube	1
22A	222- 5131	FITTING ASSEMBLY - tube	1-2
22B	NSS	FITTING - body, order 222-5131	1
22C	NSS	SLEEVE - compression, order 222-5131	1
22D	NSS	NUT - tube, order 222-5131	1
23	D 36961	TUBE - gauge to air intake tube	1
24	L 13268	NUT - lock, nipple retaining, used before tractor sn. 9122224	1
25	L 13267	NIPPLE - gauge to coupling, used before tractor sn. 9122224	1
25A	222- 600	FITTING ASSEMBLY - at gauge, used on tractor sn. 9122224 and after	1
25B	NSS	FITTING - body	1
25C	222- 650	SLEEVE - compression	1
25D	222- 660	NUT - tube	1
25E	195- 26	WASHER - used with 222-600 fitting only	1
26	A 17652	GAUGE - air cleaner restriction	1
27	49851	CLAMP - to hood bracket, if used	1

Continued on next page

***NOTE:** On tractors with extra parts added for noise reduction, two L55254 hoses are used. One is used as illustrated, and the other is used to extend the air intake opening on the air cleaner.



AIR CLEANER AND MUFFLER


REF.	PART NO.	DESCRIPTION	REQ'D
28	13- 616	HHCS - 3/8" - 16 NC x 1"	4
29	92- 6	WASHER - lock, 3/8"	4
30	L 57839	ADAPTER - muffler to manifold, used before tractor sn. 9127796	1
30A	L 78911	ADAPTER - muffler to manifold, used on tractor sn. 9127796 and after	1
31	L 14218	GASKET - muffler adapter to manifold	1
32	A 13240	CLAMP - muffler to exhaust pipe and adapter	3
32A	95- 6	WASHER - flat, 5/16"	4
33	L 55720	MUFFLER - exhaust, early production, 23-3/16" (588.9 mm) long, if used	1
34	L 58969	MUFFLER - exhaust, spark arresting type, early production, 23-3/16" (588.9 mm) long, if used	1
35	217- 78	PLUG - pipe, brass, 1/2" NPT	1
35A	L 73117	MUFFLER - exhaust, late production, 22- 11/16" (576.2 mm) long	1
36	L 57841	PIPE - exhaust, standard	1
37	L 58994	PLATE - support, muffler, use before tractor sn. 9127796	1
37A	L 78909	STRAP - exhaust pipe, used on tractor sn. 9127796 and after	1
38	L 58993	STRAP - exhaust pipe, use before tractor sn. 9127796	1
38A	L 78889	BRACKET - exhaust support, used on tractor 9127796 and after	1
38B	A 56092	CLAMP - L78889 bracket to manifold, includes nuts	1
38C	92- 6	WASHER - flat, 3/8"	2
39	13- 824	HHCS - 1/2" - 13 NC x 1-1/2"	1
40	95- 8	WASHER - flat, 1/2"	1
41	92- 8	WASHER - lock, 1/2"	1
42	25- 108	NUT - hex, 1/2" - 13 NC	1

USED WITH VERTICAL SPARK ARRESTER

43	L 70064	PIPE - exhaust, lower	1
44	D 45256	ARRESTER - spark, includes one clamp	1
45	A 13240	CLAMP - arrester to pipe	1
46	L 70063	PIPE - exhaust, upper	1

USED WITH NOISE CONTROL MUFFLER


47	L 72680	ADAPTER - muffler to manifold	1
48	L 70100	MUFFLER - increased noise control	1
49	L 70511	PIPE - exhaust, used with L70100 muffler	1



COLD START SYSTEM
*** EARLY PRODUCTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 53196	KIT - cold starting aid	1
1	D 55767	CYLINDER - ether	1
2	D 55949	BRACKET - clamp mounting	1
3	214- 262	CLAMP - tank retaining	1
4	L 35280	VALVE ASSEMBLY - actuator	1
5	222- 650	SLEEVE - compression	1
6	222- 660	NUT - tube	1
	L 35283	SEAL KIT - overhaul repair	1
	NSS	SEAL - O-ring, cylinder to valve	1
	NSS	SEAL - O-ring, armature	1
	NSS	SEAL - O-ring, retainer fitting	1
	NSS	WASHER - bumper, retainer fitting	1
7	L 35281	TUBE - nylon, 1/8" (3.1 mm) O.D. x 60" (1524 mm) long	1
8	222- 660	NUT - tube	1
9	222- 650	SLEEVE - compression	1
10	L 35282	NOZZLE - manifold	1
11	13- 416	HHCS - 1/4" - 20 NC x 3/4"	4
12	92- 4	WASHER - lock, 1/4"	4
13	25- 104	NUT - hex., 1/4" - 20 NC	4
14	L 11778	CONNECTOR - male bullet	1
15	L 11779	INSULATOR - connector tubing	1
16	49851	CLAMP - wiring	3
17	13- 656	HHCS - 3/8" - 16 NC x 3-1/2"	1
18	13- 616	HHCS - 3/8" - 16 NC x 1"	2
19	92- 6	WASHER - lock, 3/8"	3
20	25- 106	NUT - hex., 3/8" - 16 NC	3
21	49853	CLAMP - wiring	2
22	13- 612	HHCS - 3/8" - 16 NC x 3/4"	2
23	92- 6	WASHER - lock, 3/8"	2
24	25- 106	NUT - hex., 3/8" - 16 NC	2
25	L 58842	WIRE - connecting, cold start to button	1
	L 72776	SWITCH - push button, cold start	1
26	NSS	SWITCH - cold start	1
27	D 73741	NUT - face	1
28	H 275784	NUT - jam	1
29	174- 93	SCREW - terminal	2
30	L 59605	WIRE - jumper, cold start switch to buzzer terminal	1

*NOTE: See page 63 for late production models.




COLD START SYSTEM
*** LATE PRODUCTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 59605	WIRE-jumper, cold start switch to buzzer	1
2	L 58842	WIRE-connecting, cold start solenoid to push button	1
3	13- 656	HHCS-3/8"- 16 NC x 3-1/2"	1
4	49851	CLAMP-wiring	2
5	13- 616	HHCS-3/8"- 16 NC x 1"	1
6	92- 6	WASHER-lock, 3/8"	2
7	25- 106	NUT-hex., 3/8"- 16 NC	2
8	13- 516	HHCS-5/16"- 18 NC x 1"	2
9	92- 5	WASHER-med. sect. lock, 5/16"	2
10	25- 105	NUT-hex., 5/16"- 18 NC	2
	L 73025	SOLENOID-cold start	1
11	NSS	SOLENOID-cold start	1
12	R 30786	GASKET-solenoid	1
13	D 74444	BAIL-solenoid	1
14	222- 615	ELBOW-solenoid	1
15	R 30812	EXTENSION-bail	2
16	L 73023	WIRE-solenoid	1
17	B 17072	FLUID-starting, ether (16 oz. can)	1
18	D 35090	TUBE-cold start	1
19	13- 612	HHCS-3/8"- 16 NC x 3/4"	2
20	49853	CLAMP-tube	2
21	92- 6	WASHER-lock, 3/8"	2
22	25- 106	NUT-hex., 3/8"- 16 NC	2
23	L 73024	NOZZLE-atomizer	1
	L 72776	SWITCH-push button, cold start	1
24	NSS	SWITCH-push button	1
25	D 73741	NUT-hex., face	1
26	H 275784	NUT-jam	1
27	174- 93	SCREW-terminal	2

* NOTE:

See page 61 for early production models.



FUEL TANK AND LINES

REF.	PART NO.		DESCRIPTION	REQ'D.
1	REF.		CHASSIS ASSEMBLY - see page 421	1
2	L	57512	SENDING UNIT - fuel level gauge	1
3	A	11822	GASKET - sending unit to tank	1
4	163-	4	SCREW - machine, #10 - 32 NF x 5/8"	5
5	92-	3	WASHER - lock, #10	5
6	L	13194	RIVNUT - retainer, #10 - 32 NF	5
7	L	58208	CAP - fuel filler pipe, for lock up parts see page 459	1
8	L	71484	PIPE - fuel filler	1
9	L	40248	HOSE - fuel filler 2-1/2" (63.5 mm) I.D. x 4" (101.6 mm) long	1
10	214-	263	CLAMP - hose	2
11	L	58025	BRACKET - support, filler pipe, if used	1
12	L	58024	"U" BOLT - filler pipe to bracket, if used	1
13	95-	4	WASHER - flat, 1/4"	2
14	92-	4	WASHER - lock, 1/4"	2
15	25-	104	NUT - hex., 1/4" - 20 NC	2
15A	L	73711	CLAMP - filler pipe, if used	1


MODELS WITHOUT ELECTRIC FUEL PUMP

16	L	58022	STRAINER - fuel	1
17	A	27862	VALVE - fuel drain, if used	1
17A	221-	12	PLUG - fuel drain, if used, not shown	1
	222-	48	FITTING ASSEMBLY - hose, 90°, at tank	1
18		NSS	BODY - fitting	1
19	222-	114	NUT - fitting	1
20	222-	104	SLEEVE - fitting	1
21	L	71665	TUBE - fuel tank to pump	1
21A	L	11541	STRAP - tie, tube support	1
22		49852	CLAMP - hose	2
23	L	17627	VALVE - check	1
24	222-	14	FITTING - valve	1
25	222-	27	FITTING - valve	1

MODELS WITH ELECTRIC FUEL PUMP


26	L	58022	STRAINER - fuel	1
	222-	48	FITTING ASSEMBLY - hose, 90°, at tank	1
27		NSS	BODY - fitting	1
28	222-	114	NUT - fitting	1
29	222-	104	SLEEVE - fitting	1
30	L	40164	HOSE - tank to pump	1
31	L	11541	TIE - hose	4
32	L	52634	PUMP - fuel, electric, parts list page 69	1
33	13-	420	HHCS - 1/4" - 20 NC x 1-1/4"	2
34	95-	4	WASHER - flat, 1/4"	2
35	92-	4	WASHER - lock, 1/4"	2
36	25-	104	NUT - hex., 1/4" - 20 NC	2
37			RESERVED	
38		49852	CLAMP - hose	2

Continued on next page




**FUEL TANK AND LINES
USED ON ALL MODELS**

REF.	PART NO.	DESCRIPTION	REQ'D.
39	L 40164	HOSE - fuel line to injector pump	1
	222- 47	FITTING ASSEMBLY - hose, 90°	1
40	NSS	BODY - fitting	1
41	222- 104	SLEEVE - fitting	1
42	222- 114	NUT - fitting	1
43	L 57137	HOSE - return, injector pump to tank	1
	222- 23	FITTING ASSEMBLY - flex. type, straight	1
44	NSS	BODY - fitting	1
45	222- 112	NUT - fitting	1
46	222- 102	SLEEVE - fitting	1




ELECTRIC FUEL PUMP

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 52634	PUMP - fuel transfer	1
1	A 40312	COVER - fuel pump	1
2	A 40315	GASKET - cover	1
3	A 40311	MAGNET - plunger	1
4	L 33210	SCREEN - filtering	1
5	A 40316	RETAINER - seal	1
6	A 40317	WASHER — special, retainer	1
7	A 40318	O-RING - valve	1
8	A 40313	VALVE - cup	1
9	L 35316	SPRING - plunger	1
10	A 40310	PLUNGER - fuel pump	1
11	NSS	BODY - pump, fuel transfer	1
12	L 11779	SLEEVE - insulation	1
13	L 11778	CONNECTOR - male, bullet	1
14	222- 46	FITTING - 90°, 1/8" NPT x 3/8" NPT	2




FOOT THROTTLE CONTROL

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 48004	PEDAL - accelerator, foot	1
2	L 48674	PAD - accelerator pedal	1
3	L 48003	PIN - pedal pivot	1
4	A 27795	RING - pin retaining, 5-1/2"	2
5	13- 888	HHCS - 1/2" - 13 NC x 5-1/2", accelerator stop	1
6	25- 148	NUT - hex., jam, 1/2" - 13 NC	1
7	13- 416	HHCS - 1/4" - 20 NC x 1"	2
8	L 48002	BRACKET - accelerator pedal pivot	1
9	95- 4	WASHER - flat, 1/4"	2
10	92- 4	WASHER - lock, 1/4"	2
11	25- 104	NUT - hex., 1/4" - 20 NC	2
12	L 55855	BRACKET - cable mounting, accelerator, rear	1
13	13- 820	HHCS - 1/2" - 13 NC x 1-1/4"	1
14	92- 8	WASHER - lock, 1/2"	1
15	25- 108	NUT - hex., 1/2" - 13 NC	1
16	L 72961	CABLE ASSEMBLY - accelerator	1
17	L 14227	TURNBUCKLE - throttle adjustment	1
18	L 58515	ROD - throttle adjustment	1
19	129- 27	NUT - hex., #10 - 32 NF, Right hand thread	1
19A	129- 315	NUT - hex., #10 - 32 NF, Left hand thread	1
20	L 78680	BRACKET - cable mounting, accelerator, front	1
21	129- 37	NUT - hex., #10 - 32 NF, plated	2
22	92- 3	WASHER - lock, 3/16"	2
23	L 12437	BALL JOINT - cable end	2
24	L 40703	PLATE - retaining, return spring, if used	2
25	L 50735	SPRING - return, accelerator pedal, 3" (76 mm) free length	1
26	L 48104	SPRING - return, accelerator pedal, 2-1/4" (57 mm) free length	1



HAND THROTTLE AND FUEL SHUTOFF


REF.	PART NO.	DESCRIPTION	REQ'D.
1	D 49996	KNOB - hand throttle lever	1
2	L 55583	LEVER - hand throttle	1
3	13- 836	HHCS - 1/2" - 13 NC x 2-1/4"	1
4	R 14771	WASHER - spring, special	1
5	R 15071	DISC - friction	1
6	25- 148	NUT - hex., jam, 1/2" - 13 NC	2
7	132- 6	PIN - cotter, 1/16" dia. x 5/8"	1
8	141- 2	PIN - clevis, 1/4"	1
9	213- 2	CLEVIS - adjustable 1/4"	1
10	L 55603	CABLE ASSEMBLY - backhoe throttle	1
11	L 58548	TURNBUCKLE - throttle adjustment	1
12	25- 214	NUT - hex., 1/4" - 28 NF, R.H. thread	3
13	L 58523	ROD - control, backhoe throttle	1
14	129- 361	NUT - hex., 1/4" L.H. thread	1
15	L 58210	SLIDE - throttle, backhoe	1
16	L 55741	PLATE - retaining, return spring, if used	1
17	14- 412	HHCS - 1/4" - 28 NF x 3/4", used with L50735 spring	1
17	113- 169	HHCS - 1/4" - 20 NC x 1-3/4", used with L48104 spring	1
18	92- 4	WASHER - lock, 1/4"	1
19	25- 154	NUT - hex., jam, 1/4" - 28 NF, used with L50735 spring	1
19	25- 144	NUT - hex., jam, 1/4" - 20 NC, used with L48104 spring	1
20	L 50735	SPRING - return, throttle, 3" (76 mm) free length	1
20A	L 48104	SPRING - return, throttle, 2-1/4" (57 mm) free length	1
21	L 40703	PLATE - retaining, return spring, if used	1
22	L 57925	CABLE - control, fuel shutoff	1
23	13- 68	HHCS - 3/8" - 16 NC x 1/2"	1
24	92- 6	WASHER - lock, 3/8"	1
25	L 71856	BRACKET - support, fuel shutoff	1
26	13- 612	HHCS - 3/8" - 16 NC x 3/4"	1
27	49853	CLAMP - cable to bracket	1
28	92- 6	WASHER - lock, 3/8"	1
29	25- 106	NUT - hex., 3/8" - 16 NC	1
30	L 45037	SPRING - return, fuel shutoff, if used	1
31	L 46009	PIN - return spring, if used	1



ELECTRICAL SYSTEM FRONT HARNESS AND CONNECTIONS


REF.	PART NO.	DESCRIPTION	REQ'D
1	L 58334	HARNESS - front, models with Case built cab	1
1	L 71684	HARNESS - front, Sims cab and 5 lead voltage regulator, see ref. nos. 33A and 33B	1
1	L 76350	HARNESS - front, Sims cab and 4 lead voltage regulator, see ref. nos. 33A and 33B, used before sn. 9127825	1
1	L 79230	HARNESS - front, sn. 9127825 and after	1
2	L 43743	LIGHT - front, flood, parts list page 105	2
3	193- 6	WASHER - flat, #10	6
4	129- 7	NUT - hex, #10 - 24 NC	6
5	A 15941	WIRE - flood light ground	2
6	L 11352	WIRE - front flood light connecting, pink color	1
6	L 70179	WIRE - front flood light connecting, dark green color	1
7	49857	CLAMP - wire retaining	2
8	92- 6	WASHER - lock, 3/8"	2
9	13- 610	HHCS - 3/8" - 16 NC x 5/8"	2
10	L 72967	BRACKET - solenoid mounting	1
11	L 58091	RESISTOR - 10 Ohm	1
12	192- 15	WASHER - lock, #6, if used	2
13	182- 46	SCREW - pan head, #6 - 32 NC x 1/2"	1
13A	195- 7	WASHER - flat, #6	1
13B	192- 5	WASHER - lock, #6	1
13C	129- 5	NUT - hex, #6 - 32 NC	1
13D	L 78495	TUBE - shrink, insulation, if used	2
14	173- 274	SCREW - round head, #8 - 32 NC x 1/2", plated, if used	2
14A	173- 73	SCREW - round head, #8 - 32 NC x 1/4", plated	2
14B	L 70217	CLAMP - resistor mounting, if used	1
15	192- 6	WASHER - lock, #8	2
16	129- 6	NUT - hex, #8 - 32 NC	2
17	L 58820	WIRE - resistor to oil sending unit	1
18		RESERVED	
19	A 66737	SWITCH - oil pressure sending unit	1
20	D 37203	BREAKER - circuit, 15 amp	1
21	L 11342	BREAKER - circuit, 25 amp	1
22	187- 811	SCREW - pan head, #6, breaker mounting	4
23	L 57036	WIRE - jumper, breaker to breaker, orange-black color	1
23	L 70057	WIRE - jumper, breaker to breaker, red color, if used	1
23A	L 74683	BAR - jumper, breaker to breaker, if used	1
24	192-o18	WASHER - lock, #10	4
25	129- 37	NUT - hex, #10 - 32 NF, plated	4
26	L 57035	WIRE - solenoid relay to circuit breaker, orange-black color	1
26	L 70058	WIRE - solenoid relay to circuit breaker, red color	1
27	S 219533	SOLENOID - relay, starter	1
28	13- 412	HHCS - 1/4" - 20 NC x 3/4", solenoid mounting	2
29	95- 4	WASHER - flat, 1/4"	2
30	92- 4	WASHER - lock, 1/4"	2
31	25- 104	NUT - hex, 1/4" - 20 NC	2
32	A 31060	WIRE - solenoid relay ground, if used	1

Continued on next page



ELECTRICAL SYSTEM FRONT HARNESS AND CONNECTIONS

REF.	PART NO.	DESCRIPTION	REQ'D
33	REF.	ALTERNATOR - 24 volt, parts lists page 53	1
33A A	44783	REGULATOR - voltage, 5 leads, order L76431 kit for service	1
	L	KIT - voltage regulator, replaces 5 lead alternator with 4 lead alternator	1
33B L	74931	REGULATOR - voltage, 4 leads	1
34 L	58496	RESISTOR - 25 Ohm, if used	1
34A 223-	125	TUBE - shrink, insulation, if used	1
35 A	18312	WIRE - ground, alternator	1
36		RESERVED	
37 R	26136	STARTING MOTOR - engine, parts list pages 47 and 49	1
38 L	14552	WIRE - starter to solenoid, 13" (330 mm) long	1
38 L	70385	WIRE - starter to solenoid, 16" (406 mm) long	1
39 L	50012	WIRE - solenoid to starter, red color	1
39 L	70191	WIRE - solenoid to starter, orange color	1
40 13-	848	HHCS - 1/2" - 13 NC x 3", starter mounting	1
41 92-	8	WASHER - lock, 1/2"	3
42 R	24323	WASHER - starter mounting	3
43 13-	824	HHCS - 1/2" - 13 NC x 1-1/2", starter mounting	2
44 L	40793	WIRE - ground, starter to engine frame	1
45		RESERVED	
46 195-	2051	WASHER - flat, 1/2"	1
47		RESERVED	
48 25-	148	NUT - hex, 1/2" - 13 NC	1
49 L	56217	SENDING UNIT- engine water temperature	1
50 L	57176	SENDING UNIT - air pressure	1
51	REF.	VALVE - loader, see pages 381 and 383 for related parts	1
52	49774	CLAMP - front harness	1
53 L	56217	SENDING UNIT - converter oil temperature	1
54		RESERVED	
55 L	100566	SENDING UNIT - fuel level	1
56 163-	4	SCREW - #10 - 32 NF x 5/8"	5
57 92-	3	WASHER - lock, #10	5
58 L	13194	RIVNUT - fuel tank, #10 - 32 NF	5
59 92-	3	WASHER - lock, #10	1
60 129-	37	NUT - hex, #10 - 32 NF, plated	1
61 L	71304	SWITCH - neutral start, transmission sn. 75001 and after	1
62 L	58511	TERMINAL - electrical	2




740047 C

ELECTRICAL SYSTEM INSTRUMENT PANEL

REF.	PART NO.	DESCRIPTION	REQ'D
1	REF.	HARNESS - front, see page 75	1
2	L 55778	SWITCH - starting, push button, used before transmission sn. 75001	1
3	L 57050	PANEL - instrument, inner, used before sn. 9124838	1
3	L 77296	PANEL - instrument, inner, used on sn. 9124838 thru 9127823	1
3	L 79233	PANEL - instrument, inner, used on sn. 9127823 and after	1
4	182- 527	SCREW - 1/4" - 20 NC x 5/8"	4
5	193- 8	WASHER - lock, 1/4"	4
	L 55650	CLUSTER - instrument panel, L.H.	1
6	NSS	CASE AND GASKET - cluster mounting	1
7	L 35954	STRAP - case mounting	2
8	192- 18	WASHER - lock, #10, plated	4
9	129- 37	NUT - hex, #10 - 32 NF, plated	4
10	L 35948	PANEL - instrument, L.H. outer	1
11	L 35950	CIRCUIT BOARD - wiring and gauges	1
12	L 35953	PANEL - identification, brake, alternator, engine oil pressure and clutch pressure warning light	1
13	L 35946	GAUGE - engine water temperature	1
14	L 35943	GAUGE - fuel level	1
15	L 35944	GAUGE - air pressure	1
16	L 35945	GAUGE - converter oil temperature	1
17	L 35947	COVER - rubber, light socket	7
18	L 35949	SOCKET - instrument light	7
19	W 10478	BULB - light, instrument (#194)	7
20	164- 215	SCREW - hex, socket head, #6 - 32 NC x 3/4", special	4
21	187- 976	SCREW - hex head, self-tapping, #6 - 3/8"	13
22	L 57685	DECAL - "CASE", included in decal kits, see pages 463 and 465	1
23	L 55774	PANEL - instrument, R.H. outer	1
24	164- 215	SCREW - #6 - 32 NC x 3/4"	4
25	192- 15	WASHER - lock, #6	4
26	129- 15	NUT - hex, #6 - 32 NC	4
27	L 55655	SWITCH ASSEMBLY - electrical, uses D36822 key, see item 47	1
27A	D 36822	KEY - set of 2	1
28	L 55654	SWITCH - lights	1
29	L 48480	SWITCH - air pressure	1
30	L 15056	BUZZER - air pressure warning	1
31	L 57801	WIRE - switch to buzzer	1
32	L 57052	RESISTOR - 25 ohm, has mounting lugs, if used	1
32A	L 59799	RESISTOR - 15 ohm, mounted with "P" type clamp, if used	1
33	182- 44	SCREW - #6 - 32 NC x 3/8"	2
34	L 58511	TERMINAL - panel, 90°	1
34A	L 59682	TERMINAL - panel, straight	1
34B	49833	CLAMP - resistor mounting, L59799 resistor only	1
34C	223- 125	SLEEVE - insulation, if used	1
35	192- 15	WASHER - lock, #6	5
36	129- 15	NUT - hex, #6 - 32 NC	5
37	182- 47	SCREW - #6 - 32 NC x 5/8"	3
38	195- 7	WASHER - flat, #6	3


Continued on next page



740047 C

ELECTRICAL SYSTEM INSTRUMENT PANEL

REF.	PART NO.	DESCRIPTION	REQ'D
39	L 58497	RESISTOR - 40 ohm, if used	1
40	L 57799	WIRE - tachometer light, black-red color	1
40	L 70185	WIRE - tachometer light, gray color	1
41	A 14553	BULB - tachometer light (#57)	1
42	L 58174	GAUGE - tachometer, for security cover see page 459	1
43	R 29332	SHAFT - tachometer drive, flexible	1
44	L 58335	HARNESS - middle, wiring	1
45	353- 404	PLUG - heater switch mounting, if used	1
46	353- 407	PLUG - cold start switch mounting, if used	1
47	*A 77312	SWITCH - electrical, uses A77313 key, see item 27	1
48	*A 77313	KEY - set of 2	1
49	*A 77314	NUT - mounting	1
50	*193- 37	WASHER - internal tooth lock, 1"	1
51	*L 31557	WASHER - flat	1
52	NSS	PLUG - wiring harness	1
*L 36185 KIT - electrical switch. Includes items preceded by an asterisk			1




ELECTRICAL SYSTEM

REAR HARNESS AND CONNECTIONS

REF.	PART NO.	DESCRIPTION	REQ'D
1	L 58335	HARNESS - middle, wiring	1
2	L 47989	SWITCH - stop light	1
3	*A 38411	BATTERY - dry charge (12 volt) Must be used with A60553 nonspill caps ..	2
3A	A 60553	CAP - battery, nonspill	12
4	L 57444	PLATE - battery support	1
5	13- 824	HHCS - 1/2" - 13 NC x 1-1/2"	4
6	92- 8	WASHER - lock, 1/2"	4
7	25- 108	NUT - hex, 1/2" - 13 NC	4
8	L 57488	HOLDDOWNS - battery, angle	2
9	L 52096	BOLT - hook, battery holdown	4
10	95- 5	WASHER - flat, 5/16"	4
11	92- 5	WASHER - lock, 5/16"	4
12	25- 105	NUT - hex, 5/16" - 18 NC	4
13	L 57766	CABLE - jumper, battery to battery	1
14	L 79907	CABLE - battery to starter	1
15	L 14552	CABLE - starter to solenoid	1
16	S 219533	SOLENOID - starter	1
17	L 50012	WIRE - solenoid to starter	1
18	R 26136	STARTER - engine, parts list pages 47 and 49	1
19	L 57765	CABLE - battery ground	1
20	13- 852	HHCS - 1/2" - 13 NC x 3-1/2", starter mounting	1
21	92- 8	WASHER - lock, 1/2"	3
22	R 24323	WASHER - starter mounting	3
23	13- 824	HHCS - 1/2" - 13 NC x 1-1/2", starter mounting	2
24	L 57937	SWITCH - air pressure	1
25	L 58497	RESISTOR - 40 ohm, if used	1
26	L 58511	TERMINAL - plug in, 90°	1
26A	L 59682	TERMINAL - plug in, straight	1
26B	223- 125	SLEEVE - insulation, if used	1
27	49853	CLAMP - harness	1
28	REF.	LAMP - engine warning, see page 107	1
29	L 11345	GASKET - engine warning light	1

***NOTE:** When replacing battery, conventional caps must be removed from new battery and replaced by (6) A60553 nonspill caps. Nonspill caps can be removed from the existing battery and reused or new nonspill caps can be ordered.




TO MIDDLE WIRING HARNESS

760608 A


**ELECTRICAL SYSTEM
ONE PIECE REAR LIGHT HARNESS**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 57900	HARNESS - rear light, used with items 12-23 or item 24	1
2	L 73162	HARNESS - rear light, used with items 32-36	1
3	L 57910	BRACKET - rear light mounting, used with L57900 harness	2
4	L 73486	BRACKET - rear light mounting, used with L73162 harness	2
5	13- 820	HHCS - 1/2" - 13 NC x 1-1/4"	4
6	95- 8	WASHER - flat, 1/2"	4
7	92- 8	WASHER - lock, 1/2"	4
8	25- 108	NUT - hex., 1/2" - 13 NC	4
9	L 43738	LIGHT - turn signal and flasher, parts list page 105	2
10	L 43737	LIGHT - stop and tail, parts list page 105	2
11	D 71193	LIGHT - rear flood, parts list page 105	2
11A	L 11779	SLEEVE - insulation, light terminals	8
12	49799	CLAMP - harness, if used	2
13	13- 820	HHCS - 1/2" - 13 NC x 1-1/4", if used	2
14	95- 8	WASHER - flat, 1/2", if used	2
15	92- 8	WASHER - lock, 1/2", if used	2
16	25- 108	NUT - hex., 1/2" - 13 NC, if used	2
17	L 58070	TUBE - shield, rear harness, R.H., if used	1
18	L 58069	TUBE - shield, rear harness, L.H., if used	1
19	49858	CLAMP - tube retaining, if used	2
20	13- 616	HHCS - 3/8" - 16 NC x 1", if used	2
21	95- 6	WASHER - flat, 3/8", if used	2
22	92- 6	WASHER - lock, 3/8", if used	2
23	25- 106	NUT - hex., 3/8" - 16 NC	2
24	L 54606	CLIP - harness mounting, stick on, if used	14
25	L 13765	GROMMET - harness	2
26	13- 640	HHCS - 3/8" - 16 NC x 2-1/2"	4
27	95- 6	WASHER - flat, 3/8"	4
28	92- 6	WASHER - lock, 3/8"	4
29	25- 106	NUT - hex., 3/8" - 16 NC	4
30	L 73479	COVER - light support	2
31	353- 403	PLUG - light bracket	2
32	49852	CLAMP - harness	6
33	13- 416	HHCS - 1/4" - 20 NC x 1"	6
34	95- 4	WASHER - flat, 1/4"	6
35	92- 4	WASHER - lock, 1/4"	6
36	25- 104	NUT - hex., 1/4" - 20 NC	6



ELECTRICAL SYSTEM
TWO PIECE REAR LIGHT HARNESS

REF.	PART NO.	DESCRIPTION	REQ'D
1	L 74575	HARNESS - rear light, R.H.	1
2	L 74574	HARNESS - rear light, L.H.	1
3	L 73486	BRACKET - rear light mounting, used before sn. 9127825	2
3A	L 78742	BRACKET - rear light mounting, used on sn. 9127825 and after	2
4	L 13765	GROMMET - harness	2
5	L 73479	COVER - light support, used before sn. 9127825	2
5A	L 79121	COVER - light support, used on sn. 9127825 and after	2
6	353- 403	PLUG - light bracket	2
7	13- 640	HHCS - 3/8" - 16 NC x 2-1/2"	4
8	95- 6	WASHER - flat, 3/8"	4
9	92- 6	WASHER - lock, 3/8"	4
10	25- 106	NUT - hex, 3/8" - 16 NC	4
11	13- 820	HHCS - 1/2" - 13 NC x 1-1/4"	4
12	95- 8	WASHER - flat, 1/2"	4
13	92- 8	WASHER - lock, 1/2"	4
14	25- 108	NUT - hex, 1/2" - 13 NC	4
15	L 43738	LIGHT - turn signal and flasher, parts list page 105	2
16	L 43737	LIGHT - stop and tail, parts list page 105	2
17	D 71193	LIGHT - rear flood, parts list page 105	2
17A	L 11779	SLEEVE - insulation, light terminals	8
18	49852	CLAMP - harness	2
19	13- 416	HHCS - 1/4" - 20 NC x 1"	2
20	95- 4	WASHER - flat, 1/4"	2
21	92- 4	WASHER - lock, 1/4"	2
22	25- 104	NUT - hex, 1/4" - 20 NC	2
23	L 77093	CONDUIT - flood light wire, used on sn. 9127825 and after	2




**ELECTRICAL SYSTEM
CAB HEATER AND DEFROSTER
*MODELS WITH CASE BUILT CAB
EARLY PRODUCTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	221- 1092	BUSHING - reducer, 3/4" x 3/8" NPT	1
2	A 16764	VALVE - shut-off	1
3	L 78623	HOSE - heater, 5/8" (15.8 mm) I.D. x 63" (1600 mm) long	1
4	L 11541	STRAP - tie, hose retaining	2
5	D 65132	NIPPLE - straight, pipe	2
6	214- 253	CLAMP - hose	4
7	L 59043	PLATE - heater mounting	1
8	13- 616	HHCS - 3/8" - 16 NC x 1"	2
9	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	2
10	92- 6	WASHER - lock, 3/8"	4
11	95- 6	WASHER - flat, 3/8"	4
12 **D	65190	HEATER ASSEMBLY - operators cab, parts list page 95	1
13	L 59280	PLATE - air deflector, if used	1
14	92- 4	WASHER - lock, 1/4"	4
15	25- 104	NUT - hex., 1/4" - 20 NC	4
16	A 136406	HOSE - heater return, 5/8" (15.8 mm) I.D. x 29" (736 mm) long ..	1
17	A 16764	VALVE - water shut-off	1
18	221- 337	COUPLING - 3/8" NPT	1
19 **221-	158	NIPPLE - 3/8" NPT x 1"	1
20	L 48971	FAN - defroster, parts list page 97	1
21	169- 99	SCREW - fillister head, #10 - 24 NC x 5/8"	4
22	92- 3	WASHER - lock, #10	4
23	L 59696	HARNESS - cab wiring	1
24	L 54606	CLIP - cab harness	11
25 **L	33827	SWITCH - heater motor	1
26	L 59161	WIRE - heater switch to cab harness	1
27	L 59170	WIRE - heater switch to heater motor	1

*NOTE: Case built cabs may be identified by the J I Case Co. Sn. plate located in the upper L.H. corner of the cab.

**NOTE: Items preceded by an asterisk are included in L59025 heater kit.




**ELECTRICAL SYSTEM
CAB HEATER AND DEFROSTER
*MODELS WITH CASE BUILT CAB
LATE PRODUCTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	221-	BUSHING - reducer, 3/4" x 3/8" NPT	1
2	A	VALVE - shutoff	1
3	L	HOSE - heater, 5/8" (15.8 mm) I.D. x 63" (1600 mm) long	1
4	L	STRAP - tie, hose retaining	2
5	D	NIPPLE - straight, pipe	2
6	214-	CLAMP - hose	4
7	L	PLATE - heater mounting	1
8	13-	HHCS - 3/8" - 16 NC x 1"	2
9	13-	HHCS - 3/8" - 16 NC x 1-1/4"	2
10	92-	WASHER - lock, 3/8"	4
11	95-	WASHER - flat, 3/8"	4
12	**D	HEATER ASSEMBLY - operators cab, parts list page 95	1
13	L	PLATE - air deflector, if used	1
14	92-	WASHER - lock, 1/4"	4
15	25-	NUT - hex., 1/4" - 20 NC	4
16	A	HOSE - heater return, 5/8" (15.8 mm) I.D. x 29" (736 mm) long ..	1
17	A	VALVE - water shutoff	1
18	221-	COUPLING	1
19	**221-	NIPPLE - 3/8" NPT x 1"	1
20	L	FAN - defroster, parts list page 97	1
21	169-	SCREW - fillister head, #10 - 24 NC x 5/8"	4
22	92-	WASHER - lock, #10	4
23	L	HARNESS - cab wiring	1
24	L	CLIP - cab harness	11
25	**L	SWITCH - heater motor	1
26	L	WIRE - heater switch to cab harness	1
27	L	WIRE - heater switch to heater motor	1
28	173-	SCREW - #8 - 32 NC x 5/16"	1
29	129-	NUT - hex., #8 - 32 NC	1
30	192-	WASHER - lock, #8	1
31	REF.	PLATE - solenoid and circuit breaker mounting, see page 75 for related parts	1
32	L	BREAKER - circuit, 25 amp	1
33	187-	SCREW - self-tapping	2
34	L	WIRE - jumper, breaker to breaker, if used	1
34A	L	BAR - jumper, breaker to breaker, if used	1

*NOTE: Case built cabs may be identified by the J I Case Co. Sn. plate located in the top L.H. corner of the cab.

**NOTE: Items preceded by an asterisk are included in L59025 heater kit.




**ELECTRICAL SYSTEM
CAB HEATER AND DEFROSTER
*MODELS WITH SIMS BUILT CAB**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	221- 1092	BUSHING - reducer, 3/4" x 3/8" NPT	1
2	A 16764	VALVE - shutoff	1
3	L 78623	HOSE - heater, 5/8" (15.8 mm) I.D. x 63" (1600 mm) long	1
4	L 11541	STRAP - tie, hose retaining	2
5	D 65132	NIPPLE - straight, pipe	2
6	214- 253	CLAMP - hose	4
7	L 59043	PLATE - heater mounting	1
8	13- 616	HHCS - 3/8" - 16 NC x 1"	2
9	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	2
10	92- 6	WASHER - lock, 3/8"	4
11	95- 6	WASHER - flat, 3/8"	4
12 **D	65190	HEATER ASSEMBLY - operators cab, parts list page 95	1
13	L 59280	PLATE - air deflector, if used	1
14	92- 4	WASHER - lock, 1/4"	4
15	25- 104	NUT - hex., 1/4" - 20 NC	4
16	A 136406	HOSE - heater return, 5/8" (15.8 mm) I.D. x 29" (736 mm) long ..	1
17	A 16764	VALVE - water shutoff	1
18	221- 337	COUPLING - 3/8" NPT	1
19 **221-	158	NIPPLE - 3/8" NPT x1"	1
20	L 48971	FAN - defroster, parts list page 97	1
21	169- 99	SCREW - fillister head, #10 - 24 NC x 5/8"	4
22	92- 3	WASHER - lock, #10	4
23	D 70623	HARNESS - cab wiring	1
24	L 54606	CLIP - cab harness	11
25 **L	33827	SWITCH - heater motor	1
26	L 71699	WIRE - heater switch to cab harness	1
27	L 59170	WIRE - heater switch to heater motor	1
28	REF.	HARNESS - front wiring, see page 75	1
29	REF.	PLATE - solenoid and circuit breaker mounting, see page 75 for related parts	1
30	L 11342	BREAKER - circuit, 25 amp	1
31	187- 811	SCREW - self-tapping	2
32	L 70057	WIRE - jumper, breaker to breaker, if used	1
32A	L 74683	BAR - jumper, breaker to breaker, if used	1


*NOTE: Sims built cabs may be identified by the Sims part number stamped on the cab Sn. plate.

**NOTE: Items preceded by an asterisk are included in L59025 heater kit.




**ELECTRICAL SYSTEM
CAB HEATER**

REF.	PART NO.	DESCRIPTION	REQ'D.
D	65190	HEATER ASSEMBLY - operator's cab	1
1	NSS	SHELL - heater	1
2	NSS	COVER - heater	1
3 D	63393	CORE - heater	1
4	NSS	GASKET - heater mounting	1
5 D	63395	MOTOR ASSEMBLY - heater fan	1
6 D	63396	FAN - heater	1



**ELECTRICAL SYSTEM
CAB DEFROSTER**


REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 48971	FAN - defroster, cab rear window	1
2	L 30907	GRILLE - fan, front	1
3	L 30904	GRILLE - fan, back	1
4	L 30906	BOLT - special	1
5	L 30902	BLADE ASSEMBLY - fan	1
6	129- 26	NUT - hex., #8 - 36 NF	2
7	L 35760	WASHER - special	2
8	D 54871	MOTOR - fan, 24 volt	1
9	L 30900	BASE - fan	1
10	L 30909	KNOB - control	1
11	L 30908	NUT - hex., special	1
12	D 54872	SWITCH - control	1
13	L 30910	SCREW - thumb swivel, if used	1



ELECTRICAL SYSTEM


WIPER MOTORS

REF.	PART NO.	DESCRIPTION	REQ'D
	REF.		
	F 93455	MOTOR - wiper, front, bullet connectors, use F93455	1
1	D 71423	MOTOR - wiper, front, spade connectors	1
2	F 44453	MOTOR - 24 volt	1
3	193- 1001	WASHER - wave	1
4	A 36091	NUT AND EXTERNAL WASHER - 1/4" - 28 NF	1
5	F 44455	ARM - drive	1
6	D 72849	CLIP - spring	2
7	D 72850	SCREW AND WASHER - #10 - 32 NF	2
8	D 71427	BRACKET	1
9	A 22431	LINK	1
	D 72848	SPACER - washer	2
10	NSS	SHAFT AND PIVOT	1
11	D 71417	SHAFT	1
12	D 71418	WASHER - felt	1
13	D 71419	WASHER - flat	1
14	D 71420	NUT	1
15	D 71421	COVER - rubber	1
16	193- 9	SPROCKET - driver	1
17	D 71472	WASHER - lock, 5/16"	1
18	129- 161	NUT - cap	1
19	193- 60	NUT - hex, 1/4" - 28 NF	1
20	D 73642	WASHER - flat, 1/4"	1
21	F 44456	PIN - threaded	1
22	92- 3	SCREW - round head slotted, #10 - 32 NF x 3/8"	2
		WASHER - flat, #10, if used	2



ELECTRICAL SYSTEM
DIPPER LIGHT FOR NON-EXTENDABLE DIPPER


REF.	PART NO.	DESCRIPTION	REQ'D
1	L 73161m	WIRE - rear harness to dipper light switch, 36" (914 mm) long	1
2	A 39887	SWITCH - dipper light	1
2A	A 39888	NUT - switch mounting	1
3	NSS	WIRE - switch to dipper light, 185" (4699 mm) long, if used, order items 3A and 3B	1
3A	L 79801	WIRE - from switch, 28" (711 mm) long	1
3B	L 79986	WIRE - to dipper light, 209" (5308 mm) long	1
4	L 11541	STRAP - tie, wire retaining	UAR
5	13- 820	HHCS - 1/2" - 13 NC x 1-1/4"	4
6	92- 8	WASHER - lock, 1/2"	4
7	95- 8	WASHER - flat, 1/2"	4
8	D 41427	SHIELD - dipper light	1
9	49857	CLAMP - wire	1
10	25- 108	NUT - hex, 1/2" - 13 NC	4
11	13- 814	HHCS - 1/2" - 13 NC x 7/8"	4
12	92- 8	WASHER - lock, 1/2"	4
13	95- 8	WASHER - flat, 1/2"	4
14	L 58510	PLATE - mounting, dipper lamp	2
15	L 50502	BLOCK - tapped, weld on	2
16	131- 354	NUT - hex, self lock. 1/2" - 13 NC	1
17	195- 33	WASHER - flat, 1/2"	1
	L 45149	LAMP ASSEMBLY - dipper arm	1
18	NSS	BODY - lamp	1
19	173- 73	SCREW - machine, round head, #8 - 32 NC x 1/4"	2
20	193- 25	WASHER - external tooth lock, #8	2
21	10927	SPRING - lamp	1
22	B 50293	INSULATOR - lamp	1
23	A 40033	WIRE - lamp	1
24	L 10499	BULB - sealed beam, 24 volt (#4589)	1
25	D 31441	RETAINER - lamp	1



740092 A

ELECTRICAL SYSTEM
DIPPER LIGHT FOR EXTENDABLE DIPPER


REF.	PART NO.	DESCRIPTION	REQ'D
1	A 39887	SWITCH - dipper light	1
1A	A 39888	NUT - switch mounting	1
2	L 73161	WIRE - rear wiring harness to switch, 36" (914 mm) long	1
3	L 55370	WIRE - dipper light, 266" (6756 mm) long, used before sn. 9122202, if used	1
3	NSS	WIRE - dipper light, 254" (6451 mm) long, used on sn. 9122201 and after, if used, order items 3A and 3B	1
3A	L 79801	WIRE - from switch, 28" (711 mm) long, used on sn. 9122201 and after	1
3B	L 100002	WIRE - to dipper light, 254" (6451 mm) long, used on sn. 9122201 and after	1
4	L 11541	STRAP - wire	12
5	49857	CLAMP - wire, at dipper light	1
6	L 59067	ANGLE - dipper light bracket	2
7	D 41427	SHIELD - dipper light	1
8	26- 624	HHCS - 3/8" - 16 NC x 1-1/2", grade 8	4
9	D 41740	WASHER - special	4
10		RESERVED	
11	13- 820	HHCS - 1/2" - 13 NC x 1-1/4"	4
12	5- 8	WASHER - flat, 1/2"	4
13	92- 8	WASHER - lock, 1/2"	4
14	25- 108	NUT - hex, 1/2" - 13 NC	4
	L 45149	LIGHT ASSEMBLY - dipper arm	1
15	NSS	BODY - light	1
16	173- 73	SCREW - machine, round head, #8 - 32 NC x 1/4"	2
17	193- 25	WASHER - external tooth lock, #8	2
18	10927	SPRING - light	1
19	B 50293	INSULATOR - light	1
20	A 40033	WIRE - light	1
21	L 10499	LIGHT - sealed beam, 24 volt (#4589)	1
22	D 31441	RETAINER - light	1
23	195- 33	WASHER - flat, 1/2"	1
24	131- 354	NUT - hex, self lock, 1/2" - 13 NC	1



ELECTRICAL SYSTEM LIGHTS


REF.	PART NO.	DESCRIPTION	REQ'D.
L43743 FRONT LIGHT			
1 L	43743	LIGHT ASSEMBLY - front, 24 volt	2
1 A	25213	RETAINER - light	1
2 R	17306	BODY - light	1
3 L	10499	LAMP - sealed beam (#4589)	1
L43737 STOP AND TAIL LIGHT			
4 L	43737	LIGHT ASSEMBLY - stop and tail	2
4 NSS		BODY - light	1
5 L	33194	BULB - light (#1662)	1
L	32213	LENS KIT - replacement	1
6 NSS		LENS - red	1
7 NSS		GASKET - lens	1
8 173-	279	SCREW - machine, #6 - 32 NC x 5/8"	3
9 192-	23	WASHER - lock, 1/2"	1
10 129-	125	NUT - hex., self lock, 1/2" - 20 NF	1
D71193 REAR FLOOD LIGHT			
D	71193	LIGHT ASSEMBLY - rear flood, 24 volt	2
11 NSS		BODY - light	1
12 A	25212	LAMP - sealed beam (#4593)	1
13 A	25213	RETAINER - light	1
14 D	37048	BUSHING - light pivot	1
15 D	37049	WASHER - special	1
16 131-	9	NUT - hex., self lock, 1/2" - 20 NF	1
L43738 TURN SIGNAL AND FLASHER			
L	43738	LIGHT ASSEMBLY - turn signal and flasher	2
17 NSS		BODY - light	1
18 L	32257	BULB - light (#307)	1
L	32214	LENS KIT - replacement	2
19 NSS		LENS - signal light	1
20 NSS		GASKET - lens	1
21 173-	279	SCREW - machine, #6 - 32 NC x 5/8"	3
22 129-	125	NUT - hex., 1/2" - 20 NF	1
23 192-	23	WASHER - lock, 1/2"	1
24 L	32256	WASHER - rubber	1
25 195-	106	WASHER - flat, 1/2"	1

Continued on next page




**ELECTRICAL SYSTEM
LIGHTS**

REF.	PART NO.	DESCRIPTION	REQ'D.
L73251 ENGINE WARNING LIGHT			
L	73251	LIGHT ASSEMBLY - engine warning, backhoe console, with red bulb and clear lens, if used	1
26	L 36002	LENS AND HOUSING - clear	1
27	L 30505	SPRING - light	1
28	45490	BULB - red (#1003R)	1
29	NSS	SOCKET - light base	1
L78150 ENGINE WARNING LIGHT			
L	73251	LIGHT ASSEMBLY - engine warning, backhoe console, with clear bulb and red lens, if used	1
26	D 78345	LENS AND HOUSING - red	1
27	L 30505	SPRING - light	1
28	B 50223	BULB - clear (#1003)	1
29	NSS	SOCKET - light base	1




**ELECTRICAL SYSTEM
TURN SIGNAL AND FLASHER CONTROL**

REF.	PART NO.	DESCRIPTION	REQ'D.
EARLY PRODUCTION			
1	214- 258	CLAMP - flasher switch	2
	L 52823	SIGNAL - turn and flasher, use L73667 signal, L59393 wire and F43508 spade	1
2	NSS	SWITCH - turn signal	1
3	A 14928	BULB - directional indicator, 24 volt (#358)	1
4	L 32658	STRAP - mounting, signal	1
	L 32659	KIT - mounting, turn signal	1
5	169- 148	SCREW - flat head machine, #8 - 32 NC x 1"	2
6	NSS	CLIP - strap mounting	2
7	223- 6	FUSE - 6 amp (3AG6)	1
8	L 32657	FLASHER - signal	1
9	L 11778	BULLET - connecting, male	1
10	L 11779	TUBING - protective	1
LATE PRODUCTION			
	L 73252	SIGNAL KIT - turn and flasher, use L73667 signal, L73672 wire and F43508 spade	1
	L 73667	SIGNAL KIT - turn and flasher	1
11	NSS	SWITCH - turn signal	1
12	A 14928	BULB - direction indicator, 24 volt (#358)	1
13	L 32658	STRAP - mounting, signal	1
14	NSS	FLASHER - signal	1
	L 32659	KIT - mounting, turn signal	1
15	169- 148	SCREW - flat head machine, #8 - 32 NC x 1"	2
16	NSS	CLIP - strap mounting	2
17	214- 258	CLAMP - flasher mounting	2
18	L 73672	WIRE - to circuit breaker, L73667 signal	1
19	F 43508	TERMINAL - spade, L73672 wire	1




ELECTRIC HORN

REF.	PART NO.	DESCRIPTION	REQ'D.
1	REF.	GEAR AND VALVE - steering, parts list page 125 and 127	1
2 A	65544	WHEEL - steering	1
	A 16843	BUTTON ASSEMBLY - horn	1
3 A	13088	COVER - horn button.....	1
4 A	13089	BUTTON - horn	1
5 A	13092	CUP - contact	1
6 A	13091	SPRING - button	1
7 A	13090	CAP - contact.....	1
8 A	13093	PLATE - base	1
9 187-	321	SCREW - self-tapping, #8 - 32 NC x 1/2"	3
10 A	13058	FERRULE - insulating	1
11 A	13059	SPRING - contact (Not used on 680E)	1
12 A	13057	CONTACT - lower (Not used on 680E)	1
13 L	60175	ADAPTOR - horn button	1
14 195-	2099	WASHER - flat, 7/8", plated	1
15 L	70486	WIRE - steering column to horn	1
16 L	11541	TIE - wire mounting	2
17 *L	10353	HORN - electric, 24 volt	1
18 13-	520	HHCS - 3/8" - 16 NC x 1-1/4"	1
19 92-	5	WASHER - lock, 3/8"	1
20 25-	105	NUT - hex., 3/8" - 16 NC	1
21 L	70487	WIRE - horn to circuit breaker	1
22 *L	73799	BRACKET - horn mounting	1
23 *L	30866	NUT - horn mounting	1
*D	77650	HORN ASSEMBLY - includes items above preceded by an asterisk	1




**BACKUP ALARM
EARLY PRODUCTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 47989	SWITCH - stop light	1
2	L 57475	WIRE - jumper, stop light switch to pressure switch, orange-black color	1
2	L 79089	WIRE - jumper, stop light switch to pressure switch, pink-white color	1
3	223- 10	FUSE - protective, 10 amp. (3AG10)	1
4	221- 51	BUSHING - reducing, 1/4" NPT to 1/8" NPT	1
5	L 57459	SWITCH - pressure, alarm	1
6	L 57474	WIRE - pressure switch to alarm	1
	L 57528	ALARM ASSEMBLY - backup	1
7	NSS	ALARM - backup	1
8	R 18653	CONNECTOR - male bullet	1
9	223- 56	EYELET - backup alarm	1
10	13- 616	HHCS - 3/8" - 16 NC x 1"	2
11	92- 6	WASHER - lock, 3/8"	2
12	25- 106	NUT - hex., 3/8" - 16 NC	2
13	L 13766	GROMMET - wire	1



**BACKUP ALARM
LATE PRODUCTION**


REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 47989	SWITCH - stop light	1
2	L 79089	WIRE - jumper, stop light switch to pressure switch, pink-white color	1
3	223- 10	FUSE - protective, 10 amp, (3AG10)	1
4	221- 51	BUSHING - reducing, 1/4" NPT to 1/8" NPT	1
5	L 57459	SWITCH - pressure, alarm	1
6	L 79067	WIRE - pressure switch to alarm	1
7	L 70498	ALARM ASSEMBLY - backup	1
8	L 59563	WIRE - alarm ground	1
9	13- 616	HHCS - 3/8" - 16 NC x 1"	2
10	92- 6	WASHER - lock, 3/8"	2
11	25- 106	NUT - hex., 3/8" - 16 NC	2



STEERING HYDRAULICS
MANUAL STEERING PUMP TO STEERING CYLINDERS


REF.	PART NO.	DESCRIPTION	REQ'D.
1 A	62210	CAP - steering wheel	1
2 A	29884	RING - medallion retaining	1
2A A	14567	NUT - hex., special (Steering wheel mounting)	1
3 A	65544	WHEEL - steering	1
4 13-	620	HHCS - 3/8" - 16 NC x 1-1/4"	2
5 L	45471	BEARING - column support.....	1
6 95-	6	WASHER - flat, 3/8"	4
7 92-	6	WASHER - lock, 3/8"	2
8 25-	106	NUT - hex., 3/8" - 16 NC	2
9	REF.	GEAR AND VALVE - steering, see page 125 and 127 for proper gear	1
10 13-	512	HHCS - 5/16" - 18 NC x 3/4"	3
11 92-	5	WASHER - lock, 5/16"	3
12 95-	5	WASHER - flat, 5/16"	3
13 L	59106	HOSE - steering valve to relief valve, 17" (432 mm) long	2
14 218-	5005	O-RING - hose	1
15 218-	573	FITTING - at check valve, 3-way	1
16 L	59038	VALVE - check	2
17 218-	5442	FITTING - check valve to relief valve	2
17A 218-	5006	O-RING - fitting	1
18 L	59037	VALVE - secondary relief	1
19	NSS	BODY - valve	1
20 L	36080	CARTRIDGE ASSEMBLY - relief	1
21	NSS	CARTRIDGE - relief, non-adjustable, not shown	1
22 R	31000	KIT - repair, seal, not shown	1
23 13-	432	HHCS - 1/4" - 20 NC x 2"	2
24 92-	4	WASHER - lock, 1/4"	2
25 25-	104	NUT - hex., 1/4" - 20 NC	2
26 L	59107	PLATE - mounting, relief valve, if used	1
27 T	31659	BOLT - "U" type, if used	1
28 95-	6	WASHER - flat, 3/8", if used	2
29 131-	471	NUT - hex., lock, 3/8" - 16 NC, if used	2
29A	REF.	PLATE - mounting, relief valve, welded to chassis	1
30 217-	348	FITTING - 90° adjustable, barb stem	1
31 218-	5006	O-RING - fitting	1
32 214-	254	CLAMP - hose	6
33 L	55952	HOSE - return, relief valve to tank, 1/2" (13 mm) I.D. x 16" (406 mm) long	1
34 L	59112	HOSE - return, steering 1/2" (13 mm) I.D. x 8" (203 mm) long ..1	
34A L	77374	HOSE - return, to tank 1/2" (13 mm) I.D. x 8" (203 mm) long ..1	
35 L	59109	FITTING - barb type, return hoses, 3-way	1
36 L	59105	HOSE - relief valve to steering cylinders, 85" (2159 mm) long ..2	

Continued on next page



STEERING HYDRAULICS
MANUAL STEERING PUMP TO STEERING CYLINDERS


REF.	PART NO.	DESCRIPTION	REQ'D.
37	L 11541	STRAP - hose tie	2
38	13- 624	HHCS - 3/8" - 16 NC x 1-1/2"	4
39	49858	CLAMP - hose	4
40	95- 6	WASHER - flat, 3/8"	4
41	92- 6	WASHER - lock, 3/8"	4
42	25- 106	NUT - hex., 3/8" - 16 NC	4
43	L 57911	FITTING - tee, special, closed end of steering cylinder	2
44	218- 5005	O-RING - seal	1
45	218- 5105	FITTING - adjustable, 90°, rod end	2
46	218- 5005	O-RING - fitting	1
47	L 57299	HOSE - R.H to L.H. steering cylinder, 36" (914 mm) long	2
48	G 34886	CYLINDER - steering, parts list page 129	2
49	132- 48	PIN - cotter, 1/8" dia. x 1"	4
50	217- 397	FITTING - hose stem, straight	1
51	218- 5005	O-RING - fitting	1



STEERING VALVE HYDRAULIC CIRCUIT
***EARLY PRODUCTION**


REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 55247	PUMP - hydraulic, equipment, parts list page 335	1
2	218- 5064	FITTING - straight, male connector	1
3	218- 5008	O-RING - fitting	1
4	L 55955	HOSE - pump to relief valve, 26-1/2" (673 mm) long	1
5	218- 576	FITTING - pressure check, 3-way	1
6	218- 665	PLUG - pressure check, 3/4" NPT	1
7	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	1
8	49858	CLAMP - tube, 3/4" (19 mm) tube O.D.	1
9	95- 6	WASHER - flat, 3/8"	1
10	92- 6	WASHER - lock, 3/8"	1
11	25- 106	NUT - hex., 3/8" - 16 NC	1
12	L 55802	TUBE - pump to relief valve	1
13	218- 5064	FITTING - straight, male connector	2
14	218- 5008	O-RING - fitting	1
15	*L 54772	VALVE - relief, hydraulic, parts list page 333	1
16	13- 648	HHCS - 3/8" - 16 NC x 3"	3
17	195- 104	WASHER - flat, 3/8"	3
18	92- 6	WASHER - lock, 3/8"	3
19	25- 106	NUT - hex., 3/8" - 16 NC	3
20	L 55804	TUBE - relief valve to flow divider valve	1
21	218- 5065	FITTING - straight, male connector	1
22	218- 5007	O-RING - fitting	1
23	13- 548	HHCS - 5/16" - 18 NC x 3"	2
24		RESERVED	
25	L 54770	VALVE - flow control, parts list page 331	1
26	195- 2042	WASHER - flat, 5/16"	2
27	92- 5	WASHER - lock, 5/16"	2
28	25- 105	NUT - hex., 5/16" - 18 NC	2
29	218- 5060	FITTING - straight, male connector	1
30	218- 5007	O-RING - fitting	1
31	218- 5576	FITTING - adjustable, 3-way	1
32	218- 5007	O-RING - fitting	1
33	L 55806	TUBE - upper port of flow control valve to steering valve	1
34	L 55808	TUBE - lower port of flow control valve to steering valve	1
35	218- 5351	FITTING - straight, male connector	2
36	218- 5005	O-RING - fitting	1
37	REF.	VALVE - steering control, see page 127 for proper valve	1
	L 71138	KIT - relief valve	1
38	L 59641	VALVE - relief, hydraulic, parts list page 333	1
39	L 71137	HOSE - return, relief valve, 1" (25 mm) I.D. x 26" (660 mm) long	1
40	218- 5065	FITTING - straight, male connector	2
40A	218- 5007	O-RING - fitting	1
41	214- 257	CLAMP - hose	2
42	217- 366	FITTING - 90°, barb stem adjustable	1
43	218- 5008	O-RING - fitting	1

*NOTE: Early production circuits used a Gresch manufactured relief valve. For service of complete relief valve, order L71138 relief valve kit, parts list above.




STEERING VALVE HYDRAULIC CIRCUIT
***LATE PRODUCTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 55247	PUMP - hydraulic, equipment, parts list page 335	1
2	218- 5064	FITTING - straight, male connector	1
3	218- 5008	O-RING - fitting	1
4	L 55955	HOSE - pump to relief valve, 26-1/2" (673 mm) long	1
5	218- 583	TEE - pressure check, steering valve	1
6	218- 665	PLUG - pressure check, 3/4" NPT	1
7	13- 648	HHCS - 3/8" - 16 NC x 3"	1
8	L 17788	CLAMP - used with tubes only	1
8A	L 59126	CLAMP - used with hoses, see item 14A	1
9	95- 6	WASHER - flat, 3/4"	1
10	92- 6	WASHER - lock, 3/8"	1
11	25- 106	NUT - hex., 3/8" - 16 NC	1
12	D 37116	BLOCK - spacer, tube mounting	1
13	L 59801	CHANNEL - tube mounting, used with tubes only	1
14	L 59796	TUBE - to relief valve	1
14A	L 71569	HOSE - to relief valve, models with increased noise control, 29-1/4" (743 mm) long	1
15	218- 5046	FITTING - straight, male connector	2
16	218- 5010	O-RING - fitting	1
17	L 59641	VALVE - relief, hydraulic, parts list page 333	1
18	L 59790	TUBE - relief valve to flow divider valve	1
19	218- 5065	FITTING - straight, male connector	2
20	218- 5007	O-RING - fitting	1
21	13- 548	HHCS - 5/16" - 18 NC x 3"	2
22	L 54770	VALVE - flow control, parts list page 331	1
23	195- 2042	WASHER - flat, 5/16"	2
24	92- 5	WASHER - lock, 5/16"	2
25	25- 105	NUT - hex., 5/16" - 18 NC	2
26	218- 5060	FITTING - straight, male connector	1
27	218- 5007	O-RING - fitting	1
28	218- 5576	TEE - adjustable	1
29	218- 5007	O-RING - seal	1
30	L 55806	TUBE - upper port of flow control valve to steering valve	1
30A	L 71566	HOSE - special, upper port of flow control valve to steering valve, models with increased noise control	1
31	L 55808	TUBE - lower port of flow control valve to steering valve	1
31A	L 71567	HOSE - special, lower port of flow control valve to steering valve, models with increased noise control	1
32	218- 5351	FITTING - straight, male connector	2
33	218- 5005	O-RING - fitting	1
34	REF.	VALVE - steering control, see page 127 for proper valve	1



STEERING COLUMN


REF.	PART NO.	DESCRIPTION	REQ'D.
L	54773	STEERING COLUMN ASSEMBLY - tractor, models without electric horn	1
L	59941	STEERING COLUMN ASSEMBLY - tractor, models with electric horn	1
1	L 36068 NSS	VALVE ASSEMBLY - steering, parts list page 127	1
		SHAFT AND TUBE - steering column, models without electric horn	1
2	A 14567	NUT - steering wheel	1
3	L 36008	SHAFT - steering column	1
	L 36009	TUBE ASSEMBLY - shaft	1
4	NSS	TUBE - jacket, shaft	1
5	L 35675	BEARING AND SEAL - shaft	1
6	L 35654	PIN - coupling	2
	D 72851	KIT - coupling	1
7	NSS	COUPLING - steering column shaft and valve shaft	1
8	NSS	RING - pin retaining	2
	L 35657	CLAMP ASSEMBLY - tube	1
9	NSS	CLAMP - tube	1
10	14- 532	HHCS - 5/16" - 24 NF x 2"	1
11	193- 29	WASHER - internal tooth lock, 5/16"	1
12	129- 122 NSS	NUT - hex., 5/16" - 24 NF, zinc plated	1
		SHAFT AND TUBE - steering column, models with electric horn	1
13	A 14567	NUT - steering wheel	1
14	D 66476	SHAFT - steering column	1
	D 66478	CABLE ASSEMBLY - electric horn	1
15	A 14954	TERMINAL - electric horn	1
16	A 13058	FERRULE - cable guide	1
17	NSS	CABLE - electric horn	1
18	T 30271	O-RING - cable protection	1
19	D 66479	TUBING - cable protection	1
20	D 66480	TERMINAL - electric horn	1
21	D 66477	RING - contact, electric horn	1
22	182- 82 D 66475	SCREW - ring mounting	1
		TUBE ASSEMBLY - steering column	1
23	NSS	TUBE - steering column	1
24	L 35675	BEARING AND SEAL - steering column	1
25	A 13060	TERMINAL - electric horn connections	1
26	182- 82	SCREW - #8 - 32 NC x 1/4"	2
27	193- 41	WASHER - internal tooth lock, #8	2
28	195- 10	WASHER - flat, #8	2
29	L 35653	COUPLING - steering column and pump shaft	1
30	L 35654	PIN - coupling	2
31	L 35655 L 35657	RING - pin retaining	2
		CLAMP ASSEMBLY - tube	1
32	NSS	CLAMP - tube	1
33	14- 532	HHCS - 5/16" - 24 NF x 2"	1
34	193- 29	WASHER - internal tooth lock, 5/16"	1
35	129- 122	NUT - hex., 5/16" - 24 NF, plated	1



STEERING VALVE

REF.	PART NO.	DESCRIPTION	REQ'D.
L	54773	STEERING COLUMN ASSEMBLY - tractor, models without electric horn	1
L	59941	STEERING COLUMN ASSEMBLY - tractor, models with electric horn	1
1	NSS	SHAFT AND TUBE — steering column, models without electric horn, parts list page 125	1
1	NSS	SHAFT AND TUBE — steering column, models with electric horn, parts list page 125	1
L	36068	VALVE ASSEMBLY - steering	1
2	NSS	HOUSING AND SPOOL ASSEMBLY	1
3 A	43551	SHAFT - input, pump	1
4 D	53297	PIN - torsion bar retaining	1
D	65140	SEAL KIT - shaft, order D73671 kit for service	1
5	NSS	SEAL - dust	1
6	NSS	RING - seal	1
7	NSS	SPACER - seal kit	1
8	NSS	PACKING - input shaft	1
D	73671	SEAL KIT - shaft	1
8A D	70586	SEAL - dust	1
8B	NSS	RING - seal	1
8C	NSS	SEAL AND SPACER - shaft	1
9 A	21145	SNAP RING - bearing retaining	1
10 D	65139	COVER - upper, uses cast bushing surface	1
11 A	43567	SCREW - 5/16" - 18 NC x 3/4"	4
12 A	43566	SEAL - cover	1
13 A	43564	BEARING - roller, needle, used with A43562 cover only	1
14 A	44435	SHIM KIT - cover	1
15 A	43720	RING - retaining, shaft	1
16 A	43558	WASHER - thrust	1
17 F	19633	BEARING - thrust	1
18 F	19634	WASHER - thrust	1
19 A	43721	WASHER - wave	1
20 A	43728	SPACER - bearing	1
21 A	43554	RING - drive	1
22 L	36070	SPACER - drive link	1
23 L	36069	BAR - torsion	1
24 211-	9	BALL - 5/16" dia.	1
25 A	43560	SPRING - preload	1
L	36015	PLUG ASSEMBLY - valve	1-2
26	NSS	PLUG - valve	1
27 A	43729	O-RING - seal	1
27A 211-	7	BALL - check	1
F	82943	CHECK ASSEMBLY - ball type	1
28	NSS	PLUG - check assembly	1
29 218-	5002	SEAL - O-ring	1
30 138-	60	PIN - check assembly	1
31 211-	7	BALL - check assembly	1
32 A	43569	SPACER - link	1


Continued on next page



MODEL 680E CONSTRUCTION KING LOADER BACKHOE 127B

STEERING VALVE


REF.	PART NO.		DESCRIPTION	REQ'D.
L	54773		STEERING COLUMN ASSEMBLY - tractor, models without electric horn	1
L	59941		STEERING COLUMN ASSEMBLY - tractor, models with electric horn	1
33 A	43568		LINK - drive	1
D	66466		ROTOR SET - valve	1
34	NSS		GEAR - star	1
35	NSS		GEAR - ring	1
36 L	36076		VANE - valve star	6
37 L	36075		SPRING - vane	6
38 A	43573		MANIFOLD - valve	1
39 A	43574		COMMUTATOR - valve	1
40 L	36072		SEAL - rotor	1
41 D	71233		RETAINER - seal	1
42 A	43579		WASHER - wear, rotor	1
43 A	43580		COVER - end	1
44 L	36074		HHCS - 5/16" - 18 NC x 3-1/4", special	7



741994 A


MODEL 680E CONSTRUCTION KING LOADER BACKHOE 129

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 34886	CYLINDER ASSEMBLY - 2-1/8" (54 mm) I.D. x 7-1/2" (190 mm) stroke	2
2	G 34691	TUBE - cylinder body	1
3	L 59042	BALL JOINT ASSEMBLY - closed end	1
4	D 72832	COVER - dust	1
5	25- 1314	NUT - hex., slotted, 7/8" - 14 NF	1
6	129- 169	NUT - hex., jam, 7/8" - 14 NF	1
7	L 59041	BALL JOINT ASSEMBLY - rod end	1
8	D 72832	COVER - dust	1
9	25- 1314	NUT - hex., slotted, 7/8" - 14 NF	1
10	G 34695	ROD - piston, 1-1/4" dia.	1
11	187- 1031	SCREW - gland lock, #8 - 32 x 1/4", self tapping.	1
12	A 62071	GLAND - cylinder	1
13	A 61428	PISTON - cylinder	1
14		RESERVED	
	A 43296	SEAL KIT - cylinder repair	1
15	A 61426	WIPER - piston rod, in gland, step type	1
16	A 61425	SEAL - piston rod, in gland	1
17	A 60212	O-RING - gland	1
18	A 62070	RING - gland, back-up	1
19	A 61429	O-RING - piston	1
20	A 61430	RING - piston	1
21	28- 1028	BOLT - piston, 5/8" x 1-3/4" NF	1
22	D 43266	WASHER - piston bolt	1
G100674 STEERING CYLINDER			
1	G 100674	CYLINDER ASSEMBLY - 2-1/8" (54 mm) I.D. x 7-1/2" (190 mm) stroke	2
2	G 34691	TUBE - cylinder body	1
3	L 59042	BALL JOINT ASSEMBLY - closed end	1
4	D 72832	COVER - dust	1
5	25- 1314	NUT - hex., slotted, 7/8" - 14 NF	1
6	129- 169	NUT - hex., jam, 7/8" - 14 NF	1
7	L 59041	BALL JOINT ASSEMBLY - rod end	1
8	D 72832	COVER - dust	1
9	25- 1314	NUT - hex., slotted, 7/8" - 14 NF	1
10	G 34695	ROD - piston, 1-1/4" dia.	1
11	187- 1031	SCREW - gland lock, #8 - 32 NC x 1/4", self tapping	1
12	* NSS	GLAND - cylinder	1
13	A 61428	PISTON - cylinder	1
14		RESERVED	
	G 101021	SEAL KIT - cylinder repair	1
15A*D	95141	WIPER - piston rod, U-cup type	1
16A*D	36968	SEAL - piston rod, U-cup type	1
17 *A	60212	SEAL - O-ring, gland	1
18 *A	62070	RING - gland, backup	1
19 A	61429	SEAL - O-ring, piston	1
20 A	61430	RING - piston	1
21 28-	1028	BOLT - piston, 5/8" - 18 NF x 1-3/4", grade 8	1
22 D	43266	WASHER - piston bolt	1
*G	34820	GLAND ASSEMBLY - with seals, includes all items marked with an asterisk. Can be used to convert G34886 cylinder above into G100674 cylinder	1



G102602 STEERING CYLINDER

REF.	PART NO.	DESCRIPTION	REQ'D
1	G 102602	CYLINDER ASSEMBLY - 2-1/8" (54 mm) I.D. x 7-1/2" (190 mm) stroke	2
2	G 34691	TUBE - cylinder body	1
3	L 59042	BALL JOINT ASSEMBLY - closed end	1
4	D 72832	COVER - dust	1
5		RESERVED	
6	129- 169	NUT - hex, jam, 7/8" - 14 NF	1
7	L 59041	BALL JOINT ASSEMBLY - rod end	1
8	D 72832	COVER - dust	1
9		RESERVED	
10	G 34695	ROD - piston, 1-1/4" (32 mm) O.D.	1
11	187- 1031	SCREW - gland lock, #8 - 32 NC x 1/4", self tapping	1
12	*NSS	GLAND - cylinder	1
13	G 102604	PISTON - cylinder	1
	G 34819	SEAL KIT - cylinder repair	1
14	*D 95141	WIPER - piston rod, U-cup type	1
15	*D 36968	SEAL - piston rod, U-cup type	1
16	*A 60212	O-RING - gland	1
17	*A 62070	RING - gland, backup	1
18	A 61429	O-RING - piston	1
19	A 61430	RING - piston	1
20	G 101837	RING - wear	1
21	28- 1028	BOLT - piston, 5/8" - 18 NF x 1- 3/4", grade 8	1
22	D 43266	WASHER - piston bolt	1
*G	34820	GLAND ASSEMBLY - with seals, includes all items marked with an asterisk ..	1




FRONT AXLE, SPINDLES AND TIE ROD

REF.	PART NO.	DESCRIPTION	REQ'D.
1 L	71446	AXLE ASSEMBLY - front steering, uses short bushings, see item 3 for identification	1
1 L	73640	AXLE ASSEMBLY - front steering, uses long bushings, see items 3A and 3B for identifications	1
2 L	71756	BUSHING - steering arm pin	4
3 L	57710	BUSHING - axle to chassis, short bushings, used in L71446 axle.....	4
3A L	73643	BUSHING - axle to chassis, long bushing, used in L73640 axle assembly	1
3B L	73635	BUSHING - axle to chassis, rear, long bushing, used in L73640 axle assembly	1
4 219-	55	FITTING - grease, 90°, 1/8" NPT	2
5 L	57714	PIN - pivot, axle to chassis	1
6 L	11917	SHIM - axle to chassis	UAR
7 D	26919	RING - retaining	2
8 219-	1	FITTING - grease, straight, 1/8" NPT	2
9 13-	1224	HHCS - 3/4" - 10 NC x 1-1/2"	2
10 A	61406	WASHER - steering arm pin	2
11 L	57457	SHIM - steering arm pin, 2-9/32" (57.94 mm) I.D. x 2-1/2" (63.5 mm) O.D., if used	UAR
.11A 95-	12	WASHER - flat, 3/16" (4.76 mm) I.D. x 2" (50.8 mm) O.D., used with L71370 and L71371 spindles, not shown	UAR
12 L	71370	SPINDLE AND KING PIN - steering, R.H., early production use L73886 spindle and king pin	1
12 L	73886	SPINDLE AND KING PIN - steering, R.H., late production	1
13 L	71371	SPINDLE AND KING PIN - steering, L.H., early production, use L73887 spindle and king pin	1
13 L	73887	SPINDLE AND KING PIN - steering, L.H., late production	1
14 132-	56	PIN - cotter, 1/8" x 2"	2
15 195-	45	WASHER - flat, 3/4"	2
16 G	34886	CYLINDER ASSEMBLY - steering, parts list page 129	2
17 L	71369	SHIM - thrust, steering	UAR

MODELS WITH NUT RETAINED BALL JOINTS TO TUBE


18 L	54130	TUBE - tie rod	1
19 A	41511	NUT - jam, tie rod	2
20 L	13421	BALL JOINT - tie rod to spindle	2
21 A	41515	SEAL - boot, ball joint	1
22 25-	1310	NUT - hex., slotted, 5/8" - 18 NF	1

Continued on next page



FRONT AXLE, SPINDLES AND TIE ROD**MODELS WITH CLAMP RETAINED BALL JOINTS TO TUBE**

REF.	PART NO.	DESCRIPTION	REQ'D.
L	70639	TIE ROD ASSEMBLY - front steering	1
D	66470	BALL JOINT ASSEMBLY - tie rod to spindle, R.H.	1
D	66467	BALL JOINT ASSEMBLY - tie rod to spindle, L.H.	1
23	NSS	BALL JOINT - tie rod	1
24	129- 610	NUT - hex., 5/8" - 18 NF	1
25	A 31186	SEAL - dust cover	1
26	D 66468	TUBE - tie rod	1
27	A 16638	CLAMP - ball joint retaining	2
28	14- 840	HHCS - 1/2" - 20 NF x 2-1/2", if used	2
28	113- 422	HHCS - 1/2" - 13 NC x 2-1/2", plated, if used	2
29	92- 8	WASHER - lock, 1/2", if used	2
30	25- 118	NUT - hex., 1/2" - 20 NF, if used	2
30	131- 1116	NUT - hex., lock, 1/2" - 13 NC, plated, if used	2



FRONT WHEELS AND HUBS

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 76788	BOLT - wheel to hub	16
2	A 61450	CAP - bearing cover	2
3	25- 1918	NUT - hex., castle	2
4	132- 99	PIN - cotter, 3/16" dia. x 2"	2
5	D 74949	WASHER - thrust, outer bearing	2
6	G 15215	CONE - bearing, outer	1
	A 66759	HUB ASSEMBLY - front wheel	2
7	NSS	HUB - front wheel	1
8	G 15214	CUP - bearing, outer	1
9	A 61446	CUP - bearing, inner	1
10	A 61447	CONE - bearing, inner	2
10A	A 61448	SEAL - oil, hub	1
11	A 61449	SEAL - oil, spindle	2
12	REF.	TIRE - front	2

USED ON MODELS WITH 11.00 X 16-12 PLY TIRES


13	A 61570	WHEEL - front	2
14	A 20058	VALVE STEM - wheel	2

USED ON MODELS WITH 12.5L X 16-12 PLY TIRES

15	L 73000	WHEEL - front	2
16	A 20058	VALVE STEM - wheel	2

USED ON MODELS WITH 14L OR 14.5/.75 X 16.1 - 10 PLY TIRES

17	L 57966	WHEEL - front steering	2
18	A 20058	VALVE STEM - wheel	2



710743

REAR WHEELS

REF.	PART NO.	DESCRIPTION	REQ'D.
------	----------	-------------	--------

USED ON MODELS WITH 16.9 X 24-8 PLY TIRES

1 L	57550	RIM - rear drive wheel	2
2	REF.	TIRE - rear drive, 16.9 x 24 - 8 ply	2
3 L	50592	NUT - valve stem, tube type tires only	2
4 A	20058	VALVE STEM - wheels, tubeless tires only.....	2

USED ON MODELS WITH 16.9 X 24-10 PLY TIRES

1 L	57550	RIM - rear drive wheel	2
2	REF.	TIRE - rear drive, 16.9 x 24 - 10 ply	2
3 L	50592	NUT - valve stem, tube type tires only	2
4 A	20058	VALVE STEM - wheel, tubeless tires only.....	2

USED ON MODELS WITH 16.9 X 24-12 PLY TIRES


1 L	57550	RIM - rear drive wheel	2
2	REF.	TIRE - rear drive, 16.9 x 24 - 12 ply	2
3 L	50592	NUT - valve stem, tube type tires only	2
4 A	20058	VALVE STEM - wheel, tubeless tires only.....	2

USED ON MODELS WITH 16.9 X 28-8 - 10 PLY TIRES

1 L	57552	RIM - rear drive wheel	2
2	REF.	TIRE - rear drive, 16.9 x 28 - 8 or 10 ply	2
3 L	50592	NUT - valve stem, tube type tires only	2
4 A	20058	VALVE STEM - wheel, tubeless tires only.....	2

**USED ON MODELS WITH 19.5L X 24-12 PLY TIRES
(FOR TRACTORS EXCEPT WHEN EQUIPPED WITH EXTENDAHOE)**


1 L	57551	RIM AND DISC - rear drive wheel	2
2	REF.	TIRE - rear drive, 19.5L x 24-12 ply	2
3 L	50592	NUT - valve stem, tube type tires only	2
4 A	20058	VALVE STEM - wheel, tubeless tires only.....	2



TRANSMISSION AND RELATED PARTS


REF.	PART NO.	DESCRIPTION	REQ'D.
1	13- 616	HHCS - 3/8" - 16 NC x 1", transmission to flywheel housing . . .	12
2	92- 6	WASHER - lock, 3/8"	12
3	REF.	TRANSMISSION ASSEMBLY - forward and reverse, parts list pages 143 thru 163	1
4 L	47759	GASKET - forward-reverse transmission to adapter plate, before transmission sn. 75001	1
4A D	72754	GASKET - forward-reverse transmission to adapter plate, transmission sn. 75001 and after	1
5 L	35545	SCREW - sealing, special, before trans. sn. 75001	9
5A 165-	168	SCREW - hex., socket head, 5/16" - 18 NC x 1-1/2", trans. sn. 75001 and after	9
6 D	78400	PLATE - adapter, forward-reverse to four speed transmission	1
7 138-	127	PIN - roll, 1/4" dia. x 1/2" long, if used	1
8 D	71460	GASKET - adapter plate to four speed transmission	1
9 13-	924	HHCS - 9/16" - 12 NC x 1-1/2"	1
9 13-	928	HHCS - 9/16" - 12 NC x 1-3/4"	3
10 92-	9	WASHER - lock, 9/16"	4
11 L	54268	TRANSMISSION ASSEMBLY - four speed, parts list pages 167 thru 173	1
12 26-	1036	HHCS - 5/8" - 11 NC x 2-1/4", grade 8	4
13 D	43266	WASHER - hardened, 5/8"	4
14 L	55862	BRACKET - mounting, adapter plate to chassis R.H.	1
15 L	55863	BRACKET - mounting, adapter plate to chassis L.H.	1
16 S	93392	CUSHION - rubber, transmission	2
17 13-	1264	HHCS - 3/4" - 10 NC x 4"	2
18 L	50197	SHIM - 16 gauge	UAR
19 L	50194	SHIM - 12 gauge	UAR
20 A	19068	WASHER - special, rubber mount	2
21 95-	12	WASHER - flat, 3/4"	2
22		RESERVED	
23 131-	1205	NUT - hex., self lock, 3/4" - 10 NC	2
24 L	59905	DRIVE SHAFT ASSEMBLY - four speed transmission to rear axle, includes items 25 thru 36	1
25 L	31781	BOLT - special, front spider and bearing to four speed transmission, 3/8" - 24 NF x 1-7/8"	4
26 192-	161	WASHER - heavy lock, 3/8"	4
	L 32423	SPIDER AND BEARING ASSEMBLY - front	1
27	NSS	SPIDER AND BEARING - front	1
28 219-	1	FITTING - grease, straight, 1/8" NPT	1
29 L	48345	COUPLING - center, spider and bearing	1

Continued on next page



TRANSMISSION AND RELATED PARTS


REF.	PART NO.	DESCRIPTION	REQ'D.
	L 31776	SPIDER AND BEARING ASSEMBLY - rear	1
30	NSS	SPIDER AND BEARING - rear.....	1
31	219- 1	FITTING - grease, straight, 1/8" NPT	1
32	28- 648	BOLT - special, spider and bearing assemblies to center coupling, 3/8" - 24 NF x 3"	4
33	L 33426	BOLT - special, rear spider and bearing to splined yoke, 3/8" - 24 NF x 1-3/4"	4
34	192- 161	WASHER - heavy lock, 3/8"	8
35	D 65185	YOKE - splined, to rear axle	1
35A	41- 51	PLUG - expansion, not shown	1
36	219- 1	FITTING - grease, straight, 1/8" NPT	1
37	REF.	AXLE ASSEMBLY - rear drive, parts list pages 177 thru 219	1
38	L 48498	SEAL - drive shaft, at splined yoke	1



**TRANSMISSION
TORQUE CONVERTER HOUSING AND PUMP
BEFORE TRANSMISSION SN 75001**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 35677	TRANSMISSION ASSEMBLY - forward and reverse.....	1
	D 66379	HOUSING ASSEMBLY - transmission	1
1	NSS	HOUSING - transmission	1
2	G 13075	BEARING - housing	1
3	221- 841	PLUG - pipe, hex. socket head, 1/4" NPT	2
4	221- 13	PLUG - pipe, square head, 3/8" NPT, not shown	2
4A	D 73701	PLUG - pipe, drain, 5/8" NF, not shown	1
5	L 30972	VALVE ASSEMBLY - forward and reverse control, see page 155.....	1
6	L 32119	GASKET - valve body	1
7	13- 520	HHCS - 5/16" - 18 NC x 1-1/4".....	8
8	13- 536	HHCS - 5/16" - 18 NC x 2-1/4".....	4
9	92- 5	WASHER - lock, 5/16"	12
10	221- 4	PLUG - pipe, 1/2" NPT	1
11	L 32746	SPRING - screen	1
12	L 32745	SCREEN - oil	1
13	L 30237	RING - sealing, 3-1/2" (89 mm) O.D.	2
14	A 14833	RING - sealing, 3" (76 mm) O.D.	2
15	L 30486	RING - sealing, 2" (51 mm) O.D.	1
16	L 35684	CLUTCH ASSEMBLY - forward and reverse, see page 151	1
17	D 66388	GASKET - transmission housing	1
18	L 35692	CASE - transmission, front	1
19	211- 12	BALL - steel, 7/16" (11 mm) dia.	2
20	L 33705	SPRING - pop valve	2
21	A 14810	WASHER - special	2
22	A 14811	SEAT - spring, pop valve	2
23	13- 618	HHCS - 3/8" - 16 NC x 1-1/8"	5
23	13- 628	HHCS - 3/8" - 16 NC x 1-3/4"	3
24	92- 6	WASHER - lock, 3/8"	8
25	221- 661	PLUG - pipe, hex. head, 1/8" NPT	3
26	L 30487	GASKET - jump	1
27	L 30488	PUMP ASSEMBLY - torque converter charging	1
28	L 30489	SEAL - pump	1
29	221- 846	PLUG - square socket head, 1" NPT	1
30	221- 654	PLUG - hex. head, 1/2" NPT	1
31	13- 516	HHCS - 5/16" - 18 NC x 1"	6
32	92- 5	WASHER - lock, 5/16"	6
	L 30479	RETAINER ASSEMBLY - bearing	1
33	NSS	RETAINER - bearing	1
34	L 30245	PLUG - retainer	2
35	40025	BEARING - clutch	1
36	L 30483	SPACER - bearing	1
37	L 30484	RING - retaining, input shaft	1
38	13- 616	HHCS - 3/8" - 16 NC x 1"	12


Continued on next page



**TRANSMISSION
TORQUE CONVERTER HOUSING AND PUMP
BEFORE TRANSMISSION SN. 75001**

REF.	PART NO.	DESCRIPTION	REQ'D
39	92- 6	WASHER - lock, 3/8"	12
40	L 77848	CONVERTER - torque	1
41	L 11172	SHIM - pump engagement	UAR
42	195- 2024	WASHER - flat, 3/8"	UAR
	L 100684	KIT - torque converter drive	1
43	121- 104	BOLT - place, 5/16" - 18 NC x 3/ 4"	6
44	A 14512	WASHER - torque converter drive plate	6
45	A 14509	PLATE - torque converter drive	1
46	D 81592	PLATE - reinforcement	1
47	121- 203	BOLT - place, 3/8" - 24 NF x 1/2"	6

SEE PAGES 143 THRU 163 FOR COMPLETE TRANSMISSION




**TRANSMISSION
TORQUE CONVERTER HOUSING AND PUMP
TRANSMISSION SN. 75001 AND AFTER**

REF.	PART NO.	DESCRIPTION	REQ'D.
D	73700	TRANSMISSION ASSEMBLY - forward and reverse.....	1
D	66379	HOUSING ASSEMBLY - transmission	1
1	NSS	HOUSING - transmission	1
2	G 13075	BEARING - housing	1
3	221- 841	PLUG - pipe, hex. socket head, 1/4" NPT	2
4	221- 13	PLUG - pipe, square head, 3" NPT, not shown	2
4A	D 73701	PLUG - pipe, drain, 5/8" NF, not shown	1
5	D 66391	VALVE ASSEMBLY - forward and reverse control, parts list page 157	1
5A	D 72753	GASKET - valve body, trans. sn 76081 and after, part of D66391 valve, see page 157, not shown	1
6	D 66390	GASKET - valve body, before trans sn. 76081	1
7	13- 534	HHCS - 5/16" - 18 NC x 2-1/8"	5
8	13- 524	HHCS - 5/16" - 18 NC x 1-1/2"	5
8A	13- 518	HHCS - 5/16" - 18 NC x 1-1/8"	1
8B	13- 532	HHCS - 5/16" - 18 NC x 2"	1
9	92- 5	WASHER - lock, 5/16"	12
10	221- 4	PLUG - pipe, 1/2" NPT	1
11	L 32746	SPRING - screen	1
12	L 32745	SCREEN - oil	1
13	L 30237	RING - sealing, 3-1/2" (89 mm) O.D.	2
14	A 14833	RING - sealing, 3" (76 mm) O.D.	2
15	L 30486	RING - sealing, 2" (51 mm) O.D.	1
16	D 66382	CLUTCH ASSEMBLY - forward and reverse, parts list page 153	1
17	D 66388	GASKET - transmission housing	1
18	D 66389	CASE - transmission, front, includes item 35	1
19	211- 12	BALL - steel, 7/16" (11.1 mm) dia.	2
20	L 33705	SPRING - pop valve	2
21	A 14810	WASHER - special	2
22	A 14811	SEAT - spring, pop valve	2
23	13- 618	HHCS - 3/8" - 16 NC x 1-1/8"	5
23	13- 628	HHCS - 3/8" - 16 NC x 1-3/4"	3
24	92- 6	WASHER - lock, 3/8"	8
25	221- 661	PLUG - pipe, hex. head, 1/8" NPT	3
26	L 30487	GASKET - pump	1
27	L 30488	PUMP ASSEMBLY - torque converter charging	1
28	L 30489	SEAL - pump	1
29	221- 846	PLUG - square socket head, 1" NPT	1
30	221- 654	PLUG - hex. head, 1/2" NPT	1

SEE PAGES 143 THRU 163 FOR COMPLETE TRANSMISSION

Continued on next page




742509 A

TRANSMISSION
TORQUE CONVERTER HOUSING AND PUMP
TRANSMISSION SN. 75001 AND AFTER

REF.	PART NO.	DESCRIPTION	REQ'D
31	13- 516	HHCS - 5/16" - 18 NC x 1"	6
32	92- 5	WASHER - lock, 5/16"	6
	L 30479	RETAINER ASSEMBLY - bearing	1
33	NSS	RETAINER - bearing	1
34	L 30245	PLUG - retainer	2
35	40025	BEARING - clutch	1
36	L 30483	SPACER - bearing	1
37	L 30484	RING - retaining, input shaft	1
38	13- 616	HHCS - 3/8" - 16 NC x 1"	12
39	92- 6	WASHER - lock, 3/8"	12
40	L 77848	CONVERTER - torque	1
41	L 11172	SHIM - pump engagement	UAR
42	195- 2024	WASHER - flat, steel	UAR
	L 100684	KIT - torque converter dirve	1
43	121- 104	BOLT - place, 5/16" - 18 NC x 3/ 4"	6
44	A 14512	WASHER - torque converter drive plate	6
45	A 14509	PLATE - torque converter drive	1
46	D 81592	PLATE - reinforcement	1
47	121- 203	BOLT - place, 3/8" - 24 NF x 1/2"	6


SEE PAGES 143 THRU 163 FOR COMPLETE TRANSMISSION



**TRANSMISSION
FORWARD AND REVERSE CLUTCH
BEFORE TRANSMISSION SN. 75001**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 35677	TRANSMISSION ASSEMBLY - forward and reverse.....	1
1	D 66388	GASKET - transmission housing	1
2	L 30484	RING - snap, input shaft	1
3	L 30483	SPACER - bearing	1
4	40025	BEARING - clutch	1
5	13- 516	HHCS - 5/16" - 18 NC x 1"	6
6	92- 5	WASHER - lock, 5/16"	6
	L 30479	RETAINER ASSEMBLY - bearing.....	1
7	NSS	RETAINER - bearing	1
8	L 30245	PLUG - retainer	2
9	L 35692	CASE - transmission, front	1
10	L 35684	CLUTCH ASSEMBLY forward and reverse	1
11	L 32121	RING - snap, cylinder to plate	2
12	L 32120	PLATE - lock, snap ring.....	2
13	L 32084	SCREW - locking	2
	L 35685	CYLINDER AND SHAFT ASSEMBLY - clutch	1
14	L 35686	CYLINDER AND FLYBALL ASSEMBLY - reverse clutch ..	1
15	NSS	CYLINDER - reverse clutch	1
16	L 33326	SLEEVE - flyball	1
17	L 30440	BOLT - special	8
	L 30477	SHAFT ASSEMBLY - input.....	1
18	NSS	SHAFT - input	1
19	T 32720	BEARING - needle	1
20	L 35690	PISTON - clutch	1
21	L 35691	PLATE - reverse clutch	1
22	A 14832	RING - seal, inner	1
23	A 14831	RING - seal, outer	1
24	A 14827	SPRING - clutch retractor	24
	L 30694	PLATE ASSEMBLY - pressure	1
25	NSS	PLATE - pressure	1
26	A 14829	PIN - pressure plate drive	4
27	L 35687	PLATE - forward clutch	1
28	L 35690	PISTON - clutch	1
29	A 14831	RING - seal, outer	1
30	A 14832	RING - seal, inner	1
	L 35688	CYLINDER AND BEARING ASSEMBLY - clutch	1
31	NSS	CYLINDER AND FLYBALL ASSEMBLY - forward	
		clutch, usese L35688	1
32	NSS	CYLINDER - forward clutch	1
33	L 33326	SLEEVE - flyball	1
34	L 30245	PLUG - cylinder	2
35	A 28230	BEARING - needle	1


SEE PAGES 143 THRU 163 FOR COMPLETE TRANSMISSION



**TRANSMISSION
FORWARD AND REVERSE CLUTCH
TRANSMISSION SN. 75001 AND AFTER**

REF.	PART NO.	DESCRIPTION	REQ'D.
D	73700	TRANSMISSION ASSEMBLY - forward and reverse	1
1	D 66388	GASKET - transmission housing	1
2	L 30484	RING - snap, input shaft	1
3	L 30483	SPACER - bearing	1
4	40025	BEARING - clutch	1
5	13- 516	HHCS - 5/16" - 18 NC x 1"	6
6	92- 5	WASHER - lock, 5/16"	6
	L 30479	RETAINER ASSEMBLY - bearing	1
7	NSS	RETAINER - bearing	1
8	L 30245	PLUG - retainer	2
9	D 66389	CASE - transmission, front, includes item 4	1
10	D 66382	CLUTCH ASSEMBLY - forward and reverse	1
11	L 32121	RING - snap, cylinder to plate	2
12	L 32120	PLATE - lock, snap ring	2
13	L 32084	SCREW - locking	2
	D 66386	CYLINDER AND SHAFT ASSEMBLY - reverse clutch	1
14	NSS	CYLINDER - reverse clutch	1
15		RESERVED	
16	L 30440	BOLT - special	8
	L 30477	SHAFT ASSEMBLY - input	1
17	NSS	SHAFT - input	1
18	T 32720	BEARING - needle	1
19	D 66383	PISTON - clutch	2
20	211- 306	BALL - steel, 7/32" (5 mm)	2
21	L 35691	PLATE - reverse clutch	1
22	D 66384	RING - seal, outer	2
23	A 14827	SPRING - clutch retractor	24
	L 30694	PLATE ASSEMBLY - pressure	1
24	NSS	PLATE - pressure	1
25	A 14829	PIN - pressure plate drive	4
26	L 35687	PLATE - forward clutch	1
27	A 14832	RING - seal, inner (Steel) If used	2
27	D 66414	RING - seal, inner (Rubber) If used	2
	D 66385	CYLINDER AND BEARING ASSEMBLY - forward clutch	1
28	NSS	CYLINDER - forward clutch	1
29	L 30245	PLUG - cylinder	2
30	A 28230	BEARING - needle	1

SEE PAGES 143 THRU 163 FOR COMPLETE TRANSMISSION




B672863

**TRANSMISSION
FORWARD AND REVERSE CONTROL VALVE
BEFORE TRANSMISSION SN. 75001**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 30972	VALVE ASSEMBLY - forward and reverse control	1
2	13- 520	HHCS - 5/16" - 18 NC x 1-1/4"	6
3	92- 5	WASHER - lock, 5/16"	6
4	L 30491	COVER - valve body	1
5	A 14871	GASKET - cover	1
6	13- 514	HHCS - 5/16" - 18 NC x 7/8"	2
7	92- 5	WASHER - lock, 5/16"	2
8	L 30973	PLATE - separator	1
9	L 30974	GASKET - plate to body	1
10	NSS	BODY - valve	1
11	L 35696	PLUG - pipe, hex. head, special	2
12	A 14882	SCREW - pressure regulator valve	1
13	G 10964	GASKET - valve retainer screw	1
14	A 14885	SPRING - regulator valve	1
15	A 14883	VALVE - pressure regulator	1
16	A 14877	SEAL - oil, clutch control	1
17	A 14873	PLUNGER - clutch control	1
18	A 14876	STOP - clutch control plunger	1
19	A 14874	SPRING - plunger	1
20	A 14878	VALVE - clutch control	1
21	A 14880	STOP - clutch control valve	1
22	A 14879	SPRING - clutch control valve	1
23	A 14882	SCREW - clutch supply valve	1
24	G 10964	GASKET - valve retainer screw	1
25	A 14881	SPRING - clutch supply valve	1
26	A 14884	VALVE - clutch supply	1
27	A 14863	SEAL - oil, direction selector spool	1
28	L 30255	SPOOL - direction selector	1
29	A 14864	PLUNGER - detent spring	1
30	L 35694	SPRING - detent ball	1
31	211- 7	BALL - steel, 1/4" (6 mm) dia.	1
32	A 14866	STOP - selector spool	1


SEE PAGES 143 THRU 163 FOR COMPLETE TRANSMISSION



**TRANSMISSION
FORWARD AND REVERSE CONTROL VALVE
TRANSMISSION SN. 75001 AND AFTER**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D 66391	VALVE ASSEMBLY - complete	1
2	D 66401	HHCS - 5/16" - 18 NC x 1-1/4"	6
3	92- 5	WASHER - lock, 5/16"	6
4	D 66400	COVER - valve body	1
5	13- 512	HHCS - 5/16" - 18 NC x 7/8", order item 5A	2
5A	D 80336	BOLT AND WASHER ASSEMBLY - replaces items 5 and 6 ..	1
6	92- 5	WASHER - lock, 5/16"	2
7	D 66399	PLATE - separator, before transmission sn. 76081 .110" -.128" (2.79-3.25 mm) thick	1
7A	D 72751	PLATE - separator, trans. sn. 76801 and after, .057" - .063" (1.45-1.60 mm) thick (When ordered for transmissions prior to 76081 also order (9) of item 43)	1
8	D 66398	GASKET - plate to body	1
9	NSS	BODY - valve	1
10	221- 661	PLUG - pipe, hex. head, 1/8" NPT	2
11	A 14882	SCREW - pressure regulator valve	1
12	G 10964	GASKET - valve retainer screw	1
13	A 14885	SPRING - regulator valve	1
14	D 66393	VALVE - pressure regulator	1
15	A 14877	SEAL - oil, clutch control	1
16	D 66394	PLUNGER - clutch control	1
17	A 14874	SPRING - plunger	1
18	A 14878	VALVE - clutch control	1
19	A 14879	SPRING - clutch control valve	1
20	A 14882	SCREW - clutch supply valve	1
21	G 10964	GASKET - valve retainer screw	1
22	A 14881	SPRING - clutch supply valve	1
23	A 14884	VALVE - clutch supply	1
24	A 14863	SEAL - oil, direction selector spool	1
25	D 66395	SPOOL - direction selector	1
26	D 66397	PIN - detent spring	1
27	D 66396	SPRING - detent ball	1
28	211- 7	BALL - steel, 1/4" (6 mm) dia.	1
29	D 71461	PIN - dowel	1
30	D 72748	PLUG - converter regulating valve retainer	1
31	G 10964	GASKET - converter regulating valve screw	1
32	D 72749	SPRING - converter regulating valve	1
33	NSS	VALVE - converter regulating, for service order L72748 plug, D72749 spring, D72750 valve and D72747 plug	1
33A	D 72750	VALVE - converter regulating	1
34	D 66404	PLATE - valve stop	1
35	D 66402	VALVE - lube regulating valve	1
36	D 66403	SPRING - lube regulating valve	1
37	D 72747	PLUG - converter regulator valve	1
38	D 72752	PLUG - special, .56" (14.22 mm) long, if used	1
39	221- 12	PLUG - pipe, 1/4" NPT	1
40	163- 25	SCREW - #10 - 24 NC x 7/8"	1
41	D 73728	STOP - valve	1
42	D 72753	GASKET - valve body	1
43	195- 2026	WASHER - flat	9


SEE PAGES 143 THRU 163 FOR COMPLETE TRANSMISSION



**TRANSMISSION
POWER SHUTTLE AND HOUSING
BEFORE TRANSMISSION SN. 75001**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 35677	TRANSMISSION ASSEMBLY - forward and reverse	1
1	A 14837	DIPSTICK - oil level	1
2	L 30225	TUBE - filler and dipstick	1
3	221- 654	PLUG - pipe, hex. head, 1/2" NPT	1
4	221- 846	PLUG - pipe, square socket head, 1" NPT	1
5	221- 12	PLUG - pipe, hex. head, 1/4" NPT	1
6	13- 520	HHCS - 5/16" - 18 NC x 1-1/4"	5
7	92- 5	WASHER - lock, 5/16"	5
8	L 30236	RETAINER - bearing	1
9	A 27089	RING - snap	3
10	L 32122	BOLT - locking and sealing	4
11	A 14854	RETAINER - shaft bearing	1
12	A 14855	GASKET - bearing retainer	1
13	A 14835	RING - retaining, shaft	1
14	A 28153	RING - retaining, bearing to retainer	1
15	L 33854	BEARING - forward drive shaft	1
16	A 14853	GEAR - low and reverse, 35 teeth	2
17	A 14850	SHAFT - forward drive	1
	L 30230	SHAFT ASSEMBLY - drive	1
18	A 27089	RING - snap	1
19	NSS	SHAFT - drive	1
20	A 14858	BEARING - needle	1
21	L 30233	RING - snap, bearing	1
22	A 31209	BEARING - reverse	1
23	L 33320	RETAINER - output shaft bearing	1
24	D 50034	O-RING - retainer	1
25	A 55446	SEAL - oil, output shaft	1
26	G 13075	BEARING - output shaft	1
	L 35680	SHAFT ASSEMBLY - output	1
27	NSS	SHAFT - output	1
28	A 7509	PLUG - expansion	1
29	L 30470	GEAR - countershaft	1
30	F 37914	PIN - lock, shaft	1
31	L 32122	BOLT - locking and sealing	4
32	L 33892	RETAINER - idler shaft	1
33	A 14844	GASKET - retainer	1
34	A 14841	SHAFT - idler gear	1
35	L 35681	GEAR - idler, used with items 36 and 37 only	1
35A*D	78402	GEAR - idler, used with items 36A and 37A only	1
36	A 63087	BEARING - needle, idler gear, .187" (4.75 mm) dia., if used ..	48
36A*D	78403	BEARING - needle, idler gear, .216" (5.49 mm) dia., if used ..	42
37	L 35683	SPACER - needle bearing, used with item 36 only	3
37A*D	78404	SPACER - needle bearing, used with item 36A only	3
38	L 33891	WASHER - thrust, idler gear	2
*D	78401	KIT - gear and bearing, includes items 35A, 36A and 37A	1

SEE PAGES 143 THRU 163 FOR COMPLETE TRANSMISSION




**TRANSMISSION
POWER SHUTTLE AND HOUSING
TRANSMISSION SN. 75001 AND AFTER**

REF.	PART NO.	DESCRIPTION	REQ'D.
D	73700	TRANSMISSION ASSEMBLY - forward and reverse.....	1
1		RESERVED	
2		RESERVED	
3	221- 654	PLUG - pipe, hex. head, 1/2" NPT	1
4	221- 846	PLUG - pipe, square socket head, 1" NPT	1
5	221- 12	PLUG - pipe, hex. head, 1/4" NPT	1
6	13- 520	HHCS - 5/16" - 18 NC x 1-1/4"	5
7	92- 5	WASHER - lock, 5/16"	5
8	L 30236	RETAINER - bearing	1
9	A 27089	RING - snap	3
10	L 32122	BOLT - locking and sealing	4
11	A 14854	RETAINER - shaft bearing	1
12	A 14855	GASKET - bearing retainer	1
13	A 14835	RING - snap, shaft	1
14	A 28153	RING - snap, bearing to retainer	1
15	L 33854	BEARING - forward drive shaft	1
16	A 14853	GEAR - low and reverse, 35 teeth	2
17	A 14850	SHAFT - forward drive	1
	L 30230	SHAFT ASSEMBLY - drive	1
18	A 27089	RING - snap	1
19	NSS	SHAFT - drive	1
20	A 14858	BEARING - needle	1
21	L 30233	RING - retaining	1
22	A 31209	BEARING - reverse	1
23	L 33320	RETAINING - output shaft bearing	1
24	D 50034	SEAL - O-ring, retainer	1
25	A 55446	SEAL - oil, output shaft	1
26	G 13075	BEARING - output shaft	1
	L 35680	SHAFT ASSEMBLY - output	1
27	NSS	SHAFT - output	1
28	A 7509	PLUG - expansion	1
29	L 30470	GEAR - countershaft	1
30	F 37914	PIN - lock, shaft	1
31	L 32122	BOLT - locking and sealing	4
32	D 66381	RETAINER - idler shaft	1
33	A 14844	GASKET - retainer	1
34	A 14841	SHAFT - idler gear	1

Continued on next page


SEE PAGES 143 THRU 163 FOR COMPLETE TRANSMISSION



**TRANSMISSION
POWER SHUTTLE AND HOUSING
TRANSMISSION SN. 75001 AND AFTER**


REF.	PART NO.	DESCRIPTION	REQ'D.
35 L	35681	GEAR - idler, used with items 36 and 37 only	1
35A*D	78402	GEAR - idler, used with items 36A and 37A only	1
36 A	63087	BEARING - needle, idler gear, .187 (4.75 mm) dia., if used ..	48
36A*D	78403	BEARING - needle, idler gear, .216" (5.49 mm) dia., if used ..	42
37 L	35683	SPACER - needle bearing, used with item 36 only	3
37A*D	78404	SPACER - needle bearing, used with item 36A only	3
38 L	33891	WASHER - thrust, idler gear.....	2
39 222-	1034	FITTING - 45°	1
40 222-	768	FITTING - 90°	1
41 D	66409	TUBE - valve to sump.....	1
41A L	58031	TUBE - dipstick, lower	1
42 L	59122	TUBE - filler and dipstick, upper	1
43 L	73981	DIPSTICK - oil level	1
44 L	40247	HOSE - dipstick connecting.....	1
45 214-	256	CLAMP - hose	2
46 **L	72971	BRACKET - dipstick mounting	1
47 **A	34979	"U" BOLT - 1/4" - 20 NC	1
48 **92-	4	WASHER - lock, 1/4"	2
*D	78401	KIT - gear and bearing, includes items 35A, 36A and 37A	1
**L	73097	KIT - dipstick bracket, includes items 46 thru 48	1

SEE PAGES 143 THRU 163 FOR COMPLETE TRANSMISSION



**FORWARD AND REVERSE TRANSMISSION
COOLING SYSTEM**


REF.	PART NO.	REF.	DESCRIPTION	REQ'D.
1		REF.	TRANSMISSION - forward and reverse, see pages 143 thru 163 for complete transmission	1
2	221- 164		NIPPLE - pipe, 3/8" NPT x 2"	1
3	221- 1056		REDUCING BUSHING - hex., pipe, 1/2" x 3/8" NPT	1
4	L 56217		SENDING UNIT - torque converter temperature gauge	1
5	221- 1424		TEE - pipe, 1/2" NPT	1
6	L 48749		HOSE - forward and reverse transmission to radiator, 56" (1422 mm) long	1
7	218- 1098		ADAPTER - radiator to hoses, 45°	2
8		REF.	RADIATOR ASSEMBLY - engine and forward and reverse transmission cooling, see page 55 for related parts	1
9	L 48750		HOSE - radiator to forward and reverse transmission, 62" (1575 mm) long	1
10	L 11541		STRAP - hose tie	UAR
11	221- 1403		FITTING - 45°, 3/8" NPT	1



**TRANSMISSION
CASE AND COVERS**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 54268	TRANSMISSION ASSEMBLY - 4-speed	1
1	D 72755	CASE - transmission	1
2	221- 676	PLUG - drain, magnetic	1
3	13- 610	HHCS - 3/8" - 16 NC x 5/8"	6
4	193- 10	WASHER - external tooth lock, 3/8"	6
5	L 33330	COVER - side, transmission	1
6	L 33331	GASKET - cover to case	1
7	13- 614	HHCS - 3/8" - 16 NC x 7/8"	6
8	92- 6	WASHER - lock, 3/8"	6
9	L 33366	COVER - shift control	1
10	L 33377	GASKET - cover to case	1
11	41- 12	PLUG - expansion	6
12	L 33367	PLUG - taper	1
13	L 33376	BREATHER - transmission case	1


SEE PAGES 167 THRU 173 FOR COMPLETE TRANSMISSION



**TRANSMISSION
MAIN SHAFT AND GEARS**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 54268	TRANSMISSION ASSEMBLY - 4 speed	1
1	L 33360	RING - retaining, main drive gear, color code - white	UAR
1	L 33361	RING - retaining, main drive gear, color code - blue	UAR
1	L 33362	RING - retaining, main drive gear, color code - orange	UAR
1	L 33363	RING - retaining, main drive gear, color code - green	UAR
2	A 14857	RING - retaining, bearing retaining	1
3	L 33357	BEARING - main drive gear	1
4	L 33358	SLINGER - oil	1
5	L 33356	GEAR - main drive	1
6	R 17820	BEARING - roller, main shaft	22
7	L 33352	SPACER - bearing	1
	L 33333	SYNCHRONIZER ASSEMBLY - third and fourth gear	1
8	NSS	HUB - synchronizer	1
9	NSS	SLEEVE - synchronizer	1
10	L 33395	PLATE - shifting	3
11	L 33396	SPRING - synchronizer	2
12	L 33336	RING - blocking, synchronizer, third and fourth gears	2
13	L 33337	RING - retaining, synchronizer to shaft	1
14	L 33335	GEAR - third speed	1
15	L 33332	SHAFT - main	1
15A	L 35314	WASHER - thrust, main shaft, if used	1
16	L 33339	GEAR - second speed	1
17	L 33343	RING - blocking, synchronizer, first and second gears	2
18	L 33338	RING - retaining, synchronizer to shaft	2
	L 33334	SYNCHRONIZER ASSEMBLY - first and second gears	1
19	NSS	HUB - synchronizer	1
20	NSS	SLEEVE - synchronizer	1
21	L 33397	PLATE - shifting	3
22	L 33398	SPRING - synchronizer	2
23	L 33338	RING - retaining, synchronizer, color code - steel	UAR
23	L 33340	RING - retaining, synchronizer, color code - white	UAR
23	L 33341	RING - retaining, synchronizer, color code - blue	UAR
23	L 33342	RING - retaining, synchronizer, color code - orange	UAR
24	L 33344	GEAR - first speed	1
25	L 33342	RING - retaining, gear to main shaft	1
26	L 33345	SPACER - reverse gear	1
27	L 33346	BEARING - main shaft	1
28	A 14857	RING - retaining, bearing	1
29	13- 616	HHCS - 3/8" - 16 NC x 1"	4
30	13- 630	HHCS - 3/8" - 16 NC x 1-7/8"	1
31	193- 10	WASHER - external tooth lock, 3/8"	5
32	L 35603	RETAINER - bearing, main shaft, uses item 33	1
32	D 78405	RETAINER - bearing, main shaft, does not use item 33, not illustrated	1
33	L 33402	PLUG - speedometer outlet	1
34	L 33364	GASKET - bearing retainer	1
35	D 50060	OIL SEAL - main shaft	1
36	L 33347	SPACER - speedometer gear	1
37	132- 54	PIN - cotter, 1/8" (3.17 mm) dia. x 1-3/4" (43.9 mm)	1
38	L 48339	NUT - output shaft to companion flange	1
39	L 48234	FLANGE - companion	1


SEE PAGES 167 THRU 173 FOR COMPLETE TRANSMISSION



**TRANSMISSION
INPUT, IDLER GEAR AND COUNTERSHAFT**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 54268	TRANSMISSION ASSEMBLY - 4 speed	1
1	L 33360	RING - retaining, main drive gear, color code - white	UAR
1	L 33361	RING - retaining, main drive gear, color code - blue	UAR
1	L 33362	RING - retaining, main drive gear, color code - orange	UAR
1	L 33363	RING - retaining, main drive gear, color cose - green	UAR
2	A 14857	RING - retaining, bearing	1
3	L 33357	BEARING - main drive gear	1
4	L 33358	SLINGER - oil	1
5	L 33356	GEAR - main drive	1
6	L 33350	WASHER - thrust, countershaft, outer	2
7	L 33351	WASHER - thrust, countershaft, inner	2
8	L 33352	SPACER - countershaft bearing	6
9	R 17820	BEARING - roller, countershaft	88
10	L 33349	SPACER - bearing, center, 5" (127 mm) long	1
11	L 33354	SHAFT - counter	1
12	L 33348	GEAR - countershaft and reverse idler	1
13	13- 612	HHCS - 3/8" - 16 NC x 3/4"	2
14	193- 10	WASHER - lock	2
15	L 33355	PLATE - lock, countershaft	1


SEE PAGES 167 THRU 173 FOR COMPLETE TRANSMISSION



**TRANSMISSION CONTROLS
FOUR SPEED SHIFTING PARTS**


REF.	PART NO.	DESCRIPTION	REQ'D.
	L 54268	TRANSMISSION ASSEMBLY - 4 speed	1
1	A 26727	KNOB - shift lever	1
2	D 72860	LEVER - shift control	1
3	L 33378	CAP - control cover	1
4	L 33379	WASHER - spring, control lever	1
5	L 33380	SPRING - control lever	1
6	L 33375	PIN - control cover	1
7	L 33369	RAIL - shift, first and second gears	1
8	L 33372	END - shift rail, first and second gears	1
9	L 33368	RAIL - shift, third and fourth gears	1
10	L 33373	SPRING - poppet	2
11	211- 11	BALL - steel, 3/8" (9.5 mm) dia.....	2
12	L 33374	PLUNGER - interlock	1
13	L 33371	FORK - shifting, first and second gears	1
14	L 33370	FORK - shifting, third and fourth gears	1
15	138- 97	PIN - roll, 3/16" (4.76 mm) dia. x 1-1/8" (28.57 mm)	3
16	L 33366	COVER - shift control, see page 167 for related parts	1
17	L 33986	BOOT - shift lever	1
18	L 58835	KNOB - transmission shift, if used	1

SEE PAGES 167 THRU 173 FOR COMPLETE TRANSMISSION



**TRANSMISSION CONTROLS
FORWARD-REVERSE SHIFTING PARTS**


REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 55721	HANDLE - shift lever	1
2	25- 156	NUT - hex., lock, 5/8" - 11 NC	1
3	L 57819	LEVER - shift, forward and reverse, used before transmission sn. 75001	1
4	L 74516	BEARING - support, lever, upper	1
5		RESERVED	
6	138- 63	PIN - roll, 1/8" x 1-1/4"	1
7	L 55937	BRACKET - mounting, neutral start button, used before transmission sn. 75001	1
8	13- 520	HHCS - 5/16" - 18 NC x 1-1/4"	2
9	195- 21	WASHER - flat, 5/16"	4
10	92- 5	WASHER - lock, 5/16"	2
11	25- 105	NUT - hex., 5/16" - 18 NC	2
12	L 55778	SWITCH - starting, push button, see page 79 for electrical connection, used before transmission sn. 75001	1
13	L 58543	BEARING - support, lever, lower	1
14	13- 520	HHCS - 5/16" - 18 NC x 1-1/4"	2
15	92- 5	WASHER - lock, 5/16"	2
16	195- 2074	WASHER - flat, 5/8"	3
17	L 74517	SPRING - forward and reverse	1
18	L 12479	SLEEVE - spring	1
19	L 70051	PLATE - forward and reverse lever	1
20	25- 105	NUT - hex., 5/16" - 18 NC	2
21		RESERVED	
22	138- 104	PIN - roll, 3/16" x 2"	1
23	L 70454	LEVER - forward-reverse control	1
24	132- 7	PIN - cotter, 1/16" x 3/4"	1
25	141- 2	PIN - clevis, 1/4"	1
26	213- 2	CLEVIS - cable end, 1/4"	1
27	L 55718	CABLE - control, forward-reverse	1
28	25- 214	NUT - hex., 1/4" - 28 NF	2
29	L 55867	BRACKET - cable mounting, lower	1
30	13- 616	HHCS - 3/8" - 16 NC x 1"	2
31	92- 6	WASHER - lock, 3/8"	2
32	25- 106	NUT - hex., 3/8" - 16 NC	2
33	L 55717	CLEVIS - offset, at control valve	1
34	L 26373	PIN - clevis, special	1
35	132- 7	PIN - cotter, 1/16" x 3/4"	1
36	13- 524	HHCS - 5/16" - 18 NC x 1-1/2"	1
37	92- 5	WASHER - lock, 5/16"	1
38	25- 105	NUT - hex., 5/16" - 18 NC	1
39	L 74086	LEVER - forward-reverse, shift, used transmission sn. 75001 and after	1



**L57350 AND L70686 REAR AXLE
AXLE HOUSING AND PLANETARY**
FIND ROCKWELL NUMBER ON AXLE — THEN USE CORRECT PARTS LIST


REF.	PART NO.	DESCRIPTION	REQ'D.
	L 57350	AXLE ASSEMBLY - complete, rear, PR65-PX-6/17.44-1	1
	L 70686	AXLE ASSEMBLY - complete, rear, PR65-PX-8/17.44-1	1
1 A	18221	CAPSCREW - special	32
	L 35235	SPIDER AND COVER ASSEMBLY - planetary	2
	L 35236	SPIDER ASSEMBLY - planetary	1
2	NSS	SPIDER - planetary	1
3	178- 256	SCREW - set, 3/8" x 5/8"	3
4 A	18246	SHAFT - pinion	3
5 A	18247	BUTTON - thrust	1
6 L	35237	PINION - gear	3
7 A	18236	WASHER - thrust	3
8 A	18242	RING - snap	3
9 A	18218	O-RING - planetary cover	2
10 221-	3	PLUG - drain, square head, 3/8" NPT	2
11 221-	25	PLUG - fill, square socket, 3/4" NPT	2
12 A	18241	RING - snap, sun gear retaining	2
13 L	35232	GEAR - sun	2
	L 35228	NUT ASSEMBLY - lock, bearing	2
14	NSS	NUT - lock	1
15 138-	132	PIN - roll	1
16 L	35221	CONE - bearing, roller	4
16A L	35226	SEAL - bearing	2
17 L	35220	SLEEVE - oil seal	2
18 L	35230	GEAR - ring, pinion	2
	NSS	HUB AND DRUM ASSEMBLY - axle	2
	L 35223	HUB AND CUP ASSEMBLY - axle	1
19	NSS	HUB - wheel	1
20 A	63171	CUP - bearing, roller	2
21 L	35224	SLINGER - oil	1
22 L	35580	DRUM - brake	1
23 26-	1024	HHCS - 5/8" - 11 NC x 1-1/2", grade 8	10
24		RESERVED	
25 A	13112	STUD - wheel	8
26 A	12522	NUT - wheel to hub	16
27 L	35231	SHAFT - axle, L.H.	1
28 L	35234	SHAFT - axle, R.H.	1
29	REF.	BRAKE ASSEMBLY - axle, see pages 205 and 209 for proper brakes	2
30 28-	930	HHCS - 9/16" - 18 NF x 1-7/8", grade 8	20
31 L	35233	WASHER - special	20
32 131-	1235	NUT - lock, 9/16" - 18 NF	20
33 221-	25	PLUG - fill and drain	2
34 A	12928	BREATHER - axle housing	1
35 L	73207	PAD - axle mounting, lower pads not shipped with axle, order separately	4

Continued on next page



**L57350 AND L70686 REAR AXLE
AXLE HOUSING AND PLANETARY
FIND ROCKWELL NUMBER ON AXLE — THEN USE CORRECT PARTS LIST**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 57350	AXLE ASSEMBLY - complete, rear, PR65-PX-6/17.44-1	1
	L 70686	AXLE ASSEMBLY - complete, rear, PR65-PX-8/17.44-1	1
	L 35957	HOUSING ASSEMBLY - axle	1
36	NSS	HOUSING - axle	1
37	L 33691	STUD - carrier mounting, 3" (76.2 mm) long	2
37	L 33692	STUD - carrier housing, 2-1/2" (63.5 mm) long	2
37	L 33693	STUD - carrier housing, 1-7/8" (47.6 mm) long	6
38	D 47367	WASHER - special	10
39	129- 530	NUT - hex., 7/16" - 20 NF, grade 8	10
40	L 35977	GASKET - differential to housing	1
41	116- 707	HHCS - 3/4" - 16 NF x 9", grade 8	8
42	L 74506	WASHER - special, hardened	16
43	131- 186	NUT - hex., self lock, 3/4" - 16 NF	8




760611 A

**L72035, L74029 AND L76807 REAR AXLE
AXLE HOUSING AND PLANETARY**
FIND ROCKWELL NUMBER ON AXLE — THEN USE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 72035	AXLE ASSEMBLY - complete, rear, PR65-PX-11/17.44-1	1
	L 74029	AXLE ASSEMBLY - complete, rear, PR65-PX-13/17.44-1	1
	L 76807	AXLE ASSEMBLY - complete, rear, PRS-204-P-2/17.44-1	1
1	26- 822	CAPSCREW - special	32
	L 35235	SPIDER AND COVER ASSEMBLY - planetary	2
	L 35236	SPIDER ASSEMBLY - planetary	1
2	NSS	SPIDER - planetary	1
3	178- 256	SCREW - set, 3/8" x 5/8"	3
4	A 18246	SHAFT - pinion	3
5	A 18247	BUTTON - thrust	1
6	L 35237	PINION - gear	3
7	A 18236	WASHER - thrust	3
8	A 18242	RING - snap	3
9	A 18218	SEAL - O-ring, planetary cover	2
10	221- 3	PLUG - drain, square head, 3/8" NPT	2
11	221- 25	PLUG - fill, square socket, 3/4" NPT	2
12	A 18241	RING - snap, sun gear retaining	2
13	L 35232	GEAR - sun	2
	L 35228	NUT ASSEMBLY - lock, bearing	2
14	NSS	NUT - lock	1
15	138- 132	PIN - roll	1
16	L 35221	CONE - bearing, roller	4
16A	L 35226	SEAL - bearing	2
17	L 35220	SLEEVE - oil seal	2
18	L 35230	GEAR - ring, pinion	2
	NSS	HUB AND DRUM ASSEMBLY - axle	2
	L 35223	HUB AND CUP ASSEMBLY - axle	1
19	NSS	HUB - wheel	1
20	A 63171	CUP - bearing, roller	2
21	L 35224	SLINGER - oil	1
22	L 35580	DRUM - brake	1
23	26- 1024	HHCS - 5/8" - 11 NC x 1-1/2", grade 8	10
24		RESERVED	
25	A 13112	STUD - wheel	8
26	A 12522	NUT - wheel to hub	16
27	L 35231	SHAFT - axle, L.H.	1
28	L 35234	SHAFT - axle, R.H.	1
29	REF.	BRAKE ASSEMBLY - axle, see pages 213 and 215 or 217 and 219 for proper brakes	2


Continued on next page



760611 A

**L72035, L74029 AND L76807 REAR AXLE
AXLE HOUSING AND PLANETARY**
FIND ROCKWELL NUMBER ON AXLE — THEN USE CORRECT PARTS LIST


REF.	PART NO.	DESCRIPTION	REQ'D.
	L 72035	AXLE ASSEMBLY - complete, rear, PR65-PX-11/17.44-1	1
	L 74029	AXLE ASSEMBLY - complete, rear, PR65-PX-13/17.44-1	1
	L 76807	AXLE ASSEMBLY - complete, rear, PRS-204-P-2/17.44-1	1
30	28- 930	HHCS - 9/16" - 18 NF x 1-7/8", grade 8, if used	20
30	28 1032	HHCS - 5/8" - 18 NF x 1-7/8", grade 8, if used	20
31	L 35233	WASHER - special, 9/16", if used	20
31	L 30737	WASHER - special, 5/8", if used	20
32	131- 1235	NUT - hex., self lock, 9/16" - 18 NF, if used	20
32	131- 1236	NUT - lock, 5/8" - 18 NF, if used	20
33	221- 25	PLUG - fill	1
33A	221- 678	PLUG - drain, magnetic	1
34	A 12928	BREATHER - axle housing	1
35	L 35587	PAD - axle mounting, L72035 or L74029 axles, lower pads not shipped with axle, order separately	2
35	L 76970	PAD - axle mounting, L76807 axle only, lower pads shipped with axle - order separately	4
	L 35957	HOUSING ASSEMBLY - L72035 or L74029 axles	1
	D 77623	HOUSING ASSEMBLY - L76807 axle only	1
36	NSS	HOUSING - axle	1
37	L 33691	STUD - carrier mounting, 3" (76.2 mm) long	2
37	L 33692	STUD - carrier housing, 2-1/2" (63.5 mm) long	2
37	L 33693	STUD - carrier housing, 1-7/8" (47.6 mm) long	6
38	D 47367	WASHER - special	10
39	129- 530	NUT - hex., 7/16" - 20 NF, grade 8	10
40	NSS	GASKET - differential housing, order M20704 gasket material	1
41	116- 707	HHCS - 3/4" - 16 NF x 9", grade 8, if used	8
41	116- 701	HHCS - 3/4" - 16 NF x 8", grade 8, if used	8
42	L 74506	WASHER - special, hardened	16
43	131- 186	NUT - hex., self lock, 3/4" - 16 NF	8



760838 A

**L78317 AND L100707 REAR AXLE
AXLE HOUSING AND PLANETARY
FIND ROCKWELL NUMBER ON AXLE - THEN USE CORRECT PARTS LIST**


REF.	PART NO.	DESCRIPTION	REQ'D
	L 78317	AXLE ASSEMBLY - complete, rear, PRS-204-P3/17.44-1	1
	L 100707	AXLE ASSEMBLY - complete, rear, PRS-204-P4/17.44-1	1
1	A 18221	CAPSCREW - special	32
	L 35235	SPIDER AND COVER ASSEMBLY - planetary	2
	L 35236	SPIDER ASSEMBLY - planetary	1
2	NSS	SPIDER - planetary	1
3	178- 256	SCREW - set, 3/8" x 5/8"	3
4	A 18246	SHAFT - pinion	3
5	A 18247	BUTTON - thrust	1
6	L 35237	PINION - gear	3
7	A 18236	WASHER - thrust	3
8	A 18242	RING - snap	3
9	A 18218	O-RING - planetary cover, if used	2
9	345- 84	GASKET - form-in-place, if used, not shown	2
10	221- 3	PLUG - drain, square head, 3/8" NPT	2
11	221- 25	PLUG - fill, square socket, 3/4" NPT	2
12	A 18241	RING - snap, sun gear retaining	2
13	L 35232	GEAR - sun	2
	L 35228	NUT ASSEMBLY - lock, bearing	2
14	NSS	NUT - lock	1
15	138- 132	PIN - roll	1
16	L 35221	CONE - bearing, roller	4
16A	L 35226	SEAL - bearing	2
17	L 35220	SLEEVE - oil seal	2
18	L 35230	GEAR - ring, pinion	2
	L 35223	HUB AND CUP ASSEMBLY - axle	2
19	NSS	HUB - wheel	1
20	A 63171	CUP - bearing, roller	2
21	L 35224	SLINGER - oil	2
22	L 35580	DRUM - brake	2
23	26- 1024	HHCS - 5/8" - 11 NC x 1-1/2", grade 8	20
24		RESERVED	
25	A 13112	STUD - wheel	16
26	A 12522	NUT - wheel, not shipped with axle, order separately	16
27	L 35231	SHAFT - axle, L.H.	1
28	L 35234	SHAFT - axle, R.H.	1
29	REF.	BRAKE ASSEMBLY - axle, see pages 217 and 219 for proper brakes	2
30	28- 1032	HHCS - 5/8" - 18 NF x 2", grade 8	20
31	L 30737	WASHER - special	20
32	131- 1236	NUT - hex, self lock, 5/8" - 18 NF	20
Continued on next page			
**D	78348	HOUSING ASSEMBLY - service, includes items, 33, 35 and 36	1



760838 A

**L78317 AND L100707 REAR AXLE
AXLE HOUSING AND PLANETARY
FIND ROCKWELL NUMBER ON AXLE - THEN USE CORRECT PARTS LIST**

REF.	PART NO.	DESCRIPTION	REQ'D
	L 78317	AXLE ASSEMBLY - complete, rear, PRS-204-P3/17.44 -1	1
	L 100707	AXLE ASSEMBLY - complete, rear, PRS-204-P4/17.44 -1	1
33	**221- 25	PLUG - fill	1
34	A 12928	BREATHER - axle housing	1
35	**221- 678	PLUG - drain, magnetic	1
35A	L 76957	PAD - axle, lower pads not shipped with axle, order separately	4
36	** NSS	HOUSING - axle	1
37	26- 824	HHCS - 1/2" - 13 NC x 1-1/2", grade 8	12
37	26- 728	HHCS - 7/16" - 14 NC x 1-3/4", grade 8	2
37	26- 740	HHCS - 7/16" - 14 NC x 2-1/2", grade 8	2
37A	D 47366	WASHER - flat	12
38	D 47367	WASHER - special	4
39		RESERVED	
40	NSS	GASKET - differential to housing, order M20704 from-in-place gasket ..	1
41	116- 703	HHCS - 3/4" - 16 NF x 9-1/2", grade 8	8
42	L 74506	WASHER - special, hardened	16
43	131- 1251	NUT - hex, lock, 3/4" - 16 NF	8
**D	78348	HOUSING ASSEMBLY - service, includes items 33, 35 and 36	1



760612 A

**L57350 AND L70686 REAR AXLE
DIFFERENTIAL**

FIND ROCKWELL NUMBER ON AXLE — THEN USE CORRECT PARTS LIST


REF.	PART NO.	DESCRIPTION	REQ'D.
L	57350	AXLE ASSEMBLY - complete, rear, PR65-PX-6/17.44-1	1
L	70686	AXLE ASSEMBLY - complete, rear, PR65-PX-8/17.44-1	1
D	73626	DIFFERENTIAL ASSEMBLY - axle, replaces D66310	1
1 *L	35091	NUT - slotted, special, sleeve to shaft	1
2 A	13124	WASHER - sleeve retaining	1
3 L	35585	SLEEVE - splined	1
4 13-	720	HHCS - 7/16" - 14 NC x 1-1/4"	8
L	35927	COVER ASSEMBLY - includes seal	1
5	NSS	COVER - pinion shaft	1
6 L	35584	SEAL - oil, pinion shaft	1
7 L	33674	GASKET - pinion cover to cage	1
D	73692	CAGE ASSEMBLY - pinion shaft bearing	1
8	NSS	CAGE - pinion bearing	1
8A	NSS***	CUP - bearing, inner, 3-7/8" (98.4 mm) O.D., if used	1
8A R	10277	CUP - bearing, inner, 3-1/2" (88.9 mm) O.D., if used	1
9 A	13161	CUP - bearing, outer	1
10 A	13160	CONE - bearing, outer	1
10A	NSS***	CONE - inner, see below	1
10A R	10276	CONE - bearing, inner used with R10277 cup only	1
11 **D	74357	SPACER - bearing, .153" (3.886 mm) thick	UAR
11 **D	74358	SPACER - bearing, .154" (3.911 mm) thick	UAR
11 **D	74359	SPACER - bearing, .155" (3.937 mm) thick	UAR
11 **D	74360	SPACER - bearing, .156" (3.962 mm) thick	UAR
11 **D	74361	SPACER - bearing, .157" (3.987 mm) thick	UAR
11 **D	74362	SPACER - bearing, .158" (4.013 mm) thick	UAR
11 **D	74363	SPACER - bearing, .164" (4.165 mm) thick	UAR
11 **D	74364	SPACER - bearing, .170" (4.318 mm) thick	UAR
11 **A	18358	SPACER - bearing, .172" (4.368 mm) thick	UAR
11 **A	18359	SPACER - bearing, .173" (4.394 mm) thick	UAR
11 **A	18390	SPACER - bearing, .174" (4.419 mm) thick	UAR
11 **A	18361	SPACER - bearing, .175" (4.445 mm) thick	UAR
11 **D	74365	SPACER - bearing, .176" (4.470 mm) thick	UAR
11 **A	18363	SPACER - bearing, .177" (4.495 mm) thick	UAR
11 **D	74366	SPACER - bearing, .182" (4.662 mm) thick	UAR
11 **A	18364	SPACER - bearing, .188" (4.775 mm) thick	UAR
11 **A	18365	SPACER - bearing, .189" (4.800 mm) thick	UAR
11 **A	18366	SPACER - bearing, .195" (4.953 mm) thick	UAR
11 **A	18367	SPACER - bearing, .201" (5.105 mm) thick	UAR

Continued on next page

*A 18200 KIT - gear, includes items 1, 12, 13, 15, 33, 34 and 35.

**NOTE: Use two spacers (item 11) together to replace the single original equipment spacer.


***D 72766 BEARING - includes cup and cone with outer cup diameter of 3-7/8" (98.4 mm) see item 8A and 10A above, if used



**L57350 AND L70686 REAR AXLE
DIFFERENTIAL**

FIND ROCKWELL NUMBER ON AXLE — THEN USE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
L	57350	AXLE ASSEMBLY - complete, rear, PR65-PX-6/17.44-1	1
L	70686	AXLE ASSEMBLY - complete, rear, PR65-PX-8/17.44-1	1
D	73626	DIFFERENTIAL ASSEMBLY - axle (continued)	1
*	REF.	GEAR SET - ring and pinion, order A18200 kit, see note below	1
12 *	NSS	GEAR - ring	1
13 *	NSS	GEAR - pinion	1
14 A	18182	BEARING - inner, drive pinion	1
15 *A	18199	RING - bearing retaining	1
16 L	36104	SHIM - bearing cage, .003" (0.076 mm) thick	UAR
16 L	36105	SHIM - bearing cage, .005" (0.127 mm) thick	UAR
16 L	36106	SHIM - bearing cage, .010" (0.254 mm) thick	UAR
17 A	18196	PIN - lock, cotter	2
	L 35924	CARRIER AND CAP ASSEMBLY - differential	1
18 221-	835	PLUG - square head, 3/4" NPT	1
	L 35925	CARRIER AND CAP - differential	1
19	NSS	CARRIER - differential	1
20	NSS	CAP - differential bearing	2
21 A	15443	DOWELL - cap	4
22 26-	1056	HHCS - 5/8" - 11 NC x 3-1/2", grade 8	4
23 L	30737	WASHER - special	4
	D 66306	CASE AND GEAR ASSEMBLY - differential	1
	D 66305	CASE ASSEMBLY - differential	1
24	NSS	CASE - plain half	1
25	NSS	CASE - flange half	1
26 26-	848	BOLT - special	8
27 D	47366	WASHER - special hardened	8
28 F	9740	WASHER - thrust, side gear	2
29 D	66304	GEAR - differential, side	2
30 A	18181	SPIDER - differential	1
31 A	18175	GEAR - differential, pinion	4
32 A	18176	WASHER - thrust	4
33 *L	35919	BOLT - special, ring gear to differential	12
34 *D	47366	WASHER - special	12
35 *131-	1138	NUT - hex., lock, 1/2" - 13 NC	12
36 A	18194	RING - bearing adjusting	2
37 A	18173	CONE - bearing	2
38 L	35931	CUP - bearing	2
*A	18200	KIT - gear, includes items 1, 12, 13, 15, 33, 34 and 35.	



**L72035 REAR AXLE
DIFFERENTIAL**


FIND ROCKWELL NUMBER ON AXLE — THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 72035	AXLE ASSEMBLY - complete, rear, PR65-PX-11/17.44-1	1
	L 73626	DIFFERENTIAL ASSEMBLY - axle	1
1 *L	35091	NUT - slotted, special, sleeve to shaft	1
2 A	13124	WASHER - sleeve retaining	1
3 L	35585	SLEEVE - splined	1
4 13-	720	HHCS - 7/16" - 14 NC x 1-1/4"	8
	L 35927	COVER ASSEMBLY - includes seal	1
5	NSS	COVER - pinion shaft	1
6 L	35584	SEAL - oil, pinion shaft	1
7 L	33674	GASKET - pinion cover to cage	1
D	73692	CAGE ASSEMBLY - pinion shaft bearing	1
8	NSS	CAGE - pinion bearing	1
8A L	33668	CUP - bearing, inner, 3-7/8" (98.4 mm) O.D., if used	1
8A R	10277	CUP - bearing, inner, 3-1/2" (88.9 mm) O.D., if used	1
9 A	13161	CUP - bearing, outer	1
10 A	13160	CONE - bearing, outer	1
10A L	30397	CONE - bearing, inner, used with L33668 cup only	1
10A R	10276	CONE - bearing, inner used with R10277 cup only	1
11 **D	74357	SPACER - bearing, .153" (3.886 mm) thick	UAR
11 **D	74358	SPACER - bearing, .154" (3.911 mm) thick	UAR
11 **D	74359	SPACER - bearing, .155" (3.937 mm) thick	UAR
11 **D	74360	SPACER - bearing, .156" (3.962 mm) thick	UAR
11 **D	74361	SPACER - bearing, .157" (3.987 mm) thick	UAR
11 **D	74362	SPACER - bearing, .158" (4.013 mm) thick	UAR
11 **D	74363	SPACER - bearing, .164" (4.165 mm) thick	UAR
11 **D	74364	SPACER - bearing, .170" (4.318 mm) thick	UAR
11 **A	18358	SPACER - bearing, .172" (4.368 mm) thick	UAR
11 **A	18359	SPACER - bearing, .173" (4.394 mm) thick	UAR
11 **A	18390	SPACER - bearing, .174" (4.419 mm) thick	UAR
11 **A	18361	SPACER - bearing, .175" (4.445 mm) thick	UAR
11 **D	74365	SPACER - bearing, .176" (4.470 mm) thick	UAR
11 **A	18363	SPACER - bearing, .177" (4.495 mm) thick	UAR
11 **D	74366	SPACER - bearing, .182" (4.662 mm) thick	UAR
11 **A	18364	SPACER - bearing, .188" (4.775 mm) thick	UAR
11 **A	18365	SPACER - bearing, .189" (4.800 mm) thick	UAR
11 **A	18366	SPACER - bearing, .195" (4.953 mm) thick	UAR
11 **A	18367	SPACER - bearing, .201" (5.105 mm) thick	UAR

Continued on next page

*A 18200 KIT - gear, includes items 1, 12, 13, 15, 33, 34 and 35.


**NOTE: Use two spacers (item 11) together to replace the single original equipment spacer.



**L72035 REAR AXLE
DIFFERENTIAL**

FIND ROCKWELL NUMBER ON AXLE — THEN USE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
L	72035	AXLE ASSEMBLY - complete, rear, PR65-PX-11/17.44-1	1
D	73626	DIFFERENTIAL ASSEMBLY - axle (continued)	1
*	REF.	GEAR SET - ring and pinion, order A18200 kit, see note below	1
12 *	NSS	GEAR - ring	1
13 *	NSS	GEAR - pinion	1
14 A	18182	BEARING - inner, drive pinion	1
15 *A	18199	RING - bearing retaining	1
16 L	36104	SHIM - bearing cage, .003" (0.076 mm) thick	UAR
16 L	36105	SHIM - bearing cage, .005" (0.127 mm) thick	UAR
16 L	36106	SHIM - bearing cage, .010" (2.254 mm) thick	UAR
17 A	18196	PIN - lock, cotter	2
	L 35924	CARRIER AND CAP ASSEMBLY - differential	1
18 221-	835	PLUG - square head, 3/4" NPT	1
	L 35925	CARRIER AND CAP - differential	1
19	NSS	CARRIER - differential	1
20	NSS	CAP - differential bearing	2
21 A	15443	DOWEL - cap	4
22 26-	1056	HHCS - 5/8" - 11 - NC x 3-1/2", grade 8	4
23 L	30737	WASHER - special	4
	D 66306	CASE AND GEAR ASSEMBLY - differential	1
	D 66305	CASE ASSEMBLY - differential	1
24	NSS	CASE - plain half	1
25	NSS	CASE - flange half	1
26 26-	848	BOLT - special	8
27 D	47366	WASHER - special hardened	8
28 F	9740	WASHER - thrust, side gear	2
29 D	66304	GEAR - differential, side	2
30 A	18181	SPIDER - differential	1
31 A	18175	GEAR - differential, pinion	4
32 A	18176	WASHER - thrust	4
33 *L	35919	BOLT - special, ring gear to differential	12
34 *D	47366	WASHER - special	12
35 *131-	1138	NUT - hex., self lock, 1/2" - 13 NC	12
36 A	18194	RING - bearing adjusting	2
37 A	18173	CONE - bearing	2
38 L	35931	CUP - bearing	2
*A	18200	KIT - gear, includes items 1, 12, 13, 15, 33, 34 and 35.	




**L74029 AND L76807 REAR AXLE
DIFFERENTIAL**
FIND ROCKWELL NUMBER ON AXLE — THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
L	74029	AXLE ASSEMBLY - complete, rear, PR65-PX-13/17.44-1	1
L	76807	AXLE ASSEMBLY - complete, rear, PRS-204-P2/17.44-1	1
D	73639	DIFFERENTIAL ASSEMBLY - axle	1
1 *L	35091	NUT - slotted, special, sleeve to shaft	1
2 A	13124	WASHER - sleeve retaining	1
3 L	35585	SLEEVE - splined	1
4 13-	720	HHCS - 7/16" - 14 NC x 1-1/4"	8
L	35927	COVER ASSEMBLY - includes seal	1
5	NSS	COVER - pinion shaft	1
6 L	35584	SEAL - oil, pinion shaft	1
7 L	33674	GASKET - pinion cover to cage	1
D	73641	CAGE ASSEMBLY - pinion shaft bearing	1
8	NSS	CAGE - pinion bearing	1
8A R	10277	CUP - bearing, tapered roller type, inner	1
9 A	13161	CUP - bearing, tapered roller type, outer	1
10 A	13160	CONE - bearing, tapered roller type, outer	1
10A R	10276	CONE - bearing, tapered roller type, inner	1
11 **D	74357	SPACER - bearing, .153" (3.886 mm) thick	UAR
11 **D	74358	SPACER - bearing, .154" (3.911 mm) thick	UAR
11 **D	74359	SPACER - bearing, .155" (3.937 mm) thick	UAR
11 **D	74360	SPACER - bearing, .156" (3.962 mm) thick	UAR
11 **D	74361	SPACER - bearing, .157" (3.987 mm) thick	UAR
11 **D	74362	SPACER - bearing, .158" (4.013 mm) thick	UAR
11 **D	74363	SPACER - bearing, .164" (4.165 mm) thick	UAR
11 **D	74364	SPACER - bearing, .170" (4.318 mm) thick	UAR
11 **D	74365	SPACER - bearing, .176" (4.470 mm) thick	UAR
11 **D	74366	SPACER - bearing, .182" (4.622 mm) thick	UAR
*	REF.	GEAR SET - ring and pinion, order A18200 kit, see note below	1
12 *	NSS	GEAR - ring	1
13 *	NSS	GEAR - pinion	1
14 A	18182	BEARING - inner, drive pinion	1
15 *A	18199	RING - bearing retaining	1
16 L	36104	SHIM - bearing cage, .003" (0.076 mm) thick	UAR
16 L	36105	SHIM - bearing cage, .005" (0.127 mm) thick	UAR
16 L	36106	SHIM - bearing cage, .010" (0.254 mm) thick	UAR
17 A	18196	PIN - lock, cotter	2
L	35924	CARRIER AND CAP ASSEMBLY - differential	1
18 221-	835	PLUG - square head, 3/4" NPT	1
L	35925	CARRIER AND CAP ASSEMBLY - differential	1
19	NSS	CARRIER - differential	1
20	NSS	CAP - differential bearing	2
21 A	15443	DOWEL - cap	4
22 26-	1052	HHCS - 5/8" - 11 NC x 3-1/4", grade 8	4
23 L	30737	WASHER - special	4

Continued on next page

*A 18200 KIT - gear, includes items 1, 12, 13, 15, 33, 34 and 35


**NOTE: Use two spacers (item 11) together to replace the single original equipment spacer.



**L74029 AND L76807 REAR AXLE
DIFFERENTIAL**

FIND ROCKWELL NUMBER ON AXLE — THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
L	74029	AXLE ASSEMBLY - complete, rear, PR65-PX-13/17.44-1	1
L	76807	AXLE ASSEMBLY - complete, rear, PRS-204-P2/17.44-1	1
D	73639	DIFFERENTIAL ASSEMBLY - axle (continued)	1
D	66306	CASE AND GEAR ASSEMBLY - differential	1
D	66305	CASE ASSEMBLY - differential	1
24	NSS	CASE - plain half	1
25	NSS	CASE - flange half	1
26	26- 848	BOLT - special	8
27	D 47366	WASHER - special hardened	8
28	F 9740	WASHER - thrust, side gear	2
29	D 66304	GEAR - differential, side	2
30	A 18181	SPIDER - differential	1
31	A 18175	GEAR - differential, pinion	4
32	A 18176	WASHER - thrust	4
33	*L 35919	BOLT - special, ring gear to differential	12
34	*D 47366	WASHER - special	12
35	*131- 1138	NUT - hex. self lock	12
36	A 18194	RING - bearing adjusting	2
37	A 18173	CONE - bearing, differential	2
38	L 35931	CUP - bearing, differential	2
*A 18200		KIT - gear, includes items 1, 12, 13, 15, 33, 34 and 35	1




**L78317 AND L100707 REAR AXLE
DIFFERENTIAL**

FIND ROCKWELL NUMBER ON AXLE - THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D
	L 78317	AXLE ASSEMBLY - complete, rear, PRS-204-P3/17.44-1	1
	L 100707	AXLE ASSEMBLY - complete, rear, PRS-204- P4/17.44-1	1
	D 78347	DIFFERENTIAL ASSEMBLY - L78317 axle	1
	D 83067	DIFFERENTIAL ASSEMBLY - L100707 axle	1
1	*L 35091	NUT - hex, slotted, sleeve to pinion shaft	1
2	A 13124	WASHER - sleeve retaining	1
3	L 35585	SLEEVE - splined	1
4	13- 720	HHCS - 7/16" - 14 NC x 1-1/4"	8
5		RESERVED	
6	D 73689	SEAL - oil, pinion shaft	1
7		RESERVED	
	D 73688	CAGE ASSEMBLY - pinion shaft bearing	1
8	NSS	CAGE - pinion bearing	1
8A	R 10277	CUP - bearing, tapered roller type, inner	1
9	A 13161	CUP - bearing, tapered roller type, outer	1
10	A 13160	CONE - bearing, tapered roller type, outer	1
10A	R 10276	CONE - bearing, tapered roller type, inner	1
11	**D 74357	SPACER - bearing, .153" (3.886 mm) thick	UAR
11	**D 74358	SPACER - bearing, .154" (3.911 mm) thick	UAR
11	**D 74359	SPACER - bearing, .155" (3.937 mm) thick	UAR
11	**D 74360	SPACER - bearing, .156" (3.962 mm) thick	UAR
11	**D 74361	SPACER - bearing, .157" (3.987 mm) thick	UAR
11	**D 74362	SPACER - bearing, .158" (4.013 mm) thick	UAR
11	**D 74363	SPACER - bearing, .164" (4.165 mm) thick	UAR
11	**D 74364	SPACER - bearing, .170" (4.318 mm) thick	UAR
11	**D 74365	SPACER - bearing, .176" (4.470 mm) thick	UAR
11	**D 74366	SPACER - bearing, .182" (4.622 mm) thick	UAR
	*	REF.	
12	*	GEAR SET - ring and pinion, order A 18200 kit, see note below	1
12	*	GEAR - ring	1
13	*	GEAR - pinion	1
14	A 18182	BEARING - inner, drive pinion, L 78317 axle, order D83068	1
14	D 83068	BEARING - inner, drive pinion, L 100707 axle	1
15	*A 18199	RING - bearing retaining	1
16	L 36104	SHIM - bearing cage, .003" (0.076 mm) thick	UAR
16	L 36105	SHIM - bearing cage, .005" (0.127 mm) thick	UAR
16	L 36106	SHIM - bearing cage, .010" (0.254 mm) thick	UAR
*A	18200	KIT - gear, includes items 1, 12, 13, 15, 33, 34 and 35	1

Continued on next page


****NOTE:** Use two spacers (item 11) together to replace the single original equipment spacer.



**L78317 AND L100707 REAR AXLE
DIFFERENTIAL**

FIND ROCKWELL NUMBER ON AXLE - THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D
	L 78317	AXLE ASSEMBLY - complete, rear, PRS-204- P3/17.44-1	1
	L 100707	AXLE ASSEMBLY - complete, rear, PRS-204- P4/17.44-1	1
	REF.	DIFFERENTIAL ASSEMBLY - axle, complete (continued)	1
	D 73630	CARRIER AND CAP ASSEMBLY - differential	1
17	NSS	CARRIER - differential	1
18	NSS	CAP - differential bearing	2
19	26- 1056	HHCS - 5/8" - 11 NC x 3-1/4", grade 8	4
20	L 30737	WASHER - special	4
20A	A 15443	DOWEL - cap	4
21	221- 25	PLUG - pipe, fill	1
22	A 18196	PIN - lock, cotter	2
	D 66306	CASE AND GEAR ASSEMBLY - differential	1
	D 66305	CASE ASSEMBLY - differential	1
23	NSS	CASE - plain half	1
24	NSS	CASE - flange half	1
25	26- 848	BOLT - special	8
26	D 47366	WASHER - special hardened	8
27	F 9740	WASHER - thrust, side gear	2
28	D 66304	GEAR - differential, side	2
29	A 18181	SPIDER - differential	1
30	A 18175	GEAR - differential, pinion	4
31	A 18176	WASHER - thrust	4
32	*L 35919	BOLT - special, ring gear to differential	12
33	*D 47366	WASHER - special	12
34	*131- 1138	NUT - hex, self lock	12
35	A 18194	RING - bearing adjusting	2
36	A 18173	CONE - bearing, differential	2
37	L 35931	CUP - bearing, differential	2
*A	18200	KIT - gear, includes items 1, 12, 13, 15, 33, 34 and 35	1



L57350 REAR AXLE


REAR BRAKES AND ADJUSTERS

FIND ROCKWELL NUMBER ON AXLE — THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
L	57350	AXLE ASSEMBLY - complete, rear, PR65-PX-6/17.44-1	1
L	35561	SPIDER ASSEMBLY - brake mounting, order L76714 kit or its components for service, see items 46 thru 56	2
1	NSS	SPIDER - brake	1
2	L 35560	BUSHING - cam	1
3	L 35559	RETAINER - seal	1
4	L 31689	SEAL - felt	1
5	L 31690	RETAINER - seal	1
	L 35563	SHOE AND LINING ASSEMBLY - brake	4
6	NSS	SHOE - brake	1
7	L 35588	PIN - return spring, brake shoe	1
8	L 35589	RETAINER - roller	1
9	L 35590	ROLLER - shoe, cam follower	1
10	*NSS	LINING - shoe, anchor end	1
11	*NSS	LINING - shoe, cam end	1
11A*L	35591	RIVET - brake lining	16
12	L 35564	SPRING - return, brake shoe	4
13	L 35566	FELT - anchor pin	8
14	L 35567	RETAINER - felt	8
15	L 35565	PIN - anchor, brake shoe	4
16	L 35960	RETAINER - spring type	8
17		RESERVED	
18	L 35961	CAM AND SHAFT - L.H. brake adjustment, not shown	1
19	L 35962	CAM AND SHAFT - R.H. brake adjustment	1
20	L 35706	WASHER - flat, cam head	2
21	R 13338	RING - lock, cam groove	2
22	26- 824	HHCS - 1/2" - 13 NC x 1-1/2", grade 8	8
23	92- 8	WASHER - lock, 1/2"	8
	L 35958	BRACKET ASSEMBLY - mounting, L.H. brake chamber, not shown	1
	L 35959	BRACKET ASSEMBLY - mounting, R.H. brake chamber	1
24	NSS	BRACKET - mounting, brake chamber, R.H. or L.H.	1
25	L 35559	RETAINER - seal, order D71280 seal for service	1
26	L 31689	SEAL - felt, order D71280 seal for service	1
27	L 31690	RETAINER - seal, order D71280 seal for service	1
27A	D 71280	SEAL - oil, replaces L35559 retainer, L31689 seal and L31690 retainer	1
28	L 35560	BUSHING - cam and shaft	1
29	L 35577	LUG - mounting, chamber bracket, welded to axle housing ..	2
30	26- 928	HHCS - 9/16" - 12 NC x 1-3/4", grade 8	2
31	L 35578	WASHER - special	2
32	25- 109	NUT - hex., 9/16" - 12 NC	2
33	L 35705	PIN - anchor, not shown	4

Continued on next page


*D 66415 KIT - brake linings and rivets, for two wheels



**L57350 REAR AXLE
REAR BRAKES AND ADJUSTERS**

FIND ROCKWELL NUMBER ON AXLE — THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 57350	AXLE ASSEMBLY - complete, rear, PR65-PX-6/17.44-1	1
	L 35572	ADJUSTER - slack, brake shoe	2
34	NSS	BODY - adjuster	1
35	L 35598	RIVET - adjuster body	5
36	L 35600	COVER - adjuster gear	2
37	41- 10	PLUG - welch, body	1
38	L 35597	PIN - lock	1
39	L 35594	SHAFT - drive, worm gear	1
40	L 35595	GEAR - drive, worm	1
41	L 35593	LOCK - worm gear shaft	1
42	L 35592	SPRING - lock, worm	1
43	L 35601	GEAR - worm, splined, driven	1
44	L 35602	BUSHING - adjuster body	2
45	219- 1	FITTING - grease, straight, 1/8" NPT	4
	L 76714	KIT - repair, brake spider	1
	L 77556	SPIDER ASSEMBLY - brake mounting	2
46	NSS	SPIDER - brake	1
47	L 35560	BUSHING - cam	1
48	D 77629	BUSHING - brake pin	2
49	D 71280	SEAL - oil	1
50	D 77627	RETAINER - oil seal	1
51	D 77626	O-RING	1
52	A 15983	SCREW - lock, anchor pin	4
53	391- 751	WIRE - lock, anchor pin lock screw	2
54	D 77557	BOLT - 9/16" - 18 NC x 2", grade 9	20
55	L 35233	WASHER - flat, 9/16", special	20
56	D 77558	NUT - hex. lock, 9/16" - 18 NC, grade 9	20




**L70686 REAR AXLE
REAR BRAKES AND ADJUSTERS**

FIND ROCKWELL NUMBER ON AXLE — THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
L	70686	AXLE ASSEMBLY - complete, rear, PR65-PX-8/17.44-1	1
L	35561	SPIDER ASSEMBLY - brake mounting, order L76714 kit or its components, see items 46 thru 56	2
1	NSS	SPIDER - brake	1
2	L	BUSHING - cam	1
3	L	RETAINER - seal	1
4	L	SEAL - felt	1
5	L	RETAINER - seal	1
D	66311	SHOE AND LINING ASSEMBLY - brake	4
6	NSS	SHOE - brake	1
7	D	PIN - return spring, brake shoe	1
8	L	RETAINER - roller	1
9	L	ROLLER - shoe, cam follower	1
10	*NSS	LINING - shoe, anchor end	1
11	*NSS	LINING - shoe, cam end	1
11A*L	35591	RIVET - brake lining	16
12	L	SPRING - return, brake shoe	4
13	L	FELT - anchor pin	8
14	L	RETAINER - felt	8
15	L	PIN - anchor, brake shoe	4
16	L	RETAINER - spring type	8
17		RESERVED	
18	L	CAM AND SHAFT - L.H. brake adjustment, not shown	1
19	L	CAM AND SHAFT - R.H. brake adjustment	1
20	L	WASHER - flat, cam head	2
21	R	RING - lock, cam groove	2
22	26-	HHCS - 1/2" - 13 NC x 1-1/2", grade 8	8
23	92-	WASHER - lock, 1/2"	8
L	35958	BRACKET ASSEMBLY - mounting, L.H. brake chamber, not shown	1
L	35959	BRACKET ASSEMBLY - mounting, R.H. brake chamber	1
24	NSS	BRACKET - mounting, brake chamber, R.H. or L.H.	1
25	L	RETAINER - seal, order D71280 seal for service	1
26	L	SEAL - felt, order D71280 seal for service	1
27	L	RETAINER - seal, order D71280 seal for service	1
27A	D	SEAL - oil, replaces L35559 retainer, L31689 seal and L31690 retainer	1
28	L	BUSHING - cam and shaft	1
29	L	LUG - mounting, chamber bracket, welded to axle housing ..	2
30	26-	HHCS - 9/16" - 12 NC x 1-3/4", grade 8	2
31	L	WASHER - special	2
32	25-	NUT - hex., 9/16" - 12 NC	2
33	L	PIN - anchor, not shown	4
*D 66415 KIT - brake linings and rivets, for two wheels			

Continued on next page


*D 66415 KIT - brake linings and rivets, for two wheels



**L70686 REAR AXLE
REAR BRAKES AND ADJUSTERS**

FIND ROCKWELL NUMBER ON AXLE — THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 70686	AXLE ASSEMBLY - complete, rear, PR65-PX-8/17.44-1	1
	L 35572	ADJUSTER - slack, brake shoe	2
34	NSS	BODY - adjuster	1
35	L 35598	RIVET - adjuster body	5
36	L 35600	COVER - adjuster gear	2
37	41- 10	PLUG - welch, body	1
38	L 35597	PIN - lock	1
39	L 35594	SHAFT - drive, worm gear	1
40	L 35595	GEAR - drive, worm	1
41	L 35593	LOCK - worm gear shaft	1
42	L 35592	SPRING - lock, worm	1
43	L 35601	GEAR - worm, splined, driven	1
44	L 35602	BUSHING - adjuster body	2
45	219- 1	FITTING - grease, straight, 1/8" NPT	4
	L 76714	KIT - repair, brake spider	1
	L 77556	SPIDER ASSEMBLY - brake mounting	2
46	NSS	SPIDER - brake	1
47	L 35560	BUSHING - cam	1
48	D 77629	BUSHING - brake pin	2
49	D 71280	SEAL - oil	1
50	D 77627	RETAINER - oil seal	1
51	D 77626	O-RING	1
52	A 15983	SCREW - lock, anchor pin	4
53	391- 751	WIRE - lock, anchor pin lock screw	2
54	D 77557	BOLT - 9/16" - 18 NC x 2", grade 9	20
55	L 35233	WASHER - flat, 9/16", special	20
56	D 77558	NUT - hex. lock, 9/16" - 18 NC, grade 9	20



760613 A


**L72035 AND L74029 REAR AXLE
REAR BRAKES AND ADJUSTERS**

FIND ROCKWELL NUMBER ON AXLE — THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
L	72035	AXLE ASSEMBLY - complete, rear, PR65-PX-11/17.44-1	1
L	74029	AXLE ASSEMBLY - complete, rear, PR65-PX-13/17.44-1	1
L	35561	SPIDER ASSEMBLY - brake mounting, order L76714 kit or its components for service, see items 46 thru 56	2
1	NSS	SPIDER - brake	1
2	L 35560	BUSHING - cam	1
3	L 35559	RETAINER - seal	1
4	L 31689	SEAL - oil	1
5	L 31690	RETAINER - seal	1
	L 35563	SHOE AND LINING ASSEMBLY - brake	4
6	NSS	SHOE - brake	1
7	L 35589	RETAINER - roller	1
8	L 35590	ROLLER - shoe, cam follower	1
9	* NSS	LINING - shoe, anchor end	1
10	* NSS	LINING - shoe, cam end	1
11	*L 35591	RIVET - brake lining	16
12	L 35564	SPRING - return, brake shoe L72035 axle only	4
12A	D 73640	SPRING - return, brake shoe, L74029 axle only, not shown ..	2
13	L 35566	FELT - anchor pin	8
14	L 35567	RETAINER - felt	8
15	L 35565	PIN - anchor, brake shoe	4
16	L 35960	RETAINER - spring type	8
17		RESERVED	
18	L 35961	CAM AND SHAFT - L.H. brake adjustment, not shown	1
19	L 35962	CAM AND SHAFT - R.H. brake adjustment	1
20	L 35706	WASHER - flat, cam head	2
21	R 13338	RING - lock, cam groove	2
22	26- 824	HHCS - 1/2" - 13 NC x 1-1/2", grade 8	8
23	92- 8	WASHER - lock, 1/2"	8
	L 35958	BRACKET ASSEMBLY - mounting, L.H. brake chamber, not shown	1
	L 35959	BRACKET ASSEMBLY - mounting, R.H. brake chamber	1
24	NSS	BRACKET - mounting, brake chamber, R.H. or L.H.	1
25	D 71280	SEAL - oil	1
26	L 35560	BUSHING - cam and shaft	1
27	L 35577	LUG - mounting, chamber bracket, welded to axle housing ..	2
28	26- 928	HHCS - 9/16" - 12 NC x 1-3/4", grade 8	2
29	L 35578	WASHER - special	2
30	25- 109	NUT - hex., 9/16" - 12 NC	2
31	L 35705	PIN - anchor	4
32	L 35573	WASHER - flat	4
33	132- 28	PIN - cotter, 3/32" x 1"	4
34	S 89827	GASKET - bracket, not shown	2
*D 66415 KIT - brake linings and rivets, for two wheels			

Continued on next page

*D 66415 KIT - brake linings and rivets, for two wheels




760613 A

**L72035 AND L74029 REAR AXLE
REAR BRAKES AND ADJUSTERS**

FIND ROCKWELL NUMBER ON AXLE — THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 72035	AXLE ASSEMBLY - complete, rear, PR65-PX-11/17.44-1	1
	L 74029	AXLE ASSEMBLY - complete, rear, PR65-PX-13/17.44-1	1
	L 35572	ADJUSTER - slack, brake shoe	2
35	NSS	BODY - adjuster	1
36	L 35598	RIVET - adjuster body	10
37	L 35600	COVER - adjuster gear	2
38	41- 10	PLUG - welch, body	1
39	L 35597	PIN - lock	1
40	L 35594	SHAFT - drive, worm gear	1
41	L 35595	GEAR - drive, worm	1
42	L 35593	LOCK - worm gear shaft	1
43	L 35592	SPRING - lock, worm	1
44	L 35601	GEAR - worm, splined, driven	1
45	L 35602	BUSHING - adjuster body	2
45A	219- 1	FITTING - grease, straight, 1/8" NPT	4
	L 76714	KIT - repair, brake spider	1
	L 77556	SPIDER ASSEMBLY - brake mounting	2
46	NSS	SPIDER - brake	1
47	L 35560	BUSHING - cam	1
48	D 77629	BUSHING - brake pin	2
49	D 71280	SEAL - oil	1
50	D 77627	RETAINER - oil seal	1
51	D 77626	O-RING	1
52	A 15983	SCREW - lock, anchor pin	4
53	391- 751	WIRE - lock, anchor pin lock screw	2
54	D 77557	BOLT - 9/16" - 18 NC x 2", grade 9	20
55	L 35233	WASHER - flat, 9/16", special	20
56	D 77558	NUT - hex. lock, 9/16" - 18 NC, grade 9	20




771029

**L76807 AND L100707 REAR AXLE
REAR BRAKES AND ADJUSTERS**

FIND ROCKWELL NUMBER ON AXLE - THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D
	L 76807	AXLE ASSEMBLY - complete, rear, PRS-204- P2/17.44-1	1
	L 78317	AXLE ASSEMBLY - complete, rear, PRS-204- P3/17.44-1	1
	L 100707	AXLE ASSEMBLY - complete, rear, PRS-204- P4/17.44-1	1
	L 77117	SPIDER ASSEMBLY - brake mounting	2
1	NSS	SPIDER - brake	1
2	L 35560	BUSHING - cam	1
3	D 77629	BUSHING - brake pin	2
4	D 71280	SEAL - oil	1
5	D 77627	RETAINER - O-ring	1
5A	D 77626	O-RING - shaft seal	1
	L 35563	SHOE AND LINING ASSEMBLY - brake	4
6	NSS	SHOE - brake	1
7	L 35589	RETAINER - roller	1
8	L 35590	ROLLER - shoe	1
9	*	NSS LINING - shoe, anchor end	1
10	*	NSS LINING - shoe, cam end	1
11	*L 35591	RIVET - brake lining	16
11A	L 35588	PIN - anchor, alternate to item 31, if used	1
12	D 73640	SPRING - return, brake shoe	4
13	L 35566	FELT - anchor pin	8
14	L 35567	RETAINER - felt	8
15	D 77625	PIN - anchor, brake shoe	4
16	F 62020	RETAINER - spring type	8
17		RESERVED	
18	L 35961	CAM AND SHAFT - L.H. brake adjustment, not shown	1
19	L 35962	CAM AND SHAFT - R.H. brake adjustment	1
20	L 35706	WASHER - flat, cam head	2
21	R 13338	RING - lock, cam groove	2
22	26- 824	HHCS - 1/2" - 13 NC x 1-1/2", grade 8	8
23	92- 8	WASHER lock, 1/2"	8
	L 35958	BRACKET ASSEMBLY - mounting, L.H. brake chamber, not shown	1
	L 35959	BRACKET ASSEMBLY - mounting, R.H. brake chamber	1
24	NSS	BRACKET - mounting, brake chamber, R.H. or L.H.	1
25	D 71280	SEAL - oil	1
26	L 35560	BUSHING - cam and shaft	1
27	L 35577	LUG - mounting, chamber bracket, welded to axle housing	2
28	26- 928	HHCS - 9/16" - 12 NC x 1-3/4", grade 8	2
29	L 35578	WASHER - special	2
30	25- 109	NUT - hex, 9/16" - 12 NC	2
31	L 35705	PIN - anchor, alternate to item 11A, if used	4
32	L 35573	WASHER - flat	4
33	132- 28	PIN - cotter, 3/32" x 1", if used	4
34	S 89827	GASKET - bracket, not shown	2
*D 66415 KIT - brake lining and rivets, for two wheels			1

Continued on next page




771029

**L76807 AND L100707 REAR AXLE
REAR BRAKES AND ADJUSTERS**


FIND ROCKWELL NUMBER ON AXLE - THEN USE THE CORRECT PARTS LIST

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 76807	AXLE ASSEMBLY - complete, rear, PRS-204- P2/17.44-1	1
	L 78317	AXLE ASSEMBLY - complete, rear, PRS-204- P3/17.44-1	1
	L 100707	AXLE ASSEMBLY - complete, rear, PRS-204- P4/17.44-1	1
	L 35572	ADJUSTER - slack, brake shoe	2
35	NSS	BODY - adjuster	1
36	L 35598	RIVET - adjuster body	10
37	L 35600	COVER - adjuster gear	2
38	41- 10	PLUG - welch, body	1
39	L 35597	PIN - lock	1
40	L 35594	SHAFT - drive, worm gear	1
41	L 35595	GEAR - drive, worm	1
42	L 35593	LOCK - worm , gear shaft	1
43	L 35592	SPRING - lock, worm	1
44	L 35601	GEAR - worm, splined, driven	1
45	L 35602	BUSHING - adjuster body	2
46	A 15983	SCREW - lock, anchor pin	4
47	391- 751	WIRE - lock, anchor pin lock screw	2
48	219- 1	FITTING - grease, straight, 1/8" NPT	4




**BRAKE SYSTEM
AIR COMPRESSOR AND RESERVOIR
BEFORE TRACTOR SN 9121647**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 71196	HOSE - intake, 14-1/2" (368.3 mm) long x 1/2" (13 mm) I.D. . .	1
2	214- 253	CLAMP - hose	2
3	217- 134	STEM - hose, 90°, at compressor	1
4	REF.	COMPRESSOR - air, see pages 239 and 241	1
5	L 10354	GASKET - air compressor to bracket	1
6	13- 622	HHCS - 3/8" - 16 NC x 1-3/8"	4
7	L 57721	BRACKET - compressor mounting	1
8	92- 6	WASHER - lock, 3/8"	4
9	25- 106	NUT - hex., 3/8" - 16 NC	4
10	26- 724	HHCS - 7/16" - 14 NC x 1-1/2", grade 8	3
11	R 24323	WASHER - hardened, 7/16"	3
12	132- 48	PIN - cotter, 1/8" x 1"	1
13	L 51052	PULLEY - compressor	1
14	221- 402	FITTING - 45°, street, 1/4" NPT	1
15	221- 84	FITTING - adapter, 1/4" x 1/8" NPT	1
16	221- 691	FITTING - tee, 1/4" NPT	1
17	221- 53	FITTING - adapter, 3/8" x 1/4" NPT	1
18	L 57976	HOSE - lubrication, compressor, 28" (711 mm) long	1
19	221- 1401	FITTING - 45°, street, 1/8" NPT	1
20	217- 133	FITTING - 90°, stem, 3/8" NPT x 1/2" tube	1
21	L 57344	HOSE - oil return, 34" (864 mm) long x 5/8" (15.9 mm) I.D.	1
22	214- 253	CLAMP - hose	2
23	217- 186	FITTING - 45°, stem, 1/2" NPT x 1/2" tube	1
24	218- 1024	ADAPTOR - 3/4" JIC x 3/8" NPT	1
25	L 57158	HOSE - compressor, 15-1/2" (394 mm) long	1
26	L 12586	VALVE - check	1
27	221- 1414	FITTING - 90°, street, 1/2" NPT	1
28	L 57152	TANK - reservoir, air	1
29	A 61155	BRACKET - compressor mounting	1
30	13- 822	HHCS - 1/2" - 13 NC x 1-3/8"	2
31	92- 8	WASHER - lock, 1/2"	2




**BRAKE SYSTEM
AIR COMPRESSOR AND RESERVOIR
TRACTOR SN. 9121647 AND AFTER**

REF.	PART NO.	DESCRIPTION	REQ'D
1	L 74393	HOSE - intake, air cleaner to compressor	1
2	214- 254	CLAMP - hose	2
3	L 73296	COMPRESSOR - air, parts list pages 243 to 247	1
3A	L 32918	GASKET - mounting	1
4	13- 724	HHCS - 7/16" - 14 NC x 1-1/2"	4
5	L 79224	BRACKET - compressor mounting, upper	1
6	92- 7	WASHER - lock, 7/16"	4
7	25- 107	NUT - hex, 7/16" - 14 NC	4
8	132- 48	PIN - cotter, 1/8" x 1"	1
9	L 73154	PULLEY - compressor	1
10	221- 1411	FITTING - 90°, street 1/8" NPT	1
11	221- 1084	FITTING - adapter, 1/4" x 1/8" NPT	1
12	221- 691	FITTING - tee, 1/4" NPT	1
13	221- 53	FITTING - adapter, 3/8" x 1/4" NPT	1
13A	L 74391	FITTING - special, will replace items 10-13, if used	1
14	L 57976	HOSE - lubrication, 28" (711 mm) long	1
15	221- 1411	FITTING - 90°, street, 1/4" NPT	1
16	217- 152	FITTING - stem, 3/8" NPT x 1/2" tube	1
17	L 57344	HOSE - compressor oil return, 34" (864 mm) long	1
18	214- 253	CLAMP - hose	2
19	217- 186	FITTING - 45°, 1/2" NPT x 1/2" tube	1
20	218- 1096	FITTING - 45°	1
21	L 73294	HOSE - compressor, 15-1/2" (394 mm) long	1
22	L 12586	VALVE - check	1
23	L 57152	TANK - reservoir, air	1
24	L 79225	BRACKET - air compressor mounting, lower	1
25	13- 820	HHCS - 1/2" - 13 NC x 1-1/4"	2
26	92- 8	WASHER - lock, 1/2"	2
27	13- 720	HHCS - 7/16" - 14 NC x 1-1/4"	1
27A	26- 720	HHCS - 7/16" - 14 NC x 1-1/4", grade 8	1
27B	L 79092	WASHER - special	1
28	95- 7	WASHER - flat, 7/16"	1
29	92- 7	WASHER - lock, 7/16"	1
30	13- 828	HHCS - 1/2" - 13 NC x 1-3/4"	4
31	92- 8	WASHER - lock, 1/2"	4
32	25- 108	NUT - hex, 1/2" - 13 NC	4
33	95- 8	WASHER - flat, 1/2"	4



BRAKE SYSTEM
RESERVOIR TO PROTECTION VALVES AND TREADLES


REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 57152	RESERVOIR - air tank	1
2	221- 1691	FITTING - tee, 1/4" NPT	1
3	L 57163	HOSE - reservoir, 50" (1270 mm) long	1
4	218- 443	FITTING - adapter, 3/8" tube to 1/4" NPT	1
5	REF.	TREADLE - R.H. valve, parts list page 251	1
6	221- 1014	PLUG - 1/2" NPT, square head	5
7	13- 516	HHCS - 5/16" - 18 NC x 1"	6
8	92- 5	WASHER - lock, 5/16"	6
9	25- 105	NUT - hex., 5/16" - 18 NC	6
10	218- 454	ADAPTER - 1/2" NPT x 9/16" JIC	2
11	L 57157	TUBE - brake valve connecting	1
12	REF.	TREADLE - L.H. valve, parts list page 251	1
13	221- 1088	FITTING - 1/2" NPT x 1/4" NPT	1
14	221- 1139	NIPPLE - 1/4" NPT x 3"	1
15	221- 1327	FITTING - 1/4" NPT	1
16	L 47989	SWITCH - stop light	1
17	221- 1412	FITTING - 90°, street, 1/4" NPT	1
18	L 48992	VALVE - safety	1
19	221- 1412	FITTING - 90°, street, 1/4" NPT	1
20	218- 443	FITTING - 3/8" tube to 1/4" NPT	1
21	L 57160	HOSE - L.H. treadle, 21" (533 mm) long	1
22	L 13530	VALVE - pressure protection, parts list page 255	1
23	221- 1131	NIPPLE - 1/4" NPT x 1", if used	1-2
24	L 72409	VALVE - pressure reduction, if used	1
24A	221- 1138	NIPPLE - 1/4" NPT x 2-1/2", if used	1
25	221- 1849	PLUG - hex. socket head, 1/8" NPT, if used	1
26	L 53739	VALVE - air, shut-off, if used	1
27	221- 1502	FITTING - 4-way, 1/4" NPT, if used	1
27A	221- 1422	FITTING - tee, 1/4" NPT, if used	1
28	221- 1084	FITTING - adapter, 1/4" NPT to 1/8" NPT	2
29	221- 1402	FITTING - street, 45°, 1/4" NPT	1
30	L 13271	GAUGE - pressure, hydraulic tank, if used	1
31	D 38663	VALVE - relief, pressure	1
32	218- 443	FITTING - 3/8" tube to 1/4" NPT	1
33	13- 432	HHCS - 1/4" - 20 NC x 2"	2
34	95- 4	WASHER - flat, 1/4"	2
35	92- 4	WASHER - lock, 1/4"	2
36	25- 104	NUT - hex., 1/4" - 20 NC	2
37	L 58388	TUBE ASSEMBLY - air vent	1
38	221- 1375	FITTING - 90°, 1/4" NPT, if used	1
39	L 51311	VALVE - tank, if used	1



BRAKE SYSTEM
RESERVOIR TO BRAKE TREADLES AND BRAKE CHAMBER


REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 70056	PLATE - reservoir mounting	1
2	26- 512	HHCS - 5/16" - 18 NC x 3/4", grade 8	2
3	92- 5	WASHER - lock, 5/16"	2
4	95- 5	WASHER - flat, 5/16"	2
5	26- 614	HHCS - 3/8" x 16 NC x 7/8", grade 8	2
6	92- 6	WASHER - lock, 3/8"	2
7	95- 6	WASHER - flat, 3/8"	2
8	L 57146	BRACKET - reservoir mounting	2
9	L 57979	STRAP - reservoir mounting	2
10	L 57152	RESERVOIR - air	1
11	13- 416	HHCS - 1/4" - 20 NC x 1"	2
12	92- 4	WASHER - lock, 1/4"	2
13	25- 104	NUT - hex., 1/4" - 20 NC	2
14	221- 1662	PLUG - hex. head, 1/4" NPT	1
15	217- 109	VALVE - drain	1
15A	221- 1084	FITTING - adapter, 1/4" to 1/8" NPT	1
16	221- 1411	FITTING - 90°, street, 1/8" NPT	1
17	L 57176	SENDING UNIT - air pressure	1
18	221- 1691	FITTING - street, tee, 1/4" NPT	1
19	L 57163	HOSE - reservoir to treadle, 50" (1270 mm) long	1
20	218- 443	FITTING - 3/8" tube to 1/4" NPT	1
21	L 53601	TREADLE - R.H., brake valve, parts list page 251, early production	1
22	221- 1014	PLUG - square head, 1/2" NPT	5
23	L 53600	TREADLE - L.H., brake valve, parts list page 251, early production	1
24	221- 1088	FITTING - adapter, 1/2" NPT to 1/4" NPT	1
25	218- 443	FITTING - adapter, 3/8" tube to 1/4" NPT	1
26	L 53613	HOSE - treadle to R.H. brake chamber, 41" (1041 mm) long, used before sn. 9124666	1
26	L 53612	HOSE - treadle to R.H. brake chamber, 35" (889 mm) long, used on sn. 9124666 and after	1
26A	L 11541	STRAP - tie, hoses, if used	2
27	218- 533	FITTING - adapter, 45°, 1/2" NPT to 9/16" JIC	1
28	REF.	CHAMBER ASSEMBLY - brake, see pages 257 and 259	2
29	95- 10	WASHER - flat, 5/8"	4
30	92- 10	WASHER - lock, 5/8"	4
31	25- 1110	NUT - hex., 5/8" - 18 NF	4
32	218- 483	FITTING - 90°, 1/4" NPT to 9/16" JIC	2
33	L 53612	HOSE - L.H. brake chamber to treadle, 35" (889 mm) long	1
34	L 53599	PIN - brake lock, used with L53600 and L53601 treadles	1
35	173- 274	SCREW - machine, #8 x 1/2", zinc plated, if used	1
36	192- 16	WASHER - lock, #8, zinc plated, if used	1
37	129- 16	NUT - hex., #8 zinc plated, if used	1

Continued on next page



**BRAKE SYSTEM
RESERVOIR TO BRAKE TREADLES AND BRAKE CHAMBER**


REF.	PART NO.	DESCRIPTION	REQ'D.
38	REF.	TREADLE - R.H. brake valve, parts list page 251, late production	1
39	REF.	TREADLE - L.H. brake valve, parts list page 251, late production	1
40 L	71273	BRACKET - locking bar	2
41 13-	412	HHCS - 1/4" - 20 NC x 3/4", if used	4
42 95-	4	WASHER - flat, 1/4", if used	4
43 92-	4	WASHER - lock, 1/4", if used	4
44 129-	724	NUT - weld, if used	2
45 L	71180	BAR - locking, if used	1
46 13-	516	HHCS - 5/16" - 18 NC x 1", if used	1
47 131-	4	NUT - hex., self lock, 5/16" - 18 NC, if used	1



BRAKE SYSTEM
TREADLE TO CLUTCH CUTOUT

REF.	PART NO.	DESCRIPTION	REQ'D.
1	REF.	TREADLE - brake valve, R.H., parts list page 167	1
2	221- 1088	FITTING - 1/2" to 1/4" NPT	2
2A	222- 5024	FITTING ASSEMBLY - 90°, male, order item 5A	2
3	NSS	BODY - male fitting	1
4	222- 5047	SLEEVE - fitting	1
5	222- 5060	NUT - fitting	1
5A	222- 2695	FITTING ASSEMBLY - 90°, male, if used	2
5B	NSS	BODY - male fitting	1
5C	222- 2610	SLEEVE - fitting	1
5D	222- 2600	NUT - fitting	1
6	L 16536	TUBE - treadle to floor mounted clutch cutout valve	1
6A	222- 5023	FITTING ASSEMBLY - 90°, male, order item 9A	2
7	NSS	BODY - male fitting	1
8	222- 5047	SLEEVE - fitting	1
9	222- 5060	NUT - fitting	1
9A	222- 2640	FITTING ASSEMBLY - 90°, male, if used	2
9B	NSS	BODY - male fitting	1
9C	222- 2610	SLEEVE - fitting	1
9D	222- 2600	NUT - fitting	1
10	L 14818	VALVE - clutch cut-out, parts list page 253	1
10A	222- 5002	FITTING ASSEMBLY - straight, order item 13A	2
11	NSS	BODY - straight fitting	1
12	222- 5047	SLEEVE - fitting	1
13	222- 5060	NUT - fitting	1
13A	222- 2625	FITTING ASSEMBLY - straight, if used	2
13B	NSS	BODY - straight fitting	1
13C	222- 2610	SLEEVE - fitting	1
13D	222- 2600	NUT - fitting	1
14	L 55262	TUBE - clutch cutout valve to cutout cylinder	1
14A	222- 5003	FITTING ASSEMBLY - straight, order item 17A	1
15	NSS	BODY - straight fitting	1
16	222- 5047	SLEEVE - fitting	1
17	222- 5060	NUT - fitting	1
17A	222- 2630	FITTING ASSEMBLY - straight, if used	1
17B	NSS	BODY - straight fitting	1
17C	222- 2610	SLEEVE - fitting	1
17D	222- 2600	NUT - fitting	1
18	L 55059	VALVE - double check	1
19	221- 1133	NIPPLE - 1/4" NPT x 1-3/8", early production	1
20	L 12627	CYLINDER - clutch cutout	1
21	L 54140	NUT - lock, cutout cylinder mounting	1
22	L 54114	TUBE - cylinder to manual cutout valve	2
23	221- 1849	PLUG - 1/8" NPT, hex. socket head	1
24	L 12630	VALVE - clutch cutout, manual, parts list page 255	1
25	173- 97	SCREW - machine, round head, #10 x 1/2"	2
26	92-	WASHER - lock, #10	2

Continued on next page



**BRAKE SYSTEM
TREADLE TO CLUTCH CUTOUT**


REF.	PART NO.	DESCRIPTION	REQ'D.
	L 55059	VALUE - double check	1
27	L 35711	BODY - valve	1
28	L 31497	GUIDE - shuttle	1
29	L 31498	SHUTTLE - check	1
30	113- 3	HHCS - 1/4" - 20 NC x 3/4", plated	2
31	195- 515	WASHER - flat, 1/4", plated	2
32	L 33702	CAP - valve	1
33	L 31499	O-RING - cap to body	1
34	13- 540	HHCS - 5/16" - 18 NC x 2-1/2"	2
35	95- 5	WASHER - flat, 5/16"	4

BEFORE TRACTOR SN 9118513

36	L 55881	BRACKET - mounting, clutch cutout cylinder	1
37	14- 512	HHCS - 5/16" - 24 NF x 3/4"	1
38	92- 5	WASHER - lock, 5/16"	1
39	L 70250	DISC - clutch cutout	1
40	L 48104	SPRING - return, clutch cutout	2

TRACTOR SN 9118513 AND AFTER


	L 73098	KIT - clutch cutout repair	1
41	L 72956	BRACKET - clutch cutout cylinder mounting	1
42	14- 532	HHCS - 5/16" - 24 NF x 2"	1
43	95- 5	WASHER - flat, 5/16"	1
44	L 72882	SPRING - return, clutch cutout	1
45	L 72895	LEVER - clutch cutout	1
46	L 72896	SPACER - clutch cutout lever	1
47	A 26381	WASHER - flat, special	1



BRAKE SYSTEM
PARKING BRAKE CONTROLS AND QUICK RELEASE VALVE


REF.	PART NO.	DESCRIPTION	REQ'D
1	REF.	COMPRESSOR - air, see pages 239-247	1
1A	222-	5002 FITTING ASSEMBLY - straight, order item 4A	1
2	NSS	BODY - straight fitting	1
3	222-	5047 SLEEVE - fitting	1
4	222-	5060 NUT - fitting	1
4A	222-	2625 FITTING ASSEMBLY - straight, if used	1
4B	NSS	BODY - straight fitting	1
4C	222-	2610 SLEEVE - fitting	1
4D	222-	2600 NUT - fitting	1
5	L	48192 TUBE - governor to reservoir, before tractor sn. 9121647	1
5	L	46110 TUBE - governor to reservoir, tractor sn. 9121647 and after	1
5A	222-	5375 FITTING ASSEMBLY - tee, reservoir, order item 8A	1
6	NSS	BODY - tee	1
7	222-	5047 SLEEVE - fitting	2
8	222-	5060 NUT - fitting	2
8A	222-	2680 FITTING ASSEMBLY - tee, reservoir, if used	1
8B	NSS	BODY - tee	1
8C	222-	2610 SLEEVE - fitting	2
8D	222-	2600 NUT - fitting	2
9	221-	1691 FITTING - tee, street, 1/4" NPT	3
10	L	57152 RESERVOIR - air	1
11	L	48191 TUBE - reservoir to parking brake valve	1
11A	222-	5003 FITTING ASSEMBLY - straight, order item 14A	1
12	NSS	BODY - straight fitting	1
13	222-	5047 SLEEVE - fitting	1
14	222-	5060 NUT - fitting	1
14A	222-	2630 FITTING ASSEMBLY - straight, if used	1
14B	NSS	BODY - straight fitting	1
14C	222-	2610 SLEEVE - fitting	1
14D	222-	2600 NUT - fitting	1
15	L	48480 SWITCH - buzzer	1
16	221-	1412 FITTING - street, 90°, 1/4" NPT	2
	L	57682 VALVE - parking brake	1
17	NSS	BODY - valve	1
17A	L	36025 KNOB - valve	1
17B	169-	146 SCREW - machine, Phillips head, #8 - 32 NC x 3/8"	1
17C	182-	202 SCREW - 1/4" - 20 NC x 1/2"	2
17D	D	80516 KIT - repair, parking brake valve, not shown	1
18	L	57165 HOSE - parking brake, 44" (1117 mm) long	1
19	221-	1084 FITTING - 1/4" NPT to 1/8" NPT	1
20	L	57937 SWITCH - brake warning light	1
21		RESERVED	
22	13-	516 HHCS - 5/16" - 18 NC x 1"	2
23	95-	5 WASHER - flat, 5/16"	2
24	92-	5 WASHER - lock, 5/16"	2
25	25-	105 NUT - hex, 5/16" - 18 NC	2

Continued on next page



BRAKE SYSTEM
PARKING BRAKE CONTROLS AND QUICK RELEASE VALVE


REF.	PART NO.	DESCRIPTION	REQ'D.
26	218- 936	ADAPTER - swivel union, 45°	1
27	L 58459	HOSE - to L.H. brake chamber, used before sn. 9124666, 24" (610 mm) long	1
27	L 53615	HOSE - to L.H. brake chamber, used on sn. 9124666 and after, 21" (533 mm) long	1
27A	L 11541	STRAP - tie, hoses, if used	2
28	218- 483	ELBOW - 1/4" NPT to 9/16" JIC	2
29	REF.	CHAMBER - air brakes, see pages 257 and 259	2
30	L 53615	HOSE - to R.H. brake chamber, 21" (533 mm) long	1
31	L 71758	VALVE - quick release, brake.....	1
32	NSS	BODY - valve	1
33	D 72740	COVER - valve	1
34	D 73718	SEAL - cover	1
35	D 72741	DIAPHRAGM - valve	1
36	182- 204	SCREW - 1/4" - 20 NC x 3/4"	4



BRAKE SYSTEM
L52092 AND L73263 AIR COMPRESSOR
(TU-FLO 300)

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 52092	COMPRESSOR - air, before tractor sn. 9118505	1
1	L 73263	COMPRESSOR - air, tractor sn. 9118505 thru 9121646 and service replacement for prior models	1
2	L 32588	BOLT - special, long cover to head assembly	1
3	L 32561	BOLT - special, short, cover to head assembly	4
4	L 32560	COVER - head	1
5	L 31458	BOLT - special, head assembly to cylinder block	5
	L 32554	HEAD ASSEMBLY - cylinder	1
6	L 32556	SEAT - discharge valve	2
7	NSS	HEAD - cylinder	1
	L 32590	KIT - repair, cylinder head and block	1
8	NSS	GASKET - cover	1
9	NSS	SPRING - valve	2
10	NSS	VALVE - discharge	2
11	NSS	GUIDE - valve	2
12	L 32562	GASKET - head assembly to cylinder block	1
13	NSS	SPRING - valve, inlet	2
14	NSS	VALVE - inlet	2
15	NSS	GUIDE - inlet valve	2
	L 32591	KIT - unloader, air compressor	1
16	NSS	GUIDE - plunger	2
17	NSS	PLUNGER - unloader	2
18	NSS	PISTON - unloader	2
19	L 31407	RING - backup	2
20	L 31406	O-RING	2
21	L 31412	SEAT - spring	1
22	NSS	SPRING - unloader	1
23	NSS	SADDLE - spring	1
	L 32517	BLOCK ASSEMBLY - cylinder	1
24	L 32519	SEAT - inlet valve	2
25	NSS	BLOCK - cylinder	1
	L 32570	PISTON AND WRIST PIN ASSEMBLY - standard	2
	L 32571	PISTON AND WRIST PIN ASSEMBLY - .010" (0.254 mm) oversize	2
	L 32572	PISTON AND WRIST PIN ASSEMBLY - .020" (0.508 mm) oversize	2
	L 32573	PISTON AND WRIST PIN ASSEMBLY - .030" (0.762 mm) oversize	2
26	NSS	PISTON - air compressor	1
27	NSS	WRIST PIN - piston	1
28	L 32574	LOCK WIRE - wrist pin	2
	L 32580	RING SET - piston (Standard) Color - steel	1
	L 32581	RING SET - piston, .010" (0.254 mm) oversize, Color, yellow ..	1


Continued on next page



721039

BRAKE SYSTEM
L52092 AND L73263 AIR COMPRESSOR
(TU-FLO 300)


REF.	PART NO.	DESCRIPTION	REQ'D.
	L 32582	RING SET - piston, .020" (0.508 mm) oversize, Color - blue	1
	L 32583	RING SET - piston, .030" (0.762 mm) oversize, Color - green	1
29	NSS	RING - piston	6
	L 32569	ROD ASSEMBLY - connecting	2
30	NSS	ROD - connecting	1
31	NSS	CAP - connecting rod	1
32	L 32579	STRAP - locking	1
33	L 32589	BOLT - special	2
34	13- 516	HHCS - 5/16" - 18 NC x 1"	4
35	192- 110	WASHER - lock 5/16"	4
36	L 32516	GASKET - cylinder block to crankcase	1
37	L 32515	CRANKCASE - air compressor	1
38	25- 2312	NUT - hex., slotted, 3/4" - 16 NF	1
39	L 31458	BOLT - special, front cover mounting	4
40	92- 4	WASHER - lock, 1/4"	4
41	L 32529	COVER - front	1
42	L 32528	GASKET - front cover	1
43	L 32530	SEAL - oil, front crankcase	1
44	A 8218	RING - retaining	1
45	L 32527	BEARING - ball	1
46	126- 213	KEY - Woodruff, special	1
47	L 32526	CRANKSHAFT - air compressor	1
48	163- 11	BOLT - hex., special	4
49	192- 18	WASHER - lock, #10, plated	4
50	L 32532	COVER - rear, crankcase	1
51	L 32531	GASKET - rear cover	1
52	L 31458	BOLT - special, inlet adapter mounting	2
53	92- 4	WASHER - lock, 1/4"	2
54	L 32586	ADAPTER - special, inlet	1
55	L 32585	GASKET - inlet adapter	1
56	113- 119	HHCS - 5/16" - 18 NC x 2-3/4"	2
57	L 32563	GOVERNOR ASSEMBLY - air compressor, see page 249	1
58	L 35410	BRACKET - governor mounting	1
59	192- 110	WASHER - lock, 5/16"	2
60	129- 142	NUT - hex., lock, 5/16" - 18 NC	2
	222- 617	FITTING ASSEMBLY - at governor	1
61	NSS	BODY - fitting	1
62	222- 102	SLEEVE - fitting	1
63	222- 112	NUT - fitting	1
64	L 35411	TUBE - copper, 1/4" (6 mm) dia., compressor to governor	1
	222- 618	FITTING ASSEMBLY - at compressor	1
65	222- 112	NUT - fitting	1
66	222- 102	SLEEVE - fitting	1
67	NSS	BODY - fitting	1



BRAKE SYSTEM
L79808 AND L73296 AIR COMPRESSOR
(TU-FLO 400)

REF.	PART NO.	DESCRIPTION	REQ'D
	L 73296	COMPRESSOR -air, tractor sn. 9121647 thru 9127879	1
	L 79808	COMPRESSOR - air tractor sn. 9127879 and after	1
1	113- 110	HHCS - 5/16" - 18 NC x 2-1/4"	8
2	L 32917	WASHER - special	8
	L 32899	DISCHARGE VALVE AND HEAD ASSEMBLY - cylinder	1
3	L 32916	CAP - discharge valve	2
4	L 31451	SPRING - valve	2
5	L 32915	VALVE - discharge	2
	NSS	HEAD ASSEMBLY - cylinder	1
6	L 32909	SEAT - discharge valve	2
7	NSS	HEAD - cylinder	1
8	L 32914	STOP - valve	2
9	L 32898	GASKET - head to cylinder block	1
10	L 31442	SPRING - inlet valve	2
11	L 31441	VALVE - inlet	2
12	L 31440	GUIDE - inlet valve	2
	L 32880	BLOCK ASSEMBLY - cylinder	1
13	L 31409	GUIDE - plunger	2
14	L 31408	PLUNGER - unloader	2
	L 31404	PISTON ASSEMBLY - unloader	2
15	NSS	PISTON - unloader	1
16	L 31406	RING - backup, unloader piston seal	1
17	L 31407	O-RING - unloader piston	1
18	L 31412	SEAT - spring, unloader	1
19	L 31413	SPRING - unloader	1
20	L 32885	SADDLE - spring, unloader	1
	L 32881	BLOCK - cylinder	1
21	L 39948	SEAT - inlet valve	2
22	L 33174	BUSHING - cylinder block	2
23	NSS	BODY + cylinder	1
24	L 32910	RING - piston, standard, 2.0625" (52.387 mm)	6-8
24	L 32911	RING - piston, oversize, 2.0725" (52.641 mm)	6-8
24	L 32912	RING - piston, oversize, 2.0825" (52.895 mm)	6-8
24	L 32913	RING - piston, oversize, 2.0925" (53.149 mm)	6-8
	L 32904	PISTON ASSEMBLY - standard, L73296 compressor	2
	D 80617	PISTON ASSEMBLY - standard, L79808 compressor	2
	L 32905	PISTON ASSEMBLY - .010" (0.254 mm) oversize, L73296 compressor ..	2
	D 80618	PISTON AND ASSEMBLY - .010" (0.254 mm) oversize, L79808 compressor	2
	L 32906	PISTON ASSEMBLY - .020" (0.508 mm) oversize, L73296 compressor ..	2
	D 80619	PISTON ASSEMBLY - .020" (0.508 mm) oversize, L79808 compressor ..	2
	L 32907	PISTON ASSEMBLY - .030" (0.762 mm) oversize, L73296 compressor ..	2
	D 80620	PISTON ASSEMBLY - .030" (0.762 mm) oversize, L79808 compressor ..	2
25	NSS	PISTON - air compressor	1
26	NSS	WRIST PIN - piston	1
27	L 31437	LOCK WIRE - wrist pin	2

Continued on next page




BRAKE SYSTEM
L79808 AND L73296 AIR COMPRESSOR
(TU-FLO 400)

REF.	PART NO.	DESCRIPTION	REQ'D
	L 79808	COMPRESSOR - air, tractor sn. 9127879 and after	1
	L 73296	COMPRESSOR - air, tractor sn. 9121647 thru 9127879	1
	L 32894	ROD ASSEMBLY - connecting, standard, 1.253" (31.825 mm)	2
	L 32895	ROD ASSEMBLY - connecting, undersize, 1.1153" (28.328 mm)	2
	L 32896	ROD ASSEMBLY - connecting, undersize, 1.1053" (28.074 mm)	2
	L 32897	ROD ASSEMBLY - connecting, undersize, 1.0953" (27.820 mm)	2
28	NSS	ROD - connecting	1
29	NSS	BUSHING - wrist pin	1
30	L 31427	BOLT - special, connecting rod	2
31	L 31426	WASHER - special, connecting rod	2
32	NSS	CAP - rod	1
33	L 33720	INSERT KIT - bearing, L32894 rod, .05210" to .05185" (1.323 to 1.316 mm) thick	1
33	L 33721	INSERT KIT - bearing, L32895 rod, .05710" to .05685 (1.450 to 1.443 mm) thick	1
33	L 33722	INSERT KIT - bearing, L32896 rod, .96210" to .06185" (1.577 to 1.570 mm) thick	1
33	L 33723	INSERT KIT - bearing, L32897 rod, .06710" to .06685" (1.704 to 1.697 mm) thick	1
34	113- 288	HHCS - 3/8" - 16 NC x 7/8"	6
35	92- 6	WASHER - lock, 3/8"	6
36	L 32879	GASKET - cylinder block to crankcase, L73296 compressor	1
36	D 80609	GASKET - cylinder block to crankcase, L79808 compressor	1
37	L 32878	CRANKCASE - air compressor, L73296 compressor	1
37	D 80611	CRANKCASE - air compressor, L79808 compressor	1
38	L 32918	GASKET - flange, L73296 compressor	1
38	D 80610	GASKET - flange, L79808 compressor	1
39	25- 2312	NUT - crankshaft, 3/4" - 16 NF	1
40	126- 216	KEY - Woodruff, special	1
41	13- 514	HHCS - 5/16" - 18 NC x 7/8"	4
42	192- 110	WASHER - lock, 5/16"	4
43	L 32889	COVER - end, front	1
44	L 32888	GASKET - cover, front end	1
45	A 50423	SEAL - oil, front cover	1
46	L 32887	BEARING - ball	1
47	L 32886	CRANKSHAFT - air compressor	1
48	A 57116	O-RING - rear cover	1
49	L 31414	WASHER - thrust, crankshaft	1
50	13- 512	HHCS - 5/16" - 18 NC x 3/4"	4
51	192- 110	WASHER - lock, 5/16"	4


NOTE: Each insert bearing kit contains two inserts.

Continued on next page




BRAKE SYSTEM
L79808 AND L73296 AIR COMPRESSOR
(TU-FLO 400)

REF.	PART NO.	DESCRIPTION	REQ'D
	L 79808	COMPRESSOR - air, tractor sn. 9127879 and after	1
	L 73296	COMPRESSOR - air, tractor sn. 9121647 thru 9127879	1
52	L 32890	COVER - rear, crankcase, 1.381" (35.07 mm) I.D. bushing, L73296 compressor	1
52	D 80612	COVER - rear, crankcase, 1.381" (35.07 mm) I.D. bushing, L79808 compressor	1
53	L 32824	BUSHING - crankshaft, 1.381" (35.07 mm) I.D.	1
52	L 32891	COVER - rear, crankcase, 1.371" (34.82 mm) I.D. bushing, L73296 compressor	1
52	D 80613	COVER - rear, crankcase, 1.371" (34.82 mm) I.D. bushing L79808 compressor	1
53	L 32825	BUSHING - crankshaft, 1.371" (34.82 mm) I.D.	1
52	L 32892	COVER - rear, crankcase, 1.361" (34.56 mm) I.D. bushing, L73296 compressor	1
52	D 80614	COVER - rear, crankcase, 1.361" (34.56 mm) I.D. bushing, L79808 compressor	1
53	L 32826	BUSHING - crankshaft, 1.361" (34.56 mm) I.D.	1
52	L 32893	COVER - rear crankcase, 1.351" (34.31 mm) I.D. bushing, L73296 compressor	1
52	D 80615	COVER - rear crankcase, 1.351" (34.31 mm) I.D. bushing, L79808 compressor	1
53	L 32827	BUSHING - crankshaft, 1.351" (34.31 mm) I.D.	1
54	25- 115	NUT - hex, 5/16" - 24 NF	2
55	192- 110	WASHER - lock, 5/16"	2
56	L 13524	FITTING - discharge	1
57	L 31456	GASKET - discharge fitting	1
58	D 66472	STUD - discharge fitting	2
58A	13- 516	HHCS - 5/16" - 18 NC x 1", used on some models in place of items 54 and 58, not shown	1
59	113- 149	HHCS - 5/16" - 18 NC x 7/8"	2
60	192- 110	WASHER - lock, 5/16"	2
61	L 31457	GASKET - strainer	2
62	221- 1662	PLUG - pipe, hex head, 1/4" NPT	1
63	113- 142	HHCS - 5/16" - 18 NC x 2-7/8", governor mounting	2
64	192- 110	WASHER - lock, 5/16"	2
65	REF.	GOVERNOR ASSEMBLY - compressor, parts list page 249	1
66	L 13526	GASKET - governor mounting	1
67	L 32921	FITTING - inlet	1
68	L 32920	PLATE - strainer	1




**BRAKE SYSTEM
AIR COMPRESSOR GOVERNOR**

REF.	PART NO.	DESCRIPTION	REQ'D
1	L 32563	GOVERNOR - air compressor, TU-FLO-300 compressor, before tractor sn. 9118505	1
1	D 72831	GOVERNOR - air compressor, TU-FLO-300 compressor, tractor sn. 9118505 and after and service replacement for prior models ..	1
1	D 66474	GOVERNOR - air compressor, TU-FLO-400 compressor, before tractor sn. 9127879	1
1	D 82776	GOVERNOR - air compressor, TO-FLO-400 compressor, tractor sn. 9127879 and after	1
2	*NSS	COVER - top, governor	1
3	T 28550	RING - retaining	1
	L 31533	ADJUSTING ASSEMBLY - governor	1
4	25- 104	NUT - hex, 1/4" - 20 NC	1
4A	NSS	WASHER - special	1
5	NSS	SEAT - spring, upper	1
6	NSS	SPRING - tension	1
7	NSS	GUIDE - adjusting spring	1
8	NSS	SEAT - spring, lower	2
9	NSS	SCREW - special, adjusting	1
10	L 31532	STEM - exhaust	1
11	L 31531	SPRING - stem, exhaust	1
12	*L 31499	O-RING - piston	2
	L 31528	PISTON ASSEMBLY - governor	1
13	L 31541	WASHER - special	1
14	*L 31540	O-RING - piston	1
15	NSS	PISTON - governor	1
16	*L 31529	VALVE - inlet and exhaust	1
17	*L 31530	SPRING - valve, inlet and exhaust	1
18	L 31527	BODY - governor	1
19	NSS	FILTER - inlet and outlet ports	2
20	221- 1849	PLUG - hex, socket head, 1/8" NPT	4
	*L 31808	KIT - governor repair, includes items preceded by an asterisk	1





BRAKE SYSTEM
L53600 AND L53601 TREADLE AND BRAKE VALVES

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 53600	TREADLE AND VALVE ASSEMBLY - brake, L.H., before tractor sn. 9118497	1
	L 53601	TREADLE AND VALVE ASSEMBLY - brake, R.H., before tractor sn. 9118497	1
	L 71274	TREADLE AND VALVE ASSEMBLY - brake, R.H., tractor sn. 9118497 and after, order L73042 treadle for service.....	1
	L 71275	TREADLE AND VALVE ASSEMBLY - brake, L.H., tractor sn. 9118497 and after, order L73042 treadle	1
	L 73042	TREADLE AND VALVE ASSEMBLY - brake, R.H. and L.H.	2
1	L 32927	TREADLE - brake valve, also order L53639 boss for service of L53600 or L53601 only	1
1	D 73635	TREADLE - brake valve, used with L73042 treadle only	1
2	L 31367	PIN - roller, treadle valve	1
3	L 32676	ROLLER - treadle valve	1
4	132- 26	PIN - cotter, 3/32" x 3/4"	1
5	L 31364	COVER - treadle, brake (Included in L31806 repair kit)	1
6	L 32925	PLUNGER - treadle, brake	1
7	L 31362	BUTTON - stop, treadle	1
8	L 31465	PIN - fulcrum, treadle	1
9	138- 59	PIN - roll, fulcrum pin	1
10	13- 512	HHCS - 5/16" - 18 NC x 3/4"	3
11	92- 5	WASHER - lock, 5/16"	3
12	L 32924	PLATE - mounting, brake treadle	1
	L 31360	VALVE ASSEMBLY - brake	1
13	L 31382	RETAINER - valve	1
	L 31380	PISTON ASSEMBLY - valve	1
14	L 31384	BOLT - locking, special	1
15	L 31387	WASHER - compression, spring	1
16	L 31386	SEAT - spring, piston	1
17	L 31385	SPRING - rubber, piston	1
18	L 31383	PISTON - valve	1
19	L 31459	FILTER - vent	1
20	NSS	BODY - valve	1
21	D 27833	RING - retaining, washer	1
	L 31806	KIT - repair, valve (also includes item 5 above)	1
23	L 31381	O-RING - piston	1
24	L 31379	SPRING - return, piston	1
	NSS	VALVE ASSEMBLY - inlet and exhaust	1
25	L 31375	VALVE - inlet and exhaust	1
26	L 31378	SPRING - valve	1
27	L 31376	RETAINER - valve	1
28	L 31377	O-RING - valve	1
29	L 31374	O-RING - exhaust check valve	1
30	L 31370	SEAT - check valve, exhaust	1
31	L 31371	SPRING - preload, inlet valve	1
32	L 31372	DIAPHRAGM - valve	1
33	L 31373	WASHER - diaphragm, valve	1
34	182- 84	SCREW - machine, slotted head, #8 - 32 NC x 3/8"	1
35	L 53639	BOSS - slotted, treadle locking, if used	1



**BRAKE SYSTEM
L14818 CLUTCH CUTOUT VALVE**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 14818	VALVE - clutch cutout	1
2	L 32338	BOOT - valve, brake control.....	1
3	129- 574	NUT - hex., 3/4" - 16 NC	2
4	L 32337	ADAPTER - valve, brake control	1
5	L 32336	O-RING - plunger, large	1
6	L 32335	PLUNGER - valve, brake control.....	1
7	NSS	BODY - valve, brake control.....	1
8	L 31798	O-RING - stem, small	1
9	L 32332	STEM - valve, brake control	1
10	L 31354	POPPET - air intake	1
11	L 32333	SPRING - valve, brake control.....	1
12	L 32334	ADAPTER - air intake	1



BRAKE SYSTEM


REF.	PART NO.	DESCRIPTION	REQ'D.
------	----------	-------------	--------

L12630 CLUTCH CUTOUT VALVE

1	L 12630	VALVE ASSEMBLY - clutch control	1
2	L 31396	CAP NUT - clutch control valve	1
3	L 31397	RING - seal, cap nut	1
4	L 31391	SPRING - return, plunger	1
5	L 31394	VALVE - control	1
6	L 31395	SPRING - control valve	1
7	L 31390	O-RING - valve plunger	1
8	L 31389	PLUNGER - valve, clutch control	1
9	NSS	BODY - valve, clutch control	1
10	L 31392	LEVER - clutch control valve	1
11	L 31393	RIVET - clutch control valve	1

L13530 PRESSURE PROTECTION VALVE


12	L 13530	VALVE ASSEMBLY - pressure protection	1
13	NSS	BODY - valve	1
14	L 31802	VALVE - inlet	1
15	NSS	RETAINER - valve	1
16	L 31800	SPRING - inlet valve	1
17	NSS	STEM - valve	1
18	131- 414	PALNUT - hex., lock, 7/8" - 14 NF	1
19	NSS	PISTON - valve	1
20	L 31797	O-RING - piston	1
21	NSS	PLUG - valve	1
22	L 31798	O-RING - plug	1
23	NSS	SPRING - pressure regulating	1
24	L 33316	END CAP - adjusting	1



BRAKE SYSTEM
***L54297 BRAKE CHAMBER**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 54297	CHAMBER ASSEMBLY - brake	2
1	187- 835	SCREW - self-tapping, #10 - 32 NC x 5/8"	2
2	L 35621	WASHER - stop	1
3	113- 330	HHCS - 7/16" - 14 NC x 3-3/4"	1
4	L 35624	CYLINDER - brake chamber	1
5	121- 123	BOLT - flange head type	8
6	L 35620	SPRING - brake chamber	1
6A	L 35623	LOCATOR - spring	1
8		RESERVED	
9	L 35625	BULKHEAD - brake chamber	1
10	L 35609	FOLLOWER - piston rod	1
	L 35605	CLAMP ASSEMBLY - brake chamber	1
11	NSS	CLAMP - brake chamber	2
12	114- 213	HHCS - 3/8" - 24 NF x 2-1/4"	2
13	25- 176	NUT - hex., heavy, 3/8" - 24 NF	2
14	L 35610	DIAPHRAGM - brake chamber	1
15	L 35626	PUSH ROD - brake chamber	1
16	L 35615	SCREW - return, push rod	1
17	L 35614	PLATE - non pressure	1
	L 35613	YODE ASSEMBLY - brake connecting	1
18	NSS	YODE - brake	1
19	L 33649	PIN - yoke	1
20	132- 310	PIN - cotter, 1/8" x 1"	1
21	129- 167	NUT - hex., lock, 5/8" - 18 NF	1
	L 35612	KIT - repair, brake chamber, contains components to service two complete chambers	1
22	L 35622	PLUG - snap	2
23	L 35618	FILTER - air	2
24	L 35606	RING - wiper, felt	2
25	T 29460	RING - piston seal	2
26	A 40052	SEAL - ring, bulkhead	2
27	F 62075	RING - seal, rod	2
28	L 35608	BUSHING - nylon, rod	2
29	A 36277	RING - retaining, nylon bushing	2
30	164- 99	SCREW - machine, hex. socket head, 5/16" - 18 NC x 5/8" ..	2
31	NSS	LUBRICANT - TR3, 8 oz. (236.5 ml) tube, not shown	1


*NOTE: Used on models before tractor Sn. 9118416 and on 9118417, 9118420 thru 9118474 and 9118478 thru 9118482.



BRAKE SYSTEM
***L73081 BRAKE CHAMBER**


REF.	PART NO.	DESCRIPTION	REQ'D.
	L 73081	CHAMBER ASSEMBLY - brake	2
1	187- 835	SCREW - self-tapping, #10 - 32 NC x 5/8"	2
2	L 35621	WASHER - stop	1
3	113- 330	HHCS - 7/16" - 14 NC x 3-3/4"	1
4	D 72838	CYLINDER - brake chamber	1
5	121- 124	BOLT - flange head type	8
6	L 35620	SPRING - brake chamber	1
6A	L 35623	LOCATOR - spring	1
7	221- 86	FITTING - 3/8" to 1/4"	2
8	D 72839	PISTON ASSEMBLY - brake	1
9	D 72840	BULKHEAD - brake chamber	1
10	L 35609	FOLLOWER - piston rod	1
	L 35605	CLAMP ASSEMBLY - brake chamber	1
11	NSS	CLAMP - brake chamber	2
12	114- 213	HHCS - 3/8" - 24 NF x 2-1/4"	2
13	25- 176	NUT - hex., heavy, 3/8" - 24 NF	2
14	L 35610	DIAPHRAGM - brake chamber	1
15	L 35626	PUSH ROD - brake chamber	1
16	L 35615	SCREW - return, push rod	1
17	L 35614	PLATE - non pressure	1
	L 35613	YOKE ASSEMBLY - brake connecting	1
18	NSS	YOKE - brake	1
19	L 33649	PIN - yoke	1
20	132- 310	PIN - cotter, 1/8" x 1"	1
21	129- 167	NUT - hex., lock, 5/8" - 18 NF	1
	L 35612	KIT - repair, brake chamber, contains components to service two complete chambers	1
22	L 35622	PLUG - snap	2
23	L 35618	FILTER - air	2
24	L 35606	RING - wiper, felt	2
25	T 29460	RING - piston seal	2
26	A 40052	SEAL - ring, bulkhead	2
27	F 62075	RING - seal, rod	2
28	L 35608	BUSHING - nylon, rod	2
29	A 36277	RING - retaining, nylon bushing	2
30	164- 99	SCREW - machine, hex. socket head, 5/16" - 18 NC x 5/8" ..	2
31	NSS	LUBRICANT - TR3, 8 oz. (236.5 ml) tube, not shown	1

*NOTE: L73081 used after tractor Sn. 9118483 also used on 9118416, 9118418-
9118419 and 9118475 thru 9118477.




**ALCOHOL EVAPORATOR
BEFORE TRACTOR SN 9121647**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 71749	EVAPORATOR ASSEMBLY - alcohol	1
	L 46411	KIT - alcohol evaporator	1
1	L 35409	GASKET - adapter	2
2	L 35408	ADAPTER - compressor	1
	L 33157	VALVE ASSEMBLY - check, at evaporator.....	1
3	L 33162	NUT - cap	1
4	L 33161	GROMMET - valve	1
5	L 33160	VALVE - check	1
6	L 33159	SPRING - valve	1
7	NSS	HOUSING - valve	1
	L 33145	EVAPORATOR ASSEMBLY - alcohol	1
8	L 33151	PLUG - filler	1
9	41- 102	PLUG - expansion, steel, 1/2"	1
10	L 33146	BODY - alcohol evaporator	1
11	L 33153	GASKET - housing to jar	1
12	L 33156	RING - sealing, evaporator tube	1
13	L 33152	TUBE - evaporator	1
14	L 33154	JAR - alcohol evaporator, plastic	1
15	L 33150	FILTER - air intake	1
16	A 58439	RING - retaining, filter	1
17	L 71412	BRACKET - alcohol evaporator mounting	1
18	13- 412	HHCS - 1/4" - 20 NC x 3/4"	3
19	92- 4	WASHER - lock, 1/4"	3
20	25- 104	NUT - hex., 1/4" - 20 NC	3
	222- 5023	FITTING ASSEMBLY - 90°	3
21	NSS	BODY - fitting	1
22	222- 5047	SLEEVE - fitting	1
23	222- 5060	NUT - fitting	1
	222- 5002	FITTING ASSEMBLY - straight	1
24	NSS	BODY - fitting	1
25	222- 5047	SLEEVE - fitting	1
26	222- 5060	NUT - fitting	1
27	L 52494	TUBE - jar to compressor, 33" (838 mm) long	2
28	13- 428	HHCS - 1/4" - 20 NC x 1-3/4"	2




**ALCOHOL EVAPORATOR
TRACTOR SN 9121647 AND AFTER**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 73277	EVAPORATOR ASSEMBLY - alcohol	1
	L 46372	KIT - alcohol evaporator	1
1	L 31457	GASKET - adapter	2
2	L 32930	ADAPTER - compressor	1
	L 33157	VALVE ASSEMBLY - check, at evaporator.....	1
3	L 33162	NUT - cap	1
4	L 33161	GROMMET - valve	1
5	L 33160	VALVE - check	1
6	L 33159	SPRING - valve	1
7	NSS	HOUSING - valve	1
	L 33145	EVAPORATOR ASSEMBLY - alcohol	1
8	L 33151	PLUG - filler	1
9	41- 102	PLUG - expansion, steel, 1/2"	1
10	L 33146	BODY - alcohol evaporator	1
11	L 33153	GASKET - housing to jar.....	1
12	L 33156	RING - sealing, evaporator tube	1
13	L 33152	TUBE - evaporator	1
14	L 33154	JAR - alcohol evaporator, plastic	1
15	L 33150	FILTER - air intake	1
16	A 58439	RING - retaining, filter	1
17	L 79058	BRACKET - alcohol evaporator mounting	1
18	13- 412	HHCS - 1/4" - 20 NC x 3/4"	3
19	92- 4	WASHER - lock, 1/4"	3
20	25- 104	NUT - hex., 1/4" - 20 NC	3
	222- 5023	FITTING ASSEMBLY - 90°	3
21	NSS	BODY - fitting	1
22	222- 5047	SLEEVE - fitting	1
23	222- 5060	NUT - fitting	1
	222- 5002	FITTING ASSEMBLY - straight	1
24	NSS	BODY - fitting	1
25	222- 5047	SLEEVE - fitting	1
26	222- 5060	NUT - fitting	1
27	L 52494	TUBE - jar to compressor, 33" (838 mm) long	2
28	13- 428	HHCS - 1/4" - 20 NC x 1-3/4"	2



**EQUIPMENT HYDRAULIC CIRCUIT
OIL COOLER LINE**


REF.	PART NO.	REF.	DESCRIPTION	REQ'D.
1 L	55951		TANK - hydraulic oil, see page 421 for complete chassis and related parts	1
1A L	77084		HOSE - return, hydraulic oil, 1-1/4" (32 mm) I.D. x 9" (229 mm) long, used before tractor sn. 9124781	1
2 214-	255		HOSE - return, hydraulic oil, 1-1/4" (32 mm) I.D. x 11-1/2" (292 mm) long, used on tractor sn. 9124781 and after	1
2A 214-	257		CLAMP - hose	6-8
3 L	55399		CLAMP - hose	2
3A L	77083		BLOCK - junction, used before tractor sn. 9124781.....	1
4 R	20804		BLOCK - junction, used on tractor sn. 9124781 and after	1
5 L	57656		HOSE - block to cooler tube, 3/4" (19 mm) I.D. x 3" (76 mm) long, if used	1
5A L	77086		TUBE - junction block to cooler, used before tractor sn. 9124781.....	1
6 13-	616		TUBE - junction block to cooler, used on tractor sn. 9124781 and after	1
7	49799		HHCS - 3/8" - 16 NC x 1"	2
8 92-	6		CLAMP - oil cooler tubes	1
9 25-	106		WASHER - lock, 3/8"	3
10	49858		NUT - hex., 3/8" - 16 NC	3
11 R	21518		CLAMP - tube mounting	3
12 14-	512		HOSE - oil cooler, 3/4" (19 mm) I.D. x 12" (305 mm) long	1
13 92-	5		HHCS - 5/16" - 24 NF x 3/4"	4
14 195-	21		WASHER - lock, 5/16"	4
15 L	43582		WASHER - flat, 5/16"	4
16 131-	607		COOLER - hydraulic oil	1
17 D	95231		NUT - "J" type, 5/16" - 24 NF	4
18 L	57652		HOSE - oil cooler, 3/4" (19 mm) I.D. x 8" (203 mm) long	1
19 13-	636		TUBE - cooler to reservoir	1
20 A	19774		HHCS - 3/8" - 16 NC x 2-1/4"	1
21 L	13707		SPACER - tube clamp	1
			HOSE - return, cooler to reservoir, 3/4" (19 mm) I.D. x 5" (127 mm) long	1



**EQUIPMENT HYDRAULIC CIRCUIT
RESERVOIR TO LOADER VALVE**


REF.	PART NO.	DESCRIPTION USED ON ALL MODELS	REQ'D.
1	REF.	TANK - hydraulic oil reservoir, see page 423 for complete chassis	1
2 L	55950	HOSE - suction, at tank, 2" (51 mm) I.D. x 5" (127 mm) long	1
3 214-	260	CLAMP - hose	2
4 L	55826	TUBE - suction, rear	1
5 13-	824	HHCS - 1/2" - 13 NC x 1-1/2"	2
6 R	14097	CLAMP - tube to chassis	2
7 95-	8	WASHER - flat, 1/2"	2
8 92-	8	WASHER - lock, 1/2"	2
9 25-	108	NUT - hex., 1/2" - 13 NC	2
10 L	55953	HOSE - suction, at pump, 2" (51 mm) I.D. x 24" (610 mm) long ..	1
11 214-	351	CLAMP - hose	2
12 L	57792	FITTING - adapter, (At pump inlet)	1
13 218-	5012	O-RING - fitting	1
14 L	55247	PUMP - hydraulic, equipment, parts list page 335	1
15 13-	824	HHCS - 1/2" - 13 NC x 1-1/2"	2
16 92-	8	WASHER - lock, 1/2"	2
17 113-	2611	BOLT - special, coupling mounting	8
18 195-	29	WASHER - flat, 7/16"	8
	L 16692	COUPLING - pump to crankshaft pulley	1
19	NSS	HUB - splined	1
20 G	36905	BUSHING - hub	8
21 L	50435	BRACKET - pump and engine mounting, order L72189	1
21A L	72189	BRACKET - pump and engine mounting	1
22 218-	5077	FITTING - straight, male	1
23 218-	5008	O-RING - fitting	1
24 L	55955	HOSE - pump to loader valve, 26-1/2" (673 mm) long	1
25 218-	583	FITTING - pressure check, loader valve	1
26 221-	655	PLUG - pressure check, 3/4" NPT	1
27 218-	5050	FITTING - male, straight	1
28 218-	5008	O-RING - fitting	1

Continued on next page



**EQUIPMENT HYDRAULIC CIRCUIT
RESERVOIR TO LOADER VALVE**

REF.	PART NO.	DESCRIPTION	REQ'D.
USED ON ALL MODELS			
29	REF.	VALVE - hydraulic, loader control, see pages 299 and 301 for proper valve	1
USED WITH 90° CLAMP BRACKET			
30	13- 828	HHCS - 1/2" - 13 NC x 1-3/4"	1
31	L 55882	BRACKET - support, tube clamp	1
32	95- 8	WASHER - flat, 1/2"	1
33	92- 8	WASHER - lock, 1/2"	1
34	25- 108	NUT - hex., 1/2" - 13 NC	1
35	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	1
36	R 14668	CLAMP - tube	1
37	95- 6	WASHER - flat, 3/8"	1
38	92- 6	WASHER - lock, 3/8"	1
39	25- 106	NUT - hex., 3/8" - 16 NC	1
40	L 55800	TUBE - pressure, at loader valve	1
USED WITH FLAT CLAMP BLOCK			
41	13- 648	HHCS - 3/8" - 16 NC x 3"	1
41	13- 644	HHCS - 3/8" - 16 NC x 2-3/4", if used	1
42	D 37116	BLOCK - spacer, tube mounting	1
43	L 59801	CHANNEL - tube mounting, if used	1
44	L 17788	CLAMP - tube mounting	1
44A	L 78057	CLAMP - tube, not used with item 43, if used	1
45	95- 6	WASHER - flat, 3/8"	1
46	92- 6	WASHER - lock, 3/8"	1
47	25- 106	NUT - hex., 3/8" - 16 NC	1
48	L 70340	TUBE - pressure, at loader valve, used with 2 spool valve only, used before sn. 9124952	1
48	L 59816	TUBE - pressure at loader valve, used with 3 spool valve only, used before sn. 9125074	1
48	L 77020	TUBE - pressure, at loader valve, used with 2 spool valve only, used on sn. 9124952	1
48	L 77011	TUBE - pressure, at loader valve, used with 3 spool valve only, used on sn. 9125074	1
48A	L 71568	HOSE - pressure, at loader valve, used in place of tube on some models	1
	L 59126	CLAMP - used with L71568 hose only, not shown	1
48B	218- 5124	FITTING - 90°, at valve, used with hose	1
48C	218- 5008	O-RING - fitting	1




**EQUIPMENT HYDRAULIC CIRCUIT
TO BACKHOE CONTROL VALVE
*EARLY PRODUCTION**

REF.	PART NO.	REF.	DESCRIPTION	REQ'D.
1		REF.	VALVE - hydraulic, loader, see page 299 for proper valve	1
2	L 30446		FITTING - straight, special	1
3	218- 5010		O-RING - large	1
3A	L 32680		O-RING - small	1
4	L 55810		TUBE - loader valve to backhoe valve, end inlet, front	1
5	218- 739		FITTING - tube	1
6	L 55814		TUBE - loader valve to backhoe valve, end inlet, rear	1
7	218- 5069		FITTING - straight, male	1
8	218- 5010		O-RING - fitting	1
9	**L 54770		VALVE - flow divider, parts list page 331	1
10	218- 5576		FITTING - adjustable tee	1
11	218- 5007		O-RING - fitting	1
12	L 55812		TUBE - flow divider valve to stabilizer control valve, front	1
13	218- 737		FITTING - tube	1
14	L 55816		TUBE - flow divider valve to stabilizer control valve, rear	1
15	13- 832		HHCS - 1/2" - 13 NC x 2"	1
16	L 55306		SPACER - tube clamp	1
17	49799		CLAMP - tube	1
18	49891		CLAMP - tube	1
19	92- 8		WASHER - lock, 1/2"	1
20	25- 108		NUT - hex., 1/2" - 13 NC	1
21	218- 5064		FITTING - straight, male	2
22	218- 5008		O-RING - fitting	1
23	D 62348		VALVE - control, stabilizer, parts list page 313	1
24	L 55822		TUBE - stabilizer valve to backhoe control valve	1
25	218- 5077		FITTING - straight, male	1
26	218- 5010		O-RING - fitting	1
27	G 34669		VALVE - backhoe control, parts list page 315	1
28	13- 644		HHCS - 3/8" - 16 NC x 2-3/4"	1
29	D 40236		CLAMP - tube mounting	1
30	95- 6		WASHER - flat, 3/8"	1
31	92- 6		WASHER - lock, 3/8"	1
32	25- 106		NUT - hex., 3/8" - 16 NC	1

*NOTE: Before tractor Sn. 9118436 except for 9118396, 9118398 thru 9118401, 9118403, 9118404, 9118406 thru 9118415, 9118417, 9118420 thru 9118429, 9118431 thru 9118433.

**NOTE: See pages 221 and 223 for the backhoe and steering hydraulic circuit from the pump to flow divider valve.




**EQUIPMENT HYDRAULIC CIRCUIT
TO BACKHOE CONTROL VALVE
*LATE PRODUCTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	REF.	VALVE - hydraulic, loader, see page 301 for proper valve	1
2 L	30446	FITTING - straight, special	1
3 218-	5010	O-RING - large	1
3A L	32680	O-RING - small	1
4 L	55810	TUBE - loader valve to stabilizer valve	1
5 218-	739	FITTING - tube	1
6 L	70096	TUBE - loader valve to stabilizer valve	1
7 218-	5050	FITTING - straight, male	1
8 218-	5010	O-RING - fitting	1
9 **L	54770	VALVE - flow divider, parts list page 331	1
10 218-	5576	FITTING - adjustable tee	1
11 218-	5007	O-RING - fitting	1
12 L	55812	TUBE - flow divider valve to backhoe control valve, front	1
13 218-	737	FITTING - tube	1
14 L	70094	TUBE - flow divider valve to backhoe control valve, rear	1
15 13-	644	HHCS - 3/8" - 16 NC x 2-3/4"	1
16 L	55306	SPACER - tube clamp	1
17 D	40236	CLAMP - tube	1
18 95-	6	WASHER - flat, 3/8"	1
19 92-	6	WASHER - lock, 3/8"	1
20 25-	106	NUT - hex., 3/8" - 16 NC	1
21 218-	5069	FITTING - straight, male, if used	1
22 218-	5010	O-RING - fitting	1
23 D	62348	VALVE - control, stabilizer, parts list page 313	1
24 L	70098	TUBE - stabilizer valve to backhoe control valve, before sn. 9122980	1
24 L	74489	TUBE - stabilizer valve, sn. 9122980 and after, order items 24A thru 24E	1
24A L	79454	TUBE - stabilizer valve	1
24B 218-	5110	FITTING - 90°, male, if used	1
24C 218-	5010	O-RING - fitting	1
24D 218-	5147	FITTING - 45°, male, if used	1
24E 218-	5010	O-RING - fitting	1
25 218-	5077	FITTING - straight, male	1
25A 218-	5050	FITTING - straight, male, if used	1
26 218-	5010	O-RING - fitting for 218-5077 and 218-5050	1
27	REF.	VALVE - backhoe control, see page 315	1

*NOTE: Tractor Sn. 9118396 and after, except for 9118397, 9118402, 9118405,
9118416, 9118418 and 9118419, 9118430, 9118434 and 9118435.


**NOTE: See pages 221 and 223 for the backhoe and steering hydraulic circuit
from the pump to flow divider valve.

TO HYD. TANK




**EQUIPMENT HYDRAULIC CIRCUIT
RETURN LINES
BEFORE TRACTOR SN 9124781**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D 62348	VALVE - control, stabilizer, parts list page 313	1
2	218- 5065	FITTING - straight, male	1
3	218- 5007	O-RING - fitting	1
4	L 55818	TUBE - return, from stabilizer control valve	1
5	L 55918	FITTING - valve return, 3-way	1
5A	REF.	VALVE - backhoe control, see page 315	1
6	218- 5069	FITTING - straight, male	1
7	218- 5010	O-RING - fitting	1
8	L 55820	TUBE - return, from backhoe control valve	1
9	L 70343	HOSE - return, low pressure	3
10	214- 257	CLAMP - hose	6
11	L 55824	TUBE - return, backhoe valve, rear	1
12	L 55825	TUBE - return, backhoe valve, front	1
13	13- 824	HHCS - 1/2" - 13 NC x 1-1/2"	2
13A	13- 832	HHCS - 1/2" - 13 NC x 2"	1
13B	L 58752	SPACER - clamp	1
14	R 17416	CLAMP - tube	2
15	92- 8	WASHER - lock, 1/2"	2
16	25- 108	NUT - hex., 1/2" - 13 NC	2
17	L 55399	BLOCK - junction, return hose	1
18	L 55951	HOSE - return, block to hydraulic tank	1
19	214- 351	CLAMP - hose	2
20	REF.	VALVE - relief, hydraulic, see page 333 for proper valve	1
21	217- 366	FITTING - 90°, hose stem, adjustable	1
22	218- 5008	O-RING - fitting	1
23	L 71137	HOSE - return, relief valve, 26" (660 mm) long, if used	1
23	L 59001	HOSE - return, relief valve, 14" (355 mm) long, used with Gresen relief valve	1
23	L 70287	HOSE - return, relief valve, 22" (558 mm) long, used with Parker Hannifin relief valve	1
24	214- 257	CLAMP - hose	2
25	L 58992	FITTING - special, return, at loader valve	1
26	218- 5008	O-RING - fitting	1
27	REF.	VALVE - hydraulic, loader, see pages 299 and 301 for proper valve	1
28	L 70286	HOSE - return, loader valve to junction block	1
29	214- 257	CLAMP - hose	2



**EQUIPMENT HYDRAULIC CIRCUIT
RETURN LINES
TRACTOR SN 9124781 AND AFTER**


REF.	PART NO.	DESCRIPTION	REQ'D.
1	D 62348	VALVE - control, stabilizer, parts list page 313	1
2	218- 5065	FITTING - straight, male	1
3	218- 5008	O-RING - fitting	1
4	L 77532	TUBE - return, from stabilizer valve	1
5	218- 1576	FITTING - valve return, 3-way	1
5A	REF.	VALVE - backhoe control, see page 301	1
6	218- 5069	FITTING - straight, male	1
7	218- 5010	O-RING - fitting	1
8	L 77541	TUBE - return, from backhoe valve	1
9	L 77082	TUBE - return, from backhoe and stabilizer valves	1
10	R 17416	CLAMP - tube	2
11	13- 824	HHCS - 1/2" - 13 NC x 1-1/2" rear clamp only	1
11A	13- 836	HHCS - 1/2" - 13 NC x 2-1/4" front clamp only	1
12	95- 8	WASHER - flat, 1/2"	4
12A	D 37548	SPACER - front clamp only	1
13	92- 8	WASHER - lock, 1/2"	2
14	25- 108	NUT - hex., 1/2" - 13 NC	2
15	218- 1577	FITTING - tee	1
16	REF.	VALVE - relief, see page 333 for proper valve	1
17	218- 5108	FITTING - 90°, relief valve outlet	1
18	218- 5008	O-RING - fitting	1
19	L 77088	HOSE - return, from relief valve, 34" (864 mm) long	1
20	L 77091	TUBE - to reservoir	1
21	L 77083	BLOCK - junction, return lines	1
22	REF.	VALVE - loader control, see pages 299 and 301 for proper valve	1
23	218- 5064	FITTING - straight, male	1
24	218- 5008	O-RING - fitting	1
25	L 77087	HOSE - return, loader valve, 20"	1
26	L 77084	HOSE - at tank, 1-1/4" (32 mm) I.D. x 11-1/2" (292 mm)	1
27	214- 257	CLAMP - hose	2



740080


LOADER LIFT CYLINDER HYDRAULIC CIRCUIT

REF.	PART NO.	REF.	DESCRIPTION	REQ'D.
1			VALVE - hydraulic, loader control, see pages 299 and 301 for proper valve	1
2	218- 5063		FITTING - straight, male	2
3	218- 5008		O-RING - fitting	1
4	218- 5220		FITTING - swivel type	2
5	L 57596		TUBE - tee to L.H. lift cylinder, rod end	1
6	L 57598		TUBE - tee to L.H. lift cylinder, closed end	1
7	L 57592		TUBE - tee to R.H. lift cylinder, closed end	1
8	L 57594		TUBE - tee to R.H. lift cylinder, rod end	1
9	L 57599		HOSE - valve to lift cylinders, 37" (940 mm) long	4
10	13- 652		HHCS - 3/8" - 16 NC x 3-1/4"	2
11	D 40236		CLAMP - tube to chassis	4
12	D 33554		SPACER - tube	2
13	92- 6		WASHER - lock, 3/8"	2
14	25- 106		NUT - hex., 3/8" - 16 NC	2
15	218- 5062		FITTING - straight, male	2
16	218- 5007		O-RING - fitting	1
17	L 57601		TUBE - lift cylinder, closed end	2
18	218- 5007		O-RING - rod end of lift cylinder	2
19	D 38648		SPACER - tube	2
20	214- 269		CLAMP - tube	2
21	REF.		CYLINDER - hydraulic, R.H. loader lift, see page 337 or 339	1
22	REF.		CYLINDER - hydraulic, L.H. loader lift, see page 337 or 339	1




LOADER BUCKET TILT CYLINDER HYDRAULIC CIRCUIT

REF.	PART NO.	REF.	DESCRIPTION	REQ'D.
1			VALVE - hydraulic, loader control, see pages 299 and 301 for proper valve	1
2	218-	5063	FITTING - straight, male	1
3	218-	5008	O-RING - fitting	1
4	218-	5220	FITTING - swivel type	1
5	218-	5294	FITTING - adjustable	1
6	218-	5008	O-RING - fitting	1
7	L	57609	TUBE - tee to L.H. bucket cylinder, closed end	1
8	L	57607	TUBE - tee to L.H. bucket cylinder, rod end	1
9	L	57603	TUBE - tee to R.H. bucket cylinder, rod end	1
10	L	57605	TUBE - tee to R.H. bucket cylinder, closed end	1
11	13-	624	HHCS - 3/8" - 16 NC x 1-1/2"	4
12	L	57616	BRACKET - hose support	2
13	95-	6	WASHER - flat, 3/8"	4
14	92-	6	WASHER - lock, 3/8"	4
15	25-	106	NUT - hex., 3/8" - 16 NC	4
16	13-	640	HHCS - 3/8" - 16 NC x 2-1/2"	2
17	13-	628	HHCS - 3/8" - 16 NC x 1-3/4"	2
18	92-	6	WASHER - lock, 3/8"	4
19	95-	6	WASHER - flat, 3/8"	2
20	25-	106	NUT - hex., 3/8" - 16 NC	2
21	D	40236	CLAMP - tube and hose	6
22	D	33554	SPACER - tube	6
23	L	57611	TUBE - valve to bucket cylinder, upper, at lift arm	2
24	L	57613	TUBE - valve to bucket cylinder, lower, at lift arm	2
25	L	57599	HOSE - bucket cylinder, 37" (940 mm) long	8
26	218-	5007	SEAL - O-ring	2
27	L	73331	TUBE - to bucket cylinder, rod end	2
28	218-	5062	FITTING - male, straight	2
29	218-	5007	O-RING - fitting	1
30	D	38648	SPACER - tube	2
31	214-	267	CLAMP - tube	2
32		REF.	CYLINDER - hydraulic, R.H. and L.H. loader bucket, see page 341 or 343	1
33	D	34174	CLAMP - tube retaining	2
34	A	27256	CLAMP - hose retaining	2
35	13-	612	HHCS - 3/8" - 16 NC x 3/4"	2
36	92-	6	WASHER - lock, 3/8"	2




LOADER HYDRAULICS
CONTROL VALVE TO CLAM CYLINDERS

REF.	PART NO.	DESCRIPTION	REQ'D.
1	REF.	VALVE - hydraulic, loader, 3 spool, see pages 299 and 301	1
2	218- 5063	FITTING - straight, male	2
3	218- 5008	O-RING - fitting	1
4	L 58406	TUBE - valve to R.H. lift arm tube, at valve	1
5	L 58408	TUBE - valve to L.H. lift arm tube, at valve	1
6	A 12032	CLAMP - tube	8
7	13- 516	HHCS - 5/16" - 18 NC x 1"	4
8	92- 5	WASHER - lock, 5/16"	4
9	25- 105	NUT - hex., 5/16"- 18 NC	4
10	L 57599	HOSE - valve to lift arm tubes, 37" (940 mm) long	2
11	L 58402	TUBE - valve to clam cylinder, at R.H. lift arm	1
12	L 58404	TUBE - valve to clam cylinder, at L.H. lift arm	1
13		RESERVED	
14	13- 612	HHCS - 3/8" - 16 NC x 3/4"	4
15	92- 6	WASHER - lock, 3/8"	4
16		CLAMP - tube to tapped block	4
17	L 49771	HOSE - lift arm tubes to clam cylinders, 50" (1270 mm) long	2
18	218- 776	PLUG - hex. head, 5/8", used when bucket is removed to plug clam cylinder hoses, not shown.....	2




BACKHOE STABILIZER CYLINDER HYDRAULIC CIRCUIT

REF.	PART NO.	DESCRIPTION	REQ'D
1	D 62348	VALVE - stabilizer control, parts list page 313	1
2	13- 544	HHCS - 5/16" - 18 NC x 2-3/4", valve mounting	2
3	95- 5	WASHER - flat, 5/16"	2
4	92- 5	WASHER - lock, 5/16"	2
5	25- 105	NUT - hex, 5/16" - 18 NC	2
6	218- 5060	FITTING - male, straight, early production	2
6A	218- 5146	FITTING - 45°, adjustable, late production	2
7	218- 5007	O-RING - fitting	1
8	L 54790	HOSE - stabilizer valve to stabilizer cylinder, closed end, 63" (1600 mm) long .	2
9	L 26312	CLAMP - hose to chassis, if used	2
9A	D 56781	SPACER - clamp to frame, if used	2
10	13- 624	HHCS - 3/8" - 16 NC x 1-1/2", clamp mounting, if used	2
11	92- 6	WASHER - lock, 3/8", if used	2
12	25- 106	NUT - hex, 3/8" - 16 NC, if used	2
13	218- 5121	FITTING - 90°, adjustable	2
14	218- 5007	O-RING - fitting	1
15	REF.	CYLINDER - hydraulic, stabilizer, parts list page 349 or 349B	2
16	218- 5062	FITTING - male, straight	2
17	218- 5007	O-RING - fitting	1
18	L 54786	TUBE - L.H. stabilizer cylinder	1
19	L 54788	TUBE - R.H. stabilizer cylinder	1
20	214- 273	CLAMP - tube to cylinder	2
21	L 54789	HOSE - stabilizer valve to rod end of stabilizer cylinder, 42" (1067 mm) long , if used	2
21	L 71092	HOSE - stabilizer valve to rod end of stabilizer cylinder, 58" (1473 mm) long, if used	2
22	218- 5146	FITTING - 45°, adjustable	2
23	218- 5007	O-RING - fitting	1
24	L 59006	ORIFICE - stabilizer cylinder, 1/8" (3.17 mm) dia. orifice	2
24	D 61933	ORIFICE - stabilizer cylinder, 5/32" (3.96 mm) dia. orifice	2



BACKHOE SWING CYLINDER HYDRAULIC CIRCUIT

REF.	PART NO.	DESCRIPTION	REQ'D
1	REF.	VALVE - backhoe control, parts list page 315	1
2	218- 5071	FITTING - male, straight	2
3	218- 5010	O-RING - fitting	1
4	R 28980	HOSE - backhoe valve to rod end of swing cylinder 58" (1473 mm) long ...	2
4A	49891	CLAMP - swing cylinder hoses, if used	2
5	REF.	CYLINDER - hydraulic, swing, see page 351 or 353	2
6	D 39140	HOSE - cross-over, 23-1/2" (597 mm) long, includes item 13	2
7	218- 5059	FITTING - male	2
8	218- 5006	O-RING - fitting	1
9	218- 5121	FITTING - adjustable, 90°	2
10	218- 5007	O-RING - fitting	1
11	REF.	VALVE - relief, swing cylinder, see page 355	2
12	L 78722	RESTRICTOR - check, swing cylinder	2
13	218- 5006	O-RING - included with item 6	2




BACKHOE BOOM CYLINDER HYDRAULIC CIRCUIT

REF.	PART NO.	DESCRIPTION	REQ'D
1	REF.	VALVE - backhoe control, parts list page 315	1
2	218- 5077	FITTING - male, straight	1
2A	L 55143	FITTING - male, straight, special	1
3	218- 5010	O-RING - 218-5077 and L55143 fittings	1
4	L 58934	RESTRICTOR - boom drop	1
5	L 55955	HOSE - backhoe valve to boom manifold, 26-1/2" (673 mm) long	2
6	L 58202	BLOCK - boom manifold support, used before sn. 9125069	1
7	L 59126	CLAMP - boom manifold, used before sn. 9125069	1
8	13- 644	HHCS - 3/8" - 16 NC x 2-3/4"	1
9	95- 6	WASHER - flat, 3/8"	1
10	131- 6	NUT - hex, self lock, 3/8" - 16 NC	1
11	L 58132	MANIFOLD - boom cylinder	2
12	L 58147	CLAMP - boom cylinder hose to tower	4
13	13- 616	HHCS - 3/8" - 16 NC x 1"	4
14	92- 6	WASHER - lock, 3/8"	4
15	T 41362	HOSE - boom cylinder manifold to boom cylinder, 27-1/2" (698 mm) long ..	4
16	R 15257	CLAMP - tube	4
17	13- 614	HHCS - 3/8" - 16 NC x 7/8"	2
18	92- 6	WASHER - lock, 3/8"	2
19	25- 106	NUT - hex, 3/8" - 16 NC	2
20	L 58145	TUBE - boom cylinder, rod end	2
21	218- 5077	FITTING - male, straight	2
22	218- 5010	O-RING - fitting	1
23	REF.	CYLINDER - hydraulic, boom, see page 357 or 359	2
23A	218- 5108	FITTING - 90°, adjustable, used on cylinders requiring four 90° fittings ..	42
23B	218- 5008	O-RING - fitting	1
24	214- 273	CLAMP - tubes to boom cylinder	2
25	D 38648	SPACER - tube	2
26	L 58142	TUBE - boom cylinder, closed end	2
27	218- 5118	FITTING - adjustable, 90°, if used, see item-23A	2
28	218- 5010	O-RING - fitting	1

USED ON SN. 9125069 AND AFTER

29	L 78210	BRACKET - hose support	1
30	L 78057	CLAMP - hose	1
31	13- 624	HHCS - 3/8" - 16 NC x 1-1/2"	1
32	13- 636	HHCS - 3/8" - 16 NC x 2-1/4"	1
33	95- 6	WASHER - flat, 3/8"	1
34	92- 6	WASHER - lock, 3/8"	2
35	25- 106	NUT - 3/8" - 16 NC	2




BACKHOE DIPPER AND BUCKET CYLINDER HYDRAULIC CIRCUIT

REF.	PART NO.	DESCRIPTION	REQ'D
1	REF.	VALVE - backhoe control, parts list page 315	1
2	218- 5077	FITTING - male, straight	4
3	218- 5010	O-RING - fitting	1
4	L 77824	HOSE - valve to dipper cylinder, 102" (2597 mm) long	2
5	*L 77825	HOSE - valve to bucket cylinder, 58" (1473 mm) long	2
6	L 58088	BLOCK - hose support	4
6A	L 76698	BRACKET - support, hose block, if used	1
7	13- 680	HHCS - 3/8" - 16 NC x 5"	1-2
7	13- 688	HHCS - 3/8" - 16 NC x 5-1/2", if used	1
8	95- 6	WASHER - flat, 3/8"	2
9	131- 6	NUT - hex, self lock, 3/8" - 16 NC	2
10	L 79095	GUARD - hose protecting	1
11	L 78634	CLAMP - hose guard	1
12	13- 812	HHCS - 1/2" - 13 NC x 3/4"	4
13	92- 8	WASHER - lock, 1/2"	4
14	D 40236	CLAMP - hose to guard, at boom	1
15	13- 628	HHCS - 3/8" - 16 NC x 1-3/4", if used	1
15	13- 632	HHCS - 3/8" - 16 NC x 2", if used	1
16	92- 6	WASHER - lock, 3/8"	1
17	R 15257	CLAMP - dipper hose to boom, single, if used	1
17A	D 78057	CLAMP - dipper hose to boom, used in pairs, if used	1
18	D 36040	SPACER - clamp	1
19	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	1
19A	13- 632	HHCS - 3/8" - 16 NC x 2", if used	1
20	92- 6	WASHER - lock, 3/8"	1
21	25- 106	NUT - hex, 3/8" - 16 NC	1
22	REF.	CYLINDER - hydraulic, dipper, see page 361 or 363	1
23	L 54749	TUBE - dipper cylinder, closed end	1
24	214- 273	CLAMP - tube to dipper cylinder	1
25	D 38648	SPACER - tube	2
26	218- 5108	FITTING - adjustable, 90°	1
27	218- 5008	O-RING - fitting	1
28	L 54522	TUBE - dipper cylinder, rod end, used on G34323 cylinder	1
28A	L 74390	TUBE - dipper cylinder, rod end, used on G100004 cylinder	1
28B	L 58145	TUBE - dipper cylinder, rod end, used on G101348 cylinder	1
29	218- 5064	FITTING - male, straight, if used	1
30	218- 5008	O-RING - fitting	1
31	*L 58822	HOSE - bucket cylinder, middle, 104" (2642 mm) long	2
32	R 15257	CLAMP - hose to boom	1
32A	L 79113	CLAMP AND NUT ASSEMBLY - option to item 32, if used, not shown	1
33	13- 664	HHCS - 3/8" - 16 NC x 4"	1
34	L 59005	SPACER - clamp, if used	1
34A	131- 6	NUT - hex, self lock, 3/8" - 16 NC, if used	1


Continued on next page

***NOTE:** On models with extendable dipper, items 5 and 31 above are used in the dipper extension circuit, and separate hoses are used for the bucket cylinder circuit. See pages 295-295D.



BACKHOE DIPPER AND BUCKET CYLINDER HYDRAULIC CIRCUIT

REF.	PART NO.	DESCRIPTION	REQ'D.
35	L 58821	HOSE - bucket cylinder, 47" (1194 mm) long	2
36	REF.	CYLINDER - hydraulic, bucket, see page 365 or 367	1
36A	218- 5108	FITTING - 90°, adjustable, cylinder port, if used	2
36B	218- 5008	O-RING - fitting	1
37	L 58142	TUBE - bucket cylinder, closed end.....	1
38	214- 277	CLAMP - tube to cylinder	1
39	D 38648	SPACER - tube	2
40	218- 5064	FITTING - male, straight, if used.....	2
41	218- 5008	O-RING - fitting	1
42	L 57038	TUBE - bucket cylinder, rod end.....	1
42A	L 77131	TUBE - bucket cylinder, rod end, used with item 36A only	1
43	L 18331	STRAP - hose tie	1




BACKHOE EXTENDABLE DIPPER HYDRAULIC CIRCUIT BEFORE TRACTOR SN. 9125069

REF.	PART NO.	DESCRIPTION	REQ'D
1	REF.	VALVE - backhoe and extendable control, parts list page 315	1
2	218- 5077	FITTING - straight, male	4
3	218- 5010	O-RING - fitting	1
4	*L 77825	HOSE - to extension cylinders, 58" (1473 mm) long	2
4A	L 74090	HOSE - to bucket cylinders, 58" (1473 mm) long	2
4B	L 18331	STRAP - hose tie	2
5	L 59101	BRACKET - clamp support, welded to tower	2
6	13- 612	HHCS - 3/8" - 16 NC x 3/4"	4
7	D 40471	CLAMP - bucket cylinder hoses	4
8	92- 6	WASHER - lock, 3/8"	4
9	25- 106	NUT - hex, 3/8" - 16 NC	4
10	L 58748	TUBE - valve to bucket cylinder, R.H., used with L58351 hose	1
10	L 73190	TUBE - valve to bucket cylinder, L.H., used with L73182 or L78165 hose ..	1
11	L 58746	TUBE - valve to bucket cylinder, L.H., used with L58351 hose	1
11	L 73192	TUBE - valve to bucket cylinder, R.H., used with L73182 or L78165 hose ..	1
12	13- 824	HHCS - 1/2" - 13 NC x 1-1/2"	2
12A	95- 8	WASHER - flat, 1/2"	3
13	92- 8	WASHER - lock, 1/2"	3
14	L 58750	GUARD - boom tubes, lower	1
15	L 58752	SPACER - tube, if used	3
16		RESERVED	
17		RESERVED	
18	13- 616	HHCS - 3/8" - 16 NC x 1"	2
19	95- 6	WASHER - flat, 3/8"	2
20	L 25930	CLAMP - bucket tubes, upper	2
21	92- 6	WASHER - lock, 3/8"	2
22	25- 106	NUT - hex, 3/8" - 16 NC	2
23	13- 636	HHCS - 3/8" - 16 NC x 2-1/4"	2-4
23	13- 620	HHCS - 3/8" - 16 NC x 1-1/4", if used	2
24	95- 6	WASHER - flat, 3/8"	4
25	D 40471	CLAMP - bucket cylinder hoses	4
25A	L 14794	SPACER - lower clamp, 1.09" (28 mm) long	2-4
26	92- 6	WASHER - lock, 3/8"	2-4
27	25- 106	NUT - hex, 3/8" - 16 NC	2-4
28	L 73182	HOSE - at bucket cylinder, 108" (2743 mm) long, used before sn. 9122310 except for 9122278 and 9122290	2
28	L 73182	HOSE - at bucket cylinder, 96" (2438 mm) long, used on sn. 9122278, 9122290 and 9122310 thru 9124627	2
28A	L 78165	HOSE - at bucket cylinder, 98" (2489 mm) long, used on sn. 9124628 and after	2
28B	L 78175	SPACER - clamp, 1/2" (13 mm) long, if used	2
28C	13- 624	HHCS - 3/8" - 16 NC x 1-1/2", if used	2
28D	195- 2034	WASHER - flat, 3/8", if used	2-4
28E	131- 652	NUT - hex, self lock, 3/8" - 16 NC, if used	2

Continued on next page


***NOTE:** On models without extendable dipper, D77825 hoses are used as bucket cylinder circuit hoses. See page 291 for these hoses and hose clamps.



**BACKHOE EXTENDABLE DIPPER HYDRAULIC CIRCUIT
BEFORE TRACTOR SN. 9125069**

REF.	PART NO.	DESCRIPTION	REQ'D
29	L 57038	TUBE - bucket cylinder, at rod end	1
29	L 77131	TUBE - bucket cylinder, at rod end, used with item 32A only	1
29A	L 100128	TUBE - bucket cylinder, at rod end, models with dual lever controls only, if used	1
30	L 58142	TUBE - bucket cylinder, at closed end	1
31	218- 5064	FITTING - male, straight, if used	2
32	218- 5008	O-RING - fitting	1
32A	218- 5108	FITTING - male, 90°, if used	1
32B	218- 5008	O-RING - fitting	1
33	214- 277	CLAMP - tube to cylinder	1
34	D 38648	SPACER - tube	2
35	REF.	CYLINDER - hydraulic, bucket, see page 365 or 367	1
36	*L 58822	HOSE - valve to extension cylinder, 107" (2718 mm) long	2
37	L 76819	HOSE - valve to extension cylinder, 24" (609 mm) long	2
38	13- 652	HHCS - 3/8" - 16 NC x 3-3/4"	1
39	R 49858	CLAMP - extension cylinder hose	2
39A	F 12215	WASHER - special, flat	4
40	92- 6	WASHER - lock, 3/8"	1
41	25- 106	NUT - hex, 3/8" - 16 NC	1
42	218- 5121	FITTING - adjustable, 90°	1
43	218- 5007	O-RING - fitting	1
44	218- 5060	FITTING - male, straight	1
45	218- 5007	O-RING - fitting	1
46	L 54652	TUBE - extension cylinder, rod end	1
47	D 38648	SPACER - tube	1
48	214- 265	CLAMP - tube	1
49	REF.	CYLINDER - hydraulic, dipper extension, see page 369 or 371	1
50	L 73034	GUARD - bucket tubes, if used	1
51	13- 836	HHCS - 1/2" - 13 NC x 2-1/4"	1
52	13- 820	HHCS - 1/2" - 13 NC x 1-1/4"	2

***NOTE:** On models without extendable dipper, D58822 hoses are used as bucket cylinder circuit hoses. See page 291 for hose clamps and hose guards used with these hoses.




**BACKHOE EXTENDABLE DIPPER HYDRAULIC CIRCUIT
TRACTOR SN. 9125069 AND AFTER**

REF.	PART NO.	DESCRIPTION	REQ'D
1	REF.	VALVE - backhoe, parts list page 315	1
2	218- 5077	FITTING - straight, male	4
3	218- 5010	O-RING - fitting	1
4	*L 77825	HOSE - to extension cylinder, from backhoe valve to boom, 58" (1473 mm) long	2
5	L 18331	STRAP - hose tie	UAR
6	L 55955	HOSE - to bucket cylinder, 26-1/2" (673 mm) long	2
7	L 78210	BRACKET - hose support	1
8	D 40236	CLAMP - hose	2
9	13- 624	HHCS - 3/8" - 16 NC x 1-1/2"	1
10	13- 640	HHCS - 3/8" - 16 NC x 2-1/2"	2
11	95- 6	WASHER - flat	2
12	92- 6	WASHER - lock	3
13	25- 106	NUT - hex, 3/8" - 16 NC	3
14	L 78383	TUBE - to bucket cylinder, R.H.	1
15	L 78385	TUBE - to bucket cylinder, L.H.	1
16	13- 632	HHCS - 3/8" - 16 NC x 2"	2
17	L 78192	SPACER - tube	2
18	L 58147	CLAMP - tube	2
19	92- 6	WASHER - lock, 3/8"	2
20	25- 106	NUT - hex, 3/8" - 16 NC	2
21	L 78508	HOSE - to bucket cylinder, 27-1/2" (699 mm) long	2
22	L 58147	CLAMP - hose	2
23	13- 612	HHCS - 3/8" - 16 NC x 3/4"	2
24	92- 6	WASHER - lock, 3/8"	2
25	L 78387	GUARD - bucket tubes lower	1
26	164- 577	SCREW - button head, hex socket	2
27	92- 8	WASHER - lock, 1/2"	2
28	95- 8	WASHER - flat, 1/2"	2
29	L 78415	TUBE - to bucket cylinder	2
30	L 79141	GUARD - bucket tubes	1
31	164- 573	SCREW - button head, hex socket, 1/2" - 13 NC x 1-1/2"	2
32	92- 8	WASHER - lock, 1/2"	2
33	95- 8	WASHER - flat, 1/2"	2
34	L 25930	CLAMP - tube	2
35	13- 616	HHCS - 3/8" - 16 NC x 1"	2
36	95- 6	WASHER - flat, 3/8"	2
37	92- 6	WASHER - lock, 3/8"	2
38	25- 106	NUT - hex, 3/8" - 16 NC	2
39	L 78165	HOSE - to bucket cylinders, 98" (2489 mm) long	2
40	D 40471	CLAMP - hose	2
41	L 14794	SPACER - hose to support	2
42	13- 636	HHCS - 3/8" - 16 NC x 2-1/4"	2
43	95- 6	WASHER - flat, 3/8"	2
44	92- 6	WASHER - lock, 3/8"	2
45	25- 106	NUT - hex, 3/8" - 16 NC	2
46	L 77131	TUBE - bucket cylinder, rod end	1

Continued on next page



*NOTE: On models without extendable dipper, D77825 hoses are used as bucket cylinder circuit hoses. See page 291 for these hoses and hose clamps.



**BACKHOE EXTENDABLE DIPPER HYDRAULIC CIRCUIT
TRACTOR SN. 9125069 AND AFTER**

REF.	PART NO.	DESCRIPTION	REQ'D
46A	L 100128	TUBE - bucket cylinder, rod end, models with dual lever controls only, if used	1
47	218- 5108	FITTING - male, 90°	1
48	218- 5008	O-RING - fitting	1
49	REF.	CYLINDER - bucket, see page 367	1
50	*L 58822	HOSE - to extension cylinder, 107" (2718 mm) long	2
51	L 76819	HOSE - to extension cylinder, 24" (609 mm) long	2
52	49858	CLAMP - hose	2
53	13- 652	HHCS - 3/8" - 16 NC x 3-1/4"	2
54	F 12215	WASHER - spacer	4
55	92- 6	WASHER - lock, 3/8"	1
56	25- 106	NUT - hex, 3/8" - 16 NC	1
57	218- 5121	FITTING - 90°, male	1
58	218- 5007	O-RING - fitting	1
59	L 54652	TUBE - extension cylinder	1
60	218- 5060	FITTING - straight	1
61	218- 5007	O-RING - fitting	1
62	D 38648	SPACER - tube, rubber	1
63	214- 265	CLAMP - adjustable	1
64	REF.	CYLINDER - extension, parts list page 369 or 371	1
65	D 40471	CLAMP - hose	2
66	13- 624	HHCS - 3/8" - 16 NC x 1-1/2"	2
67	195- 2034	WASHER - flat, 3/8"	4
68	L 78175	SPACER - hose clamp	2
69	131- 652	NUT - hex, self lock, 3/8" - 16 NC	2
70	L 58142	TUBE - bucket cylinder, closed end	1
71	218- 5064	FITTING - straight, male	1
72	218- 5008	O-RING - fitting	1

***NOTE:** On models without extendable dipper, D58822 hoses are used as bucket cylinder circuit hoses. See page 291 for hose clamps and hose guards used with these hoses.





L55009 LOADER CONTROL VALVE (2 SPOOL)

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 55009	VALVE - loader control, 2 spool, before tractor sn. 9118604	1
2	NSS	VALVE - secondary relief, parts list page 311	3
3	NSS	VALVE - check, parts list page 311	1
4	NSS	VALVE - main relief, parts list page 309	1
5	L 36036	SPOOL - tilt with magnetic detent, parts list page 307	1
6	L 36037	SPOOL - lift, parts list page 303	1
7	221- 662	PLUG - pressure check adapter	1
8	D 38825	ADAPTER - pressure check	1
9	218- 5008	O-RING - adapter	1
10	L 30446	CONNECTOR - power beyond	1
11	218- 5010	O-RING - connector, large	1
12	L 32680	O-RING - connector, small	1

L55010 LOADER CONTROL VALVE (3 SPOOL)

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 55010	VALVE - loader control, 3 spool, before tractor sn. 9118604	1
2	NSS	VALVE - secondary relief, parts list page 311	4
3	NSS	VALVE - check, parts list page 311	2
4	NSS	VALVE - main relief, parts list page 309	1
5	L 36036	SPOOL - tilt with magnetic detent, parts list page 307	1
6	D 52300	SPOOL - clam, without magnetic detent, parts list page 309	1
7	L 36037	SPOOL - lift, parts list page 303	1
8	221- 662	PLUG - pressure check adapter	1
9	D 38825	ADAPTER - pressure check	1
10	218- 5008	O-RING - adapter	1
11	L 30446	CONNECTOR - power beyond	1
12	218- 5010	O-RING - connector, large	1
13	L 32680	O-RING - connector, small	1





L71838 LOADER CONTROL VALVE (2 SPOOL)

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 71838	VALVE - loader control, 2 spool, tractor sn. 9118604 and after	1
2	NSS	VALVE - secondary relief, parts list page 311	3
3	NSS	VALVE - check, parts list page 311	1
4	NSS	VALVE - main relief, parts list page 309	1
5	L 36036	SPOOL - tilt with magnetic detent, parts list page 307	1
6	D 71232	SPOOL - lift, parts list page 305	1
7	221- 662	PLUG - pressure check adapter	1
8	D 38825	ADAPTER - pressure check	1
9	218- 5008	O-RING - adapter	1
10	L 30446	CONNECTOR - power beyond	1
11	218- 5010	O-RING - connector, large	1
12	L 32680	O-RING - connector, small	1



L71839 LOADER CONTROL VALVE (3 SPOOL)

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 71839	VALVE - loader control, 3 spool, tractor sn. 9118604 and after	1
2	NSS	VALVE - secondary relief, parts list page 311	4
3	NSS	VALVE - check, parts list page 311	2
4	NSS	VALVE - main relief, parts list page 309	1
5	L 36036	SPOOL - tilt with magnetic detent, parts list page 307	1
6	D 52300	SPOOL - clam, without magnetic detent, parts list page 309	1
7	D 71232	SPOOL - lift, parts list page 305	1
8	221- 662	PLUG - pressure check adapter	1
9	D 38825	ADAPTER - pressure check	1
10	218- 5008	O-RING - adapter	1
11	L 30446	CONNECTOR - power beyond	1
12	218- 5010	O-RING - connector, large	1
13	L 32680	O-RING - connector, small	1




**LOADER CONTROL VALVE
LIFT SPOOL
BEFORE TRACTOR SN 9118604**

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 36037	SPOOL ASSEMBLY - lift.....	1
1	D 37153	RETAINER - wiper ring	1
2	A 14527	RING - wiper	1
3	D 37152	GLAND - spool	1
4	A 27365	O-RING - gland, small	1
5	D 37156	O-RING - gland, large	1
6	D 37076	SLEEVE - spool, lug end	1
7	D 33857	RETAINER - O-Ring	1
8	A 7623	O-RING - housing, large	1
9	A 27365	O-RING - spool, small	1
10	D 33856	RETAINER - O-ring	1
11	L 36052	SPOOL - lift	1
12	E 88928	EYE - spool	1
13	218- 5005	O-RING - spool eye	1
14	L 30453	STUD - detent	1
15	A 16879	RETAINER - spring, at spool	1
16	A 16881	RETAINER -spring, at stud	1
17	L 36053	SPRING - centering	1
18	L 30455	WASHER - detent	1
19	211- 11	BALL - detent, 9/32" dia.....	8
20	L 30456	CAM - detent	1
21	L 36054	SPRING - detent	1
22	L 30454	CAP - valve, detent	1
23	L 30458	PLUG - detent adjustment	1





**LOADER CONTROL VALVE
LIFT SPOOL
TRACTOR SN. 9118604 AND AFTER**

REF.	PART NO.	DESCRIPTION	REQ'D.
D	71232	SPOOL ASSEMBLY - lift.....	1
1	D 37153	RETAINER - wiper ring	1
2	A 14527	RING - wiper	1
3	D 37152	GLAND - spool	1
4	A 27365	O-RING - gland, small	1
5	D 37156	O-RING - gland, large	1
6	D 37076	SLEEVE - spool, lug end	1
7	D 71282	RETAINER - O-ring	1
8	A 7623	O-RING - housing, large	1
9	R 17547	O-RING - spool small.....	1
10	D 33856	RETAINER - O-ring	1
11	L 36052	SPOOL - lift	1
12	E 88928	EYE - spool	1
13	218- 5005	O-RING - spool eye	1
14	L 30453	STUD - detent	1
15	A 16879	RETAINER - spring, at spool	1
16	A 16881	RETAINER - spring, at stud	1
17	L 36053	SPRING - centering	1
18	L 30455	WASHER - detent	1
19	211- 11	BALL - detent, 9/32" dia.....	8
20	L 30456	CAM - detent	1
21	L 36054	SPRING - detent	1
22	L 30454	CAP - valve, detent	1
23	L 30458	PLUG - detent adjustment	1



**LOADER CONTROL VALVE
TILT SPOOL**

REF.	PART NO.	DESCRIPTION	REQ'D.
L	36036	SPOOL ASSEMBLY - loader tilt	1
1 L	30744	RETAINER AND WIPER - spool, used with item 3	1
1A D	80412	RETAINER AND WIPER - spool, used with item 3A	1
2 L	36051	SPOOL - loader tilt	1
3 A	27365	O-RING - spool	2
3A D	80411	SEAL - wiper, lip type, used with item 1A	1
4 A	14535	RETAINER - spool O-ring	1
5 L	36048	PLUG - spool end	1
6 A	14533	RETAINER - spring	2
7 A	25286	WASHER - spacer	1
8 A	25285	SPRING - centering	1
9 L	36047	COVER - centering spring	1
10 D	33858	LINK - detent	1
11 138-	2012	PIN - connecting, link to spacer	2
12 L	36049	SPACER - detent	1
13 L	36046	CONNECTOR - detent housing to coil housing	1
14 L	36045	NUT - lock, housing	2
15 F	62114	O-RING - connector	1
16 L	36039	CAP - detent housing	1
17 L	36040	HOUSING - detent coil	1
18 25-	114	NUT - hex., lock, 1/4" - 28 NF	1
19 L	36038	CLAPPER - washer	2
20 L	36044	COIL - magnetic, early production, order item 21A	1
21 L	36041	SLEEVE - coil spacer, early production, order item 21A	1
21A D	80409	COIL AND HOLDER - late production, replaces items 20 and 21	1
22 L	36050	SPACER - clapper	1
23 L	36042	TUBE - wire	1
24 L	36043	CONNECTOR - electrical, coil	1
24A D	80410	GASKET - connector to housing, if used	1
25 173-	26	SCREW - machine, round head, #4 x 5/16"	4
26 192-	53	WASHER - heavy lock, #4	4





**LOADER CONTROL VALVE
CLAM SPOOL**

REF.	PART NO.	DESCRIPTION	REQ'D.
	D 52300	SPOOL ASSEMBLY - clam	1
1	L 30744	GLAND AND WIPER - spool	1
2	A 27365	O-RING - spool	1
3	NSS	SPOOL - clam control	1
4	A 27365	O-RING - spool	1
5	A 14535	RETAINER - O-ring	2
6	A 14533	RETAINER - spring	2
7	A 25286	WASHER - centering spring	1
8	A 25285	SPRING - spool return	1
9	A 27020	RING - retaining	1
10	A 14529	CAP - spool	1

MAIN RELIEF VALVE

REF.	PART NO.	DESCRIPTION	REQ'D.
1	129- 514	NUT - acorn, main relief valve	1
2	D 26270	WASHER - special	2
3	25- 155	NUT - hex., lock, 5/16" - 24 NF	1
4	176- 296	SCREW - adjusting, main relief valve, 5/16" - 24 NF x 1-3/4"	1
5	D 26268	SPRING - pilot	1
6	D 26267	PLUNGER - relief valve	1
7	A 25291	CAP - relief valve	1
8	L 30443	RING - backup, L30444 seal	1
9	L 30444	O-RING - relief valve cap, small	1
10	218- 5006	O-RING - relief valve cap, large	1
11	D 26266	SEAT - plunger	1
12	D 52319	SPRING - relief valve	1
13	D 37062	POPPET ASSEMBLY - main relief valve	1
14	D 37063	SEAT - poppet	1
15	L 30444	O-RING - sleeve	1
16	L 30443	RING - backup	1
17	D 37064	SLEEVE - poppet seat	1
18	D 37065	SLEEVE - drain	1
19	218- 5210	PLUG - main relief valve	1
20	218- 5006	O-RING - plug	1




**LOADER CONTROL VALVE
SECONDARY RELIEF VALVE**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	218- 5210	PLUG - secondary relief	1
2	218- 5006	O-RING - plug	1
3		RESERVED	
4	L 36077	SHIM - spring guide	UAR
5	D 37150	GUIDE - spring	1
6	D 54860	RING - backup, spring guide	1
7	T 41959	O-RING - spring guide	1
8	D 37148	SPRING - plunger	1
9	D 37151	PLUNGER - relief valve	1
10	D 37075	SEAT - plunger	1
11	D 37072	BODY - secondary relief valve	1
12	218- 5007	O-RING - valve body, large	1
13	D 37071	RING - backup, center O-ring	1
14	D 26265	O-RING - relief body, center	1
15	D 37070	RING - backup, small O-ring	2
16	D 26872	O-RING - relief body, small	1
17	D 37067	SPRING - poppet	1
18	D 37068	POPET - check valve	1
19	D 40358	SEAT - poppet	1


CHECK VALVE

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D 37066	CAP - check valve	1
2	218- 5007	O-RING - check valve cap, large	1
3	D 37071	RING - backup, center O-ring	1
4	D 26265	O-RING - check valve cap, center	1
5	D 37070	RING - backup, small O-ring	2
6	D 26872	O-RING - check valve cap, small	1
7	D 37067	SPRING - check valve	1
8	D 37068	POPET - check valve	1
9	D 40358	SEAT - poppet	1



D62348 STABILIZER CONTROL VALVE

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D 62348	VALVE ASSEMBLY - stabilizer control, Cessna No. 39042-AAE	.1
2	NSS	BODY - valve	1
3	NSS	SPOOL - control valve	1
4	D 56443	O-RING - valve spool	4
5	D 56439	BUSHING - valve spool	2
6	F 8235	WASHER - spring retainer	4
7	D 56909	SPACER - spring	2
8	D 56445	SPRING - spool return	2
9	A 27020	RING - retaining, washer	2
11	D 59653	PLUG - spring retainer	2
12	D 56444	SPRING - poppet	2
13	D 59654	POPPET - valve	2
14	D 56455	SEAT - plunger	2
15	D 48359	O-RING - seat	2
16	D 59655	PLUNGER - valve	2
17	D 31410	O-RING - plunger	2




BACKHOE CONTROL VALVE

REF.	PART NO.	DESCRIPTION	REQ'D.
1 G	34669	VALVE ASSEMBLY - control, 7 section valve, not shown, used before tractor sn. 9121632	1
1 G	100191	VALVE ASSEMBLY - control, 7 section valve, not shown, used on tractor sn. 9121632 and after	1
2 G	33102	INLET SECTION - see page 317	1
3	REF.	SWING SECTION - see page 327	1
4	REF.	MID-INLET SECTION - see page 325 for proper section	1
5	REF.	BUCKET & DIPPER SECTIONS - see page 319	2
6	REF.	BOOM SECTION see page 321	1
7 G	33108	OUTLET SECTION - see page 317.....	1
8 G	34001	O-RING - section ports	6
9 G	34000	O-RING - section ports	18
10 G	33964	SHIM - section, top, .002" (0.05 mm)	6
11 G	33965	SHIM - section, bottom, .002" (0.05 mm)	6
12 G	34675	ROD - tie, valve sections	4
13 25-	106	NUT - hex., 3/8" - 16 NC	8
14		RESERVED	
15		RESERVED	
16		RESERVED	


BACKHOE CONTROL VALVE
USED ON EXTENDAHOE MODELS

17 G	34670	VALVE ASSEMBLY - control, 8 section valve, not shown, used before tractor sn. 9121632	1
17 G	100183	VALVE ASSEMBLY - control, 8 section valve, not shown, used on tractor sn. 9121632 and after	1
18 G	33102	INLET SECTION - see page 317	1
19	REF.	SWING SECTION - see page 327	1
20	REF.	MID-INLET SECTION - see page 325 for proper section	1
21	REF.	BUCKET & DIPPER SECTIONS - see page 319	2
22	REF.	BOOM SECTION - see page 321	1
23	REF.	EXTENDABLE DIPPER SECTION - see page 329	1
24 G	33108	OUTLET SECTION - see page 317.....	1
25 G	34001	O-RING - section ports	7
26 G	34000	O-RING - section ports	21
27 G	33964	SHIM - section, top, .002" (0.05 mm)	7
28 G	33965	SHIM - section, bottom, .002" (0.05 mm)	7
29 G	33124	ROD - tie, valve sections	4
30 25-	106	NUT - hex., 3/8" - 16 NC	8

G33108 OUTLET SECTION



G33102 INLET SECTION




741993

**BACKHOE CONTROL VALVE
OUTLET SECTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 33108	SECTION ASSEMBLY - outlet	1
2	NSS	MANIFOLD - section body	1
3	G 33110	PISTON - regeneration sensing	1
4	G 34586	SPOOL - regeneration	1
5	G 33112	SPRING - regeneration spool, free length	1
6	A 35104	O-RING - manifold	1
7	G 33113	PLUG - regeneration spool	1
8	218- 5009	O-RING - plug	1


INLET SECTION

12	G 33102	SECTION ASSEMBLY- inlet	1
13	NSS	MANIFOLD - section body	1
14	G 33104	SEAT - check valve poppet	1
15	G 33105	POPPET - check valve	1
16	G 33106	SPRING - check valve	1
17	A 39586	PLUG - check valve	1
18	218- 5007	O-RING - plug	1



**BACKHOE CONTROL VALVE
DIPPER AND BUCKET SECTIONS**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 34671	SECTION ASSEMBLY - dipper and bucket, order G100195	
		section	2
1	G 100195	SECTION ASSEMBLY - dipper and bucket	2
2	NSS	BODY - section	1
3	NSS	SPOOL - section	1
4	A 27365	O-RING - body	2
5	A 32309	SEAL - valve spool	1
6	G 33803	RETAINER - body O-ring	1
7	G 34463	SPRING - spool centering	1
8	G 33075	RETAINING - centering spring	2
9	G 33077	RING - snap, retainer	1
10	G 33080	CAP - centering spring	1
11	G 33081	POPPET - load check	2
12	G 33573	SPRING - load check	2
13	G 33084	PLUG - load check	2
14	G 33686	O-RING - plug	2
15		RESERVED	
*G	34672	VALVE ASSEMBLY - relief	2
16	NSS	BODY - relief valve	1
17	NSS	POPPET - relief valve	1
18	A 28090	O-RING - poppet	1
19	G 33090	SPRING - relief valve, outer	1
20	G 34659	SPRING - relief valve, inner	1
21	G 33091	PISTON - relief valve	1
22	D 31409	O-RING - piston	1
23	G 33092	RETAINER - relief valve	1
24	G 46150	RING - snap, retainer	1
25	178- 630	SCREW - set, piston adjusting, 1/4" - 20 NC x 3/4"	1
26	25- 144	NUT - lock, 1/4" - 20 NC	1
27	218- 5008	O-RING - valve body, large	1
28	G 100959	O-RING - valve body, small	1
29	G 35540	RING - backup, if used	1
*G	34862	KIT - service, relief valve, this kit will service the complete relief valve and includes items 16 thru 28	2




**BACKHOE CONTROL VALVE
BOOM SECTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
1 G	34460	SECTION ASSEMBLY - boom, not shown, order G100194	
		section	1
1 G	100194	SECTION ASSEMBLY - boom, not shown.....	1
2	NSS	BODY - boom section	1
3	NSS	SPOOL - boom section	1
4 A	27365	O-RING - body	2
5 A	32309	SEAL - valve spool	1
6 G	33803	RETAINER - body O-ring	1
7 G	34463	SPRING - spool centering	1
8 G	33075	RETAINING - centering spring	2
9 G	33077	RING - snap, retaining	1
10 G	33080	CAP - centering spring	1
11 G	33081	POPPET - load check	2
12 G	33573	SPRING - load check	2
13 G	33084	PLUG - load check	2
14 G	33686	O-RING - plug	2
15		RESERVED	
16		RESERVED	
17		RESERVED	
*G	34052	VALVE ASSEMBLY - relief, upper	1
18	NSS	BODY - relief valve	1
19	NSS	POPPET - relief valve	1
20 A	28090	O-RING - poppet	1
21 G	33090	SPRING - relief valve	1
22 G	33241	PIN - stop, relief valve	1
23 G	33091	PISTON - relief valve	1
24 D	31409	O-RING - piston	1
25 G	33092	RETAINER - relief valve	1
26 G	46150	RING - snap, retainer	1
27 178-	630	SCREW - set, piston adjusting, 1/4" - 20 NC x 3/4"	1
28 25-	144	NUT - lock, 1/4" - 20 NC	1
29 218-	5008	O-RING - valve body, large	1
30 G	100959	O-RING - valve body, small	1
31 D	35540	RING - backup, if used	1
32		RESERVED	
33		RESERVED	
*G	34595	VALVE ASSEMBLY - relief, lower, includes items 34 thru 46A .	1
34	NSS	BODY - relief valve	1
35	NSS	POPPET - relief valve	1
36 A	28090	O-RING - poppet	1


Continued on next page

*G 34862 KIT - service, relief valve, this kit will service either complete relief valve and includes items 18 thru 31 or 34 thru 46A2



**BACKHOE CONTROL VALVE
BOOM SECTION**

REF.	PART NO.	REF.	DESCRIPTION	REQ'D.
*G	34595		SECTION ASSEMBLY - boom, continued from page 321	1
37	G 33090		VALVE ASSEMBLY — relief, lower, continued from page 321	1
38	G 34659		SPRING - relief valve, outer	1
39	G 33091		SPRING - relief valve, inner	1
40	D 31409		PISTON - relief valve	1
41	G 33092		O-RING - piston	1
42	G 46150		RETAINER - relief valve	1
43	178- 630		RING - snap, retainer	1
44	25- 144		SCREW - set, piston adjusting, 1/4" -20 NC x 3/4"	1
45	218- 5008		NUT - lock, 1/4" -20 NC	1
46	G 100959		O-RING - valve body, large	1
46A	D 35540		O-RING - valve body, small	1
47	G 34937		RING - backup, if used	1
48	218- 5007		PLUG - anticavitation, G100194 section only	2
49	G 34458		SEAL - O-ring, G100194 section only	2
50	G 34938		SPRING - poppet, G100194 section only	2
*G	34862		KIT - service, relief valve, this kit will service either complete relief valve and includes items 18 thru 31 or 34 thru 46A	2




BACKHOE CONTROL VALVE
G34843 MID-INLET SECTION

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 34843	MANIFOLD ASSEMBLY - mid-inlet section, not shown	1
2	NSS	BODY - manifold	1
3	G 34938	POPPET - check valve	1
4	G 34458	SPRING - check valve	1
5	G 34937	PLUG - check valve	1
6	218- 5007	O-RING - plug	1
	G 34844	PLUG ASSEMBLY - manifold port	1
7	NSS	PLUG	1
8	D 39717	O-RING - upper	1
9	G 34846	O-RING - lower	1


G34895 MID-INLET SECTION

10	G 34895	MANIFOLD ASSEMBLY - mid-inlet section, not shown	1
11	NSS	BODY - manifold	1
12	G 34938	POPPET -check valve	1
13	G 34458	SPRING - check valve	1
14	G 34937	PLUG - check valve	1
15	218- 5007	O-RING - plug	1
	218- 5159	PLUG ASSEMBLY - manifold port	1
16	NSS	PLUG	1
17	218- 5009	O-RING - plug	1
18	221- 844	PLUG - pipe, square socket head, 1/2" NPT	1




**BACKHOE CONTROL VALVE
SWING SECTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 34658	SECTION ASSEMBLY - swing, order G100192 section	1
1	G 34941	SECTION ASSEMBLY - swing, order G100192 section	1
1	G 100192	SECTION ASSEMBLY - swing	1
2	NSS	BODY swing section	1
3	NSS	SPOOL - swing section	1
4	A 27365	O-RING - body	2
5	A 32309	SEAL - valve spool	1
6	G 33803	RETAINER - body O-ring	1
7	G 34463	SPRING - spool centering	1
8	G 33075	RETAINER - centering spring	2
9	G 33077	RING - snap, retainer to spool	1
10	G 33080	CAP - centering spring	1
11	G 33081	POPPET - load check valve	2
12	G 33573	SPRING - load check valve	2
13	G 33084	PLUG - load check valve	2
14	G 33686	O-RING - plug	2
15	G 34456	POPPET - anticavitation valve, 3/8" (9.5 mm) stem on poppet, G34658 section only, for service order G34937 plug and G34938 poppet, items 32 and 33	2
16	G 34458	SPRING - anticavitation valve, free length	2
17	G 34457	PLUG - anticavitation valve, 3/8" (9.5 mm) hole in plug G34658 section only, for service order G34937 plug and poppet, items 32 and 33	2
18	218- 5007	O-RING - plug	2
*G	34657	VALVE ASSEMBLY - relief	2
19	NSS	BODY - relief valve	1
20	NSS	POPPET - relief valve	1
21	A 28090	O-RING - poppet	1
22	G 33090	SPRING - relief valve	1
23	G 34455	PIN - stop, relief valve spring	1
24	G 33091	PISTON - relief valve	1
25	D 31409	O-RING - piston	1
26	G 33092	RETAINER - relief valve	1
27	G 46150	RING - snap, retainer	1
28	178- 630	SCREW - set, piston adjusting, 1/4" - 20 NC x 3/4"	1
29	25- 144	NUT - lock, 1/4" - 20 NC	1
30	218- 5008	O-RING - valve body, large	1
31	G 100959	O-RING - valve body, small	1
31A	G 35540	RING - backup, if used	1
32	G 34937	PLUG - anticavitation valve, 15/32" (11.9 mm) hole in plug, G34941 and G100192 section only	2
33	G 34938	POPPET - anticavitation valve, 15/32" (11.9 mm) stem on poppet, G34941 and G100192 section only	2
*G	34862	KIT - service, relief valve, this kit will service either complete relief valve and includes items 19 thru 31A	1





**BACKHOE CONTROL VALVE
EXTENDABLE DIPPER SECTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 33121	SECTION ASSEMBLY - extendable dipper, order G100193	
		section	1
1	G 100193	SECTION ASSEMBLY - extendable dipper	1
2	NSS	BODY - extendable dipper section	1
3	NSS	SPOOL - extendable dipper section	1
4	A 27365	O-RING - body	2
5	A 32309	SEAL - valve spool	1
6	G 33803	RETAINER - body O-ring	1
7	G 34463	SPRING - spool centering	1
8	G 33075	RETAINER - centering spring	2
9	G 33077	RING - snap, retainer	1
10	G 33080	CAP - center spring	1
11	G 33081	POPPET - load check	2
12	G 33573	SPRING - load check	2
13	G 33084	PLUG - load check	2
14	G 33686	O-RING - plug	2
15	G 33122	PLUG ASSEMBLY - relief port	2
16	G 100959	O-RING - plug, small	1
17	218- 5008	O-RING - plug, large	1
18	G 35540	RING - backup, if used	1



L54770 FLOW CONTROL VALVE

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 54770	VALVE - flow control	1
2	NSS	BODY - flow divider valve	1
3	E 74266	VALVE - relief.....	1
4	D 46216	SPRING - compression	1
5	D 46214	RING - spring retaining	1
6	L 33959	SCREEN - filter	1
7	218- 5152	PLUG - screen retaining	1
8	218- 5002	O-RING - plug	1




740107 A

L54772 HYDRAULIC RELIEF VALVE

REF.	PART NO.	DESCRIPTION	REQ'D.
L			
	54772	VALVE ASSEMBLY - relief, hydraulic, Gresen PK-12, to service complete valve, see page 121	1
1	NSS	BODY - relief valve	1
2	L 35638	VALVE - relief	1
	NSS	CAGE ASSEMBLY - outer	1
3	L 35648	BODY - cage assembly	1
4	L 35645	CAP - cage assembly	1
5	L 35646	GASKET - cap	1
6	L 35647	SCREW - adjusting	1
7	L 35649	SPRING - poppet	1
8	A 29197	O-RING - large	1
9	L 35650	POPPET - cage	1
10	L 35403	WASHER - backup	1
11	218- 5009	O-RING - small	1
	NSS	CAGE ASSEMBLY - inner	1
12	L 35967	CYLINDER - cage assembly body	1
13	D 51516	O-RING - cylinder	1
14	D 51530	WASHER - backup	1
15	G 46147	RING - retaining	1
16	L 35967	PISTON - cage assembly	1
17	L 35643	PIN - relief	1
18	L 35642	SPRING - piston	1


L59641 HYDRAULIC RELIEF VALVE

L	59641	VALVE ASSEMBLY - relief, hydraulic, Parker Hannifin No. VPRP5B-3-A-A-270	1
1	NSS	BODY - relief valve	1
	W 12116	VALVE ASSEMBLY - relief	1
2	129- 514	NUT - acorn	1
3	D 26270	SEAL - lock and acorn nut	2
4	25- 155	NUT - lock, 5/16" - 24 NF	1
5	176- 299	SCREW - set	1
6	D 26268	SPRING - pilot	1
7	D 26267	PLUNGER - pilot	1
8	D 26262	CAP - relief valve body	1
9	218- 5006	O-RING - outer	1
10	L 30443	WASHER - backup	1
11	L 30444	O-RING - inner	1
12	D 26266	SEAT - pilot	1
13	D 26261	SPRING - plunger	1
14	L 30687	POPPET ASSEMBLY - valve	1
	NSS	PLUNGER - poppet	1
	NSS	SCREEN - poppet, order L30687	1
	W 12133	RETAINER - snap ring	1
15	D 26259	SEAT - relief valve plunger	1
16	221- 661	PLUG - pipe, 1/8" NPT	2



L55247 HYDRAULIC PUMP


REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 55247	PUMP ASSEMBLY - hydraulic, Commercial Shearing #C230-138.....	1
2	L 32111	STUD - special, 5/8" - 11 NC x 9-3/4"	4
3	129- 561	NUT - hex., 5/8" - 11 NC	4
4	D 31957	WASHER - special	4
	L 32109	COVER ASSEMBLY - closed end	1
5	NSS	COVER - pump end	1
6	L 32096	RING - seal, bronze	1
7	L 32097	BEARING - roller	2
	L 35992	HOUSING ASSEMBLY - gear, 1" (25.4 mm) wide gears	1
8	NSS	HOUSING - gear	1
9	L 32101	PLATE - thrust	2
10	L 32099	SEAL - pocket, thrust plate.....	12
11	L 32100	SEAL - ring, square edge	2
12	L 32107	GEAR - matched set, drive and driven, 1" (25.4 mm) wide	1
	L 35991	CARRIER ASSEMBLY - bearing	1
13	NSS	CARRIER - bearing	1
14	L 32096	RING - seal, bronze	2
15	L: 32097	BEARING - roller	4
16	L 32104	SHAFT - connecting, drive gears	1
	L 35990	HOUSING ASSEMBLY - gear, 1-1/2" (38.1 mm) wide gears	1
17	NSS	HOUSING - gear	1
18	L 32101	PLATE - thrust	2
19	L 32099	SEAL - pocket, thrust plate.....	12
20	L 32100	SEAL - ring, square edge	2
21	L 32102	GEAR - matched set, drive and driven, 1-1/2" (38.1 mm) wide	1
22	L 32098	SHAFT - drive pump	1
23	71466	RING - retaining	1
24	73153	BEARING - drive shaft	1
25	L 32092	RETAINING - bearing	1
26	L 35989	SPACER - bearing, drive shaft	1
27	B 18208	RING - retaining	1
28	L 32093	SEAL - lip, drive shaft.....	1
	L 32094	COVER ASSEMBLY - shaft end	1
29	NSS	COVER - pump end	1
30	L 32096	RING - seal, bronze	1
31	L 32097	BEARING - roller	2
32	L 32320	SCREW - special, 7/16" - 20 NF x 3/8"	1



**G34663 AND G34664 LOADER LIFT CYLINDER
WITH TWO PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 34663	CYLINDER - lift, R.H., 3-1/2" (89 mm) I.D. x 31" (787 mm) stroke	1
1	G 34664	CYLINDER - lift, L.H., 3-1/2" (89 mm) I.D. x 31" (787 mm) stroke	1
2	G 34717	TUBE - cylinder, R.H.	1
2	G 34716	TUBE - cylinder, L.H.	1
3	D 30735	BUSHING - tube	2
	G 34629	GLAND ASSEMBLY	1
5	NSS	GLAND - cylinder	1
6	NSS	RING - retaining	1
7 *D	95144	WIPER - piston rod	1
8 *G	34322	BEARING - center	1
9 *D	36971**	SEAL - piston rod	1
10 *G	15457	O-RING - gland	1
11 *G	32126	RING - backup	1
12 187-	1031	SCREW - #8 - 32 NC x 1/4", self tapping	1
13 G	33604	ROD - piston, 2" (51 mm) O.D.	1
14 D	33047	BUSHING - piston rod	2
15 G	33167	PISTON - split, rod end	1
16 D	28367	PISTON - split, bolt end	1
*G	33237	PACKING - piston	1
17	NSS	PACKING - "V" type	2
18	NSS	RING - center bearing	1
19 28-	1640	HHCS - piston, 1" - 14 NF x 2-1/2", grade 8	1
20 G	32303	WASHER - piston bolt	1
21 219-	1	FITTING - grease, straight, 1/8" NPT	1
*G	34630	SEAL KIT - cylinder repair, includes all items with an asterisk ..	1
**G	100778	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G102140 LOADER LIFT CYLINDERS
WITH ONE PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 102140	CYLINDER ASSEMBLY - lift, 3-1/2" (89 mm) I.D. x 31" (787 mm) stroke	2
2	G 102139	TUBE ASSEMBLY - cylinder	1
3	D 30735	BUSHING - tube	2
4		RESERVED	
	G 34629	GLAND ASSEMBLY - cylinder	1
5	NSS	GLAND - cylinder	1
6	NSS	RING - retaining	1
7 *D	95144	WIPER - piston rod	1
8 *G	34322	BEARING - center	1
9 *D	36971**	SEAL - piston rod	1
10 *G	15457	O-RING - gland	1
11 *G	32126	RING - backup	1
12 187-	1031	SCREW - self tapping, #8 - 32 NC x 1/4"	1
13 G	33604	ROD ASSEMBLY - piston, 2" (51 mm) O.D.	1
14 D	33047	BUSHING - piston rod	2
15 G	100694	PISTON - cylinder	1
16 *G	102286	SEAL - piston	1
17 *G	100710	RING - backup	1
18 *G	100711	RING - wear	2
19 28-	1640	HHCS - 1" - 14 NF x 2-1/2", grade 8	1
20 G	32303	WASHER - hardened	1
21 219-	1	FITTING - grease, straight, 1/8" NPT	1
*G	102402	KIT - seal, includes all items with an asterisk	1
**G	100778	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G33562 LOADER BUCKET TILT CYLINDER
WITH TWO PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 33562	CYLINDER - bucket, 3" (76 mm) I.D. x 23-1/2" (597 mm) stroke	2
2	D 35102	TUBE - cylinder	1
3	D 31511	BUSHING - tube	2
	G 34633	GLAND ASSEMBLY	1
5	NSS	GLAND - cylinder	1
6	NSS	RING - retaining	1
7 *D	95143	WIPER - piston rod	1
8 *G	34621	BEARING - piston rod	1
9 *D	36970**	SEAL - piston rod	1
10 *A	30095	O-RING - gland	1
11 *G	32122	RING - backup	1
12 187-	1031	SCREW - #8 - 32 NC x 1/4" self tapping	1
13 G	33563	ROD ASSEMBLY - piston, 1-3/4" (44 mm) O.D.	1
14 D	32865	BUSHING - piston rod	2
15 G	33331	PISTON - split, rod end	1
16 D	28896	PISTON - split, bolt end	1
*G	33151	PACKING - piston	1
17	NSS	PACKING - "V" type	2
18	NSS	RING - center bearing	1
19 28-	1640	HHCS - piston 1" - 14 NF x 2-1/2", grade 8	1
20 G	32303	WASHER - piston bolt	1
21 219-	36	FITTING - grease, 45°, 1/8" NPT	1
*G	34643	SEAL KIT - cylinder repair, includes all items with an asterisk ..	1
**G	100777	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G101220 LOADER BUCKET TILT CYLINDERS
WITH ONE PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1 G	101220	CYLINDER ASSEMBLY - bucket tilt, 3" (76 mm) I.D. x 23-1/2" (597 mm) stroke	2
2 D	35102	TUBE ASSEMBLY - cylinder	1
3 D	31511	BUSHING - tube	2
4		RESERVED	
	G 34633	GLAND ASSEMBLY - cylinder	1
5	NSS	GLAND - cylinder	1
6	NSS	RING - retaining	1
7 *D	95143	WIPER - piston rod	1
8 *G	34621	BEARING - center	1
9 *D	36970**	SEAL - piston rod	1
10 *A	30095	O-RING - gland	1
11 *G	32122	RING - backup	1
12 187-	1031	SCREW - self tapping, #8 - 32 NC x 1/4"	1
13 G	33563	ROD ASSEMBLY - piston, 1-3/4" (44 mm) O.D.	1
14 D	32865	BUSHING - piston rod	2
15 G	100704	PISTON - cylinder	1
16 *G	102288	SEAL - piston	1
17 *G	100444	RING - backup	1
18 *G	100449	RING - wear	2
19 28-	1640	HHCS - 1" - 14 NF x 1-1/2", grade 8	1
20 G	32303	WASHER - hardened	1
21 219-	36	FITTING - grease, 45°, 1/8" NPT	1
*G	102405	KIT - seal, includes all, items with an asterisk	1
**G	100777	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G33770 AND G33771 DROTT CLAM CYLINDERS
WITH TWO PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 33770	CYLINDER - clam, R.H., 3" (76 mm) I.D. x 10 - 1/2" (266 mm) stroke	1
1	G 33771	CYLINDER - clam, L.H., 3" (76 mm) I.D. x 10-1/2" (266 mm) stroke	1
2	D 46911	TUBE - cylinder R.H.	1
2	D 46910	TUBE - cylinder, L.H.	1
3	30364	BUSHING - tube	2
4	G 34328	GLAND ASSEMBLY - not shown	1
5	NSS	GLAND - cylinder	1
6	NSS	RING - retaining	1
7	*D 95142	WIPER - piston rod	1
8	*G 34302	BEARING - center	1
9	*D 36969**	SEAL - piston rod	1
10	*A 30095	O-RING - gland	1
11	*G 32122	RING - backup	1
12	187- 1031	SCREW - #8-32 x 1/4" self tapping	1
13	G 33467	ROD - piston, 1-1/2" (38.1 mm) O.D.	1
14	30634	BUSHING - piston rod	2
15	G 33150	PISTON - split, rod end	1
16	D 28366	PISTON - split, bolt end	1
	*G 33151	PACKING - piston	1
17	NSS	PACKING - "V" type	2
18	NSS	RING - center bearing	1
19	28- 1240	HHCS - piston, 3/4" - 16 NF x 2-1/2", grade 8	1
20	G 32317	WASHER - piston bolt	1
21	219- 1	FITTING - grease, straight, 1/8" NPT	2
	*G 34332	SEAL KIT - cylinder repair, includes all items with an asterisk ..	1
	**G 100776	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G101226 AND G101227 LOADER CLAM CYLINDER
WITH ONE PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D
1	G 101226	CYLINDER - clam, R.H., 3" (76 mm) I.D. x 10-1/2" (266 mm) stroke	1
1	G 101227	CYLINDER - clam, L.H., 3" (76 mm) I.D. x 10-1/2" (266 mm) stroke	1
2	D 46911	TUBE ASSEMBLY - R.H. cylinder	1
2	D 46910	TUBE ASSEMBLY - L.H. cylinder	1
3	30634	BUSHING - tube	2
4		RESERVED	
	G 34328	GLAND ASSEMBLY - cylinder	1
5	NSS	GLAND - cylinder	1
6	NSS	RING - retaining	1
7	*D 95142	WIPER - piston rod	1
8	*G 34302	BEARING - center	1
9	*D 36969**	SEAL - piston rod	1
10	*A 30095	O-RING - gland	1
11	*G 32122	RING - backup	1
12	187- 1031	SCREW - self tapping, #8 - 32 NC x 1/4"	1
13	G 33467	ROD ASSEMBLY - piston, 1-1/2" (38 mm) O.D.	1
14	30634	BUSHING - piston rod	2
15	G 100442	PISTON - cylinder	1
16	*G 102288	SEAL - piston	1
17	*G 100444	RING - backup	1
18	*G 100449	RING - wear	2
19	28- 1240	HHCS - 3/4" - 16 NF x 2-1/2", grade 8	1
20	G 32317	WASHER - piston bolt	1
21	219- 1	FITTING - grease, straight, 1/8" NPT	2
	*G 102404	KIT - seal, includes all items with an asterisk	1
	**G 100776	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G34829 BACKHOE STABILIZER CYLINDER
WITH TWO PIECE PISTON
USED BEFORE TRACTOR SN. 9127845**

REF.	PART NO.	DESCRIPTION	REQ'D
1	G 34829	CYLINDER - stabilizer, 4-1/2" (114 mm) I.D. x 21-3/8" (543 mm) stroke	1
2	G 34830	TUBE - cylinder	1
3	D 34340	BUSHING - tube	2
4		RESERVED	
	G 34397	GLAND ASSEMBLY - cylinder	1
5	NSS	GALND - cylinder	1
6	NSS	RING - retaining	1
7	*D 95144	WIPER - piston rod	1
8	*G 34322	BEARING - center	1
9	*D 36971**	SEAL - piston rod	1
10	*A 23316	O-RING - gland	1
11	*G 32284	RING - backup	1
12	187- 1031	SCREW - #8 - 32 NC x 1/4", self tapping	1
13	G 33831	ROD - piston, 2" (51 mm) O.D.	1
14	G 33634	PISTON - split, rod half	1
15	D 46931	PISTON - split, bolt half	1
16	*D 47205	PACKING - piston, "V" type	2
17	D 47210	RING - center bearing	1
18	28- 2048	HHCS - piston, 1-1/2" - 12 NF x 2-1/2", grade 8	1
19	G 32351	WASHER - piston bolt	1
20	219- 1	FITTING - grease, straight, 1/8" NPT	1
*G	34644	SEAL KIT - cylinder repair, includes all items with an asterisk	1
**G	100778	SEAL - piston rod, service option - extreme heat or cold	1



NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G102276 BACKHOE STABILIZER CYLINDER
WITH TWO PIECE PISTON
USED ON TRACTOR SN. 9127845 AND AFTER**

REF.	PART NO.	DESCRIPTION	REQ'D
1	G 102276	CYLINDER - stabilizer, 4-1/2" (114 mm) I.D. x 22-3/8" (568 mm) stroke	1
2	G 102277	TUBE - cylinder	1
3	D 34340	BUSHING - tube	2
4		RESERVED	
	G 34397	GLAND ASSEMBLY - cylinder	1
5	NSS	GLAND - cylinder	1
6	NSS	RING - retaining	1
7	*D 95144	WIPER - piston rod	1
8	*G 34322	BEARING - center	1
9	*D 36971**	SEAL - piston rod	1
10	*A 23316	O-RING - gland	1
11	*G 32284	RING - backup	1
12	187- 1031	SCREW - #8 - 32 NC x 1/4", self tapping	1
13	G 102280	ROD - piston, 2" (51 mm) O.D.	1
14	G 33634	PISTON - split, rod half	1
15	D 46931	PISTON - split, bolt half	1
16	*D 47205	PACKING - piston, "V" type	2
17	D 47210	RING - center bearing	1
18	28- 2048	HHCS - piston, 1-1/2" - 12 NF x 2-1/2", grade 8	1
19	G 32351	WASHER - hardened	1
20	219- 1	FITTING - grease, straight, 1/8" NPT	1
	*G 34644	SEAL KIT - cylinder repair, includes all items with an asterisk	1
	**G 100778	SEAL - piston rod, service option - extreme heat or cold	1

NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.




741986 B

**G34880 BACKHOE SWING CYLINDER
WITH TWO PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1 G	34880	CYLINDER - swing, 4" (101 mm)I.D. x 11-1/4" (285 mm) stroke	1
2 G	34877	TUBE - cylinder	1
3 G	34875	BUSHING - tube	2
G	34331	GLAND ASSEMBLY - cylinder	1
4	NSS	GLAND - cylinder	1
5	NSS	RING - retaining	1
6 *D	95144	WIPER - piston rod	1
7 *G	34322	BEARING - center	1
8 *D	36971	SEAL - piston rod	1
9 *A	27507	O-RING - gland	1
10 *G	32176	RING - backup	1
11 187-	1031	SCREW - #8 - 32 x 1/4", self tapping	1
12 G	34775	ROD - piston, 2" (51 mm) O.D.	1
13 G	34854	BUSHING - piston rod	2
14 G	33159	PISTON - split, rod end	1
15 D	49161	PISTON - split, bolt end	1
16 *D	47204	PACKING - piston, "V" type	2
17 D	47209	RING - center bearing	1
18 G	34882	PIN - cushion relief	1
19 D	38683	SPRING - cushion relief	1
20 D	38684	SPACER - cushion relief spring, if used	1
20 211-	14	BALL - cushion relief spring, if used, not shown	1
21 G	34885	BOLT - piston and cushion relief	1
22 G	32351	WASHER - bolt	1
23 219-	1	FITTING - grease, straight, 1/8" NPT	1
*G	34594	SEAL KIT - cylinder repair, includes all items with an asterisk ..	1
**G	100778	SEAL - piston rod, service option - extreme heat or cold	1

NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.

SEE PAGE 355 FOR SWING CYLINDER RELIEF VALVE




**G102214 BACKHOE SWING CYLINDER
WITH ONE PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 102214	CYLINDER ASSEMBLY - swing, 4" (101 mm) I.D. x 11-1/4" (285 mm) stroke	1
2	G 34877	TUBE ASSEMBLY - cylinder	1
3	G 34875	BUSHING - tube	2
	G 34331	GLAND ASSEMBLY - cylinder	1
4	NSS	GLAND - cylinder	1
5	NSS	RING - retaining	1
6 *D	95144	WIPER - piston rod	1
7 *G	34322	BEARING - center	1
8 *D	36971	SEAL - piston rod	1
9 *A	27507	O-RING - gland	1
10 *G	32176	RING - backup	1
11 187-	1031	SCREW - self tapping, #8 - 32 NC x 1/4"	1
12 G	34775	ROD ASSEMBLY - piston, 2" (51 mm) O.D.....	1
13 G	34854	BUSHING - piston rod	2
14 G	101309	PISTON - cylinder	1
15 *G	102285	SEAL - piston	1
16 *G	100440	RING - backup	1
17 *G	100448	RING - wear	2
18 G	102245	PIN - cushion relief	1
19 D	38683	SPRING - cushion relief	1
20 211-	14	BALL - cushion relief spring	1
21 G	34885	BOLT - piston and cushion relief	1
22 G	32351	WASHER - hardened	1
23 219-	1	FITTING - grease, straight, 1/8" NPT	1
*G	102401	KIT - seal, includes all items with an asterisk	1
**G	100778	SEAL - piston rod, service option - extreme heat or cold	1

NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.

SEE PAGE 355 FOR SWING CYLINDER RELIEF VALVE




741987

**D47557 RELIEF VALVE
USED BEFORE SN 9124799**

REF.	PART NO.	DESCRIPTION	REQ'D.
	D 47557	VALVE ASSEMBLY - relief, for service order L78723	1
1	D 47667	BODY - relief valve	1
2	218- 5007	O-RING - body	1
3	D 26265	O-RING - body	1
4	D 37071	RING - O-ring back-up	1
5	D 37151	PLUNGER - relief valve	1
6	D 37075	SEAT - plunger	1
7	D 37148	SPRING - plunger	1
8	D 37150	GUIDE - plunger spring	1
9	T 41959	O-RING - spring guide	1
10	D 37147	RING - O-ring back-up	1
11	D 40355	SHIM - spring guide, .005" (0.127 mm)	UAR
11	16917	SHIM - spring guide, .010" (0.254 mm)	UAR
12	D 40354	PLUG - relief valve	1
13	218- 5006	O-RING - plug	1

**L78723 RELIEF VALVE
USED ON SN. 9124799 AND AFTER**


REF.	PART NO.	DESCRIPTION	REQ'D.
	L 78723	VALVE ASSEMBLY - relief	1
1	D 47667	BODY - relief valve	1
2	218- 5007	O-RING - body	1
3	D 26265	O-RING - body	1
4	D 37071	RING - O-ring back-up	1
5	D 37054	PLUNGER - relief valve	1
6	D 37075	SEAT - plunger	1
7	D 37148	SPRING - plunger	1
8	D 37073	GUIDE - plunger spring	1
9	D 40356	O-RING - spring guide	1
10	D 40357	RING - O-ring back-up	1
11	R 33411	SHIM - spring guide	UAR
12	218- 5210	PLUG - relief valve	1
13	218- 5006	O-RING - plug	1



**G34821 BACKHOE BOOM CYLINDER
WITH TWO PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 34821	CYLINDER - boom, 4" (102 mm) I.D. x 41-3/16" (1046 mm) stroke	1
2	G 34822	TUBE - cylinder	1
3	D 32865	BUSHING - tube	2
4		RESERVED	
	G 34635	GLAND ASSEMBLY - cylinder	1
5	NSS	GLAND - cylinder	1
6	NSS	RING - retaining	1
7	*D 95145	WIPER - piston rod	1
8	*G 34620	BEARING - center	1
9	*D 39359**	SEAL - piston rod	1
10	*A 27507	O-RING - gland	1
11	*G 32176	RING - backup	1
12	187- 1031	SCREW - #8 - 32 NC x 1/4", self tapping	1
13	G 34848	ROD - piston, 2-1/4" (57 mm) O.D.	1
14	D 33024	BUSHING - piston rod	2
15	D 49168	PISTON - split, rod end	1
16	D 46930	PISTON - split, bolt end	1
	*G 33239	PACKING - piston	1
17	NSS	PACKING - "V" type	2
18	NSS	RING - center bearing	1
19	28- 2044	HHCS - piston, 1-1/4" - 12 NF x 2-3/4", grade 8	1
20	G 32351	WASHER - piston bolt	1
21	219- 1	FITTING - grease, straight, 1/8" NPT	1
	*G 34827	SEAL KIT - cylinder repair, includes all items with an asterisk	1
	**G 100779	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G101256 BACKHOE BOOM CYLINDER
WITH ONE PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 101256	CYLINDER ASSEMBLY - boom, 4" (102 mm) I.D. x 41-3/16" (1046 mm) stroke	1
2	G 101686	TUBE ASSEMBLY - cylinder	1
3	D 32865	BUSHING - tube	2
4		RESERVED	
	G 34635	GLAND ASSEMBLY - cylinder	1
5	NSS	GLAND - cylinder	1
6	NSS	RING - retaining	1
7	*D 95145	WIPER - piston rod	1
8	*G 34620	BEARING - center	1
9	*G 39359**	SEAL - piston rod	1
10	*A 27507	O-RING - gland	1
11	*G 32176	RING - backup	1
12	187- 1031	SCREW - self tapping, #8 - 32 NC x 1/4"	1
13	G 34848	ROD ASSEMBLY - piston, 2-1/4" (57 mm) O.D.	1
14	D 33024	BUSHING - piston rod	1
15	G 100686	PISTON - cylinder	1
16	*G 102285	SEAL - piston	1
17	*G 100440	RING - backup	1
18	*G 100448	RING - wear	2
19	28- 2044	HHCS - 1-1/4" - 12 NF x 2-3/4", grade 8	1
20	G 32351	WASHER - piston bolt	1
21	219- 1	FITTING - grease, straight, 1/8" NPT	1
	*G 102412	KIT - seal, includes all items with an asterisk	1
	**G 100779	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G34323 AND G100004 DIPPER CYLINDER
WITH TWO PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1 G	34323	CYLINDER - dipper, 4-1/2" (114 mm) I.D. x 40-1/8" (1019 mm) stroke	1
1 G	100004	CYLINDER - dipper, 4-1/2" (114 mm) I.D. x 40-1/8" (1019 mm) stroke	1
2 G	34256	TUBE - cylinder, G34323 cylinder only	1
3 G	100005	TUBE - cylinder, G100004 cylinder only	1
4 D	38943	BUSHING - tube	2
	G 34329	GLAND ASSEMBLY - cylinder	1
5	NSS	GLAND - cylinder	1
6	NSS	RING - retaining	1
7 *D	95146	WIPER - piston rod	1
8 *G	34307	BEARING - center	1
9 *D	45571**	SEAL - piston rod	1
10 *A	23316	O-RING - gland	1
11 *G	32284	RING - backup	1
12 187-	1031	SCREW - #8 - 32 NC x 1/4", self tapping	1
13 G	34324	ROD ASSEMBLY - piston, 2-1/2" (63 mm) O.D.	1
14 D	38943	BUSHING - piston rod	2
15 D	49163	PISTON - split, rod end	1
16 D	46931	PISTON - split, blot end	1
17 *D	47205	PACKING - piston, "V" type	2
18 D	47210	RING - center bearing	1
19 28-	2052	HHCS - piston, 1-1/4" - 12 NF x 3-1/4", grade 8	1
20 G	32351	WASHER - piston bolt	1
21 219-	1	FITTING - grease, straight, 1/8" NPT	1-2
22 219-	55	FITTING - grease, 90°, 1/8" NPT, if used	1
*G	34333	SEAL KIT - cylinder repair, includes all items with an asterisk ..	1
**G	100780	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G101348 BACKHOE DIPPER CYLINDER
WITH TWO PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1 G	101348	CYLINDER ASSEMBLY - dipper, 4-1/2" (114 mm) I.D. x 40-1/8" (1019 mm) stroke.....	1
2 G	101688	TUBE ASSEMBLY - cylinder	1
3 D	38943	BUSHING - tube	2
4 G	34329	RESERVED	
5 NSS		GLAND ASSEMBLY - cylinder	1
6 NSS		GLAND - cylinder	1
7 *D	95146	RING - retaining	1
8 *G	34307	WIPER - piston rod	1
9 *D	45571**	BEARING - center	1
10 *A	23316	SEAL - piston rod	1
11 *G	32284	O-RING - gland	1
12 187-	1031	RING - backup	1
13 G	34324	SCREW - self tapping, #8 - 32 NC x 1/4"	1
14 D	38943	ROD ASSEMBLY - piston, 2-1/2" (63 mm) O.D.	1
15 D	49163	BUSHING - piston rod	2
16 D	46931	PISTON - split, rod end	1
17 *D	47205	PISTON - split, bolt end	1
18 D	47210	PACKING ASSEMBLY - piston, "V" type	2
19 28-	2052	RING - center bearing	1
20 G	32351	HHCS - piston, 1-1/4" - 12 NF x 3-1/4", grade 8	1
21 219-	1	WASHER - hardened	1
		FITTING - grease, straight, 1/8" NPT	2
*G	34333	KIT - seal, cylinder repair, includes all items with an asterisk	1
**G	100780	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G34662 BACKHOE BUCKET CYLINDER
WITH TWO PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1 G	34662	CYLINDER - bucket, 4" (102 mm) I.D. x 27-1/4" (692 mm) stroke	1
2 G	34710	TUBE - cylinder	1
3 D	33047	BUSHING - tube	2
4 G	34635	RESERVED GLAND ASSEMBLY - cylinder	1
5 NSS		GLAND - cylinder	1
6 NSS		RING - retaining	1
7 *D	95145	WIPER - piston rod	1
8 *G	34620	BEARING - center	1
9 *D	39359**	SEAL - piston rod	1
10 *A	27507	O-RING - gland	1
11 *G	32176	RING - backup	1
12 187-	1031	SCREW - #8 - 32 NC x 1/4", self tapping	1
13 G	34714	ROD ASSEMBLY - piston, 2-1/4" (57 mm) O.D.	1
14 D	34340	BUSHING - piston rod	2
15 D	49168	PISTON - split, rod end	1
16 D	46930	PISTON - split, bolt end	1
17 *D	47204	PACKING - piston, "V" type	2
18 D	47209	RING - center bearing	1
19 28-	2040	HHCS - piston, 1-1/4" - 12 NF x 2-1/2", grade 8	1
20 G	32351	WASHER - piston bolt	1
21 219-	1	FITTING - grease, straight, 1/8" NPT	2
*G	34636	SEAL KIT - cylinder repair, includes all items with an asterisk ..	1
**G	100779	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G101254 BACKHOE BUCKET CYLINDER
WITH ONE PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 101254	CYLINDER ASSEMBLY - bucket, 4" (102 mm) I.D. x 27-1/4" (692 mm) stroke	1
2	G 101684	TUBE ASSEMBLY- cylinder	1
3	D 33047	BUSHING - tube	2
4		RESERVED	
	G 34635	GLAND ASSEMBLY - cylinder	1
5	NSS	GLAND - cylinder	1
6	NSS	RING - retaining	1
7	*D 95145	WIPER - piston rod	1
8	*G 34620	BEARING - center	1
9	*D 39359**	SEAL - piston rod	1
10	*A 27507	O-RING - gland	1
11	*G 32176	RING - backup	1
12	187- 1031	SCREW - self tapping, #8 - 32 NC x 1/4"	1
13	G 34714	ROD ASSEMBLY - piston, 2-1/4" (57 mm) O.D.	1
14	D 34340	BUSHING - piston rod	2
15	G 100686	PISTON - cylinder	1
16	*G 102285	SEAL - piston	1
17	*G 100440	RING - backup	1
18	*G 100448	RING - wear	1
19	28- 2040	HHCS - 1-1/4" - 12 NF x 2-1/2", grade 8	1
20	G 32351	WASHER - hardened	1
21	219- 1	FITTING - grease, straight, 1/8" NPT	2
	*G 102412	KIT - seal, includes all items with an asterisk	1
	**G 100779	SEAL - piston rod, service option - extreme heat or cold	1

NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.




741983 B

**G34426 BACKHOE DIPPER EXTENSION CYLINDER
WITH TWO PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 34426	CYLINDER ASSEMBLY - dipper extension, 3" (76 mm) x 48" (1219 mm) stroke	1
2	G 34427	TUBE - cylinder	1
3	G 34328	RESERVED	
4	NSS	GLAND ASSEMBLY - cylinder	1
5	NSS	GLAND - cylinder	1
6	*D 95142	RING - retaining	1
7	*G 34302	WIPER - piston rod	1
8	*D 36969**	BEARING - center	1
9	*A 30095	SEAL - piston rod	1
10	*G 32122	O-RING - gland	1
11	187- 1031	RING - backup	1
12	G 34432	SCREW - #8 - 32 NC x 1/4", self tapping	1
13	G 33150	ROD - piston, 1-1/2" (38 mm) O.D.....	1
14	D 28366	PISTON - split, rod end	1
	*G 33151	PISTON - split, bolt end	1
15	NSS	PACKING - piston	1
16	NSS	PACKING - "V" type	2
17	28- 1240	RING - center bearing	1
18	G 32317	HHCS - piston, 3/4" - 16 NF x 2-1/2", grade 8	1
	*G 34332	WASHER - hardened	1
	**G 100778	SEAL KIT - cylinder repair, includes all items with an asterisk	1
		SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



**G101259 BACKHOE DIPPER EXTENSION CYLINDER
WITH ONE PIECE PISTON**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	G 101259	CYLINDER ASSEMBLY - dipper extension, 3" (76 mm) x 48" (1219 mm) stroke	1
2	G 34427	TUBE ASSEMBLY - cylinder	1
3		RESERVED	
	G 34328	GLAND ASSEMBLY - cylinder	1
4	NSS	GLAND - cylinder	1
5	NSS	RING - retaining	1
6	*D 95142	WIPER - piston rod	1
7	*G 34302	BEARING - center	1
8	*D 36969**	SEAL - piston rod	1
9	*A 30095	O-RING - gland	1
10	*G 32122	RING - backup	1
11	187- 1031	SCREW - self tapping, #8 - 32 NC x 1/4"	1
12	G 34432	ROD - piston, 1-1/2" (38 mm) O.D.	1
13	G 100442	PISTON - cylinder	1
14	*G 102288	SEAL - piston	1
15	*G 100444	RING - backup	1
16	*G 100449	RING - wear	2
17	28- 1240	HHCS - 3/4" - 16 NF x 2-1/2", grade 8	1
18	G 32317	WASHER - hardened	1
	*G 102404	KIT - seal, includes all items with an asterisk	1
	**G 100778	SEAL - piston rod, service option - extreme heat or cold	1


NOTE: Look for cylinder assembly part number to be stamped on cylinder gland or tube.



LOADER LIFT FRAME AND RELATED PARTS

REF.	PART NO.	DESCRIPTION	REQ'D.
	REF.		
1		CHASSIS ASSEMBLY - see page 423 for proper parts and bushings	1
2		RESERVED	
3 L	57111	FRAME ASSEMBLY - loader lift, used before tractor sn. 9114538, for service order L59852 frame and L59854 return-to-dig rod, see page 385	1
3 L	59852	FRAME ASSEMBLY - loader lift, tractor sn. 9114538 thru 9118631	1
3 L	71121	FRAME ASSEMBLY - loader lift, tractor sn. 9118631 thru 9124788 with dual bushings at chassis pivot pin	1
3 L	73721	FRAME ASSEMBLY - loader lift, tractor sn. 9118631 thru 9124788 with single bushings at chassis pivot pin	1
3 L	79371	FRAME ASSEMBLY - loader lift, used on tractor sn. 9124788 and after	1
4 D	33024	BUSHING - lift frame at chassis, models with dual bushings ..	4
4A L	79365	BUSHING - lift frame at chassis, models with single bushings ..	2
5 D	34354	BUSHING - lift frame at lift cylinders	2
6 D	30930	BUSHING - lift frame at bucket linkage	4
7 D	30929	BUSHING - lift frame at bucket cylinders	2
8 D	31142	BUSHING - lift frame at bucket	2
9 219-	1	FITTING - grease, straight, 1/8" NPT	4-6
10 L	57362	PIN - pivot, lift arm and lift cylinders to chassis	2
11 D	34668	WASHER - special	4
12 D	34664	RING - pin retaining	4
13	REF.	CYLINDER - R.H. lift, see page 337 or 339	1
14	REF.	CYLINDER - L.H. lift, see page 337 or 339	1
15 D	34658	PIN - mounting, lift cylinder to lift frame, see item 34	1-2
16 D	25280	RING - pin retaining	4
17 219-	1	FITTING - grease, straight, 1/8" NPT	2
18 L	55958	BELLCRANK ASSEMBLY - straight type, includes bushings ..	4
18A L	74595	BELLCRANK ASSEMBLY - offset type, includes bushings	4
19 D	31512	BUSHING - bellcrank at cylinder	1
20 L	57197	SPACER - bellcrank	2-4
20A L	74594	SPACER - used with offset bellcranks only	2
21 26-	12108	HHCS - 3/4" - 10 NC x 6-3/4", grade 8, if used	2-4
21A 164-	675	BOLT - button head, 3/4" - 10 NC x 6-3/4", grade 8, if used	2-4
21B 26-	1268	HHCS - 3/4" - 10 NC x 4-1/4", grade 8, used with offset bellcranks at bucket link	2
22 92-	12	WASHER - lock, 3/4"	4
23 129-	138	NUT - hex., 3/4" - 10 NC, grade 8, plated	4
24	REF.	CYLINDER - bucket tilt, see page 341 or 343	2
25 D	34656	PIN - bucket cylinder to lift frame	2
26 D	25279	RING - pin retaining	4

Continued on next page




MODEL 680E CONSTRUCTION KING LOADER BACKHOE 375

LOADER LIFT FRAME AND RELATED PARTS

REF.	PART NO.	DESCRIPTION	REQ'D.
27	L 55962	LINK ASSEMBLY - bucket, used with straight bellcranks	2
28	D 31142	BUSHING - link, at bucket	1
29	D 32919	BUSHING - link, at bellcrank	2
29A	L 78551	LINK ASSEMBLY - bucket, used with offset bellcranks	2
29B	D 31142	BUSHING - link, at bucket	1
29C	D 30930	BUSHING - link, at bellcrank	2
30	L 55737	PIN - bucket link and lift arm to bucket	4
31	195- 2155	WASHER - flat	8
32	D 26919	RING - pin retaining	8
33	219- 1	FITTING - grease, straight, 1/8" NPT	8

SPECIAL PARTS USED WITH SAFETY STRUT


34	L 78791	PIN - L.H. lift cylinder mounting	1
35	195- 2151	WASHER - flat	4
36	L 78530	STRUT - safety	1
37	D 42106	GROMMET - rubber	1
38	L 78801	PIN - hitch	1



740077

LOADER BUCKETS

REF.	PART NO.	DESCRIPTION	REQ'D.
1-1/4 CU. YD. (1.0 CU. METRE) LOADER BUCKET			
L	74889	BUCKET ASSEMBLY - 86" (2184 mm) wide, machinery item, see page 2 for ordering	1
1	NSS	BUCKET - loader	1
2	L 58159	EDGE - cutting	1
3	D 31142	BUSHING - bucket	8
1-1/2 CU. YD. (1.2 METRE) LOADER BUCKET			
L	76924	BUCKET ASSEMBLY - 96" (2438 mm) wide, machinery item see page 2 for ordering	1
1	NSS	BUCKET - loader	1
2	L 58427	EDGE - cutting	1
3	D 31142	BUSHING - bucket ear	8
1-3/4 CU. YD. (1.3 CU. METRE) LOADER BUCKET			
L	76487	BUCKET ASSEMBLY - 96" (2438 mm) wide, machinery item, see page 2 for ordering	1
4	NSS	BUCKET - loader	1
5	L 58427	EDGE - cutting	1
6	D 31142	BUSHING - bucket ear	8
BUCKET TEETH — OPTIONAL ON L74889 BUCKET			
D	50780	TOOTH ASSEMBLY - bucket	8
7	NSS	SHANK - tooth	1
8	D 51750	POINT - tooth	1
9	D 39094	FLEX PIN - point	1
10	26- 1036	HHCS - 5/8" - 11 NC x 2-1/4", grade 8	8
11	26- 1040	HHCS - 5/8" - 11 NC x 2-1/2", grade 8	8
12	129- 563	NUT - hex., 5/8" - 11 NC	16




4-IN-1 BUCKET

REF.	PART NO.	DESCRIPTION	REQ'D
	L 76489	BUCKET ASSEMBLY - without teeth, machinery item, see page 2 for ordering	1
1	L 76490	BLADE ASSEMBLY - bucket	1
2	D NSS	BLADE - bucket	1
2	D 95182	EDGE - blade cutting	1
3	D 46917	PIN - blade to clam	2
4	219- 1	FITTING - grease, straight, 1/8" NPT	6
5	D 46973	PIN - clevis	2
6	132- 48	PIN - cotter, 1/8" x 1"	2
7	D 46913	BLOCK - stop	2
	D 49616	CLAM ASSEMBLY - bucket	1
8	NSS	CLAM - bucket	1
9	D 49617	EDGE - cutting	1
10	D 49618	PLATE - wear	1
11	D 46914	HOOK - grab	2
12	D 31140	BUSHING - hinge	6
13	D 39311	PIN - upper, cylinder to clam	2
14	13- 668	HHCS - 3/8" - 16 NC x 4-1/4"	2
15	131- 471	NUT - hex, lock, 3/8" - 16 NC	2
16	D 39306	PIN - lower, cylinder to blade	2
17	13- 644	HHCS - 3/8" - 16 NC x 2-3/4"	2
18	131- 471	NUT - hex, lock, 3/8" - 16 NC	2
19	REF.	CYLINDER - clam, R.H., see page 345 and 347	1
20	REF.	CYLINDER - clam, L.H., see pages 345 and 347	1
21	218- 5107	FITTING - 90°	2
22	218- 5007	O-RING - fitting	1
23	D 46957	TUBE - closed end cylinder, R.H.	1
24	D 46955	TUBE - closed end cylinder, L.H.	1
25	214- 267	CLAMP - tube	2
26		RESERVED	
27	218- 5137	FITTING - 45°	2
28	218- 5007	O-RING - fitting	1
29	36547	HOSE - tube to cylinder, 19" (482 mm) long	4
30	L 53589	TUBE - tee to cylinder, 15-1/2" (394 mm) long	2
31	L 53591	TUBE - tee to cylinder, 35-1/2" (902 mm) long	2
32	218- 595	FITTING - swivel tee	2
33	13- 624	HHCS - 3/8" - 16 NC x 1-1/2"	3
34	92- 6	WASHER - lock, 3/8"	3
35	D 40236	CLAMP - tube	3
36	L 58345	BRACKET - decal mounting, used before sn. 9124776	1
36	L 79128	BRACKET - decal mounting, used on sn. 9124776 and after	1
37	321- 2654	DECAL - bucket position	1
38	L 58348	PLATE - gauge indicator, used before sn. 9124776	1
38	L 79069	PLATE - gauge indicator, used on sn. 9124776 and after	1
39	L 53855	PIN - mounting, bucket	4
40	R 17756	ROD - retaining, mounting pin	4
41	13- 828	HHCS - 1/2" - 13 NC x 2-1/4"	4
42	131- 10	NUT - hex, 1/2" - 13 NC	4


OPTIONAL BUCKET TEETH

43	D 46885	TOOTH - bucket	7
44	13- 832	HHCS - 1/2" - 13 NC x 2"	7
45	13- 836	HHCS - 1/2" - 13 NC x 2-1/4"	7
46	25- 108	NUT - hex, 1/2" - 13 NC	14



**LOADER CONTROLS
2 SPOOL VALVE AND LEVERS**


REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 54563	KNOB - control lever	2
2	L 72110	LEVER - lift control	1
3	L 72111	LEVER - bucket control	1
4	219- 92	FITTING - grease, 90°, 1/8" NPT, self tapping	2
5	13- 864	HHCS - 1/2" - 13 NC x 4"	1
6	195- 2054	WASHER - flat, 1/2"	1
7	L 73453	SLEEVE - pivot, loader control levers	1
8	95- 8	WASHER - flat, 1/2"	1
8A	92- 8	WASHER - lock, 1/2"	1
8B	25- 108	NUT - hex., 1/2" - 13 NC	1
9	L 73018	ROD - lift lever to valve	1
10	L 57287	ROD - bracket control lever to valve	1
11	213- 3	YOKER - rod end, 5/16"	2
12	25- 155	NUT - hex., lock, 5/16" - 24 NF	2
13	141- 3	PIN - clevis, 5/16"	4
14	132- 25	PIN - cotter, 3/32" x 5/8"	4
15	L 53636	PLATE - anti-roll back to bucket control rod	1
16	REF.	VALVE - loader control, 2 spool, see pages 299 and 301	1
17	13- 672	HHCS - 3/8" - 16 NC x 4-1/2"	3
18	95- 6	WASHER - flat, 3/8"	3
19	92- 6	WASHER - lock, 3/8"	3
20	25- 106	NUT - hex., 3/8" - 16 NC	3
21	195- 2191	WASHER - spacer	UAR



740085 B


**LOADER CONTROLS
3 SPOOL VALVE AND LEVERS**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 54563	KNOB - control lever	3
2	L 72110	LEVER - lift control	1
3	L 72111	LEVER - bucket control.....	1
4	L 72109	LEVER - clam control.....	1
5	219- 92	FITTING - grease, 90°, 1/8" NPT, self tapping	3
6	13- 888	HHCS - 1/2" - 13 NC x 5-1/2"	1
7	195- 2054	WASHER - flat, 1/2"	1
8	L 73456	PIN - mounting, loader control levers	1
9	95- 8	WASHER - flat, 1/2"	1
9A	92- 8	WASHER - lock, 1/2"	1
9B	25- 108	NUT - hex., 1/2" - 13 NC	1
10	L 73018	ROD - lift lever to valve	1
11	L 57287	ROD - bucket control lever to valve	1
12	L 77390	ROD - clam control lever to valve	1
13	213- 3	YOKES - rod end, 5/16"	3
14	25- 155	NUT - hex., lock, 5/16" - 24 NF	3
15	141- 3	PIN - clevis, 5/16"	6
16	132- 25	PIN - cotter, 3/32" x 5/8"	6
17	L 53636	PLATE - anti-roll back to bucket control rod	1
18	REF.	VALVE - loader control, 3 spool, see pages 299 and 301	1
19	13- 672	HHCS - 3/8" - 16 NC x 4-1/2"	3
20	95- 6	WASHER - flat, 3/8"	3
21	92- 6	WASHER - lock, 3/8"	3
22	25- 106	NUT - hex., 3/8" - 16 NC	3
23	195- 2191	WASHER - spacer	UAR




**LOADER CONTROL
RETURN-TO-DIG PARTS
USED ON MODELS BEFORE TRACTOR SN 9118631**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 58334	HARNESS - front wiring	1
2	L 11541	STRAP - harness tie	5
3	13- 836	HHCS - 1/2" - 13 NC x 2-1/4"	1
4	95- 8	WASHER - flat, 1/2"	3
5	L 57298	BUSHING - return-to-dig rod	1
6	L 58983	ROD - return-to-dig, before tractor sn. 9114538, 59-1/2" (1511 mm) overall	1
6A	L 59854	ROD - return-to-dig, tractor sn. 9114538 and after, 57-1/2" (1460 mm) overall, not shown	1
7	92- 8	WASHER - lock, 1/2"	1
8	25- 108	NUT - hex., 1/2" - 13 NC	1
9	182- 208	SCREW - machine, pan head, 1/4" - 20 NC x 1-1/4"	1
10	95- 4	WASHER - flat, 1/4"	2
11	92- 4	WASHER - lock, 1/4"	1
12	25- 104	NUT - hex., 1/4" - 20 NC	1
13	13- 612	HHCS - 3/8" - 16 NC x 3/4"	2
14	92- 6	WASHER - lock, 3/8"	2
15	95- 6	WASHER - flat, 3/8"	2
16	L 58984	COVER AND BRACKET - return-to-dig switch	1
17	13- 612	HHCS - 3/8" - 16 NC x 3/4"	1
18	95- 6	WASHER - flat, 3/8"	1
19	D 43839	CLAMP - harness to cover	1
20	92- 6	WASHER - lock, 3/8"	1
21	25- 106	NUT - hex., 3/8" - 16 NC	1
22	169- 143	SCREW - machine, round head, #6 - 32 NC x 1-1/2"	2
23	195- 507	WASHER - flat, #6	2
24	193- 4	WASHER - lock, #6	2
25	L 70276	SPACER - switch to cover	2
26	L 54683	SWITCH - limit, return-to-dig	1
27	L 52496	BLOCK - tapped (Switch adjustment)	1




**LOADER CONTROL
RETURN-TO-DIG PARTS
TRACTOR SN 9118631 AND AFTER**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 58334	HARNESS - front wiring	1
2	L 11541	STRAP - harness tie	6
3	L 71343	BOOT - switch, if used.....	1
4	13- 828	HHCS - 1/2" - 13 NC x 1-3/4"	1
5	195- 33	WASHER - flat, 1/2", if used	1
	L 71239	RETURN-TO-DIG ASSEMBLY - loader control	1
6	L 73773	EYE - rod	1
7	25- 148	NUT - hex., lock, 1/2" - 13 NC	1
8	L 73093	TUBE - outer	1
9	33261	GASKET - switch	1
10	L 71304	SWITCH - return-to-dig	1
11	A 11538	RING - retaining	1
12	L 72720	TUBE - inner slide.....	1
13	L 71557	SEAL - inner tube	1
14	L 72771	ROD - return-to-dig	1
15	13- 836	HHCS - 1/2" - 13 NC x 2-1/4"	1
16	95- 8	WASHER - flat, 1/2"	3
17	L 57298	BUSHING - pivot.....	1
18	92- 8	WASHER - lock, 1/2"	1
19	25- 108	NUT - hex., 1/2" - 13 NC	1



**LOADER CONTROL
ANTI-ROLLBACK PARTS**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 53636	PLATE - anti-rollback control, at valve control lever	1
2	114- 146	BOLT, control, anti-rollback, rear	1
3	25- 155	NUT - hex., lock, 5/16" - 24 NF	1
4	213- 3	YOKES - rod, 5/16"	1
5	141- 3	PIN - clevis, 5/16"	1
6	132- 25	PIN - cotter, 3/32" x 5/8"	1
7	L 57277	LINK - pivot, anti-rollback control, used with L57274 bellcrank, for service order L70413 link and L70414 bellcrank .1	
7	L 77524	LINK - pivot, anti-rollback control, used with L72910 bellcrank ..1	
8	75- 420	SCREW - round head, 1/4" x 1-1/4", used with L70413 link	1
8	182- 208	SCREW - pan head, 1/4" x 1-1/4", used with L57277 link	1
9	A 27001	KEY - parallel, 3/16" x 1-3/8"	1
10	L 57274	BELLCRANK - control, anti-rollback, used with L57277 link, for service order L70413 link and L72910 bellcrank	1
10A	L 72910	BELLCRANK - control, anti-rollback, used with L70413 link ..1	
11	195- 45	WASHER - flat, 3/4"	1
12	138- 138	PIN - roll, 1/4" x 1-1/2"	1
13	L 70193	TUBE - support, anti-rollback rod, Does not use grease fitting ..1	
13	L 73169	TUBE - support, anti-rollback rod, uses grease fitting	1
14	L 70180	ROD - control, anti-rollback, front	1
15	L 70294	SLEEVE - spring	1
16	T 51274	SPRING - anti-rollback control	1
17	195- 2122	WASHER - flat, 1-1/4"	5
18	138- 2039	PIN - roll, 1/4" x 2"	1
19	13- 836	HHCS - 1/2" - 13 NC x 2-1/4"	1
20	L 57298	BUSHING - pivot, control rod	1
21	95- 8	WASHER - flat, 1/2"	2
22	92- 8	WASHER - lock, 1/2"	1
23	25- 108	NUT - hex., 1/2" - 13 NC	1
24	219- 1	FITTING - grease, straight, 1/8" NPT	1




740094 A

BACKHOE CONTROLS WITH FOOT SWING

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 59515	CONSOLE - backhoe control	1
2	13- 820	HHCS - 1/2" - 13 NC x 1-1/4", console mounting	2
3	95- 8	WASHER - flat, 1/2"	2
4	92- 8	WASHER - lock, 1/2"	2
5	25- 108	NUT - hex., 1/2" - 13 NC	2
6	L 55451	COVER - backhoe console	1
7	13- 620	HHCS - 3/8" - 16 NC x 1-1/4", cover mounting	4
8	95- 6	WASHER - flat, 3/8"	4
9	92- 6	WASHER - lock, 3/8"	4
10	L 55445	SHAFT - control handle	1
11	L 55570	ROD END - control shaft retaining	1
12	13- 520	HHCS - 5/16" - 18 NC x 1-1/4"	1
13	92- 5	WASHER - lock, 5/16"	1
14	25- 105	NUT - hex., 5/16" - 18 NC	1
15	L 55460	BELLCRANK - foot swing	1
16	L 55461	HANDLE - stabilizer, L.H., before tractor sn. 9114317, when stock is exhausted, order L59694 and L59695	1
16	L 59694	HANDLE - stabilizer, L.H., tractor sn. 9114317 and after	1
17	L 55456	HANDLE - bucket	1
18	L 55457	HANDLE - dipper	1
19	L 55458	HANDLE - boom	1
20	L 55462	HANDLE - stabilizer, R.H., before tractor sn. 9114317, when stock is exhausted, order L59694 and L59695	1
20	L 59695	HANDLE - stabilizer, R.H., tractor sn. 9114317 and after	1
21	L 54563	KNOB - handle	5
22	L 55440	TUBE - spacer	1
23	219- 86	FITTING - grease, straight	1
24	219- 92	FITTING - grease, 90°	5
25	213- 4	CLEVIS - rod end, 3/8"	9
26	141- 4	PIN - clevis	8
27	132- 26	PIN - cotter, 3/32" x 3/4"	9
28	25- 156	NUT - lock, 3/8" - 24 NF	9
29	L 55454	ROD - swing control	1
30	L 55435	ROD - swing, L.H. foot control	1
31	L 55455	ROD - swing, R.H. foot control	1
32	L 55436	ROD - bucket, dipper and boom control	3
33	L 55466	ROD - stabilizer control	2
34	141- 3	PIN - clevis, 5/16"	6
35	132- 26	PIN - cotter, 3/32" x 3/4"	6


Continued on next page



740094 A

BACKHOE CONTROLS WITH FOOT SWING

REF.	PART NO.	DESCRIPTION	REQ'D.
36	L 55553	SHIELD - L.H. foot pedal, not used with cab	1
37	L 55554	SHIELD - R.H. foot pedal, not used with cab	1
38	13- 620	HHCS - 3/8" - 18 NC x 1-1/4", shield mounting	8
39	95- 6	WASHER - flat, 3/8"	8
40	92- 6	WASHER - lock, 3/8"	8
41	25- 106	NUT - hex. 3/8" - 18 NC	8
42	L 70129	LUG - shield and shaft retaining	2
43	L 71078	PEDAL - swing, R.H.	1
44	D 30706	BUSHING - swing pedal	2
45	L 71077	PEDAL - swing, L.H.	1
46	D 30706	BUSHING - swing pedal	2
47	L 70130	SHAFT - swing pedal mounting	1
48	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	2
49	95- 6	WASHER - flat, 3/8"	2
50	92- 6	WASHER - lock, 3/8"	2
51	25- 106	NUT - hex. 3/8" - 16 NC	2
52	L 59332	LEVER - boom lock release	1
53	138- 2033	PIN - roll, 1/4" x 1-3/8"	2
54	D 53273	WASHER - special hardened	1
55	F 41514	SPRING - boom lock	1
56	95- 10	WASHER - flat, 5/8"	1
57	L 52477	GRIP - handle, boom lock release	1




740950 A

BACKHOE CONTROLS WITH HAND SWING

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 54563	KNOB - control levers	4
2	L 58185	LEVER - backhoe control	2
3	25- 1510	NUT - hex., jam 5/8"	2
4	D 38303	BELLCRANK - dual lever control, R.H.	1
5	D 38302	BELLCRANK - dual lever control, L.H.	1
6	D 38299	PIVOT - dual lever control, uses cotter pin - item 10	2
6A	L 78119	PIVOT - dual lever control, uses retaining ring - item 10A	2
7	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	4
8	92- 6	WASHER - lock, 3/8"	4
9	25- 106	NUT - hex., 3/8" - 16 NC	4
10	132- 25	PIN - cotter, 3/32" x 5/8", used with item 6 only	2
10A	A 11538	RING - retainng, used with item 6A only	2
11	D 38305	BLOCK - wear, bellcrank	2
12	D 38298	RING - retaining	2
13	138- 96	PIN - roll, 3/16" x 1"	4
14	D 38297	BUSHING - self-aligning	2
15	92- 6	WASHER - lock, 3/8"	4
15A	25- 156	NUT - hex, lock, 3/8"	4
16	L 58163	CONSOLE - backhoe control	1
17	L 55451	COVER - backhoe console	1
18	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	6
19	95- 6	WASHER - flat, 3/8"	6
20	92- 6	WASHER - lock, 3/8"	6
20A	25- 106	NUT - hex., 3/8" - 16 NC	2
21	L 58125	LEVER - stabilizer, L.H.	1
22	L 58126	LEVER - stabilizer, R.H.	1
23	D 38296	BALL JOINT - dual lever control	4
24	25- 156	NUT - lock, 3/8"	5
25	L 58113	ROD - boom control	1
26	L 58110	ROD - swing control, upper	1
27	L 58116	ROD - bucket control, upper	1
27A	138- 53	PIN - roll, 1/8" dia. x 1/2", rod retaining	2
28	L 58108	ROD - dipper control, upper	1
29	213- 4	YOKE - clevis, 3/8"	8
30	141- 4	PIN - clevis	8
31	132- 26	PIN - cotter, 3/32" dia. x 3/4"	8
32	L 11182	YOKE - clevis, offset	1
33	L 55445	SHAFT - pivot, control	1
34	L 55570	RETAINER - pivot shaft	1
35	13- 516	HHCS - 5/16" - 18 NC x 1"	1
36	92- 5	WASHER - lock, 5/16"	1
37	25- 105	NUT - hex., 5/16" - 18 NC	1
38	L 58115	BELLCRANK - bucket control	1
39	195- 2091	WASHER - spacer, 7/8"	UAR
40	L 58114	BELLCRANK - dipper control	1



Continued on next page



740950 A

BACKHOE CONTROLS WITH HAND SWING


REF.	PART NO.	DESCRIPTION	REQ'D.
41	219- 86	FITTING - grease, 1/8" NPT, self-tapping	5
41A	219- 92	FITTING - grease, 90°	1
42	L 55445	SHAFT - control	1
43	L 55570	RETAINER - control shaft	1
44	13- 520	HHCS - 5/16" - 18 NC x 1-1/4"	1
45	92- 5	WASHER - lock, 5/16"	1
46	25- 105	NUT - hex., 5/16" - 18 NC	1
47	L 58120	BELLCRANK - swing control	1
48	195- 2091	WASHER - spacer, 7/8"	UAR
49	L 58124	BELLCRANK - boom control	1
50	L 58117	ROD - swing	1
51	L 58111	ROD - bucket and dipper control	2
52	L 58187	ROD - stabilizer control	2
53	L 58112	ROD - boom control	1
54	25- 156	NUT - hex., lock, 3/8" - 16 NC	8
55	L 58128	FOOT REST - R.H.	1
56	L 58127	FOOT REST - L.H.	1
57	13- 812	HHCS - 1/2" - 13 NC x 3/4"	4
58	92- 8	WASHER - lock, 1/2"	4
59	195- 2051	WASHER - flat, 1/2"	4
60	321- 2746	DECAL - dual lever control	1
61	214- 3	PIN - clevis, 5/16"	6
62	132- 26	PIN - cotter, 3/32" x 3/4"	6
63	L 59332	LEVER - boom lock release	1
64	138- 135	PIN - roll	2
65	D 53273	WASHER - special hardened	1
66	F 41514	SPRING - boom lock	1
67	95- 10	WASHER - flat, 5/8"	1
68	L 52477	GRIP - handle, boom lock release	1



740099


EXTENDABLE DIPPER CONTROL WITH FOOT SWING MODELS

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 54563	KNOB - control lever	1
2	L 59708	LEVER - control, extendahoe	1
3	219- 92	FITTING - grease, 90°, 1/8" NPT	1
4	L 55445	SHAFT - control lever	1
5	L 55570	ROD EYE - shaft retaining	1
6	13- 520	HHCS - 5/16" - 18 NC x 1-1/4"	1
7	92- 5	WASHER - lock, 5/16"	1
8	25- 105	NUT - hex., 5/16" - 18 NC	1
9	REF.	CONSOLE - backhoe control, see page 391	1
10	321- 2724	DECAL - extendahoe control	1
11	141- 4	PIN - clevis, 3/8"	1
12	132- 26	PIN - cotter, 3/32" x 3/4"	1
13	213- 4	CLEVIS - rod end, 3/8"	1
14	25- 156	NUT - hex., lock, 3/8" - 24 NF	1
15	L 55436	ROD - control, lever to valve	1
16	141- 3	PIN - clevis, 5/16"	1
17	132- 26	PIN - cotter, 3/32" x 3/4"	1
18	REF.	VALVE - backhoe and extendahoe control, see page 315	1




MODEL 680E CONSTRUCTION KING LOADER BACKHOE 401**EXTENDABLE DIPPER CONTROL WITH HAND SWING MODELS**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	REF.	CONSOLE - backhoe control, see page 395	1
2	L 58121	PEDAL - extendahoe control	1
3	13- 616	HHCS - 3/8" - 16 NC x 1"	4
4	92- 6	WASHER - lock, 3/8"	4
5	25- 106	NUT - hex., 3/8" - 16 NC	4
6	219- 86	FITTING - grease, 1/8" NPT, self-tapping	1
7	213- 4	YOKES - clevis, 3/8"	1
8	141- 4	PIN - clevis, 3/8"	1
9	132- 26	PIN - cotter, 3/32" x 3/4"	1
10	25- 156	NUT - hex., lock, 3/8" - 24 NF	1
11	L 58188	ROD - extendahoe control	1
13	132- 26	PIN - cotter, 3/32" x 3/4"	1
14	REF.	VALVE - backhoe and extendahoe control, see page 315	1
15	321- 2747	DECAL - extendahoe control	1



BACKHOE MONTING FRAME AND STABILIZERS

REF.	PART NO.	REF.	DESCRIPTION	REQ'D
1		REF.	FRAME ASSEMBLY - tractor and backhoe, see page 423	1
2	D	33024	BUSHING - stabilizer leg to frame	4
3	D	34340	BUSHING - stabilizer cylinder to frame	4
4	D	60159	BUSHING - swing cylinder	2
5	L	51427	LEG - stabilizer, used before tractor sn. 9122407, uses L70871, L58956 or L59831 foot	2
5	L	72990	LEG - stabilizer, used on tractor sn. 9122407 thru 9127845, uses L73675 or L73677 foot	2
5	L	78877	LEG - stabilizer, used on tractor sn. 9127845 and after, uses L73675 or L73677 foot	2
6	D	42911	PIN - stabilizer to chassis	2
7	195-	2155	WASHER - spacer	UAR
8	D	26919	RING - retaining	4
9	L	57696	FOOT - stabilizer, standard, uses D26001 pin, order L70871 foot and L71043 pin for service	2
9	L	70871	FOOT - stabilizer, standard, uses L71043 pin, used with L51427 leg before sn. 9122407	2
9	L	73675	FOOT - stabilizer, standard, uses L71043 pin, used with L72990 leg on sn. 9122407 and after	2
10	D	26001	PIN - stabilizer to pad, 8-1/16" (204 mm) long, if used	2
10	L	71043	PIN - stabilizer to pad, 8-5/16" (211 mm) long, if used	2
11	D	25279	RING - retaining	4
11A	195-	2142	WASHER - spacer	UAR
12		REF.	CYLINDER - stabilizer, see page 349	2
13	D	25079	PIN - stabilizer to chassis	2
14	195-	2152	WASHER - spacer	4
15	D	25280	RING - retaining	8
16	D	25079	PIN - stabilizer cylinder to stabilizer	2
17	L	54129	SHIM - spacer, swing tower and main frame	4
18	L	57106	PLATE - swing, cylinder mounting	1
19	13-	1644	BOLT - 1" - 8 NC x 2-3/4", swing plate to chassis	4
20	D	30196	WASHER - special hardened	4
21	L	54782	BLOCK - bolt retaining	2
22	219-	36	FITTING - grease	2
23		REF.	CYLINDER - swing, see page 351 or 353	2
24	L	58883	PIN - swing cylinder to tower	2
25	D	25280	RING - pin retaining	2
26	L	70598	PIN - swing lock	1
27	L	70149	PIN - retaining	1
28	L	58956	FOOT - cemetery and street, uses R31222 rubber pad, used with L51427 leg before sn. 9122407	2
28	L	59831	FOOT - cemetery and street, uses R31222 or D61368 rubber pad, used with D51427 leg before sn. 9122407	2
28	L	73677	FOOT - cemetery and street, uses D61368 rubber pad, used with L72990 leg on sn. 9122407 and after	2
29	R	31222	PAD - rubber, bolt on, used with L59856 foot	4
29A	D	61368	PAD - rubber, bolt on, used with L59831 or L73677 foot	2
30	D	29712	NUT - hex, self lock, 7/16" - 20 NF, if used	8
31		REF.	VALVE - backhoe control, see page 315	1
32	L	55306	SPACER - backhoe valve mounting	3
33	13-	848	HHCS - 1/2" - 13 NC x 3"	3
34	92-	8	WASHER - lock, 1/2"	3
35	25-	108	NUT - hex, 1/2" - 13 NC	3
36	13-	1028	HHCS - 5/8" - 11 NC x 1-3/4", if used	8
37	95-	10	WASHER - flat, 5/8", if used	16
38	25-	1010	NUT - hex, 5/8" - 11 NC, if used	8




TOWER, BOOM, DIPPER ARM AND BUCKET

REF.	PART NO.	DESCRIPTION	REQ'D
1	58218	TOWER - backhoe swing, used before tractor sn. 9122041	1
1	L 74619	TOWER - backhoe swing, used on tractor sn. 9122041 thru 9125069	1
1	L 79025	TOWER - backhoe, used on tractor sn. 9125069 and after	1
2	D 30929	BUSHING - tower, at boom cylinders	2
2A	L 78951	BUSHING - tower, at boom, if used, not shown	1
3	195- 2167	WASHER - spacer, 2-1/2" (63 mm)	UAR
4	L 78203	PIN - tower mounting, upper	1
5	L 59120	PIN - tower mounting, lower	1
6	25- 1528	NUT - hex, 1-3/4" - 12 NF, thin height, if used	1
6	131- 484	NUT - hex, self lock, 1-3/4" - 12 NF, thin height, can be used to replace plain nut, if used	1
7	L 47461	SHIM - pin mounting, lower pin	UAR
8	L 79228	SHIM - pin mounting, upper pin and boom pin	UAR
9	L 47700	WASHER - special, upper pin	1
10	L 16015	RING - upper pin retaining	1
11	L 59033	RING - lower pin retaining	1
12	L 59117	WASHER - special, hardened, 3/4"	1
13	219- 1	FITTING - grease, straight, 1/8" NPT	1
14	L 74618	PIN - boom to tower, used before tractor sn. 9125069	1
14A	L 79012	PIN - boom to tower, used on tractor sn. 9125069 and after	2
14B	219- 1	FITTING - grease, straight, 1/8" NPT	2
15	L 58656	SPACER - boom	1
16	D 41472	WASHER - flat, used as shim	UAR
17	F 40807	RING - pin retaining	1-2
18	L 72807	BOOM - backhoe, used before tractor sn. 9124704	1
18	L 77902	BOOM - backhoe, used on tractor sn. 9124704 and after	1
19	L 70791	BUSHING - boom ends	4
20	D 30756	BUSHING - at cylinder mounting, 2-1/2" (64 mm) O.D.	2-4
20A	L 77788	BUSHING - at boom cylinder mounting, 3" (76 mm) O.D., if used	2
21	L 54419	PIN - boom cylinder to boom	1
22	L 59196	RING - boom lock	1
23	D 42611	PIN - boom lock	1
24	D 25279	RING - pin retaining	2
25	A 11990	WASHER - special	2
26	219- 55	FITTING - grease, 90°	1
27	L 73300	STRAP - boom lock	1
28	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	2
29	95- 6	WASHER - flat, 3/8"	2
30	131- 6	NUT - hex, self lock, 3/8" - 16 NC	2
31	REF.	CYLINDER - boom, see page 357 or 359	2

Continued on next page


NOTE: For boom and swing tower used on extendahoe models, see pages 410-413.



TOWER, BOOM, DIPPER ARM AND BUCKET


REF.	PART NO.	DESCRIPTION	REQ'D
32	L 58075	PIN - boom cylinder to tower, used before tractor sn. 9124614	2
32A	D 40037	PIN - boom cylinder to tower, used on tractor sn. 9124614 and after	2
32B	95- 24	WASHER - spacer, outer, used with D4037 pin	UAR
32C	219- 1	FITTING - grease, straight, 1/8" NPT, D40037 pin, not shown	2
33	L 58072	GUIDE - hose, boom cylinder, if used	2
33A	L 79009	WASHER - shim, inner	UAR
34	D 25279	RING - pin retaining	4
35	195- 2155	WASHER - pin	2
36	D 26919	RING - retaining	2
37	L 58319	BLOCK - stop, used before sn. 9127880	1
37	L 79185	BLOCK - stop, used on sn. 9127880 and after	1
38	13- 624	HHCS - 3/8" - 16 NC x 1-1/2", stop block mounting, if used	1
38	13- 628	HHCS - 3/8" - 16 NC x 1-3/4", if used	1
39	95- 6	WASHER - flat, 3/8"	1
40	131- 94	NUT - hex, lock, 3/8" - 16 NC	1
41	REF.	CYLINDER - hydraulic, dipper, see page 361 or 363	1
42	L 54437	PIN - dipper cylinder to boom	1
43	L 11917	SPACER - dipper cylinder to boom, .07" (1.78 mm) thick	2
43A	L 47422	SPACER - dipper cylinder to boom, .25" (6.35 mm) thick	2
43B	L 47424	SPACER - dipper cylinder to boom, .18" (4.76 mm) thick	2
44	D 26919	RING - dipper cylinder pin retaining	2
45	219- 1	FITTING - grease, straight, 1/8" NPT	4
46	L 55909	DIPPER - backhoe	1
47	D 33024	BUSHING - dipper cylinder mounting	2
48	L 55734	BUSHING - dipper pivot	2
49	D 30933	BUSHING - dipper at bucket link	2
50	D 37443	BUSHING - dipper at bucket	2
51	L 73598	PIN - dipper cylinder to dipper	1
52	195- 2155	WASHER - dipper cylinder pin	2
53	D 26919	RING - pin retaining	2
54	L 54388	PIN - dipper to boom	1
55	L 58656	SPACER - boom end casting	1
56	D 41472	WASHER - flat, 3" (76 mm) O.D.	UAR
56A	L 79228	WASHER - flat, 6" (152 mm) O.D.	UAR
57	F 40807	RING - pin retaining	2
58	REF.	CYLINDER - hydraulic, bucket, see page 365 or 367	1
59	L 57029	PIN - bucket cylinder to dipper	1
60	R 17756	PIN - retaining	1
61	13- 820	HHCS - 1/2" - 13 NC x 1-1/4"	1
62	92- 8	WASHER - lock, 1/2"	1

Continued on next page



TOWER, BOOM, DIPPER ARM AND BUCKET


REF.	PART NO.	DESCRIPTION	REQ'D
63	D 37611	PIN - bucket cylinder to bucket link	1
64	195- 2152	WASHER - bucket cylinder pin	UAR
65	D 25280	RING - pin retaining	2
66	L 55934	LINK - bucket guide, L.H.	1
67	L 55933	LINK - bucket guide, R.H.	1
68	D 31140	BUSHING - link, for 1-1/2" (38 mm) pin dia.	1
69	L 58710	BUSHING - link, for 1-3/4" (44 mm) pin dia.	1
70	D 53812	PIN - guide link to dipper	1
71	L 79009	WASHER - flat, 1-1/2" (38 mm) I.D.	UAR
72	D 25279	RING - pin retaining	2
73	L 79166	PIN - bucket to dipper	1
74	195- 2152	WASHER - flat, 1-13/16" (46 mm) I.D.	UAR
75	D 25280	RING - pin retaining	2
76	219- 1	FITTING - grease	1
77	REF.	BUCKET - backhoe, see pages 415 thru 421 for proper bucket	1
78	L 55936	LINK - backhoe	2
79	D 37392	BUSHING - link, for 1-3/4" (44 mm) pin dia.	1
80	D 30933	BUSHING - link, for 1-1/2" (38 mm) pin dia.	1
81	L 78991	PIN - link to bucket	1
82	D 37450	SPACER - link to bucket	1
83	L 79009	WASHER - flat, L41109 pin	2
84	D 25279	RING - pin retaining	2
85	D 54136	FROST POINT - backhoe	1
86	D 37495	BUSHING - frost point	2
87	D 43416	POINT - tooth	1
88	D 43417	FLEX PIN - point	1
89	D 54218	PIN - bucket link to front point	1
90	195- 63	WASHER - used with D54218 pin only	2
91	D 25279	RING - pin retaining	2




EXTENDABLE DIPPER AND RELATED PARTS

REF.	PART NO.	DESCRIPTION	REQ'D
1	L 72808	BOOM - backhoe, extendahoe, used before tractor sn. 9124704	1
1	L 77934	BOOM - backhoe, extendahoe, used on tractor sn. 9124704 thru 9125069 ..	1
1	L 79142	BOOM - extendahoe, used on tractor sn. 9124704 and after	1
1A	L 70791	BUSHING - boom to tower and dipper	4
1B	D 30756	BUSHING - at cylinder mounting, 2-1/2" (64 mm) O.D.	2-4
1C	L 77788	BUSHING - at boom cylinder mounting, 3" (76 mm) O.D., if used	2
2	L 54358	EXTENSION - dipper arm, inner	1
3	D 31140	BUSHING - at bucket link	2
4	D 37495	BUSHING - at bucket	2
5	L 55647	ARM - dipper, models without end cover	1
5A	L 79318	ARM- dipper, models with end cover, see item 62	1
6	L 55734	BUSHING - at boom pivot	2
7	D 33024	BUSHING - at dipper pivot	2
8	L 57012	PLATE - wear	1
8A	L 78390	COVER - end, if used	1
8B	13- 824	HHCS - 1/2" - 13 NC x 1-1/2"	2
8C	95- 8	WASHER - flat, 1/2"	2
8D	92- 8	WASHER - lock, 1/2"	2
8E	25- 108	NUT - hex self lock, 1/2"	2
9	321- 2058	DECAL - "EXTENDAHOE"	2
10	321- 1572	DECAL - "CASE", 4" (102 mm) high	2
11	L 58656	SPACER - dipper to boom	1
12	L 54388	PIN - dipper to boom	1
13	D 41472	WASHER - flat, 2-1/4"	2
14	F 40807	RING - pin retaining	2
15	L 73598	PIN - dipper cylinder to dipper	1
16	195- 2155	WASHER - flat, 2-1/16"	2
17	D 26919	RING - pin retaining	2
18	L 54407	PIN - extension cylinder to dipper	1
19	L 79009	WASHER - flat, 1-1/2"	2
20	D 25279	RING - pin retaining	2
21	REF.	CYLINDER - dipper extension, see page 369 or 371	1
22	L 76923	GUIDE - bucket cylinder, used before sn. 9127939	1
22	L 100120	GUIDE - bucket cylinder, used on sn. 9127939 and after	1
23	L 54741	PLATE - wear, used before sn. 9127939	1
23	L 100121	PLATE - wear, used on sn. 9127939 and after	1
24	26- 620	HHCS - 3/8" - 16 NC x 1-1/4", grade 8, used with L76923 guide	4
24	26- 820	HHCS - 1/2" - 13 NC x 1-1/4", grade 8, used with L100120 guide	4
25	92- 6	WASHER - lock, 3/8", if used	4
25	92- 8	WASHER - lock, 1/2", if used	4
26	D 52275	WASHER - flat, 3/8", hardened, if used	UAR
26	R 24323	WASHER - flat, 1/2" hardened, if used	UAR
27	D 41740	SPACER - L54741 wear plate	UAR
27	D 64050	SPACER - L100121 wear plate	UAR
28	L 78977	ANGLE - bucket cylinder hose support	2
29	L 78976	BRACKET - hose support, replaces straight bar on some models	1
30		RESERVED	

Continued on next page






extendahoe



EXTENDABLE DIPPER AND RELATED PARTS

REF.	PART NO.	DESCRIPTION	REQ'D
31	13- 616	HHCS - 3/8" - 16 NC x 1"	2
32	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	4
33	95- 6	WASHER - flat, 3/8"	2
34	92- 6	WASHER - lock, 3/8"	4
35	25- 106	NUT - hex, 3/8" - 16 NC	4
35A	131- 652	NUT - hex, self lock, 3/8" - 16 NC	2
36	L 57029	PIN - bucket cylinder to bucket cylinder guide	1
37	R 17756	LOCK - pin retaining	1
38	13- 820	HHCS - 1/2" - 13 NC x 1-1/4"	1
39	92- 8	WASHER - lock, 1/2"	1
40	L 58783	PIN - dipper extension cylinder and bucket cylinder guide to dipper extension	1
41	L 55703	WASHER - special	2
41A	L 79009	WASHER - shim, hardened	UAR
42	T 37909	RING - pin retaining	2
43	L 57903	LINK ASSEMBLY - guide, L.H.	1
44	L 57904	LINK ASSEMBLY - guide, R.H.	1
45	D 31140	BUSHING - guide link, at bar end	1
46	D 40089	BUSHING - guide link, at boss, long	1
47	D 34354	BUSHING - guide link, at boss, short	1
48	L 74047	PIN - guide and dump link to bucket cylinder at rod end	1
48A	195- 2152	WASHER - flat, shim	UAR
49	L 50511	WASHER - special, 1-3/4"	2
50	D 25280	RING - pin retaining	2
51	L 55835	LINK ASSEMBLY - dump	2
52	D 30933	BUSHING - link, 1-1/2" (38 mm) I.D.	1
53	D 37392	BUSHING - link, 1-3/4" (44 mm) I.D.	1
54	REF.	CYLINDER - hydraulic, bucket, parts list page 365 or 367	1
55	219- 1	FITTING - grease, straight, 1/8" NPT	1
56	L 55723	SPACER - dump links	1
57	L 74720	TOWER - backhoe swing, used before sn. 9125069 for mounting and related parts, see page 405	1
57	L 79025	TOWER - backhoe, used on tractor sn. 9125069 and after, for mounting and related parts, see page 405	1
57A	L 59101	BRACKET - hose clamp, part of L74720 tower only	1
58	D 30929	BUSHING - tower, at boom cylinders	2
59	321- 3120	DECAL - tread	2
60	321- 3139	DECAL - extendahoe	2
61	321- 2427	DECAL - "CASE"	2
61	219- 107	FITTING - grease, special, use for lubrication of dipper arm (store in tool box)	1



BACKHOE BUCKETS

REF.	PART NO.	DESCRIPTION	REQ'D.
------	----------	-------------	--------


TRENCHING BUCKETS

1	D 52642	BUCKET - 12 inch (305 mm) Machinery item, see page 2 for ordering, not used with extendahoe	1
2	D 29424	BLADE - cutting, R.H. side	1
3	D 29423	BLADE - cutting, L.H. side	1
4	D 37464	BLADE - cutting, center	1
5	D 40243	BUSHING - bucket, at dipper arm	2
6	D 30933	BUSHING - bucket, bucket link pin hole	4
7	D 37473	BUCKET - 18 inch (457 mm) Machinery item, see page 2 for ordering	1
8	D 21606	BLADE - cutting, R.H. side	1
9	D 21605	BLADE - cutting, L.H. side	1
10	D 37642	BLADE - cutting, center	1
11	D 37495	BUSHING - bucket, at dipper arm	2
12	D 30933	BUSHING - bucket, upper and lower bucket link pin hole	4

BUCKET TEETH

13	D 26368	SHANK - tooth, original equipment	UAR
13A	D 58499	SHANK - tooth, service option	UAR
14	D 58576	POINT - tooth, H and L manufactured, 4-7/8" (124 mm) long .	UAR
14	D 58577	POINT - tooth, Fabco manufactured, 4-3/4" (121 mm) long .	UAR
15	D 58592	POINT - tooth, H and L manufactured, Heavy duty service option, 4-7/8" (124 mm) long	UAR
	D 58593	POINT - tooth, Fabco manufacturing, heavy duty service option, 4-7/8" (124 mm) long	UAR

NOTE: Additional buckets are listed on pages 417 thru 421.




BACKHOE BUCKETS

REF.	PART NO.	DESCRIPTION	REQ'D.
TRENCHING BUCKETS			
1 L	51104	BUCKET - 24 inch (610 mm) high capacity, machinery item, see page 2 for ordering	1
1 L	59873	BUCKET - 24 inch (610 mm) high capacity, machinery item, see page 2 for ordering	1
2 D	41675	BLADE - cutting, R.H. side of L51104 bucket	1
2 L	70084	BLADE - cutting, R.H. side of L59873 bucket	1
3 D	41674	BLADE - cutting, L.H. side of L51104 bucket	1
3 L	70083	BLADE - cutting, L.H. side of L59873 bucket	1
4 D	41673	BLADE - cutting, center	1
5 D	37495	BUSHING - bucket, at dipper arm	2
6 D	30933	BUSHING - bucket, bucket link pin hole	4
1 L	53132	BUCKET - 30 inch (762 mm) high capacity, machinery item, see page 2 for ordering	1
1 L	59585	BUCKET - 30 inch (762 mm) high capacity, machinery item, see page 2 for ordering	1
2 D	41675	BLADE - cutting, R.H. side of L53132 bucket	1
2 L	70084	BLADE - cutting, R.H. side of L59585 bucket	1
3 D	41674	BLADE - cutting, L.H. side of L53132 bucket	1
3 L	70083	BLADE - cutting, L.H. side of L59585 bucket	1
4 D	41870	BLADE - cutting, center	1
5 D	37495	BUSHING - bucket, at dipper arm	2
6 D	30933	BUSHING - bucket, bucket link pin hole	4
1 L	55629	BUCKET - 36 inch (914 mm) high capacity, machinery item, see page 2 for ordering	1
1 L	59893	BUCKET - 36 inch (914 mm) high capacity, machinery item, see page 2 for ordering	1
2 D	41675	BLADE - cutting, R.H. side of L55629 bucket	1
2 L	70084	BLADE - cutting, R.H. side of L59893 bucket	1
3 D	41674	BLADE - cutting, L.H. side of L55629 bucket	1
3 L	70083	BLADE - cutting, L.H. side of L59893 bucket	1
4 L	43412	BLADE - cutting, center	1
5 D	37495	BUSHING - bucket, at dipper arm	2
6 D	30933	BUSHING - bucket, bucket link pin hole	4

BUCKET TEETH — INCLUDED WITH BUCKET

L	43266	TOOTH ASSEMBLY - includes items 7, 8 and 9	UAR
7	NSS	SHANK - tooth	1
8 D	39093	POINT - tooth	1
8A D	51750	POINT - tooth, heavy duty service option, not shown	1
9 D	39094	FLEX PIN - point	1

NOTE: Additional buckets are listed on pages 415, 419 and 421.



BACKHOE BUCKETS

REF.	PART NO.	DESCRIPTION	REQ'D.
------	----------	-------------	--------

BELLHOLE BUCKETS

1 D	41547	BUCKET - 12 inch (305 mm) Machinery item, see page 2 for ordering, not used with extendahoe	1
2 D	37490	BLADE - cutting	1
3 D	40243	BUSHING - bucket, at dipper arm	2
4 D	30933	BUSHING - bucket, bucket link pin hole	2
1 D	41548	BUCKET - 16 inch (406 mm) Machinery item, see page 2 for ordering	1
2 D	37518	BLADE - cutting	1
3 D	37495	BUSHING - bucket, at dipper arm	2
4 D	30933	BUSHING - bucket, bucket link pin hole	2
1 D	41549	BUCKET - 30 inch (762 mm) Machinery item, see page 2 for ordering	1
2 D	37515	BLADE - cutting	1
3 D	37495	BUSHING - bucket, at dipper arm	2
4 D	30933	BUSHING - bucket, bucket link pin hole	2


COMBINATION BELLHOLE AND GRAVEYARD BUCKET

5 D	41550	BUCKET - 36 inch (914 mm) Machinery item, see page 2 for ordering	1
6 D	37516	BLADE - cutting	1
7 D	37495	BUSHING - bucket, at dipper arm	2
8 D	30933	BUSHING - bucket, bucket link pin hole	2

BUCKET TEETH


9 D	58499	SHANK - tooth, service option	UAR
9A D	26368	SHANK - tooth, original equipment	UAR
10 D	58576	POINT - tooth, H and L manufactured, 4-7/8" (124 mm) long	UAR
10 D	58577	POINT - tooth, Fabco manufactured, 4-3/4" (121 mm) long .	UAR
11 D	58592	POINT - tooth, H and L manufactured, heavy duty service option	UAR
11 D	58593	POINT - tooth, Fabco manufactured, heavy duty service option	UAR

NOTE: Additional buckets are listed on pages 415, 417 and 421.



BACKHOE BUCKETS


REF.	PART NO.	DESCRIPTION	REQ'D.
TRENCHING BUCKETS			
1 L	72900	BUCKET - 24 inch (610 mm) heavy duty, machinery item, see page 2 for ordering	1
2 L	72992	BLADE - cutting, R.H. side	1
3 L	72993	BLADE - cutting, L.H. side	1
L	72991	BLADE ASSEMBLY - center	1
4	NSS	BLADE - center	1
R	38572	TOOTH ASSEMBLY	5
5	NSS	POINT - tooth	1
6 R	35318	PIN - tooth	1
7 R	35319	LOCK - tooth	1
1 L	73212	BUCKET - 30 inch (762 mm) heavy duty, machinery item, see page 2 for ordering	1
2 L	72992	BLADE - cutting, R.H. side	1
3 L	72993	BLADE - cutting, L.H. side	1
L	73209	BLADE ASSEMBLY - center	1
4	NSS	BLADE - center	1
R	38572	TOOTH ASSEMBLY	6
5	NSS	POINT - tooth	1
6 R	35318	PIN - tooth	1
7 R	35319	LOCK - tooth	1



CHASSIS, FENDERS AND STEPS

REF.	PART NO.	DESCRIPTION	REQ'D.
1 L	55000	CHASSIS AND FRAME ASSEMBLY - tractor and backhoe, models with fuel filler in forward part of operator's compartment	1
1A L	59800	CHASSIS AND FRAME ASSEMBLY - tractor and backhoe, models with fuel filler in rear part of operator's compartment, used before tractor sn. 9122234	1
2 L	11494	BUSHING - front axle pivot	2
3 D	33659	BUSHING - loader lift frame pivot	4
4 D	43508	BUSHING - lift cylinder pivot	2
5 D	60159	BUSHING - swing cylinder pivot, lower	2
6 D	33024	BUSHING - stabilizer leg to frame	4
7 D	34340	BUSHING - stabilizer cylinder to frame	4
8 L	17421	BUSHING - pivot, anti-rollback	2
8A L	70379	BUSHING - upper, swing tower mounting	1
8B L	58870	BUSHING - lower, swing tower mounting	1
9 A	26009	CAP - filler, hydraulic tank	1
10 A	7552	O-RING - filler cap	1
10A 205-	61	PLUG - button, if used	1
11 113-	419	HHCS - 1/2" - 13 NC x 2-1/2", cover retaining	1
12 L	50741	BAR - cover holdown	1
13 L	55406	COVER - access, hydraulic filter	1
14 L	55410	O-RING - access cover	1
15 221-	35	PLUG - pipe, 3/4" NPT, tank drain	1
16 L	59846	FILTER - hydraulic tank, paper cartridge, order L72877	1
16A L	72877	FILTER - hydraulic tank, metal cartridge	1
17 L	59847	RELIEF VALVE - filter	1
18 L	52759	SPRING - retainer, filter	1
19 L	53208	GAUGE - hydraulic oil level	1
20 A	27410	SEAL - gauge	2
21 92-	8	WASHER - lock, 1/2"	2
22 131-	402	NUT - hex., self lock, 1/2"	2
22A D	75821	STUD - mounting	2
22B A	30825	O-RING - end plugs to body, not shown	2
22C D	75820	TUBE - sight, internal, not shown	1
22D D	75819	GASKET - internal, sight tube, not shown	2
23 L	54670	INSULATOR - heat, hydraulic tank, foam material	1
24 13-	832	HHCS - 1/2" - 13 NC x 2"	4
25 L	58575	STEP - operator assist	2
26 95-	8	WASHER - flat, 1/2"	8
27 92-	8	WASHER - lock, 1/2"	4
28 25-	108	NUT - hex., 1/2" - 13 NC	4


Continued on next page



CHASSIS, FENDERS AND STEPS


REF.	PART NO.	DESCRIPTION	REQ'D.
29	L 58516	BRACKET - fender mounting, used with L58550 fender.....	2
29	L 72166	BRACKET - fender mounting, used with L59933 fender.....	2
30	13- 624	HHCS - 3/8" - 16 NC x 1-1/2"	18
31	95- 6	WASHER - flat, 3/8"	30
32	195- 2042	WASHER - flat	6
33	25- 106	NUT - hex., 3/8" - 16 NC	18
34	L 72634	ANGLE - fender mounting, used on units without ROPS	2
35	13- 636	HHCS - 3/8" - 16 NC x 2-1/4"	2
36	95- 6	WASHER - flat, 3/8"	2
37	195- 28	WASHER - flat, special	2
38	25- 106	NUT - hex., 3/8" - 16 NC	2
39	13- 624	HHCS - 3/8" - 16 NC x 1-1/2"	4
40	95- 6	WASHER - flat, 3/8"	8
41	25- 106	NUT - hex., 3/8" - 16 NC	4
42	L 58550	FENDER - rear wheel, R.H. and L.H., models with fuel filler in forward part of operator's compartment	2
42	L 59933	FENDER - rear wheel, R.H. and L.H., models with fuel filler in rear part of operator's compartment, without grab handle	2
42	L 73371	FENDER - rear wheel, R.H. and L.H., models with fuel filler in rear part of operator's compartment, with grab handles	2
43	L 57897	PLATE - cover, instrument wiring, for models with heater, see pages 89-93	1
43A	353- 255	PLUG - button head, 3-1/2", if used	1
43B	353- 580	PLUG - button head, 1", if used	2
44	13- 616	HHCS - 3/8" - 16 NC x 1"	2
45	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	2
46	92- 6	WASHER - lock, 3/8"	4
47	95- 6	WASHER - flat, 3/8"	4
48	L 58657	PLATE - cover, instrument wiring, end	1
49	13- 612	HHCS - 3/8" - 16 NC x 3/4"	3
50	92- 6	WASHER - lock, 3/8"	3
51	95- 6	WASHER - flat, 3/8"	3
52	L 57910	BRACKET - light, rear	2
53	13- 820	HHCS - 1/2" - 13 NC x 1-1/4"	4
54	95- 8	WASHER - flat, 1/2"	4
55	92- 8	WASHER - lock, 1/2"	4
56	25- 108	NUT - hex., 1/2" - 13 NC	4
57	REF.	SHAFT - lift cylinder mounting, see page 373 for related parts	1
58	219- 87	FITTING - grease, 1/4" - 28 NF self tapping	1
59	L 73545	HANDLE - grab, mounted on fender	2
60	13- 616	HHCS - 3/8" - 16 NC x 1"	4
61	95- 6	WASHER - flat, 3/8"	4
62	92- 6	WASHER - lock, 3/8"	4
63	25- 106	NUT - hex., 3/8" - 16 NC	4
64	L 15043	MAGNET - hydraulic tank, not shown	1

Continued on next page




MODEL 680E CONSTRUCTION KING LOADER BACKHOE 427**CHASSIS, FENDERS AND STEPS**

REF.	PART NO.	DESCRIPTION	REQ'D.
USED WITH STANDARD BUCKET ONLY			
65	13-	12120	HHCS - 3/4" - 10 NC x 7-1/2"
66	95-	12	WASHER - flat, 3/4", upper
67	L	74558	COUNTERWEIGHT - front, 690 lbs. (313 kg)
68	195-	45	WASHER - flat, 3/4", lower
69	25-	1012	NUT - hex., 3/4" - 10 NC
USED WITH 4-IN-1 BUCKET ONLY			
70	L	59642	PLATE - pump guard
71	13-	1240	HHCS - 3/4" - 10 NC x 2-1/2"
72	95-	12	WASHER - flat, 3/4"
73	25-	1012	NUT - hex., 3/4" - 10 NC




HOOD AND ENGINE SIDE PANELS

REF.	PART NO.	DESCRIPTION	REQ'D.
1	13- 612	HHCS - 3/8" - 16 NC x 3/4", hood top	6
2	92- 6	WASHER - lock, 3/8"	6
3	95- 6	WASHER - flat, 3/8"	6
4	13- 620	HHCS - 3/8" - 16 NC x 1-1/4", hood rear	2
5	13- 620	HHCS - 3/8" - 16 NC x 1-1/4", hood side	4
6	A 29277	WASHER - flat, 3/8"	6
7	R 16171	WASHER - spring wave type	6
8	95- 10	WASHER - special	6
9	D 45998	SPACER - hood to chassis	6
10	13- 620	HHCS - 3/8" - 16 NC x 1-1/4", hood front	8
11	92- 6	WASHER - lock, 3/8"	8
12	95- 6	WASHER - flat, 3/8"	8
13	131- 1202	NUT - hex., lock, 3/8" - 16 NC	4
14	L 55833	HOOD - top, center of exhaust opening is 4-1/4" (108 mm) from front edge, if used	1
14	L 70214	HOOD - top, center of exhaust opening is 11-1/2" (292 mm) from front edge, if used	1
15	L 55831	HOOD - side, R.H., used with L55693 frame	1
15	L 71803	HOOD - side, R.H., used with L73982 frame	1
16	L 55829	HOOD - side, L.H., used with L55693 frame	1
16	L 71805	HOOD - side, L.H., used with L73982 frame	1
16A	L 70501	PLATE - air cleaner access, if used	1
16B	13- 612	HHCS - 3/8" - 16 NC x 3/4"	4
16C	92- 6	WASHER - lock, 3/8"	4
17	L 55785	PANEL - engine side, R.H.	1
18	L 55786	PANEL - engine side, L.H.	1
19	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	2
20	195- 104	WASHER - flat, 3/8"	2
21	129- 471	NUT - weld type, 3/8" - 16 NC	UAR
22	L 55693	FRAME - radiator and grille, one piece formed, order L73982 frame, L71803 hood side and L71805 hood side	1
23	L 73982	FRAME - radiator and grille, Three piece welded	1



RADIATOR FRAME AND GRILLE

REF.	PART NO.	DESCRIPTION	REQ'D.
1	13- 628	HHCS - 3/8" - 16 NC x 1-3/4"	4
2	92- 6	WASHER - lock, 3/8"	4
3	L 15301	CLAMP - grille retaining	4
4	T 34922	SPACER - grille to frame	4
5	L 55682	GRILLE - radiator frame	1
6	REF.	FRAME - radiator and grille, see page 429	1
7	13- 1232	HHCS - 3/4" - 10 NC x 2"	4
7A	164- 591	CAPSCREW - button head, hex socket	4
8	92- 12	WASHER - lock, 3/4"	8
9	25- 1012	NUT - hex., 3/4" - 10 NC	8
10	L 55697	COVER - radiator cap access	1
11	A 27100	SPRING - cover mounting	1
12	95- 6	WASHER - flat, 3/8"	1
13	132- 47	PIN - cotter, 1/8" x 7/8"	1
14	13- 512	HHCS - 5/16" - 18 NC x 3/4"	4
15	92- 5	WASHER - lock, 5/16"	4
15A	95- 5	WASHER - flat, 5/16"	6
16	L 55694	BAFFLE - radiator, upper	1
17	L 50641	STRAP - radiator mounting, upper	2
18	13- 624	HHCS - 3/8" - 16 NC x 1-1/2"	4
19	95- 6	WASHER - flat, 3/8"	4
20	92- 6	WASHER - lock, 3/8"	4
21	25- 106	NUT - hex., 3/8" - 16 NC	4
22	14- 512	HHCS - 5/16" - 24 NF x 1/2"	6
23	92- 5	WASHER - lock, 5/16"	6
24	L 55699	BRACKET - radiator mounting, L.H.	1
25	L 55700	BRACKET - radiator mounting, R.H.	1
26	L 46821	BUSHING - radiator mounting, lower	2
27	13- 840	HHCS - 1/2" - 13 NC x 2-1/2"	2
28	195- 2061	WASHER - flat, 1/2"	2
29	92- 8	WASHER - lock, 1/2"	2
30	25- 108	NUT - hex., 1/2" - 13 NC	2
31	13- 824	HHCS - 1/2" - 13 NC x 1-1/2"	4
32	92- 8	WASHER - lock, 1/2"	4
33	95- 8	WASHER - flat, 1/2"	4
34	L 55701	PLATE - guard, lower radiator	1




FUEL TANK, FLOOR PLATES AND SEAT

REF.	PART NO.	DESCRIPTION	REQ'D.
	L 57148	SEAT ASSEMBLY - operator's	1
1	D 56884	BACKREST - seat	1
2	D 56883	CUSHION - seat	1
3	D 56885	FRAME - seat, L.H.	1
4	D 56886	FRAME - seat, R.H.	1
5	D 59687	BRACKET - mounting, L.H.	1
6	D 59686	BRACKET - mounting, R.H.	1
7	A 64818	ADJUSTER - seat	2
8	L 35629	ADJUSTER - seat, L.H.	1
9	D 59695	ADJUSTER - seat, front	1
10	L 35492	ROD - connecting, seat adjusters	2
11	D 59689	SPACER - seat frame	4
12	113- 118	HHCS - 5/16" - 18 NC x 5/8", zinc plated	18
13	192- 20	WASHER - lock, 5/16", plated	10
14	195- 521	WASHER - flat, 5/16", plated	10
15	129- 102	NUT - hex., 5/16" - 18 NC, plated	10
15A	D 80346	GUARD - clothing protection, slide rail front, if used, not shown	2
16	L 55925	POST - seat, inner	1
17		RESERVED	
18	13- 620	HHCS - 3/8" - 16 NC x 1-1/4"	4
19	L 54713	CLAMP - seat post	2
20	95- 6	WASHER - flat, 3/8"	4
21	92- 6	WASHER - lock, 3/8"	4
22	25- 106	NUT - hex., 3/8" - 16 NC	4
23	D 60615	BELT ASSEMBLY - seat, 3" (76 mm) wide, if used	1
23	D 75428	BELT ASSEMBLY - seat, 2" (51 mm) wide, if used	1
24	113- 424	HHCS - 1/2" - 13 NC x 1", plated	2
25	192- 23	WASHER - lock, 1/2", plated	2
26	131- 654	NUT - hex., self lock, 1/2" - 13 NC	2
27	REF.	TANK ASSEMBLY - fuel, see page 423 for chassis and related parts	1
28	13- 616	HHCS - 3/8" - 16 NC x 1", tool box mounting	2
29	D 55624	BOX - tool	1
30	95- 6	WASHER - flat, 3/8"	2
31	92- 6	WASHER - lock, 3/8"	2
32	25- 106	NUT - hex., 3/8" - 16 NC	2

Continued on next page


434



740074 B

FUEL TANK, FLOOR PLATES AND SEAT


REF.	PART NO.	DESCRIPTION	REQ'D.
33	13- 624	HHCS - 3/8" - 16 NC x 1-1/2"	2
34	13- 612	HHCS - 3/8" - 16 NC x 3/4"	2
35	13- 632	HHCS - 3/8" - 16 NC x 2"	2
36	92- 6	WASHER - lock, 3/8"	6
37	95- 6	WASHER - flat, 3/8"	8
38	25- 106	NUT - hex., 3/8" - 16 NC	2
39	L 57005	PLATE - floor, front	1
40	L 55922	PLATE - floor, rear	1
41	L 54087	SEAL - transmission, shift lever	1
42	95- 8	WASHER - flat, 1/2", seal retainer	1
43	L 52474	COVER - access, snap-in plug	1
44	L 71570	FLOORMAT - front, not shown	1
45	L 72665	FLOORMAT - rear- not shown	1
46	L 71421	PAD - non-slip, R.H., models with front fuel filler tube	1
47	L 71262	PAD - non-slip, L.H.	1
48	L 71264	PAD - non-slip, center	1
49	L 71421	PAD - non-slip, R.H., models with rear fuel filler tube	1



750363

ROPS CANOPY


REF.	PART NO.	DESCRIPTION	REQ'D.
1 F	93538	CANOPY - ROPS, bent legs, machinery item, see page 2 for ordering	1
1A L	71080	CANOPY - ROPS, straight legs, machinery item, see page 2 for ordering	1
2 13-	2056	HHCS - 1-1/4" - 7 NC x 3-1/2", ROPS mounting.....	4
3 D	43536	WASHER - flat, 1-1/4", hardened	8
4 25-	1020	NUT - hex., 1-1/4" - 7 NC	4
5 13-	624	HHCS - 3/8" - 16 NC x 1-1/2", fender mounting	4
6 95-	6	WASHER - flat, 3/8"	8
7 25-	106	NUT - hex., 3/8" - 16 NC	4
8 L	72019	HEADLINER - canopy, used with F93538 canopy	1
9 L	79212	HEADLINER - canopy, used with L71080 canopy	1
10 345-	57	ADHESIVE - headliner, not shown	UAR



***OPERATOR'S CAB (CASE BUILT)
MOUNTING AND BACKHOE CLOSURE PARTS**

REF.	PART NO.	DESCRIPTION	REQ'D.
1 F	93569	FRAME - operator's cab	1
2 F	42911	PANEL - backhoe, R.H.	1
3 F	42912	PANEL - backhoe, L.H.	1
4 F	93554	PANEL - backhoe, upper	1
5 F	93555	PANEL - backhoe, lower	1
5A F	43282	SEAL - lower backhoe panel	1
6	REF.	SEAL - backhoe panels, 45.2" (1148 mm) Cut from F43117 bulk seal, see item 24	UAR
7	113- 118	HHCS - 5/16" - 18 NC x 5/8", plated.....	29
8	192- 20	WASHER - lock, 5/16", plated	29
9	195- 103	WASHER - flat, 5/16", plated	29
10	13- 2056	HHCS - 1-1/4" - 7 NC x 3-1/2", cab mounting	4
11	D 43536	WASHER - flat, heat treated, 1-1/4"	8
12	25- 1020	NUT - hex., 1-1/4"- 7 NC	4
13	F 93630	STEP - access, R.H.	1
14	F 93631	STEP - access, L.H.	1
15	113- 607	HHCS - 5/8" - 11 NC x 1-1/2", plated	4
16	192- 25	WASHER - lock, 5/8", plated	4
17	129- 107	NUT - hex., 5/8" - 11 NC, plated	4
18	113- 219	HHCS - 3/8" - 16 NC x 2", plated.....	4
19	195- 525	WASHER - flat, 3/8", plated	4
20	192- 21	WASHER - lock, 3/8", plated	4
21	129- 103	NUT - hex., 3/8" - 16 NC, plated	4
22	REF.	SEAL - cowl, 85" (2159 mm) Cut from F43094 bulk seal, see item 25	UAR
23 F	43283	SEAL - fender, 40.3" (1023 mm) long.....	2
24 F	43117	SEAL - bulk material, 100 ft. (30 metres) roll, not shown	UAR
25 F	43094	SEAL - bulk material, 100 ft. (30 metres) roll, not shown	UAR


***NOTE:** Case built cabs may be identified by the J I Case Company serial number plate located in the top L.H. corner of the cab. For replacement of complete cab, order Sims built cab, pages 451 and 453.



***OPERATOR'S CAB (SIMS BUILT)
MOUNTING PARTS**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	Mach. Item	CAB - operator's (Sims 1000-0405) see page 2 for ordering	1
2	13- 2056	HHCS - 1-1/4" - 7 NC x 3-1/2"	4
3	D 43536	WASHER - flat, 1-1/4", hardened	8
4	25- 1020	NUT - hex., 1-1/4" - 7 NC	4
5	L 71214	BRACKET - step	2
6	L 71215	STEP - access	4
7	L 71219	PLATE - step mounting	2
8	13- 824	HHCS - 1/2" - 13 NC x 1-1/2"	8
9	13- 820	HHCS - 1/2" - 13 NC x 1-1/4"	12
10	D 64050	WASHER - flat, 1/2", special	4
11	92- 8	WASHER - lock, 1/2"	20
12	25- 108	NUT - hex., 1/2" - 13 NC	16
13		RESERVED	
14	13- 1032	HHCS - 5/8" 11 NC x 1-3/4"	4
15	195- 41	WASHER - flat, 5/8"	4
16	92- 10	WASHER - lock, 5/8"	4
17	25- 1010	NUT - hex., 5/8" - 11 NC	4
18	L 73272	FOAM - cowl, used on some tractors	1

*NOTE: Sims built cabs may be identified by the Sims part number stamped on the cab serial number plate.




740956 C

***OPERATOR'S CAB (CASE BUILT)
DOORS AND WIPERS**

REF.	PART NO.	DESCRIPTION	REQ'D.
1 F	93569	FRAME - operator's cab	1
2	REF.	MOTOR - wiper, parts list page 99	1
3 F	43096	ADAPTOR - Pantograph, double arm wiper	1
4 114-	5	HHCS - 1/4" - 28 NF x 3/4", plated	2
5 192-	19	WASHER - lock, 1/4", plated	2
6 F	43097	ARM - windshield wiper, 19" (482 mm)	1
7 F	43095	BLADE - windshield wiper, 17" (431 mm)	1
8 F	43227	BRACKET - switch, wiper motor	1
9 F	63532	SWITCH - wiper motor, spade terminals	1
9 L	35743	SWITCH - wiper motor, bullet terminals	1
10 A	42561	NUT - hex., switch mounting, 7/16" - 27 NF	1
11 A	42578	KNOB -wiper motor switch	1
12 F	93104	BUMPER - door	2
13 182-	527	SCREW - pan head, slotted, 1/4" - 20 NC x 5/8", plated	2
14 F	43138	ANGLE - door holder	2
15 179-	155	SCREW - oval head, slotted, #10 - 24 NC x 3/4", plated	4
16 195-	513	WASHER - flat, #10, plated	4
17 192-	18	WASHER - lock, 3/16", plated	4
18 129-	17	NUT - hex., #10 - 24 NC, plated	4
19 111-	203	SCREW - round head, slotted, 5/16" - 18 NC x 1", plated	4
20 195-	521	WASHER - flat, 5/16", plated	4
21 192-	20	WASHER - lock, 5/16", plated	4
22 129-	102	NUT - hex., 5/16" - 18 NC, plated	4
23 F	93573	DOOR - R.H.....	1
24 F	93574	DOOR - L.H.....	1
25 F	89824	LATCH - door, inside	2
26 F	93579	STRAP - latch	4
27 182-	534	SCREW - pan head, slotted, 1/4" - 20 NC x 1", plated	8
28 F	42982	SHAFT - door latch, inside	2
29 F	63925	HANDLE - inside release	2
30 F	93575	ARM - handle, R.H., inner	1
31 F	93576	ARM - handle, L.H., inner	1
31A 131-	421	NUT - push type	4
32 F	42980	ROD - latch	2
32A 178-	830	SCREW - set, #10 - 24 NC x 3/8"	4
32B 178-	838	SCREW - set, #10 - 24 NC x 5/8"	2
33 F	93577	ARM - handle, R.H., outer	1
34 F	93578	ARM - handle, L.H., outer	1
35 179-	154	SCREW - oval head, phillips, #10 - 24 NC x 5/8", plated	4
36 131-	50	NUT - hex., #10 - 24 NC, plated	4
37 F	93580	HANDLE - door, outside	2
37A A	42653	KEYS - handle, outside	2
38 F	63860	GASKET - outside handle.....	2
39	REF.	SEAL - door bottoms, 23.5" (597 mm) long, Cut from F43086 bulk seal, see item 63	UAR
40 F	43070	PADDING - door, inside	2


Continued on next page



***OPERATOR'S CAB (CASE BUILT)
DOORS AND WIPERS**

REF.	PART NO.	DESCRIPTION	REQ'D.
41	355- 62	PLUG - plastic	12
42 F	63580	STRIKER - door, R.H. and L.H.	2
42A F	43527	SHIM - striker, if used	UAR
43	182- 534	SCREW - pan head, slotted, 1/4" - 20 NC x 1", plated	4
44	193- 73	WASHER - internal tooth, shakeproof, plated	4
45	REF.	SEAL - door frame, 106" (2692 mm) long, Cut from F43086 bulk seal, see item 63	UAR
46 F	42990	BELLOWS - fuel filler tube	1
47 F	43064	RING - retaining, fuel filler tube	1
48 131-	1180	NUT - hex., self lock, 1/4" - 20 NC, plated	6
49 F	43071	PADDING - R.H. side panel	1
50 F	43072	PADDING - L.H. side panel	1
51 F	43066	PIPE - fuel filler tube	1
52 F	43065	BOLT - "U" self lock, 1/4" - 20 NC	1
53 131-	1180	NUT - hex., self lock, 1/4" - 20 NC, plated	2
53A L	73543	PIPE - fuel filler extension, if used	1
53B R	17765	HOSE - fuel filler, if used	1
54 F	43073	PADDING - fender panel	2
55 A	61145	GROMMET - rubber	2
56 353-	550	PLUG - plastic, with shoulder	4
57 F	42983	RETAINER - rear window seal	1
58 151-	526	RIVET - pop, 1/8" x .294" long (3.17 mm x 7.46 mm long)	6
59	REF.	SEAL - rear window, lower, 38.6" (980 mm) long, Cut from F43091 bulk seal, see item 64	UAR
60	REF.	SEAL - rear window, 97.4" (2474 mm) long, Cut from F43092 bulk seal, see item 65	UAR
61 F	43069	HEADLINER - cab	1
61A F	43577	HEADLINER - cab	1
62	REF.	REAR WINDOW ASSEMBLY - slide-up, see page 447 for breakdown	1
63 F	43086	SEAL - bulk roll, 100 ft. (30 metres), not shown	UAR
64 F	43091	SEAL - bulk roll, 100 ft. (30 metres), not shown	UAR
65 F	43092	SEAL - bulk roll, 100 ft. (30 metres), not shown	UAR


***NOTE:** Case built cabs may be identified by the J I Case Company serial number plate located in the top L.H. corner of the cab. For replacement of complete cab, order Sims built cab, pages 451 and 453. For dimensional information on glass and mouldings, see page 449.



***OPERATOR'S CAB (CASE BUILT)
REAR WINDOW**

REF.	PART NO.	DESCRIPTION	REQ'D.
1 F	93604	FRAME - rear window	1
2 F	93633	MOTOR - rear window wiper	1
3 F	42213	ARM - rear wiper, 16" (406 mm)	1
4 F	42214	BLADE - rear wiper, 18" (451 mm)	1
5 F	43217	HARNESS - rear wiper	1
6 F	54095	CLIP - wire retaining	3
7 182-	516	SCREW - pan head, slotted, #10 - 24 NC x 1/2", plated	1
8 193-	70	WASHER - lock, shakeproof, #10, plated	2
9 129-	17	NUT - hex., #10 - 24 NC, plated	1
10 192-	20	WASHER - lock, 5/16", plated	2
11 129-	102	NUT - hex., 5/16" - 18 NC, plated	2
12 195-	521	WASHER - flat, 5/16"	2
13 F	42201	BEARING - rear window carrier	2
14 F	93658	TUBE - rear window guide	2
15 F	43239	PLUNGER - lock, rear window	2
16 F	62245	SPRING - plunger	2
17 138-	129	PIN - roll, 1/4" x 11/16"	2
18 138-	321	PIN - roll, 3/16" x 2", plated	2
19 195-	518	WASHER - flat, 1/4", plated	4
20 192-	19	WASHER - lock, 1/4", plated	4
21 129-	101	NUT - hex., 1/4" - 20 NC, plated	4
22 129-	148	NUT - hex., lock, 3/4" - 10 NC, plated	4
23 195-	545	WASHER - flat, 3/4", plated	4
24 F	93651	GUIDE - R.H., rear window	1
25 F	93652	GUIDE - L.H., rear window	1
27 F	43241	PLUNGER - guide	2
28 222-	1004	NUT - hex., 3/8" tube, inverted flare	2
29 F	93662	HANDLE - window guide, R.H.	1
30 F	93663	HANDLE - window guide, L.H.	1
31 132-	331	PIN - cotter, 3/32" x 5/8"	2
32 F	13404	BOLT - shoulder, 5/16" - 18 NC	2

*NOTE: Case built cabs may be identified by the J I Case Company serial number plate located in the top L.H. corner of the cab.



3 3/16 INCH


740958 B

***OPERATOR'S CAB (CASE BUILT)
GLASS AND MOULDINGS**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	REF.	GLASS - windshield	1
2	REF.	MOULDING - windshield, 131.6" (3343 mm) long, Cut from A42677 bulk moulding, see item 11	UAR
3	REF.	GLASS - window, cowl	2
4	REF.	MOULDING - cowl window, 35.6" (904 mm) long, Cut from A42677 bulk moulding, see item 11	UAR
5	REF.	GLASS - door and side windows	4
6	REF.	MOULDING - door window, 89.5" (2273 mm) long, Cut from A42677 bulk moulding, see item 11	4
7	REF.	GLASS - rear window	1
8	REF.	MOULDING - rear window, 125.4" (3185 mm) long, Cut from A42677 bulk moulding, see item 11	1
9	REF.	GLASS - backhoe closure panels	2
10	REF.	MOULDING - backhoe closure panel glass, 47-5/8" (1209 mm) long, Cut from A42677 bulk moulding, see item 11	2
11 A	42677	MOULDING - bulk material, 50 ft. (15 metres) roll	UAR

NOTE: All cab glass must be obtained from local sources. Order laminated safety glass to dimensions shown on opposite page.


***NOTE:** Case built cabs may be identified by the J I Case Company serial plate located in the top L.H. corner of the cab.

FIGURE "A"

***OPERATOR'S CAB (SIMS BUILT)
DOORS AND WINDOWS**

REF.	PART NO.	DESCRIPTION	REQ'D.
	*Mach. Item		
1	NSS	CAB - operator's complete (Sims 1000-0405) See page 2 for ordering.....	1
2	REF.	FRAME - cab	1
3	REF.	FOAM - upper, roof, cut from L35801 bulk	1
		GASKET - rear window, sides, 33" (838 mm) long, cut from L34759 bulk, see item 68	2
4 D	70592	REAR WINDOW - roll up	1
5 D	70605	CHAIN - rear window	1
6 205-	28	PLUG - button, if used	1
6A 353-	679	PLUG - button, if used	1
7	REF.	GASKET - rear window, bottom, 37" (536 mm) long, cut from L35819 bulk, see item 69	1
8 D	70600	FOAM - lower rear	1
9 D	70621	ROLLER - rear window	4
10 D	70604	FOAM - roof	1
11 L	35747	LATCH - holdback, rear	1
12 D	70606	DOOR - R.H.....	1
13 D	70607	DOOR - L.H.....	1
14	REF.	GASKET - door, top, 16" (406 mm) long, cut from D66499 bulk, see item 70.....	2
15	REF.	GASKET - door, front, 52" (1321 mm) long, cut from D66499 bulk, see item 70.....	2
16 D	70613	HANDLE - door, locking, 3" (76 mm) shaft, order keys from Sims under the number stamped on the lock and the key	2
16 D	71372	HANDLE - door, locking, 3-3/4" (95 mm) shaft, order keys from Sims under the number stamped on the lock and the key	2
17 D	70620	RIVET - drive	4
18 F	89824	LATCH - door, Early Production	2
18A L	35737	LATCH - door, R.H. Late Production	1
18B L	35738	LATCH - door, L.H., Late Production	1
18C 187-	994	SCREW - 1/4" - 20 NC x 3/4", if used	8
19 D	70615	BLOCK - latch, spacer, Early Production	2
20 D	70616	COVER - latch, Early Production	2
21 113-	5	HHCS - 1/4" - 20 NC x 1-1/2", Early Production	8
22 192-	19	WASHER - lock, 1/4", Early Production	12
23 D	70617	HANDLE - door, inner, Early Production	2
24 D	70618	STRIKER - door, R.H., Early Production.....	1
25 D	70619	STRIKER - door, L.H., Early Production	1
26 113-	3	HHCS - 1/4" - 20 NC x 3/4", Early Production	4
27	REF.	GASKET - door, bottom, 25" (635 mm) long, cut from D66499 bulk, see item 70.....	2
28 D	70603	FOAM - door	2
29	REF.	GASKET - door, rear, 50" (1270 mm) long, cut from D66499 bulk, see item 70.....	2
30 D	70601	FOAM - side panel, R.H., lower	1
31 D	70602	FOAM - side panel, L.H., lower	1
32 D	70598	FOAM - side panel, R.H., upper	1
33 D	70599	FOAM - side panel, L.H., upper	1

Continued on next page


FIGURE "A"

***OPERATOR'S CAB (SIMS BUILT)
DOORS AND WINDOWS**

REF.	PART NO.	DESCRIPTION	REQ'D.
34 D	70596	LATCH - hold back, R.H.....	1
35 D	70595	LATCH - hold back, L.H.....	1
36 113-	207	HHCS - 3/8" - 16 NC x 1"	2
37 131-	52	NUT - hex., self lock, 3/8" - 16 NC	2
38 L	35748	SPRING - latch	2
39 D	70597	PIPE - fuel filler, see page 65 for connecting hose	1
39A A	13240	CLAMP - pipe, retaining (Includes hardware)	1
40 F	42990	BELLOWS - fuel filler pipe	1
41 D	70612	RETAINER - fuel filler	1
42 195-	102	WASHER - flat, 1/4"	6
43 129-	101	NUT - hex., 1/4" - 20 NC	6
44 D	72837	GROMMET - rubber	2
45 D	70622	HOSE - fuel filler	1
46 214-	261	CLAMP - hose	2
47	REF.	MOTOR - wiper, 24 volt, parts list page 99	1
47A L	35753	ADAPTER - panograph, wiper	1
47B 113-	3	HHCS - 1/4" - 20 NC x 3/4"	2
47C 192-	15	WASHER - lock, 1/4"	2
48 L	35986	ARM - wiper, 16" (406 mm)	1
49 A	42580	BLADE - wiper, 16" (406 mm)	1
50 D	70609	BRACKET - switch, used before cab sn. 24364	1
50A L	76555	BRACKET - switch, used on cab sn. 24364 and after	1
50B L	76554	PLATE - switch, used on cab sn. 24364 and after	1
50C 192-	19	WASHER - lock, 1/4", plated, brackets	3
50D 129-	101	NUT - hex., 1/4" - 20 NC, plated, brackets	3
50E L	77252	BRACKET - circuit breaker, rear wiper, if used	1
50F D	78370	WIRE - rear breaker to rear wiper, if used	1
51 F	63532	SWITCH ASSEMBLY - wipper, includes 51A and 51B	1
51A A	42561	NUT - hex., wiper switch	2
51B A	42578	KNOB - wiper switch	2
51C D	70623	HARNESS - cab	1
51D L	54606	CLIP - stick on	2
52 L	35834	HOOK - "S", rear window chain	1
53 L	35835	SNAP - chain	1
54 129-	145	NUT - lock, 1/2" - 13 NC	4
55 131-	912	NUT - flanged, 1/2" - 13 NC	4
56 D	72836	BRACKET - defroster mount	1
57 13-	512	HHCS - 5/16" - 18 NC x 3/4"	2
58 F	93633	MOTOR - wiper, rear	1
59 187-	988	BOLT - wiper ground	2
60 A	75994	GROMMET - wire	3
61 D	71195	ARM - wiper, rear	1
62 A	42580	BLADE - wiper, rear	1
63	REF.	RUBBER - mounting, 30" (762 mm) long, cut from L35840 bulk, see item 71	1
64	REF.	RUBBER - mounting, 29" (737 mm) long, cut from D70610 bulk, see item 72	2

Continued on next page

***NOTE:** Sims built cabs may be identified by the Sims part numbers stamped on the cab serial number plate.

FIGURE "A"


**SEE
FIG. "A"**

MODEL 680E CONSTRUCTION KING LOADER BACKHOE 453B

*OPERATOR'S CAB (SIMS BUILT) DOORS AND WINDOWS

REF.	PART NO.	DESCRIPTION	REQ'D.
65	REF.	RUBBER - mounting, 40" (1016 mm) long, cut from D71360 bulk, see item 73	2
66	REF.	RUBBER - mounting, 55-3/4" (1416 mm) long, cut from D71360 bulk, see item 73.....	1
66A F	43266	WIRE - front breaker to wiper switch, if used	1
66B L	76726	BREAKER - circuit, 3 ampres, if used	2
67 L	35801	FOAM - bulk, 50' (15 metres) roll, not shown	UAR
68 L	35759	GASKET - bulk, 50' (15 metres) roll, not shown	UAR
69 L	35819	GASKET - bulk, 50' (15 metres) roll, not shown	UAR
70 D	66499	GASKET - bulk, 50' (15 metres) roll, not shown	UAR
71 L	35840	RUBBER - bulk, 50' (15 metres) roll, not shown	UAR
72 D	70610	RUBBER - bulk, 50' (15 metres) roll, not shown	UAR
73 D	71360	RUBBER - bulk, 50' (15 metres) roll, not shown	UAR

*NOTE: Sims built cabs may be identified by the Sims part numbers stamped on the cab serial number plate.




***OPERATOR'S CAB (SIMS BUILT)
CAB GLASS AND MOULDING**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	REF.	GLASS - rear, upper	1
2	REF.	MOULDING - upper rear window, 77" (1956 mm) long, cut from L35717 bulk	1
3	REF.	GLASS - rear	1
4	REF.	MOULDING - rear window, 128" (3251 mm) long, cut from D70593 bulk	1
5	REF.	GLASS - rear, lower, outside	2
6	REF.	MOULDING - rear lower window, 36.25" (921 mm) long, cut from D70593 bulk	2
7	REF.	GLASS - rear, lower, inside	2
8	REF.	MOULDING - rear, lower, 36" (914 mm) long, cut from D70593 bulk	2
9	REF.	GLASS - side panel	2
10	REF.	MOULDING - side panel, 101" (2565 mm) long, cut from D70593 bulk	2
11	REF.	GLASS - door	2
12	REF.	MOULDING - door window, 108" (2743 mm) long, cut from D70543 bulk	2
13	REF.	GLASS - windshield	1
14	REF.	MOULDING - windshield, 144" (3658 mm) long, cut from D70593 bulk	1
15	REF.	GLASS - cowl, front	2
16	REF.	MOULDING - front cowl window, 34" (864 mm) long, cut from D70593 bulk	2
17	L 35717	MOULDING - bulk, 50' (15 metres) roll, not shown	UAR
18	D 70593	MOULDING - bulk, 50' (15 metres) roll, not shown	UAR


NOTE: All cab glass must be obtained from local sources. Order laminated safety glass to dimensions shown on opposite page.

***NOTE:** Sims built cabs may be identified by the Sims part number stamped on the cab serial number plate.



MODEL 680E CONSTRUCTION KING LOADER BACKHOE 457**NOISE REDUCTION PADS**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	L 71578	PAD - firewall, heat and noise control	1
2	345- 57	CEMENT - for L71578 pad, 1 pint (.047 litre)	1
3	L 71579	PAD - instrument panel	1
4	L 71565	PLATE - pad support, backhoe console floor	1
5	L 71563	BRACKET - support plate to console	4
6	13- 516	HHCS - 5/16" - 18 NC x 1"	8
7	95- 5	WASHER - flat, 5/16"	8
8	92- 5	WASHER - lock, 5/16"	8
9	25- 105	NUT - hex., 5/16" - 18 NC	8
10	L 72272	PAD - floor, backhoe console	1



MODEL 680E CONSTRUCTION KING LOADER BACKHOE 459**LOCKUP PARTS**

REF.	PART NO.	DESCRIPTION	REQ'D.
------	----------	-------------	--------

TACHOMETER GLASS LOCKUP




1	L 54570	COVER - tachometer glass	1
2	182- 208	SCREW - machine, pan head, 1/4" - 20 NC x 1-1/4"	4
3	92- 4	WASHER - lock, 1/4"	4
4	L 72459	SPACER - cover	4
5	151- 500	NUT - rivet, 1/4" - 20 NC	4

FUEL LOCKUP

6	L 58386	BRACKET - fuel filler lock, welded to filler neck	1
---	---------	---	---

LOCK AND KEY

7	R 29554	LOCK - padlock	3
8	R 29555	KEY - padlock	2




740110 A

**SLOW MOVING VEHICLE EMBLEM
EARLY PRODUCTION**

REF.	PART NO.	DESCRIPTION	REQ'D.
1	REF.	BOOM - backhoe, see page 405 for related parts	1
2	L 58801	BRACKET - emblem mounting	1
3	14- 616	HHCS - 3/8" - 24 NF x 1", bracket mounting	2
3A	95- 6	WASHER - flat, 3/8"	2
4	A 60977	SOCKET - slow moving vehicle emblem	1
5	11- 716	BOLT - 7/16" - 14 NC x 1", socket mounting	1
6	92- 7	WASHER - lock, 7/16"	1
7	25- 107	NUT - hex., 7/16" - 14 NC	1
	A 59450	EMBLEM - slow moving vehicle	1
8	NSS	BRACKET - emblem	1
9	NSS	EMBLEM - slow moving vehicle, plate and decal	1
9	321- 1751	DECAL - slow moving vehicle	1
10	182- 125	SCREW - machine, pan head, #10 - 24 NC x 1/2", emblem to bracket	2
11	92- 3	WASHER - lock, #10	2
12	129- 7	NUT - hex., #10 - 24 NC	2

**SLOW MOVING VEHICLE EMBLEM
LATE PRODUCTION**

13	REF.	LINKS - backhoe buckets, see pages 241 and 243 for related parts	2
14	D 52564	SPRING - fastner, emblem	1
15	195- 518	WASHER - flat, plated	2
16	129- 409	NUT - wing, 1/4" - 20 NC, plated	2
17	D 52581	EMBLEM - slow moving vehicle, plate and decal	1
17	321- 1751	DECAL - slow moving emblem	1




DECALS
***EARLY PRODUCTION**

REF.	PART NO.	DESCRIPTION	REQ'D
	*L 36081	KIT - decal, repair	1
1	321- 1573	DECAL - "CASE", 5 inch (127 mm) lift arm	2
2	321- 2728	DECAL - "680E", lift arm	2
3	321- 3061	DECAL - warning, radiator pressure	1
4	321- 2730	DECAL - "CONSTRUCTION KING 680E", at R.H. hood side	1
5	321- 2731	DECAL - "680E CONSTRUCTION KING", at L.H. hood side	1
6	321- 1572	DECAL - "CASE", 4 inch (101 mm), at hood side, dipper side and console ..	5
7	321- 663	DECAL - patent, no longer used	1
8	321- 246	DECAL - patent, no longer used	1
9	321- 704	DECAL - negative ground	1
10	321- 229	DECAL - hydraulic fluid	1
11	321- 230	DECAL - diesel fuel	1
12	321- 3209	DECAL - warning, brake pedals	1
13	321- 1000	DECAL - transmission shift pattern	1
14	321- 2799	DECAL - forward - reverse lever	1
15	321- 2613	DECAL - cluster panel, R.H.	1
16	L 57685	DECAL - "CASE", R.H. panel	1
17	321- 2785	DECAL - clutch cut-out	1
18	321- 1077	DECAL - air tank drain	1
19	321- 1482	DECAL - "OK", at dipper sides	2
20	321- 3054	DECAL - operator warning, at backhoe	2
21	321- 2729	DECAL - backhoe throttle	1
22	321- 2721	DECAL - engine warning light	1
23	321- 2725	DECAL - backhoe controls, at console	1
24	321- 2798	DECAL - backhoe hydraulic check	1
25	321- 2797	DECAL - loader hydraulic check	1
25A	321- 4901	CHART - maintenance	1
25B	321- 3596	DECAL - warning, fan and belts	2
25C	151- 525	RIVET - used with item 25A	4
26	321- 2722	DECAL - bucket control, 2 spool valve	1
27	321- 2720	DECAL - bucket control, 3 spool valve	1
28	321- 2746	DECAL - dual lever control	1
29	321- 2747	DECAL - extendahoe control, models with twin levers	1
30	321- 2724	DECAL - extendahoe control, models with individual levers	1
31	321- 3139	DECAL - extendahoe	1


***NOTE:** This decal kit should be used on machines before tractor sn. 9118170 except for 9118139, 9118196, 9118250, 911253, 9118255, 9118261 and 9118262.



(3)	J.I.CASE COMPANY ...owns or is licensed under the following patents
(2)	J.I Case Company ... owns or is licensed under the following patents



construction king



WARNING

BEFORE STARTING ENGINE
STUDY OPERATOR'S MANUAL SAFETY MESSAGES
REMEMBER TO CLEAR THE AREA OF OTHER PERSONS
LEARN & PRACTICE SAFE USE OF CONTROLS BEFORE OPERATING

WARNING

OPERATE BACKHOE FROM OPERATOR'S SEAT ONLY

WARNING

WHEN SERVICING THE UNIT WITH LIFT ARMS RAISED ALWAYS INSTALL THE
LIFT ARM SAFETY STRUT
1. EMPTY LOADER BUCKET
2. RAISE LOADER ARMS TO SUFFICIENT HEIGHT TO INSERT STRUT
3. REMOVE PIN AND PLACE SAFETY STRUT OVER CYLINDER ROD
4. PLACE PIN IN LOWER HOLE TO LOCK STRUT
5. LOWER LIFT ARMS ONTO SAFETY DEVICE. FAILURE TO FOLLOW THIS PROCEDURE COULD RESULT IN INJURY OR DEATH IF LIFT ARMS ARE LOWERED

COLD START

(35)

STABILIZER BUCKET DIPPER BOOM STABILIZER

750311 C

DECALS
***LATE PRODUCTION**

REF.	PART NO.	DESCRIPTION	REQ'D
	*L 36164	KIT - decal, items 9 and 12 are stick on type	1
	*L 36175	KIT - decal, items 9 and 12 are rivet on type	1
	*L 36180	KIT - decal, items 9 and 12 are rivet on type	1
1	321- 3061	DECAL - warning, radiator pressure	1
2	321- 663	DECAL - patent, no longer used	1
3	321- 246	DECAL - patent, no longer used	1
4	321- 704	DECAL - negative ground	1
5	321- 229	DECAL - hydraulic fluid	1
6	321- 230	DECAL - diesel fuel	1
7	321- 3209	DECAL - warning, brake pedals	1
8	321- 1000	DECAL - transmission shift pattern	1
9	321- 2799	DECAL - forward - reverse lever, stick on type	1
9	321- 4145	DECAL - forward - reverse lever, rivet on type	1
10	321- 2613	DECAL - cluster panel, R.H.	1
11	L 57685	DECAL - "CASE", R.H. panel	1
12	321- 2785	DECAL - clutch cutout, stick on type	1
12	321- 4146	DECAL - clutch cutout, rivet on type	1
13	321- 1077	DECAL - air tank drain	1
14		RESERVED	
15	321- 3054	DECAL - operator warning, at backhoe	2
16	321- 2729	DECAL - backhoe throttle	1
17	321- 2721	DECAL - engine warning light	1
18	321- 2725	DECAL - backhoe controls, at console	1
19	321- 2798	DECAL - backhoe hydraulic check	1
20	321- 2797	DECAL - loader hydraulic check	1
21	321- 4901	CHART - maintenance	1
22	321- 3069	DECAL - Construction King	2
23	321- 3090	DECAL - "CASE", R.H.	1
24	321- 3091	DECAL - "CASE", L.H.	1
25	321- 3087	DECAL - "CASE"	1
26	321- 3088	DECAL - "CASE"	1
27	321- 3089	DECAL - "CASE"	1
28	321- 3092	DECAL - 680E	2
28A	321- 3596	DECAL - warning, fan and belts	2
28B	321- 3705	DECAL - warning, read and study all safety messages before operating machine	1
28C	321- 4127	DECAL - warning, parking brake	1
28D	321- 4408	DECAL - loader safety strut, L 36175 Kit only	1
28E	151- 525	RIVET - for items 9 and 12, if used, part of L36175 Kit only, not shown ..	4
28F	321- 4633	DECAL - light switch, L36180 kit only	1
28G	321- 4632	DECAL - flood light caution, L36180 kit only	1
29	321- 3099	DECAL - "CASE"	1
30	321- 2722	DECAL - bucket control, 2 spool valve	1
31	321- 2720	DECAL - bucket control, 3 spool valve	1
32	321- 2746	DECAL - dual lever control	1
33	321- 2747	DECAL - extendahoe control, models with twin levers	1
34	321- 2724	DECAL - extendahoe control, models with individual levers	1
35	321- 2653	DECAL - cold start	1
36	151- 525	RIVET - maintenance chart, not shown	4

NOTE: L36164 Kit is used on tractor sn. 9118139, 9118916, 9118250, 9118255, 9118261, 9118262, 9118270 thru 9124838. L36175 Kit is used on tractor sn. 9124838 thru 9127825. L36180 Kit is used on sn. 9127825 and after.

HOSE AND FITTING ASSEMBLY CONVERSION PART NUMBERS

To make up a replacement hose line, find the CASE original equipment part number in the left hand column. To the right of this number are the component part numbers needed to assemble the replacement hose line.

ORIGINAL EQUIPMENT ASS'Y. NO.	BULK HOSE NO.	CUT HOSE LENGTH	USE FITTING NO.	USE FITTING NO.	ADDITIONAL PARTS REQUIRED
36547	A21573	15-3/4"	220-205	220-224	
A58774	A21565	8-3/4"	220-123	220-123	
D39140	A21572	20-5/8"	220-203	220-263	
L48749	A21572	52-3/4"	220-203	220-224	
L48750	A21572	59"	220-203	220-223	
L50629	A21572	44-5/8"	220-204	220-251	
L53612	A21565	32-1/4"	220-103	220-103	
L53613	A21565	38-1/4"	220-103	220-103	
L54789	A21572	38-3/4"	220-203	220-251	
L54790	A21572	59-5/8"	220-203	220-203	
L55083	A21572	36-5/8"	220-203	220-203	
L55955	A21572	22-3/4"	220-199	220-199	
L57158	Use Original Equipment Hose Assembly No. L57158				
L57163	Use Original Equipment Hose Assembly No. L57163				
L57165	Use Original Equipment Hose Assembly No. L57165				
L57299	A21565	33-1/4"	220-103	220-103	
L57599	A21572	33-7/8"	220-251	220-251	
L57976	Use Original Equipment Hose Assembly No. L57976				
L58094	A21573	24-1/4"	220-199	220-199	
L58351	A21574	104-3/8"	220-245	220-245	
L58459	A21565	21-3/8"	220-103	220-123	
L58821	A21574	43-3/8"	220-245	220-245	
L58822	A21574	100-1/8"	220-206	220-206	
L59105	A21565	82-1/4"	220-103	220-103	
L59106	A21565	14-5/8"	220-184	220-103	
L71566	A21572	15-7/8"	220-203	220-291	
L71567	A21572	22-5/8"	220-203	220-402	
L71568	Use Original Equipment Hose Assembly No. L71568				
L71569	A21575	24-1/2"	220-207	220-207	Use Sleeve From Old Hose
L73182	A21574	92"	220-206	220-206	
L76819	A21572	20-5/8"	220-252	220-203	
L77088	A21567	30-1/4"	220-114	220-114	
L77824	A21573	98-1/4"	220-238	220-199	Use Shield and Sleeve from Old Hose
L77825	A21573	54-1/4"	220-238	220-199	Use Shield and Sleeve from Old Hose
L78165	A21573	94-3/8"	220-245	220-245	Use Sleeve from Old Hose
T41362	A21573	24"	220-238	220-238	

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

467

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
10927	101	21	A 12928	187	34	A 14841	161	34
10927	103	18	A 13057	111	12	A 14844	159	33
16917	355	11	A 13058	111	10	A 14844	161	33
30364	345	3	A 13058	125	16	A 14850	159	17
30634	345	14	A 13059	111	11	A 14850	161	17
30634	347	3	A 13060	125	25	A 14853	159	16
30634	347	14	A 13088	111	3	A 14853	161	16
33261	387	9	A 13089	111	4	A 14854	159	11
36547	379	29	A 13090	111	7	A 14854	161	11
40025	143	35	A 13091	111	6	A 14855	159	12
40025	149	35	A 13092	111	5	A 14855	161	12
40025	151	4	A 13093	111	8	A 14857	169	2
40025	153	4	A 13112	177	25	A 14857	169	28
45490	107	28	A 13112	181	25	A 14857	171	2
49771	283	16	A 13112	185	25	A 14858	159	20
49774	77	52	A 13124	189	2	A 14858	161	20
49799	85	12	A 13124	193	2	A 14863	155	27
49799	265	7	A 13124	197	2	A 14863	157	24
49799	271	17	A 13124	201	2	A 14864	155	29
49833	79	34B	A 13160	189	10	A 14866	155	32
49851	57	27	A 13160	193	10	A 14871	155	5
49851	61	16	A 13160	197	10	A 14873	155	17
49851	63	4	A 13160	201	10	A 14874	155	19
49852	65	22	A 13161	189	9	A 14874	157	17
49852	65	38	A 13161	193	9	A 14876	155	18
49852	85	32	A 13161	197	9	A 14877	155	16
49852	87	18	A 13161	201	9	A 14877	157	15
49853	61	21	A 13240	59	32	A 14878	155	20
49853	63	20	A 13240	59	45	A 14878	157	18
49853	73	27	A 13240	453	39A	A 14879	155	22
49853	83	27	A 14509	145	45	A 14879	157	19
49857	75	7	A 14509	149	45	A 14880	155	21
49857	101	9	A 14512	145	44	A 14881	155	25
49857	103	5	A 14512	149	44	A 14881	157	22
49858	85	19	A 14527	303	2	A 14882	155	12
49858	119	39	A 14527	305	2	A 14882	155	23
49858	121	8	A 14529	309	10	A 14882	157	11
49858	265	10	A 14533	307	6	A 14882	157	20
49858	297D	52	A 14533	309	6	A 14883	155	15
49891	271	18	A 14535	307	4	A 14884	155	26
49891	287	4A	A 14535	309	5	A 14884	157	23
58218	405	1	A 14553	81	41	A 14885	155	14
70973	57	7	A 14567	117	2A	A 14885	157	13
71466	335	23	A 14567	125	2	A 14928	109	3
73153	335	24	A 14567	125	13	A 14928	109	12
A 7156	19	30	A 14810	143	21	A 14954	125	15
A 7509	159	28	A 14810	147	21	A 15443	191	21
A 7509	161	28	A 14811	143	22	A 15443	195	21
A 7552	423	10	A 14811	147	22	A 15443	197	21
A 7623	303	8	A 14827	151	24	A 15443	203	20A
A 7623	305	8	A 14827	153	23	A 15519	55	11
A 8134	21	3	A 14829	151	26	A 15941	75	5
A 8134	27	10	A 14829	153	25	A 15983	207	52
A 8218	241	44	A 14831	151	23	A 15983	211	52
A 11538	387	11	A 14831	151	29	A 15983	215	52
A 11538	395	10A	A 14832	151	22	A 15983	219	46
A 11822	65	3	A 14832	151	30	A 16638	133	27
A 11990	405	25	A 14832	153	27	A 16764	9	32
A 12032	283	6	A 14833	143	14	A 16764	13	42
A 12522	177	26	A 14833	147	14	A 16764	89	2
A 12522	181	26	A 14835	159	13	A 16764	89	17
A 12522	185	26	A 14835	161	13	A 16764	91	2
A 12928	177	34	A 14837	159	1	A 16764	91	17
A 12928	183	34	A 14841	159	34	A 16764	93	2

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
A 16764	93	17	A 18247	177	5	A 25212	105	12
A 16843	111		A 18247	181	5	A 25213	105	1
A 16879	303	15	A 18247	185	5	A 25213	105	13
A 16879	305	15	A 18312	77	35	A 25285	307	8
A 16881	303	16	A 18358	189	11	A 25285	309	8
A 16881	305	16	A 18358	193	11	A 25286	307	7
A 17652	57	26	A 18359	189	11	A 25286	309	7
A 18173	191	37	A 18359	193	11	A 25291	309	7
A 18173	195	37	A 18361	189	11	A 26009	423	9
A 18173	199	37	A 18361	193	11	A 26381	233	47
A 18173	203	36	A 18363	189	11	A 26727	173	1
A 18175	191	31	A 18363	193	11	A 27001	389	9
A 18175	195	31	A 18364	189	11	A 27020	309	9
A 18175	199	31	A 18364	193	11	A 27020	313	9
A 18175	203	30	A 18365	189	11	A 27089	159	9
A 18176	191	32	A 18365	193	11	A 27089	159	18
A 18176	195	32	A 18366	189	11	A 27089	161	9
A 18176	199	32	A 18366	193	11	A 27089	161	18
A 18176	203	31	A 18367	189	11	A 27100	431	11
A 18181	191	30	A 18367	193	11	A 27256	281	34
A 18181	195	30	A 18390	189	11	A 27365	303	4
A 18181	199	30	A 18390	193	11	A 27365	303	9
A 18181	203	29	A 18550	35	5	A 27365	305	4
A 18182	191	14	A 19068	55	19A	A 27365	307	3
A 18182	195	14	A 19068	139	20	A 27365	309	2
A 18182	197	14	A 19774	35	15	A 27365	309	4
A 18182	201	14	A 19774	265	20	A 27365	319	4
A 18194	191	36	A 20058	135	14	A 27365	321	4
A 18194	195	36	A 20058	135	16	A 27365	327	4
A 18194	199	36	A 20058	135	18	A 27365	329	4
A 18194	203	35	A 20058	137	4	A 27410	423	20
A 18196	191	17	A 20058	137	4	A 27507	351	9
A 18196	195	17	A 20058	137	4	A 27507	353	9
A 18196	197	17	A 20058	137	4	A 27507	357	10
A 18196	203	22	A 20058	137	4	A 27507	359	10
A 18199	191	15	A 20539	39	20	A 27507	365	10
A 18199	195	15	A 20663	39	9	A 27507	367	10
A 18199	197	15	A 20916	11	11	A 27795	71	4
A 18199	201	15	A 20917	11	10	A 27852	17	14
A 18200	189		A 20933	41	6	A 27853	17	13
A 18200	191		A 20933	43	3	A 27862	65	17
A 18200	193		A 21017	17	6	A 27877	15	7
A 18200	195		A 21105	15	4	A 27878	15	8
A 18200	197		A 21145	127	9	A 27880	15	11
A 18200	199		A 21235	27	25	A 27880	33	13
A 18200	201		A 21653	15	40	A 27903	21	22
A 18200	203		A 22381	43	10	A 27920	21	33
A 18218	177	9	A 22431	99	9	A 27968	29	4
A 18218	181	9	A 22463	15	40	A 27968	33	37
A 18218	185	9	A 22590	27	26	A 28028	21	20
A 18221	177	1	A 23316	349B	10	A 28090	39	6
A 18221	185	1	A 23316	349	10	A 28090	319	18
A 18236	177	7	A 23316	361	10	A 28090	321	20
A 18236	181	7	A 23316	363	10	A 28090	321	36
A 18236	185	7	A 23577	17		A 28090	327	21
A 18241	177	12	A 23577	19	8	A 28098	37	29
A 18241	181	12	A 23655	55	6	A 28153	159	14
A 18241	185	12	A 23683	13	27	A 28153	161	14
A 18242	177	8	A 23684	13	26	A 28230	151	35
A 18242	181	8	A 23684	33	12	A 28230	153	30
A 18242	185	8	A 24361	19	7	A 29197	333	8
A 18246	177	4	A 25190	43	12	A 29277	429	6
A 18246	181	4	A 25191	43	11	A 29884	117	2
A 18246	185	4	A 25192	43	9	A 30095	341	10

MODEL 680E CONSTRUCTION KING LOADER BACKHOE
NUMERICAL INDEX

469

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
A 30095	343	10	A 41402	45	12	A 42932	21	9
A 30095	345	10	A 41403	33	8	A 43095	25	12
A 30095	347	10	A 41403	45	11	A 43158	21	13
A 30095	369	9	A 41436	53	21	A 43159	21	13
A 30095	371	9	A 41511	131	19	A 43160	21	13
A 30825	423	22B	A 41515	131	21	A 43161	21	13
A 31038	17	11	A 41745	39		A 43162	21	13
A 31060	75	32	A 41753	15	41	A 43163	21	12
A 31186	133	25	A 41754	15	44	A 43164	21	12
A 31209	159	22	A 41768	45	10	A 43165	21	12
A 31209	161	22	A 41781	13	34	A 43166	21	12
A 32309	319	5	A 41781	15	43	A 43167	21	12
A 32309	321	5	A 41853	41	2	A 43173	25	22
A 32309	327	5	A 41853	43	2	A 43174	25	22
A 32309	329	5	A 41854	41	7	A 43175	25	22
A 32830	21	27	A 41854	43	7	A 43176	25	22
A 32830	33	22	A 41855	41	3	A 43177	25	22
A 34124	13	19	A 41855	43	8	A 43194	21	38
A 34133	13	6	A 41856	41	8	A 43280	53	5
A 34133	33	11	A 41856	43	6	A 43296	129	
A 34266	19	20	A 41917	47	22	A 43343	41	19
A 34540	19	9	A 41922	49	70	A 43343	43	22
A 34826	29	3	A 41924	49	48	A 43344	41	17
A 34979	163	47	A 41925	47		A 43344	43	19
A 35104	317	6	A 41977	47	27	A 43345	41	18
A 36091	99	4	A 42075	53	3	A 43345	43	20
A 36277	257	29	A 42127	47	29	A 43346	41	13
A 36277	259	29	A 42199	49	63	A 43346	43	15
A 38411	83	3	A 42221	33		A 43347	41	12
A 38492	53	49	A 42259	13	36	A 43347	43	14
A 38492	55	31	A 42259	15	45	A 43348	41	15
A 39586	317	17	A 42260	51	11	A 43348	43	17
A 39887	101	2	A 42308	49	68	A 43349	41	16
A 39887	103	1	A 42309	49	67	A 43349	43	18
A 39888	101	2A	A 42312	41	4	A 43350	41	14
A 39888	103	1A	A 42312	43	4	A 43350	43	16
A 40033	101	23	A 42313	41	5	A 43351	41	21
A 40033	103	20	A 42313	43	5	A 43351	43	21
A 40052	257	26	A 42315	39	8	A 43380	49	71
A 40052	259	26	A 42323	47	3	A 43419	49	72
A 40217	47	9	A 42376	49	75	A 43551	127	3
A 40310	69	10	A 42376	51	1	A 43554	127	21
A 40311	69	3	A 42397	49	51	A 43558	127	16
A 40312	69	1	A 42407	51	3	A 43560	127	25
A 40313	69	8	A 42410	51	10	A 43564	127	13
A 40315	69	2	A 42411	51	8	A 43566	127	12
A 40316	69	5	A 42412	51		A 43567	127	11
A 40317	69	6	A 42413	51	13	A 43568	1278	33
A 40318	69	7	A 42424	45	6	A 43569	127	32
A 40352	15	49	A 42431	53	39	A 43573	1278	38
A 40892	49	46	A 42432	53	41	A 43574	1278	39
A 40893	49	56	A 42491	25	21	A 43579	1278	42
A 40894	47	30	A 42561	443	10	A 43580	1278	43
A 40896	47	24	A 42561	453	51A	A 43599	45	3
A 40909	47	20	A 42578	443	11	A 43600	45	5
A 41035	53	43	A 42578	453	51B	A 43602	45	4
A 41038	53	24	A 42580	453	49	A 43701	51	18
A 41041	53	22	A 42580	453	62	A 43720	127	15
A 41052	53	4	A 42610	31		A 43721	127	19
A 41060	53	26	A 42653	443	37A	A 43728	127	20
A 41242	49	69	A 42677	449	11	A 43729	127	27
A 41361	53	46	A 42806	53	16	A 43733	45	8
A 41361	55	29	A 42810	53	11	A 43856	49	74
A 41402	33	9	A 42895	15	46	A 43860	47	23

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
A 43861	47	2	A 58613	35	7	A 58895	33	7
A 44056	19		A 58615	33	25	A 58899	33	17
A 44057	19	2	A 58615	35	21	A 58910	33	16
A 44060	25	11	A 58617	33	30	A 58910	57	13
A 44061	25		A 58620	13	20	A 58929	13	1
A 44075	33		A 58628	15	30	A 58931	23	12
A 44086	33		A 58628	33	14	A 58932	29	5
A 44340	49	55	A 58629	13	24	A 58960	37	18
A 44369	45	7	A 58635	13	7	A 58961	37	20
A 44423	53	32	A 58635	33	10	A 58962	37	19
A 44435	127	14	A 58637	9	2	A 58963	37	28
A 44576	13	35	A 58637	33	4	A 58964	37	25
A 44576	15	42	A 58646	9	21	A 58965	37	24
A 44581	53	12	A 58646	33	27	A 59077	11	6
A 44645	15	48	A 58649	9	33	A 59077	11	21
A 44658	15	47	A 58649	33	28	A 59111	27	5
A 44672	53	9	A 58650	9	40	A 59220	9	28
A 44713	19	31	A 58651	9	42	A 59225	11	2
A 44763	53	24	A 58654	15	3	A 59296	55	21
A 44770	53	44	A 58655	15	1	A 59450	461	
A 44771	53	23	A 58656	15	2	A 59718	31	24
A 44774	53	2	A 58657	15	10	A 60212	1298	16
A 44775	53	8	A 58659	15	14	A 60212	129	17
A 44776	53	10	A 58662	11	5	A 60212	129	17
A 44777	53	17	A 58662	33	6	A 60553	83	3A
A 44778	53	18	A 58665	11	17	A 60558	13	15
A 44779	53	33	A 58666	11	20	A 60567	13	29
A 44781	53	34	A 58666	33	7	A 60977	461	4
A 44782	53	23	A 58670	33	31	A 61040	23	2
A 44783	77	33A	A 58680	33	33	A 61041	23	2
A 44784	53	36	A 58689	35	37	A 61053	35	20
A 44785	53	35	A 58690	35	45	A 61128	15	12
A 44788	53	15	A 58691	35	46	A 61129	27	3
A 44789	53	25	A 58692	35	47	A 61130	27	20
A 44798	53	1	A 58693	35	41	A 61145	445	55
A 44812	19	28	A 58695	37	16	A 61155	221	29
A 45253	53	19	A 58696	37	17	A 61283	55	9
A 45254	53	20	A 58702	37	2	A 61406	131	10
A 45342	41	20	A 58703	37	3	A 61425	129	16
A 45342	43	23	A 58704	37	4	A 61426	129	15
A 50423	245	45	A 58705	37	5	A 61428	129	13
A 55446	159	25	A 58709	37	6	A 61428	129	13
A 55446	161	25	A 58710	37	7	A 61429	1298	18
A 56092	59	38B	A 58735	9	1	A 61429	129	19
A 57116	245	48	A 58736	9	10	A 61429	129	19
A 57457	21	26	A 58737	9	15	A 61430	1298	19
A 57470	35	38	A 58750	11	16	A 61430	129	20
A 57532	15	6	A 58752	31	1	A 61430	129	20
A 57641	9	12	A 58754	31	2	A 61446	135	9
A 58439	261	16	A 58755	31	3	A 61447	135	10
A 58439	263	16	A 58756	31	5	A 61448	135	10A
A 58566	19	13	A 58756	33	26	A 61449	135	11
A 58568	9	29	A 58757	31	15	A 61450	135	2
A 58568	9	29	A 58758	31	16	A 61570	135	13
A 58568	19	5	A 58774	39	19	A 62002	27	15
A 58569	19	6	A 58775	43	28	A 62049	21	17
A 58592	17	7	A 58783	19	10	A 62049	33	23
A 58593	17	8	A 58783	21	6	A 62049	35	3
A 58595	17	12	A 58784	19	11	A 62050	21	25
A 58609	35	1	A 58784	21	7	A 62050	33	24
A 58611	35	2	A 58785	19	12	A 62070	1298	17
A 58612	33	21	A 58785	21	8	A 62070	129	18
A 58612	35	4	A 58889	21	1	A 62070	129	18
A 58613	33	29	A 58892	33	15	A 62071	129	12

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

471

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
A 62210	117	1	A 140830	45	1	D 27833	25	13
A 62234	9	22	A 141841	15	17	D 27833	251	21
A 62339	39	1	A 142092	35	37	D 28366	345	16
A 62341	39	18	A 146368	39	10	D 28366	369	14
A 62347	39		A 146616	25	9	D 28367	337	16
A 62429	53	48	A 146984	21	4	D 28896	341	16
A 62429	55	25	A 148425	21	2	D 29423	415	3
A 62542	35	44	A 150118	35	23	D 29424	415	2
A 62573	21	9	A 150268	23	1	D 29712	403	30
A 62711	29	1	A 150672	27	19	D 29910	51	15
A 62732	13	23	A 152176	25		D 30004	51	19
A 62954	25	18	B 17072	63	17	D 30005	47	32
A 62974	9	20	B 18206	15	9	D 30006	47	33
A 63087	159	36	B 18208	335	27	D 30196	403	20
A 63087	163	36	B 50223	107	28	D 30706	393	44
A 63171	177	20	B 50293	101	22	D 30706	393	46
A 63171	181	20	B 50293	103	19	D 30735	337	3
A 63171	185	20	D 21605	415	9	D 30735	339	3
A 64434	33	32	D 21606	415	8	D 30756	405	20
A 64436	27	21	D 25079	403	13	D 30756	411	18
A 64439	45	1	D 25079	403	16	D 30929	373	7
A 64818	433	7	D 25279	373	26	D 30929	405	2
A 64993	43	1	D 25279	403	11	D 30929	413	58
A 64994	13	4	D 25279	405	24	D 30930	373	6
A 65083	27	4	D 25279	407	34	D 30930	375	29C
A 65272	11		D 25279	409	72	D 30933	407	49
A 65544	111	2	D 25279	409	84	D 30933	409	80
A 65544	117	3	D 25279	409	91	D 30933	413	52
A 65734	13	3	D 25279	411	20	D 30933	415	6
A 65734	33	3	D 25280	373	16	D 30933	415	12
A 65757	25	20	D 25280	403	15	D 30933	417	6
A 66168	27	1	D 25280	403	25	D 30933	417	6
A 66295	31	10	D 25280	409	65	D 30933	417	6
A 66296	31	17	D 25280	409	75	D 30933	419	4
A 66328	15	31	D 25280	413	50	D 30933	419	4
A 66388	21	32	D 25826	55	1	D 30933	419	4
A 66404	21	16	D 26001	403	10	D 30933	419	8
A 66410	31	12	D 26259	333	15	D 31140	379	12
A 66531	25	2	D 26261	333	13	D 31140	409	68
A 66621	21	19	D 26262	333	8	D 31140	411	3
A 66737	19	25	D 26265	311	4	D 31140	413	45
A 66737	75	19	D 26265	311	14	D 31142	373	8
A 66742	17	1	D 26265	355	3	D 31142	375	28
A 66759	135		D 26265	355	3	D 31142	375	29B
A 66992	31	14	D 26266	309	11	D 31142	377	3
A 67121	13	25	D 26266	333	12	D 31142	377	3
A 67121	15	13	D 26267	309	6	D 31142	377	6
A 75294	31	13	D 26267	333	7	D 31409	319	22
A 75994	453	60	D 26268	309	5	D 31409	321	24
A 76656	33	34	D 26268	333	6	D 31409	323	40
A 77312	81	47	D 26270	309	2	D 31409	327	25
A 77313	81	48	D 26270	333	3	D 31410	313	17
A 77314	81	49	D 26368	415	13	D 31441	101	25
A 136406	89	16	D 26368	419	9A	D 31441	103	22
A 136406	91	16	D 26872	311	6	D 31511	341	3
A 136406	93	16	D 26872	311	16	D 31511	343	3
A 136902	41	28	D 26919	131	7	D 31512	373	19
A 138012	41	1	D 26919	375	32	D 31957	335	4
A 138149	13	22	D 26919	403	8	D 32481	47	11
A 138149	33	2	D 26919	407	36	D 32488	49	59
A 138330	19	19	D 26919	407	44	D 32489	49	60
A 138498	9	28	D 26919	407	53	D 32498	51	7
A 140120	11	1	D 26919	411	17	D 32500	51	5
A 140216	25	8	D 27833	25	7	D 32502	51	4

MODEL 680E CONSTRUCTION KING LOADER BACKHOE
NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
D 32506	51	14	D 37048	105	14	D 38296	395	23
D 32507	51	12	D 37049	105	15	D 38297	395	14
D 32510	51	17	D 37054	355	5	D 38298	395	12
D 32547	49	62	D 37062	309	13	D 38299	395	6
D 32865	341	14	D 37063	309	14	D 38302	395	5
D 32865	343	14	D 37064	309	17	D 38303	395	4
D 32865	357	3	D 37065	309	18	D 38305	395	11
D 32865	359	3	D 37066	311	1	D 38648	279	19
D 32919	375	29	D 37067	311	7	D 38648	281	30
D 33024	357	14	D 37067	311	17	D 38648	289	25
D 33024	359	14	D 37068	311	8	D 38648	291	25
D 33024	373	4	D 37068	311	18	D 38648	293	39
D 33024	403	2	D 37070	311	5	D 38648	297	34
D 33024	407	47	D 37070	311	15	D 38648	297	47
D 33024	411	7	D 37071	311	3	D 38648	297D	62
D 33024	423	6	D 37071	311	13	D 38663	225	31
D 33047	337	14	D 37071	355	4	D 38683	351	19
D 33047	339	14	D 37071	355	4	D 38683	353	19
D 33047	365	3	D 37072	311	11	D 38684	351	20
D 33047	367	3	D 37073	355	8	D 38825	299	8
D 33554	279	12	D 37075	311	10	D 38825	299	9
D 33554	281	22	D 37075	355	6	D 38825	301	8
D 33659	423	3	D 37075	355	6	D 38825	301	9
D 33856	303	10	D 37076	303	6	D 38943	361	4
D 33856	305	10	D 37076	305	6	D 38943	361	14
D 33857	303	7	D 37116	123	12	D 38943	363	3
D 33858	307	10	D 37116	269	42	D 38943	363	14
D 34033	13	8	D 37147	355	10	D 39093	417	8
D 34174	281	33	D 37148	311	8	D 39094	377	9
D 34340	349	3	D 37148	355	7	D 39094	417	9
D 34340	349B	3	D 37148	355	7	D 39140	287	6
D 34340	365	14	D 37150	311	5	D 39306	379	16
D 34340	367	14	D 37150	355	8	D 39311	379	13
D 34340	403	3	D 37151	311	9	D 39359	357	9
D 34340	423	7	D 37151	355	5	D 39359	365	9
D 34354	373	5	D 37152	303	3	D 39359	367	9
D 34354	413	47	D 37152	305	3	D 39717	325	8
D 34656	373	25	D 37153	303	1	D 40037	407	32A
D 34658	373	15	D 37153	305	1	D 40089	413	46
D 34664	373	12	D 37156	303	5	D 40236	271	29
D 34668	373	11	D 37156	305	5	D 40236	273	17
D 35090	63	18	D 37203	75	20	D 40236	279	11
D 35102	341	2	D 37392	409	79	D 40236	281	21
D 35102	343	2	D 37392	413	53	D 40236	291	14
D 35540	321	31	D 37443	407	50	D 40236	297B	8
D 35540	323	46A	D 37450	409	82	D 40236	379	35
D 36040	291	18	D 37464	415	4	D 40243	415	5
D 36264	57	19	D 37473	415	7	D 40243	419	3
D 36822	79	27A	D 37490	419	2	D 40354	355	12
D 36961	57	23	D 37495	409	86	D 40355	355	11
D 36968	1298	15	D 37495	411	4	D 40356	355	9
D 36968	129	16A	D 37495	415	11	D 40357	355	10
D 36969	345	9	D 37495	417	5	D 40358	311	9
D 36969	347	9	D 37495	417	5	D 40358	311	19
D 36969	369	8	D 37495	417	5	D 40471	295	7
D 36969	371	8	D 37495	419	3	D 40471	295	25
D 36970	341	9	D 37495	419	3	D 40471	297B	40
D 36970	343	9	D 37495	419	7	D 40471	297D	65
D 36971	337	9	D 37515	419	2	D 41427	101	8
D 36971	339	9	D 37516	419	6	D 41427	103	7
D 36971	349	9	D 37518	419	2	D 41472	405	16
D 36971	349B	9	D 37548	277	12A	D 41472	407	56
D 36971	351	8	D 37611	409	63	D 41472	411	13
D 36971	353	8	D 37642	415	10	D 41547	419	1

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

473

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
D 41548	419	1	D 47366	191	34	D 58576	415	14
D 41549	419	1	D 47366	195	27	D 58576	419	10
D 41550	419	5	D 47366	195	34	D 58577	415	14
D 41673	417	4	D 47366	199	27	D 58577	419	10
D 41674	417	3	D 47366	199	34	D 58592	415	15
D 41674	417	3	D 47366	203	26	D 58592	419	11
D 41674	417	3	D 47366	203	33	D 58593	415	
D 41675	417	2	D 47367	179	38	D 58593	419	11
D 41675	417	2	D 47367	183	38	D 59653	313	11
D 41675	417	2	D 47367	187	38	D 59654	313	13
D 41740	103	9	D 47557	355		D 59655	313	16
D 41740	411	27	D 47667	355	1	D 59686	433	6
D 41870	417	4	D 47667	355	1	D 59687	433	5
D 42106	375	37	D 48359	313	15	D 59689	433	11
D 42611	405	23	D 49161	351	15	D 59695	433	9
D 42911	403	6	D 49163	361	15	D 60159	403	4
D 43266	129	22	D 49163	363	15	D 60159	423	5
D 43266	129	22	D 49168	357	15	D 60615	433	23
D 43266	129B	22	D 49168	365	15	D 61368	403	29A
D 43266	139	13	D 49616	379		D 61933	285	24
D 43416	409	87	D 49617	379	9	D 62348	271	23
D 43417	409	88	D 49618	379	10	D 62348	273	23
D 43508	423	4	D 49996	73	1	D 62348	275	1
D 43536	437	3	D 50034	159	24	D 62348	277	1
D 43536	439	11	D 50034	161	24	D 62348	285	1
D 43536	441	3	D 50060	169	35	D 62348	313	1
D 43839	385	19	D 50780	377		D 63393	95	3
D 45256	59	44	D 51516	333	13	D 63395	95	5
D 45571	361	9	D 51530	333	14	D 63396	95	6
D 45571	363	9	D 51750	377	8	D 64050	411	27
D 45998	429	9	D 51750	417	8A	D 64050	441	10
D 46214	331	5	D 52275	411	26	D 65132	89	5
D 46216	331	4	D 52300	299	6	D 65132	91	5
D 46885	379	43	D 52300	301	6	D 65132	93	5
D 46910	345	2	D 52300	309		D 65139	127	10
D 46910	347	2	D 52319	309	12	D 65140	127	
D 46911	345	2	D 52564	461	14	D 65185	141	35
D 46911	347	2	D 52581	461	17	D 65190	89	12
D 46913	379	7	D 52642	415	1	D 65190	91	12
D 46914	379	11	D 53273	393	54	D 65190	93	12
D 46917	379	3	D 53273	397	65	D 65190	95	
D 46930	357	16	D 53297	127	4	D 66304	191	29
D 46930	365	16	D 53812	409	70	D 66304	195	29
D 46931	349B	15	D 54136	409	85	D 66304	199	29
D 46931	349	15	D 54218	409	89	D 66304	203	28
D 46931	361	16	D 54860	311	6	D 66305	191	
D 46931	363	16	D 54871	97	8	D 66305	195	
D 46955	379	24	D 54872	97	12	D 66305	199	
D 46957	379	23	D 55624	433	29	D 66305	203	
D 46973	379	5	D 55767	61	1	D 66306	191	
D 47204	351	16	D 55949	61	2	D 66306	195	
D 47204	365	17	D 56439	313	5	D 66306	199	
D 47205	349	16	D 56443	313	4	D 66306	203	
D 47205	349B	16	D 56444	313	12	D 66311	209	
D 47205	361	17	D 56445	313	8	D 66379	143	
D 47205	363	17	D 56455	313	14	D 66379	147	
D 47209	351	17	D 56781	285	9A	D 66381	161	32
D 47209	365	18	D 56883	433	2	D 66382	147	16
D 47210	349	17	D 56884	433	1	D 66382	153	10
D 47210	349B	17	D 56885	433	3	D 66383	153	19
D 47210	361	18	D 56886	433	4	D 66384	153	22
D 47210	363	18	D 56909	313	7	D 66385	153	
D 47366	187	37A	D 58499	415	13A	D 66386	153	
D 47366	191	27	D 58499	419	9	D 66388	143	17

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
D 66388	147	17	D 70619	451	25	D 72851	125	
D 66388	151	1	D 70620	451	17	D 72860	173	2
D 66388	153	1	D 70621	451	9	D 73626	189	
D 66389	147	18	D 70622	453	45	D 73626	191	
D 66389	153	9	D 70623	93	23	D 73626	195	
D 66390	147	6	D 70623	453	51C	D 73630	203	
D 66391	147	5	D 71193	85	11	D 73635	251	1
D 66391	157	1	D 71193	87	17	D 73639	197	
D 66393	157	14	D 71193	105		D 73639	199	
D 66394	157	16	D 71195	453	61	D 73640	213	12A
D 66395	157	25	D 71232	301	6	D 73640	217	12
D 66396	157	27	D 71232	301	7	D 73641	197	
D 66397	157	26	D 71232	305		D 73642	99	20
D 66398	157	8	D 71233	127B	41	D 73671	127	
D 66399	157	7	D 71280	205	27A	D 73688	201	
D 66400	157	4	D 71280	207	49	D 73689	201	6
D 66401	157	2	D 71280	209	27A	D 73692	189	
D 66402	157	35	D 71280	211	49	D 73692	193	
D 66403	157	36	D 71280	213	25	D 73700	147	
D 66404	157	34	D 71280	215	49	D 73700	153	
D 66409	163	41	D 71280	217	4	D 73700	161	
D 66414	153	27	D 71280	217	25	D 73701	143	4A
D 66415	205		D 71282	305	7	D 73701	147	4A
D 66415	209		D 71360	453B	73	D 73718	237	34
D 66415	213		D 71372	451	16	D 73728	157	41
D 66415	217		D 71417	99	11	D 73741	61	27
D 66416	209	7	D 71418	99	12	D 73741	63	25
D 66466	127B		D 71419	99	13	D 74357	189	11
D 66467	133		D 71420	99	14	D 74357	193	11
D 66468	133	26	D 71421	99	15	D 74357	197	11
D 66470	133		D 71423	99	1	D 74357	201	11
D 66472	247	58	D 71427	99	8	D 74358	189	11
D 66474	249	1	D 71455	57	6	D 74358	193	11
D 66475	125		D 71460	139	8	D 74358	197	11
D 66476	125	14	D 71461	157	29	D 74358	201	11
D 66477	125	21	D 71472	99	17	D 74359	189	11
D 66478	125		D 72740	237	33	D 74359	193	11
D 66479	125	19	D 72741	237	35	D 74359	197	11
D 66480	125	20	D 72747	157	37	D 74359	201	11
D 66499	453B	70	D 72748	157	30	D 74360	189	11
D 70586	127	8A	D 72749	157	32	D 74360	193	11
D 70592	451	4	D 72750	157	33A	D 74360	197	11
D 70593	455	18	D 72751	157	7A	D 74360	201	11
D 70595	453	35	D 72752	157	38	D 74361	189	11
D 70596	453	34	D 72753	147	5A	D 74361	193	11
D 70597	453	39	D 72753	157	42	D 74361	197	11
D 70598	451	32	D 72754	139	4A	D 74361	201	11
D 70599	451	33	D 72755	167	1	D 74362	189	11
D 70600	451	8	D 72766	189		D 74362	193	11
D 70601	451	30	D 72831	249	1	D 74362	197	11
D 70602	451	31	D 72832	129	4	D 74362	201	11
D 70603	451	28	D 72832	129	4	D 74363	189	11
D 70604	451	10	D 72832	129B	4	D 74363	193	11
D 70605	451	5	D 72832	129	8	D 74363	197	11
D 70606	451	12	D 72832	129	8	D 74363	201	11
D 70607	451	13	D 72832	129B	8	D 74364	189	11
D 70609	453	50	D 72836	453	56	D 74364	193	11
D 70610	453B	72	D 72837	453	44	D 74364	197	11
D 70612	453	41	D 72838	259	4	D 74364	201	11
D 70613	451	16	D 72839	259	8	D 74365	189	11
D 70615	451	19	D 72840	259	9	D 74365	193	11
D 70616	451	20	D 72848	99		D 74365	197	11
D 70617	451	23	D 72849	99	6	D 74365	201	11
D 70618	451	24	D 72850	99	7	D 74366	189	11

MODEL 680E CONSTRUCTION KING LOADER BACKHOE
NUMERICAL INDEX

475

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
D 74366	193	11	D 81592	145	46	F 43072	445	50
D 74366	197	11	D 81592	149	46	F 43073	445	54
D 74366	201	11	D 82776	249	1	F 43086	445	63
D 74444	63	13	D 83067	201	14	F 43091	445	64
D 74949	135	5	D 83068	201	14	F 43092	445	65
D 75428	433	23	D 95141	129B	14	F 43094	439	25
D 75819	423	22D	D 95141	129	15A	F 43095	443	7
D 75820	423	22C	D 95142	345	7	F 43096	443	3
D 75821	423	22A	D 95142	347	7	F 43097	443	6
D 77557	207	54	D 95142	369	6	F 43117	439	24
D 77557	211	54	D 95142	371	6	F 43138	443	14
D 77557	215	54	D 95143	341	7	F 43217	447	5
D 77558	207	56	D 95143	343	7	F 43227	443	8
D 77558	211	56	D 95144	337	7	F 43239	447	15
D 77558	215	56	D 95144	339	7	F 43241	447	27
D 77623	183		D 95144	349B	7	F 43266	453B	66A
D 77625	217	15	D 95144	349	7	F 43282	439	5A
D 77626	207	51	D 95144	351	6	F 43283	439	23
D 77626	211	51	D 95144	353	6	F 43508	109	19
D 77626	215	51	D 95145	357	7	F 43527	445	42A
D 77626	217	5A	D 95145	359	7	F 43577	445	61A
D 77627	207	50	D 95145	365	7	F 44453	99	2
D 77627	211	50	D 95145	367	7	F 44455	99	5
D 77627	215	50	D 95146	361	7	F 44456	99	21
D 77627	217	5	D 95146	363	7	F 54095	447	6
D 77629	207	48	D 95182	379	2	F 62020	217	16
D 77629	211	48	D 95231	265	17	F 62075	257	27
D 77629	215	48	E 73655	57	4	F 62075	259	27
D 77629	217	3	E 74266	331	3	F 62114	307	15
D 77650	111		E 88928	303	12	F 62245	447	16
D 78057	291	17A	E 88928	305	12	F 63532	443	9
D 78345	107	26	F 8235	313	6	F 63532	453	51
D 78347	201		F 9740	191	28	F 63580	445	42
D 78348	185		F 9740	195	28	F 63860	443	38
D 78348	187		F 9740	199	28	F 63925	443	29
D 78370	453	50F	F 9740	203	27	F 82943	127	
D 78400	139	6	F 12215	297	39A	F 89824	443	25
D 78401	159		F 12215	297D	54	F 89824	451	18
D 78401	163		F 13404	447	32	F 93104	443	12
D 78402	159	35A	F 19633	127	17	F 93455	99	
D 78402	163	35A	F 19634	127	18	F 93538	437	1
D 78403	159	36A	F 37914	159	30	F 93554	439	4
D 78403	163	36A	F 37914	161	30	F 93555	439	5
D 78404	159	37A	F 40807	405	17	F 93569	439	1
D 78404	163	37A	F 40807	407	57	F 93569	443	1
D 78405	169	32	F 40807	411	14	F 93573	443	23
D 80336	157	5A	F 41514	393	55	F 93574	443	24
D 80346	433	15A	F 41514	397	66	F 93575	443	30
D 80409	307	21A	F 42201	447	13	F 93576	443	31
D 80410	307	24A	F 42213	447	3	F 93577	443	33
D 80411	307	3A	F 42214	447	4	F 93578	443	34
D 80412	307	1A	F 42911	439	2	F 93579	443	26
D 80516	235	17D	F 42912	439	3	F 93580	443	37
D 80609	245	36	F 42980	443	32	F 93604	447	1
D 80610	245	38	F 42982	443	28	F 93630	439	13
D 80611	245	37	F 42983	445	57	F 93631	439	14
D 80612	247	52	F 42990	445	46	F 93633	447	2
D 80613	247	52	F 42990	453	40	F 93633	453	58
D 80614	247	52	F 43064	445	47	F 93651	447	24
D 80615	247	52	F 43065	445	52	F 93652	447	25
D 80617	243		F 43066	445	51	F 93658	447	14
D 80618	243		F 43069	445	61	F 93662	447	29
D 80619	243		F 43070	443	40	F 93663	447	30
D 80620	243		F 43071	445	49	G 10964	155	13

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
G 10964	155	24	G 33081	329	11	G 33803	327	6
G 10964	157	12	G 33084	319	13	G 33803	329	6
G 10964	157	21	G 33084	321	13	G 33831	349	13
G 10964	157	31	G 33084	327	13	G 33964	315	10
G 11204	9	35	G 33084	329	13	G 33964	315	27
G 13075	143	2	G 33090	319	19	G 33965	315	11
G 13075	147	2	G 33090	321	21	G 33965	315	28
G 13075	159	26	G 33090	323	37	G 34000	315	9
G 13075	161	26	G 33090	327	22	G 34000	315	26
G 15214	135	8	G 33091	319	21	G 34001	315	8
G 15215	135	6	G 33091	321	23	G 34001	315	25
G 15457	337	10	G 33091	323	39	G 34052	321	
G 15457	339	10	G 33091	327	24	G 34256	361	2
G 32122	341	11	G 33092	319	23	G 34302	345	8
G 32122	343	11	G 33092	321	25	G 34302	347	8
G 32122	345	11	G 33092	323	41	G 34302	369	7
G 32122	347	11	G 33092	327	26	G 34302	371	7
G 32122	369	10	G 33102	315	2	G 34307	361	8
G 32122	371	10	G 33102	315	18	G 34307	363	8
G 32126	337	11	G 33102	317	12	G 34322	337	8
G 32126	339	11	G 33104	317	14	G 34322	339	8
G 32176	351	10	G 33105	317	15	G 34322	349B	8
G 32176	353	10	G 33106	317	16	G 34322	349	8
G 32176	357	11	G 33108	315	7	G 34322	351	7
G 32176	359	11	G 33108	315	24	G 34322	353	7
G 32176	365	11	G 33108	317	1	G 34323	361	1
G 32176	367	11	G 33110	317	3	G 34324	361	13
G 32284	3498	11	G 33112	317	5	G 34324	363	13
G 32284	349	11	G 33113	317	7	G 34328	345	4
G 32284	361	11	G 33121	329	1	G 34328	347	
G 32284	363	11	G 33122	329	15	G 34328	369	
G 32303	337	20	G 33124	315	29	G 34328	371	
G 32303	339	20	G 33150	345	15	G 34329	361	
G 32303	341	20	G 33150	369	13	G 34329	363	
G 32303	343	20	G 33151	341		G 34331	351	
G 32317	345	20	G 33151	345		G 34331	353	
G 32317	347	20	G 33151	369		G 34332	345	
G 32317	369	18	G 33159	351	14	G 34332	369	
G 32317	371	18	G 33167	337	15	G 34333	361	
G 32351	349	19	G 33237	337		G 34333	363	
G 32351	3498	19	G 33239	357		G 34397	349	
G 32351	351	22	G 33241	321	22	G 34397	349B	
G 32351	353	22	G 33331	341	15	G 34426	369	1
G 32351	357	20	G 33467	345	13	G 34427	369	2
G 32351	359	20	G 33467	347	13	G 34427	371	2
G 32351	361	20	G 33562	341	1	G 34432	369	12
G 32351	363	20	G 33563	341	13	G 34432	371	12
G 32351	365	20	G 33563	343	13	G 34455	327	23
G 32351	367	20	G 33573	319	12	G 34456	327	15
G 33075	319	8	G 33573	321	12	G 34457	327	17
G 33075	321	8	G 33573	327	12	G 34458	323	49
G 33075	327	8	G 33573	329	12	G 34458	325	4
G 33075	329	8	G 33604	337	13	G 34458	325	13
G 33077	319	9	G 33604	339	13	G 34458	327	16
G 33077	321	9	G 33634	349	14	G 34460	321	1
G 33077	327	9	G 33634	349B	14	G 34463	319	7
G 33077	329	9	G 33686	319	14	G 34463	321	7
G 33080	319	10	G 33686	321	14	G 34463	327	7
G 33080	321	10	G 33686	327	14	G 34463	329	7
G 33080	327	10	G 33686	329	14	G 34586	317	4
G 33080	329	10	G 33770	345	1	G 34594	351	
G 33081	319	11	G 33771	345	1	G 34595	321	
G 33081	321	11	G 33803	319	6	G 34595	323	
G 33081	327	11	G 33803	321	6	G 34620	357	8

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

477

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
G 34620	359	8	G 34875	353	3	G 100710	339	17
G 34620	365	8	G 34877	351	2	G 100711	339	18
G 34620	367	8	G 34877	353	2	G 100776	345	
G 34621	341	8	G 34880	351	1	G 100776	347	
G 34621	343	8	G 34882	351	18	G 100777	341	
G 34629	337		G 34885	351	21	G 100777	343	
G 34629	339		G 34885	353	21	G 100778	337	
G 34630	337		G 34886	119	48	G 100778	339	
G 34633	341		G 34886	129	1	G 100778	349	
G 34633	343		G 34886	131	16	G 100778	3498	
G 34635	357		G 34895	325	10	G 100778	351	
G 34635	359		G 34937	323	47	G 100778	353	
G 34635	365		G 34937	325	5	G 100778	369	
G 34635	367		G 34937	325	14	G 100778	371	
G 34636	365		G 34937	327	32	G 100779	357	
G 34643	341		G 34938	323	50	G 100779	359	
G 34644	3498		G 34938	325	3	G 100779	365	
G 34644	349		G 34938	325	12	G 100779	367	
G 34657	327		G 34938	327	33	G 100780	361	
G 34658	327	1	G 34941	327	1	G 100780	363	
G 34659	319	20	G 35540	319	29	G 100959	319	28
G 34659	323	38	G 35540	327	31A	G 100959	321	30
G 34662	365	1	G 35540	329	18	G 100959	323	46
G 34663	337	1	G 36905	267	20	G 100959	327	31
G 34664	337	1	G 39359	359	9	G 100959	329	16
G 34669	271	27	G 46146	49	66	G 101021	129	
G 34669	315	1	G 46146	49	73	G 101220	343	1
G 34670	315	17	G 46147	333	15	G 101226	347	1
G 34671	319	1	G 46150	319	24	G 101227	347	1
G 34672	319		G 46150	321	26	G 101254	367	1
G 34675	315	12	G 46150	323	42	G 101256	359	1
G 34691	129	2	G 46150	327	27	G 101259	371	1
G 34691	129	2	G 46907	9	11	G 101309	353	14
G 34691	129B	2	G 46907	33	5	G 101348	363	1
G 34695	129B	10	G 49080	39	5	G 101684	367	2
G 34695	129	10	G 49401	27	17	G 101686	359	2
G 34695	129	10	G 49402	27	17	G 101688	363	2
G 34710	365	2	G 100004	361	1	G 101837	129B	20
G 34714	365	13	G 100005	361	3	G 102139	339	2
G 34714	367	13	G 100183	315	17	G 102140	339	1
G 34716	337	2	G 100191	315	1	G 102214	353	1
G 34717	337	2	G 100192	327	1	G 102245	353	18
G 34775	351	12	G 100193	329	1	G 102276	3498	1
G 34775	353	12	G 100194	321	1	G 102277	3498	2
G 34819	129B		G 100195	319	1	G 102280	3498	13
G 34820	129		G 100440	353	16	G 102285	353	15
G 34820	129B		G 100440	359	17	G 102285	359	16
G 34821	357	1	G 100440	367	17	G 102285	367	16
G 34822	357	2	G 100442	347	15	G 102286	339	16
G 34827	357		G 100442	371	13	G 102288	343	16
G 34829	349	1	G 100444	343	17	G 102288	347	16
G 34830	349	2	G 100444	347	17	G 102288	371	14
G 34843	325	1	G 100444	371	15	G 102401	353	
G 34844	325		G 100448	353	17	G 102402	339	
G 34846	325	9	G 100448	359	18	G 102404	347	
G 34848	357	13	G 100448	367	18	G 102404	371	
G 34848	359	13	G 100449	343	18	G 102405	343	
G 34854	351	13	G 100449	347	18	G 102412	359	
G 34854	353	13	G 100449	371	16	G 102412	367	
G 34862	319		G 100674	129	1	G 102602	129B	1
G 34862	321		G 100686	359	15	G 102604	129B	13
G 34862	323		G 100686	367	15	H 275784	61	28
G 34862	327		G 100694	339	15	H 275784	63	26
G 34875	351	3	G 100704	343	15	L 10353	111	17

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 10354	221	5	L 14794	297B	41	L 30477	153	
L 10499	101	24	L 14818	231	10	L 30479	143	
L 10499	103	21	L 14818	253	1	L 30479	149	
L 10499	105	3	L 15043	425	64	L 30479	151	
L 11172	145	41	L 15056	79	30	L 30479	153	
L 11172	149	41	L 15301	431	3	L 30483	143	36
L 11182	395	32	L 16015	405	10	L 30483	149	36
L 11342	75	21	L 16536	231	6	L 30483	151	3
L 11342	91	32	L 16692	267		L 30483	153	3
L 11342	93	30	L 17421	423	8	L 30484	143	37
L 11345	83	29	L 17627	65	23	L 30484	149	37
L 11352	75	6	L 17788	123	8	L 30484	151	2
L 11494	423	2	L 17788	269	44	L 30484	153	2
L 11541	31	23	L 18331	293	43	L 30486	143	15
L 11541	65	21A	L 18331	295	48	L 30486	147	15
L 11541	65	31	L 18331	297B	5	L 30487	143	26
L 11541	89	4	L 25930	295	20	L 30487	147	26
L 11541	91	4	L 25930	297B	34	L 30488	143	27
L 11541	93	4	L 26312	285	9	L 30488	147	27
L 11541	101	4	L 26373	175	34	L 30489	143	28
L 11541	103	4	L 30225	159	2	L 30489	147	28
L 11541	111	16	L 30230	159		L 30491	155	4
L 11541	119	37	L 30230	161		L 30505	107	27
L 11541	165	10	L 30233	159	21	L 30505	107	27
L 11541	227	26A	L 30233	161	21	L 30687	333	14
L 11541	237	27A	L 30236	159	8	L 30694	151	
L 11541	385	2	L 30236	161	8	L 30694	153	
L 11541	387	2	L 30237	143	13	L 30737	183	31
L 11778	61	14	L 30237	147	13	L 30737	185	31
L 11778	69	13	L 30245	143	34	L 30737	191	23
L 11778	109	9	L 30245	149	34	L 30737	195	23
L 11779	61	15	L 30245	151	8	L 30737	197	23
L 11779	69	12	L 30245	151	34	L 30737	203	20
L 11779	85	11A	L 30245	153	8	L 30744	307	1
L 11779	87	17A	L 30245	153	29	L 30744	309	1
L 11779	109	10	L 30255	155	28	L 30866	111	23
L 11917	131	6	L 30397	193	10A	L 30900	97	9
L 11917	407	43	L 30440	151	17	L 30902	97	5
L 12437	71	23	L 30440	153	16	L 30904	97	3
L 12479	175	18	L 30443	309	8	L 30906	97	4
L 12586	221	26	L 30443	309	16	L 30907	97	2
L 12586	223	22	L 30443	333	10	L 30908	97	11
L 12627	231	20	L 30444	309	9	L 30909	97	10
L 12630	231	24	L 30444	309	15	L 30910	97	13
L 12630	255	1	L 30444	333	11	L 30972	143	5
L 13194	65	6	L 30446	271	2	L 30972	155	1
L 13194	77	58	L 30446	273	2	L 30973	155	8
L 13267	57	25	L 30446	299	10	L 30974	155	9
L 13268	57	24	L 30446	299	11	L 31354	253	10
L 13271	225	30	L 30446	301	10	L 31360	251	
L 13421	131	20	L 30446	301	11	L 31362	251	7
L 13524	247	56	L 30453	303	14	L 31364	251	5
L 13526	247	66	L 30453	305	14	L 31367	251	2
L 13530	225	22	L 30454	303	22	L 31370	251	30
L 13530	255	12	L 30454	305	22	L 31371	251	31
L 13707	265	21	L 30455	303	18	L 31372	251	32
L 13765	85	25	L 30455	305	18	L 31373	251	33
L 13765	87	4	L 30456	303	20	L 31374	251	29
L 13766	113	13	L 30456	305	20	L 31375	251	25
L 14218	59	31	L 30458	303	23	L 31376	251	27
L 14227	71	17	L 30458	305	23	L 31377	251	28
L 14552	77	38	L 30470	159	29	L 31378	251	26
L 14552	83	15	L 30470	161	29	L 31379	251	24
L 14794	295	25A	L 30477	151		L 31380	251	

MODEL 680E CONSTRUCTION KING LOADER BACKHOE
NUMERICAL INDEX

479

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 31381	251	23	L 31690	209	27	L 32530	241	43
L 31382	251	13	L 31690	213	5	L 32531	241	51
L 31383	251	18	L 31776	141		L 32532	241	50
L 31384	251	14	L 31781	139	25	L 32554	239	
L 31385	251	17	L 31797	255	20	L 32556	239	6
L 31386	251	16	L 31798	253	8	L 32560	239	4
L 31387	251	15	L 31798	255	22	L 32561	239	3
L 31389	255	8	L 31800	255	16	L 32562	239	12
L 31390	255	7	L 31802	255	14	L 32563	241	57
L 31391	255	4	L 31806	251		L 32563	249	1
L 31392	255	10	L 31808	249		L 32569	241	
L 31393	255	11	L 32084	151	13	L 32570	239	
L 31394	255	5	L 32084	153	13	L 32571	239	
L 31395	255	6	L 32092	335	25	L 32572	239	
L 31396	255	2	L 32093	335	28	L 32573	239	
L 31397	255	3	L 32094	335		L 32574	239	28
L 31404	243		L 32096	335	6	L 32579	241	32
L 31406	239	20	L 32096	335	14	L 32580	239	
L 31406	243	16	L 32096	335	30	L 32581	239	
L 31407	239	19	L 32097	335	7	L 32582	241	
L 31407	243	17	L 32097	335	15	L 32583	241	
L 31408	243	14	L 32097	335	31	L 32585	241	55
L 31409	243	13	L 32098	335	22	L 32586	241	54
L 31412	239	21	L 32099	335	10	L 32588	239	2
L 31412	243	18	L 32099	335	19	L 32589	241	33
L 31413	243	19	L 32100	335	11	L 32590	239	
L 31414	245	49	L 32100	335	20	L 32591	239	
L 31426	245	31	L 32101	335	9	L 32657	109	8
L 31427	245	30	L 32101	335	18	L 32658	109	4
L 31437	243	27	L 32102	335	21	L 32658	109	13
L 31440	243	12	L 32104	335	16	L 32659	109	
L 31441	243	11	L 32107	335	12	L 32659	109	
L 31442	243	10	L 32109	335		L 32676	251	3
L 31451	243	4	L 32111	335	2	L 32680	271	3A
L 31456	247	57	L 32119	143	6	L 32680	273	3A
L 31457	247	61	L 32120	151	12	L 32680	299	12
L 31457	263	1	L 32120	153	12	L 32680	299	13
L 31458	239	5	L 32121	151	11	L 32680	301	12
L 31458	241	39	L 32121	153	11	L 32680	301	13
L 31458	241	52	L 32122	159	10	L 32745	143	12
L 31459	251	19	L 32122	159	31	L 32745	147	12
L 31465	251	8	L 32122	161	10	L 32746	143	11
L 31497	233	28	L 32122	161	31	L 32746	147	11
L 31498	233	29	L 32213	105		L 32824	247	53
L 31499	233	33	L 32214	105		L 32825	247	53
L 31499	249	12	L 32256	105	24	L 32826	247	53
L 31527	249	18	L 32257	105	18	L 32827	247	53
L 31528	249		L 32320	335	32	L 32878	245	37
L 31529	249	16	L 32332	253	9	L 32879	245	36
L 31530	249	17	L 32333	253	11	L 32880	243	
L 31531	249	11	L 32334	253	12	L 32881	243	
L 31532	249	10	L 32335	253	6	L 32885	243	20
L 31533	249		L 32336	253	5	L 32886	245	47
L 31540	249	14	L 32337	253	4	L 32887	245	46
L 31541	249	13	L 32338	253	2	L 32888	245	44
L 31557	81	51	L 32423	139		L 32889	245	43
L 31689	205	4	L 32515	241	37	L 32890	247	52
L 31689	205	26	L 32516	241	36	L 32891	247	52
L 31689	209	4	L 32517	239		L 32892	247	52
L 31689	209	26	L 32519	239	24	L 32893	247	52
L 31689	213	4	L 32526	241	47	L 32894	245	
L 31690	205	5	L 32527	241	45	L 32895	245	
L 31690	205	27	L 32528	241	42	L 32896	245	
L 31690	209	5	L 32529	241	41	L 32897	245	

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 32898	243	9	L 33337	169	13	L 33691	179	37
L 32899	243		L 33338	169	18	L 33691	183	37
L 32904	243		L 33338	169	23	L 33692	179	37
L 32905	243		L 33339	169	16	L 33692	183	37
L 32906	243		L 33340	169	23	L 33693	179	37
L 32907	243		L 33341	169	23	L 33693	183	37
L 32909	243	6	L 33342	169	23	L 33702	233	32
L 32910	243	24	L 33342	169	25	L 33705	143	20
L 32911	243	24	L 33343	169	17	L 33705	147	20
L 32912	243	24	L 33344	169	24	L 33720	245	33
L 32913	243	24	L 33345	169	26	L 33721	245	33
L 32914	243	8	L 33346	169	27	L 33722	245	33
L 32915	243	5	L 33347	169	36	L 33723	245	33
L 32916	243	3	L 33348	171	12	L 33827	89	25
L 32917	243	2	L 33349	171	10	L 33827	91	25
L 32918	223	3A	L 33350	171	6	L 33827	93	25
L 32918	245	38	L 33351	171	7	L 33854	159	15
L 32920	247	68	L 33352	169	7	L 33854	161	15
L 32921	247	67	L 33352	171	8	L 33891	159	38
L 32924	251	12	L 33354	171	11	L 33891	163	38
L 32925	251	6	L 33355	171	15	L 33892	159	32
L 32927	251	1	L 33356	169	5	L 33959	331	6
L 32930	263	2	L 33356	171	5	L 33986	173	17
L 33145	261		L 33357	169	3	L 35091	189	1
L 33145	263		L 33357	171	3	L 35091	193	1
L 33146	261	10	L 33358	169	4	L 35091	197	
L 33146	263	10	L 33358	171	4	L 35091	201	1
L 33150	261	15	L 33360	169	1	L 35220	177	17
L 33150	263	15	L 33360	171	1	L 35220	181	17
L 33151	261	8	L 33361	169	1	L 35220	185	17
L 33151	263	8	L 33361	171	1	L 35221	177	16
L 33152	261	13	L 33362	169	1	L 35221	181	16
L 33152	263	13	L 33362	171	1	L 35221	185	16
L 33153	261	11	L 33363	169	1	L 35223	177	
L 33153	263	11	L 33363	171	1	L 35223	181	
L 33154	261	14	L 33364	169	34	L 35223	185	
L 33154	263	14	L 33366	167	9	L 35224	177	21
L 33156	261	12	L 33366	173	16	L 35224	181	21
L 33156	263	12	L 33367	167	12	L 35224	185	21
L 33157	261		L 33368	173	9	L 35226	177	16A
L 33157	263		L 33369	173	7	L 35226	181	16A
L 33159	261	6	L 33370	173	14	L 35226	185	16A
L 33159	263	6	L 33371	173	13	L 35228	177	
L 33160	261	5	L 33372	173	8	L 35228	181	
L 33160	263	5	L 33373	173	10	L 35228	185	
L 33161	261	4	L 33374	173	12	L 35230	177	18
L 33161	263	4	L 33375	173	6	L 35230	181	18
L 33162	261	3	L 33376	167	13	L 35230	185	18
L 33162	263	3	L 33377	167	10	L 35231	177	27
L 33174	243	22	L 33378	173	3	L 35231	181	27
L 33194	105	5	L 33379	173	4	L 35231	185	27
L 33210	69	4	L 33380	173	5	L 35232	177	13
L 33316	255	24	L 33395	169	10	L 35232	181	13
L 33320	159	23	L 33396	169	11	L 35232	185	13
L 33320	161	23	L 33397	169	21	L 35233	177	31
L 33326	151	16	L 33398	169	22	L 35233	183	31
L 33326	151	33	L 33402	169	33	L 35233	207	55
L 33330	167	5	L 33426	141	33	L 35233	211	55
L 33331	167	6	L 33649	257	19	L 35233	215	55
L 33332	169	15	L 33649	259	19	L 35234	177	28
L 33333	169		L 33668	193	8A	L 35234	181	28
L 33334	169		L 33674	189	7	L 35234	185	28
L 33335	169	14	L 33674	193	7	L 35235	177	
L 33336	169	12	L 33674	197	7	L 35235	181	

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

481

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 35235	185		L 35577	213	27	L 35602	211	44
L 35236	177		L 35577	217	27	L 35602	215	45
L 35236	181		L 35578	205	31	L 35602	219	45
L 35236	185		L 35578	209	31	L 35603	169	32
L 35237	177	6	L 35578	213	29	L 35605	257	
L 35237	181	6	L 35578	217	29	L 35605	259	
L 35237	185	6	L 35580	177	22	L 35606	257	24
L 35280	61	4	L 35580	181	22	L 35606	259	24
L 35281	61	7	L 35580	185	22	L 35608	257	28
L 35282	61	10	L 35584	189	6	L 35608	259	28
L 35283	61		L 35584	193	6	L 35609	257	10
L 35314	169	15A	L 35584	197	6	L 35609	259	10
L 35316	69	9	L 35585	189	3	L 35610	257	14
L 35403	333	10	L 35585	193	3	L 35610	259	14
L 35408	261	2	L 35585	197	3	L 35612	257	
L 35409	261	1	L 35585	201	3	L 35612	259	
L 35410	241	58	L 35587	183	35	L 35613	257	
L 35411	241	64	L 35588	205	7	L 35613	259	
L 35492	433	10	L 35588	217	11A	L 35614	257	17
L 35545	139	5	L 35589	205	8	L 35614	259	17
L 35559	205	3	L 35589	209	8	L 35615	257	16
L 35559	205	25	L 35589	213	7	L 35615	259	16
L 35559	209	3	L 35589	217	7	L 35618	257	23
L 35559	209	25	L 35590	205	9	L 35618	259	23
L 35559	213	3	L 35590	209	9	L 35620	257	6
L 35560	205	2	L 35590	213	8	L 35620	259	6
L 35560	205	28	L 35590	217	8	L 35621	257	2
L 35560	207	47	L 35591	205	11A	L 35621	259	2
L 35560	209	2	L 35591	209	11A	L 35622	257	22
L 35560	209	28	L 35591	213	11	L 35622	259	22
L 35560	211	47	L 35591	217	11	L 35623	257	6A
L 35560	213	2	L 35592	207	42	L 35623	259	6A
L 35560	213	26	L 35592	211	42	L 35624	257	4
L 35560	215	47	L 35592	215	43	L 35625	257	9
L 35560	217	2	L 35592	219	43	L 35626	257	15
L 35560	217	26	L 35593	207	41	L 35626	259	15
L 35561	205		L 35593	211	41	L 35629	433	8
L 35561	209		L 35593	215	42	L 35638	333	2
L 35561	213		L 35593	219	42	L 35642	333	18
L 35563	205		L 35594	207	39	L 35643	333	17
L 35563	213		L 35594	211	39	L 35645	333	4
L 35563	217		L 35594	215	40	L 35646	333	5
L 35564	205	12	L 35594	219	40	L 35647	333	6
L 35564	209	12	L 35595	207	40	L 35648	333	3
L 35564	213	12	L 35595	211	40	L 35649	333	7
L 35565	205	15	L 35595	215	41	L 35650	333	9
L 35565	209	15	L 35595	219	41	L 35653	125	29
L 35565	213	15	L 35597	207	38	L 35654	125	6
L 35566	205	13	L 35597	211	38	L 35654	125	30
L 35566	209	13	L 35597	215	39	L 35655	125	31
L 35566	213	13	L 35597	219	39	L 35657	125	
L 35566	217	13	L 35598	207	35	L 35657	125	
L 35567	205	14	L 35598	211	35	L 35675	125	5
L 35567	209	14	L 35598	215	36	L 35675	125	24
L 35567	213	14	L 35598	219	36	L 35677	143	
L 35567	217	14	L 35600	207	36	L 35677	151	
L 35572	207		L 35600	211	36	L 35677	159	
L 35572	211		L 35600	215	37	L 35680	159	
L 35572	215		L 35600	219	37	L 35680	161	
L 35572	219		L 35601	207	43	L 35681	159	35
L 35573	213	32	L 35601	211	43	L 35681	163	35
L 35573	217	32	L 35601	215	44	L 35683	159	37
L 35577	205	29	L 35601	219	44	L 35683	163	37
L 35577	209	29	L 35602	207	44	L 35684	143	16

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 35684	151	10	L 35957	179		L 36068	125	1
L 35685	151		L 35957	183		L 36068	127	
L 35686	151	14	L 35958	205		L 36069	127	23
L 35687	151	27	L 35958	209		L 36070	127	22
L 35687	153	26	L 35958	213		L 36072	1278	40
L 35688	151		L 35958	217		L 36074	1278	44
L 35690	151	20	L 35959	205		L 36075	1278	37
L 35690	151	28	L 35959	209		L 36076	1278	36
L 35691	151	21	L 35959	213		L 36077	311	4
L 35691	153	21	L 35959	217		L 36080	117	20
L 35692	143	18	L 35960	205	16	L 36081	463	
L 35692	151	9	L 35960	209	16	L 36104	191	16
L 35694	155	30	L 35960	213	16	L 36104	195	16
L 35696	155	11	L 35961	205	18	L 36104	197	16
L 35705	205	33	L 35961	209	18	L 36104	201	16
L 35705	209	33	L 35961	213	18	L 36105	191	16
L 35705	213	31	L 35961	217	18	L 36105	195	16
L 35705	217	31	L 35962	205	19	L 36105	197	16
L 35706	205	20	L 35962	209	19	L 36105	201	16
L 35706	209	20	L 35962	213	19	L 36106	191	16
L 35706	213	20	L 35962	217	19	L 36106	195	16
L 35706	217	20	L 35967	333	12	L 36106	197	16
L 35711	233	27	L 35967	333	16	L 36106	201	16
L 35717	455	17	L 35975	57	3	L 36164	465	
L 35737	451	18A	L 35976	57	5	L 36175	465	
L 35738	451	18B	L 35977	179	40	L 36180	465	
L 35743	443	9	L 35986	453	48	L 36185	81	
L 35747	451	11	L 35989	335	26	L 36187	57	4A
L 35748	453	38	L 35990	335		L 39948	243	21
L 35753	453	47A	L 35991	335		L 40164	65	30
L 35759	453B	68	L 35992	335		L 40164	67	39
L 35760	97	7	L 36002	107	26	L 40247	163	44
L 35801	453B	67	L 36008	125	3	L 40248	65	9
L 35819	453B	69	L 36009	125		L 40703	71	24
L 35834	453	52	L 36015	127		L 40703	73	21
L 35835	453	53	L 36025	235	17A	L 40793	77	44
L 35840	453B	71	L 36036	299	5	L 43266	417	
L 35919	191	33	L 36036	299	5	L 43412	417	4
L 35919	195	33	L 36036	301	5	L 43582	265	15
L 35919	199	33	L 36036	301	5	L 43737	85	10
L 35919	203	32	L 36036	307		L 43737	87	16
L 35924	191		L 36037	299	6	L 43737	105	
L 35924	195		L 36037	299	7	L 43738	85	9
L 35924	197		L 36037	303		L 43738	87	15
L 35925	191		L 36038	307	19	L 43738	105	
L 35925	195		L 36039	307	16	L 43743	75	2
L 35925	197		L 36040	307	17	L 43743	105	
L 35927	189		L 36041	307	21	L 45037	73	30
L 35927	193		L 36042	307	23	L 45149	101	
L 35927	197		L 36043	307	24	L 45149	103	
L 35931	191	38	L 36044	307	20	L 45471	117	5
L 35931	195	38	L 36045	307	14	L 46009	73	31
L 35931	199	38	L 36046	307	13	L 46110	235	5
L 35931	203	37	L 36047	307	9	L 46372	263	
L 35943	79	14	L 36048	307	5	L 46411	261	
L 35944	79	15	L 36049	307	12	L 46821	431	26
L 35945	79	16	L 36050	307	22	L 47422	407	43A
L 35946	79	13	L 36051	307	2	L 47424	407	43B
L 35947	79	17	L 36052	303	11	L 47461	405	7
L 35948	79	10	L 36052	305	11	L 47700	405	9
L 35949	79	18	L 36053	303	17	L 47759	139	4
L 35950	79	11	L 36053	305	17	L 47989	83	2
L 35953	79	12	L 36054	303	21	L 47989	113	1
L 35954	79	7	L 36054	305	21	L 47989	115	1

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 47989	225	16	L 53600	251		L 54790	285	8
L 48002	71	8	L 53601	227	21	L 55000	423	1
L 48003	71	3	L 53601	251		L 55009	299	1
L 48004	71	1	L 53612	227	26	L 55010	299	1
L 48104	71	26	L 53612	227	33	L 55059	231	18
L 48104	73	20A	L 53613	227	26	L 55059	233	
L 48104	233	40	L 53615	237	27	L 55143	289	2A
L 48191	235	11	L 53615	237	30	L 55247	121	1
L 48192	235	5	L 53636	381	15	L 55247	123	1
L 48234	169	39	L 53636	383	17	L 55247	267	14
L 48339	169	38	L 53636	389	1	L 55247	335	1
L 48345	139	29	L 53639	251	35	L 55254	57	17
L 48480	79	29	L 53739	225	26	L 55258	57	12
L 48480	235	15	L 53855	379	39	L 55262	231	14
L 48498	141	38	L 54087	435	41	L 55306	271	16
L 48674	71	2	L 54114	231	22	L 55306	273	16
L 48749	165	6	L 54129	403	17	L 55306	403	32
L 48750	165	9	L 54130	131	18	L 55370	103	3
L 48971	89	20	L 54140	231	21	L 55399	265	3
L 48971	91	20	L 54268	139	11	L 55399	275	17
L 48971	93	20	L 54268	167		L 55406	423	13
L 48971	97	1	L 54268	169		L 55408	57	1
L 48992	225	18	L 54268	171		L 55410	423	14
L 50012	77	39	L 54268	173		L 55435	391	30
L 50012	83	17	L 54297	257		L 55436	391	32
L 50194	139	19	L 54358	411	2	L 55436	399	15
L 50197	139	18	L 54388	407	54	L 55440	391	22
L 50435	55	13	L 54388	411	12	L 55445	391	10
L 50435	267	21	L 54407	411	18	L 55445	395	33
L 50502	101	15	L 54419	405	21	L 55445	397	42
L 50511	413	49	L 54437	407	42	L 55445	399	4
L 50592	137	3	L 54522	291	28	L 55451	391	6
L 50592	137	3	L 54563	381	1	L 55451	395	17
L 50592	137	3	L 54563	383	1	L 55454	391	29
L 50592	137	3	L 54563	391	21	L 55455	391	31
L 50592	137	3	L 54563	395	1	L 55456	391	17
L 50629	283	17	L 54563	399	1	L 55457	391	18
L 50641	431	17	L 54570	459	1	L 55458	391	19
L 50735	71	25	L 54606	85	24	L 55460	391	15
L 50735	73	20	L 54606	89	24	L 55461	391	16
L 50741	423	12	L 54606	91	24	L 55462	391	20
L 51052	221	13	L 54606	93	24	L 55466	391	33
L 51104	417	1	L 54606	453	51D	L 55524	55	5
L 51311	225	39	L 54652	297	46	L 55553	393	36
L 51427	403	5	L 54652	297D	59	L 55554	393	37
L 52092	239	1	L 54670	423	23	L 55570	391	11
L 52096	83	9	L 54683	385	26	L 55570	395	34
L 52474	435	43	L 54713	433	19	L 55570	397	43
L 52477	393	57	L 54741	411	23	L 55570	399	5
L 52477	397	68	L 54749	291	23	L 55580	55	22
L 52494	261	27	L 54770	121	25	L 55583	73	2
L 52494	263	27	L 54770	123	22	L 55603	73	10
L 52496	385	27	L 54770	271	9	L 55629	417	1
L 52634	65	32	L 54770	273	9	L 55647	411	5
L 52634	69		L 54770	331	1	L 55650	79	
L 52759	423	18	L 54772	121	15	L 55654	79	28
L 52823	109		L 54772	333		L 55655	79	27
L 53132	417	1	L 54773	125		L 55682	431	5
L 53196	61		L 54773	127		L 55693	429	22
L 53208	423	19	L 54773	127B		L 55694	431	16
L 53589	379	30	L 54782	403	21	L 55697	431	10
L 53591	379	31	L 54786	285	18	L 55699	431	24
L 53599	227	34	L 54788	285	19	L 55700	431	25
L 53600	227	23	L 54789	285	21	L 55701	431	34

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 55703	413	41	L 55962	375	27	L 57552	137	1
L 55717	175	33	L 56217	9	6	L 57592	279	7
L 55718	175	27	L 56217	77	49	L 57594	279	8
L 55720	59	33	L 56217	77	53	L 57596	279	5
L 55721	175	1	L 56217	165	4	L 57598	279	6
L 55723	413	56	L 57005	435	39	L 57599	279	9
L 55734	407	48	L 57012	411	8	L 57599	281	25
L 55734	411	6	L 57029	407	59	L 57599	283	10
L 55737	375	30	L 57029	413	36	L 57601	279	17
L 55741	73	16	L 57035	75	26	L 57603	281	9
L 55764	55	4	L 57036	75	23	L 57605	281	10
L 55774	79	23	L 57038	293	42	L 57607	281	8
L 55778	79	2	L 57038	297	29	L 57609	281	7
L 55778	175	12	L 57050	79	3	L 57611	281	23
L 55785	429	17	L 57052	79	32	L 57613	281	24
L 55786	429	18	L 57106	403	18	L 57616	281	12
L 55800	269	40	L 57111	373	3	L 57652	265	18
L 55802	121	12	L 57137	67	43	L 57656	265	5
L 55804	121	20	L 57146	227	8	L 57682	235	
L 55806	121	33	L 57148	433		L 57685	79	22
L 55806	123	30	L 57152	221	28	L 57685	463	16
L 55808	121	34	L 57152	223	23	L 57685	465	11
L 55808	123	31	L 57152	225	1	L 57696	403	9
L 55810	271	4	L 57152	227	10	L 57710	131	3
L 55810	273	4	L 57152	235	10	L 57714	131	5
L 55812	271	12	L 57157	225	11	L 57721	221	7
L 55812	273	12	L 57158	221	25	L 57765	83	19
L 55814	271	6	L 57160	225	21	L 57766	83	13
L 55816	271	14	L 57163	225	3	L 57792	267	12
L 55818	275	4	L 57163	227	19	L 57799	81	40
L 55820	275	8	L 57165	235	18	L 57801	79	31
L 55822	271	24	L 57176	77	50	L 57819	175	3
L 55824	275	11	L 57176	227	17	L 57839	59	30
L 55825	275	12	L 57197	373	20	L 57841	59	36
L 55826	267	4	L 57274	389	10	L 57897	425	43
L 55829	429	16	L 57277	389	7	L 57900	85	1
L 55831	429	15	L 57287	381	10	L 57903	413	43
L 55833	429	14	L 57287	383	11	L 57904	413	44
L 55835	413	51	L 57298	385	5	L 57910	85	3
L 55855	71	12	L 57298	387	17	L 57910	425	52
L 55862	139	14	L 57298	389	20	L 57911	119	43
L 55863	139	15	L 57299	119	47	L 57925	73	22
L 55867	175	29	L 57344	221	21	L 57937	83	24
L 55881	233	36	L 57344	223	17	L 57937	235	20
L 55882	269	31	L 57350	177		L 57966	135	17
L 55909	407	46	L 57350	179		L 57976	221	18
L 55918	275	5	L 57350	189		L 57976	223	14
L 55922	435	40	L 57350	191		L 57979	227	9
L 55925	433	16	L 57350	205		L 58022	65	16
L 55933	409	67	L 57350	207		L 58022	65	26
L 55934	409	66	L 57362	373	10	L 58024	65	12
L 55936	409	78	L 57444	83	4	L 58025	65	11
L 55937	175	7	L 57457	131	11	L 58031	163	41A
L 55950	267	2	L 57459	113	5	L 58069	85	18
L 55951	265	1	L 57459	115	5	L 58070	85	17
L 55951	275	18	L 57474	113	6	L 58072	407	33
L 55952	117	33	L 57475	113	2	L 58075	407	32
L 55953	267	10	L 57488	83	8	L 58088	291	6
L 55955	121	4	L 57512	65	2	L 58091	75	11
L 55955	123	4	L 57528	113		L 58108	395	28
L 55955	267	24	L 57550	137	1	L 58110	395	26
L 55955	289	5	L 57550	137	1	L 58111	397	51
L 55955	2978	6	L 57550	137	1	L 58112	397	53
L 55958	373	18	L 57551	137	1	L 58113	395	25

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

485

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 58114	395	40	L 58657	425	48	L 59332	393	52
L 58115	395	38	L 58710	409	69	L 59332	397	63
L 58116	395	27	L 58746	295	11	L 59515	391	1
L 58117	397	50	L 58748	295	10	L 59527	91	26
L 58120	397	47	L 58750	295	14	L 59563	115	8
L 58121	401	2	L 58752	275	138	L 59585	417	1
L 58124	397	49	L 58752	295	15	L 59605	61	30
L 58125	395	21	L 58783	413	40	L 59605	63	1
L 58126	395	22	L 58801	461	2	L 59641	121	38
L 58127	397	56	L 58820	75	17	L 59641	123	17
L 58128	397	55	L 58821	293	35	L 59641	333	
L 58132	289	11	L 58822	291	31	L 59642	427	70
L 58142	289	26	L 58822	297	36	L 59682	79	34A
L 58142	293	37	L 58822	297D	50	L 59682	83	26A
L 58142	297	30	L 58835	173	18	L 59694	391	16
L 58142	297D	70	L 58842	61	25	L 59695	391	20
L 58145	289	20	L 58842	63	2	L 59696	89	23
L 58145	291	28B	L 58870	423	88	L 59708	399	2
L 58147	289	12	L 58883	403	24	L 59790	123	18
L 58147	297B	18	L 58934	289	4	L 59796	123	14
L 58147	297B	22	L 58956	403	28	L 59799	79	32A
L 58159	377	2	L 58969	59	34	L 59800	423	1A
L 58163	395	16	L 58983	385	6	L 59801	123	13
L 58174	81	42	L 58984	385	16	L 59801	269	43
L 58185	395	2	L 58992	275	25	L 59816	269	48
L 58187	397	52	L 58993	59	38	L 59831	403	28
L 58188	401	11	L 58994	59	37	L 59846	423	16
L 58202	289	6	L 59001	275	23	L 59847	423	17
L 58208	65	7	L 59005	291	34	L 59852	373	3
L 58210	73	15	L 59006	285	24	L 59854	385	6A
L 58319	407	37	L 59033	405	11	L 59873	417	1
L 58334	75	1	L 59037	117	18	L 59893	417	1
L 58334	385	1	L 59038	117	16	L 59905	139	24
L 58334	387	1	L 59041	129	7	L 59933	425	42
L 58335	81	44	L 59041	129B	7	L 59941	125	
L 58335	83	1	L 59041	129	7	L 59941	127B	
L 58345	379	36	L 59042	129B	3	L 59941	127	
L 58348	379	38	L 59042	129	3	L 60175	111	13
L 58386	459	6	L 59042	129	3	L 70051	175	19
L 58388	225	37	L 59043	89	7	L 70056	227	1
L 58402	283	11	L 59043	91	7	L 70057	75	23
L 58404	283	12	L 59043	93	7	L 70057	91	34
L 58406	283	4	L 59067	103	6	L 70057	93	32
L 58408	283	5	L 59101	295	5	L 70058	75	26
L 58427	377	2	L 59101	413	57A	L 70063	59	46
L 58427	377	5	L 59105	117	36	L 70064	59	43
L 58459	237	27	L 59106	117	13	L 70083	417	3
L 58496	77	34	L 59107	117	26	L 70083	417	3
L 58497	81	39	L 59109	117	35	L 70083	417	3
L 58497	83	25	L 59112	117	34	L 70084	417	2
L 58510	101	14	L 59117	405	12	L 70084	417	2
L 58511	77	62	L 59120	405	5	L 70084	417	2
L 58511	79	34	L 59122	163	42	L 70094	273	14
L 58511	83	26	L 59126	123	8A	L 70096	273	6
L 58515	71	18	L 59126	269		L 70098	273	24
L 58516	425	29	L 59126	289	7	L 70100	59	48
L 58523	73	13	L 59161	89	26	L 70129	393	42
L 58543	175	13	L 59170	89	27	L 70130	393	47
L 58548	73	11	L 59170	91	27	L 70149	403	27
L 58550	425	42	L 59170	93	27	L 70179	75	6
L 58575	423	25	L 59196	405	22	L 70180	389	14
L 58656	405	15	L 59280	89	13	L 70185	81	40
L 58656	407	55	L 59280	91	13	L 70191	77	39
L 58656	411	11	L 59280	93	13	L 70193	389	13

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 70214	429	14	L 71567	123	31A	L 73023	63	16
L 70217	75	14B	L 71568	269	48A	L 73024	63	23
L 70250	233	39	L 71569	123	14A	L 73025	63	
L 70276	385	25	L 71570	435	44	L 73034	297	50
L 70286	275	28	L 71578	457	1	L 73042	251	
L 70287	275	23	L 71579	457	3	L 73081	259	
L 70294	389	15	L 71665	65	21	L 73093	387	8
L 70340	269	48	L 71684	75	1	L 73097	163	
L 70343	275	9	L 71699	93	26	L 73098	233	
L 70379	423	8A	L 71749	261		L 73117	59	35A
L 70385	77	38	L 71756	131	2	L 73154	223	9
L 70386	91	23	L 71758	237	31	L 73161M	101	1
L 70454	175	23	L 71803	429	15	L 73161	103	2
L 70486	111	15	L 71805	429	16	L 73162	85	2
L 70487	111	21	L 71838	301	1	L 73169	389	13
L 70498	115	7	L 71839	301	1	L 73182	295	28
L 70501	429	16A	L 71856	73	25	L 73182	295	28
L 70511	59	49	L 72019	437	8	L 73190	295	10
L 70598	403	26	L 72035	181		L 73192	295	11
L 70639	133		L 72035	183		L 73207	177	35
L 70686	177		L 72035	193		L 73209	421	
L 70686	179		L 72035	195		L 73212	421	1
L 70686	189		L 72035	213		L 73251	107	
L 70686	191		L 72035	215		L 73251	107	
L 70686	209		L 72109	383	4	L 73252	109	
L 70686	211		L 72110	381	2	L 73263	239	1
L 70791	405	19	L 72110	383	2	L 73272	441	18
L 70791	411	1A	L 72111	381	3	L 73277	263	
L 70871	403	9	L 72111	383	3	L 73294	223	21
L 71043	403	10	L 72166	425	29	L 73296	223	3
L 71077	393	45	L 72189	267	21A	L 73296	243	
L 71078	393	43	L 72272	457	10	L 73296	245	
L 71080	437	1A	L 72409	225	24	L 73296	247	
L 71092	285	21	L 72459	459	4	L 73300	405	27
L 71121	373	3	L 72507	55	2	L 73331	281	27
L 71137	121	39	L 72634	425	34	L 73371	425	42
L 71137	275	23	L 72665	435	45	L 73453	381	7
L 71138	121		L 72680	59	47	L 73456	383	8
L 71180	229	45	L 72720	387	12	L 73479	85	30
L 71196	221	1	L 72739	55	22	L 73479	87	5
L 71214	441	5	L 72771	387	14	L 73486	85	4
L 71215	441	6	L 72776	61		L 73486	87	3
L 71219	441	7	L 72776	63		L 73543	445	53A
L 71239	387		L 72807	405	18	L 73545	425	59
L 71262	435	47	L 72808	411	1	L 73598	407	51
L 71264	435	48	L 72877	423	16A	L 73598	411	15
L 71273	229	40	L 72882	233	44	L 73626	193	
L 71274	251		L 72895	233	45	L 73635	131	38
L 71275	251		L 72896	233	46	L 73640	131	1
L 71304	77	61	L 72900	421	1	L 73643	131	3A
L 71304	387	10	L 72910	389	10A	L 73667	109	
L 71343	387	3	L 72956	233	41	L 73672	109	18
L 71369	131	17	L 72961	71	16	L 73675	403	9
L 71370	131	12	L 72967	75	10	L 73677	403	28
L 71371	131	13	L 72971	163	46	L 73711	65	15A
L 71412	261	17	L 72990	403	5	L 73721	373	3
L 71421	435	46	L 72991	421		L 73773	387	6
L 71421	435	49	L 72992	421	2	L 73780	57	12
L 71446	131	1	L 72992	421	2	L 73799	111	22
L 71484	65	8	L 72993	421	3	L 73886	131	12
L 71557	387	13	L 72993	421	3	L 73887	131	13
L 71563	457	5	L 73000	135	15	L 73972	55	11
L 71565	457	4	L 73018	381	9	L 73981	163	43
L 71566	123	30A	L 73018	383	10	L 73982	429	23

MODEL 680E CONSTRUCTION KING LOADER BACKHOE
NUMERICAL INDEX

487

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 74029	181		L 77084	277	26	L 78742	87	3A
L 74029	183		L 77086	265	5A	L 78791	375	34
L 74029	197		L 77087	277	25	L 78801	375	38
L 74029	199		L 77088	277	19	L 78877	403	5
L 74029	213		L 77091	277	20	L 78889	59	38A
L 74029	215		L 77093	87	23	L 78909	59	37A
L 74047	413	48	L 77117	217		L 78911	59	30A
L 74086	175	39	L 77131	293	42A	L 78951	405	2A
L 74090	295	4A	L 77131	297	29	L 78976	411	29
L 74390	291	28A	L 77131	297B	46	L 78977	411	28
L 74391	223	13A	L 77252	453	50E	L 78991	409	81
L 74393	223	1	L 77296	79	3	L 79009	407	33A
L 74489	273	24	L 77374	117	34A	L 79009	409	71
L 74506	55	19	L 77390	383	12	L 79009	409	83
L 74506	179	42	L 77524	389	7	L 79009	411	19
L 74506	183	42	L 77532	277	4	L 79009	413	41A
L 74506	187	42	L 77541	277	8	L 79012	405	14A
L 74516	175	4	L 77556	207		L 79025	405	1
L 74517	175	17	L 77556	211		L 79025	413	57
L 74558	427	67	L 77556	215		L 79058	263	17
L 74574	87	2	L 77788	405	20A	L 79067	115	6
L 74575	87	1	L 77788	411	1C	L 79069	379	38
L 74594	373	20A	L 77824	291	4	L 79089	113	2
L 74595	373	18A	L 77825	291	5	L 79089	115	2
L 74618	405	14	L 77825	295	4	L 79092	223	27B
L 74619	405	1	L 77825	297B	4	L 79095	291	10
L 74683	75	23A	L 77848	145	40	L 79113	291	32A
L 74683	91	34A	L 77848	149	40	L 79121	87	5A
L 74683	93	32A	L 77902	405	18	L 79128	379	36
L 74720	413	57	L 77934	411	1	L 79141	297B	30
L 74747	53		L 78057	269	44A	L 79142	411	1
L 74889	377		L 78057	289	30	L 79166	409	73
L 74931	77	33B	L 78119	395	6A	L 79179	55	18
L 76350	75	1	L 78158	55	13A	L 79185	407	37
L 76431	77		L 78165	295	28A	L 79212	437	9
L 76487	377		L 78165	297B	39	L 79224	223	5
L 76489	379		L 78175	295	28B	L 79225	223	24
L 76490	379		L 78175	297D	68	L 79228	405	8
L 76554	453	50B	L 78192	297B	17	L 79228	407	56A
L 76555	453	50A	L 78203	405	4	L 79230	75	1
L 76698	291	6A	L 78210	289	29	L 79233	79	3
L 76714	207		L 78210	297B	7	L 79318	411	5A
L 76714	211		L 78317	185		L 79365	373	4A
L 76714	215		L 78317	187		L 79371	373	3
L 76726	453B	66B	L 78317	201		L 79454	273	24A
L 76788	135	1	L 78317	203		L 79801	101	3A
L 76807	181		L 78317	217		L 79801	103	3A
L 76807	183		L 78317	219		L 79808	243	
L 76807	197		L 78383	297B	14	L 79808	245	
L 76807	199		L 78385	297B	15	L 79808	247	
L 76807	217		L 78387	297B	25	L 79907	83	14
L 76807	219		L 78390	411	8A	L 79986	101	3B
L 76819	297	37	L 78415	297B	29	L 100002	103	3B
L 76819	297D	51	L 78495	75	13D	L 100120	411	22
L 76923	411	22	L 78508	297B	21	L 100121	411	23
L 76924	377		L 78530	375	36	L 100128	297	29A
L 76957	187	35A	L 78551	375	29A	L 100128	297D	46A
L 76970	183	35	L 78623	89	3	L 100566	77	55
L 77011	269	48	L 78623	91	3	L 100684	145	
L 77020	269	48	L 78623	93	3	L 100684	149	
L 77082	277	9	L 78634	291	11	L 100707	185	
L 77083	265	3A	L 78680	71	20	L 100707	187	
L 77083	277	21	L 78722	287	12	L 100707	201	
L 77084	265	1A	L 78723	355		L 100707	203	

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 100707	217		R 28980	287	4	13- 512	157	5
L 100707	219		R 29332	81	43	13- 512	245	50
M 20614	33	40	R 29554	459	7	13- 512	251	10
R 10276	189	10A	R 29555	459	8	13- 512	431	14
R 10276	193	10A	R 30786	63	12	13- 512	453	57
R 10276	197	10A	R 30812	63	15	13- 514	27	8
R 10276	201	10A	R 31000	117	22	13- 514	35	25
R 10277	189	8A	R 31222	403	29	13- 514	155	6
R 10277	193	8A	R 33411	355	11	13- 514	245	41
R 10277	197	8A	R 35318	421	6	13- 516	63	8
R 10277	201	8A	R 35318	421	6	13- 516	143	31
R 13338	205	21	R 35319	421	7	13- 516	149	31
R 13338	209	21	R 35319	421	7	13- 516	151	5
R 13338	213	21	R 38572	421		13- 516	153	5
R 13338	217	21	R 38572	421		13- 516	225	7
R 14097	267	6	R 49858	297	39	13- 516	229	46
R 14668	269	36	S 89827	213	34	13- 516	235	22
R 14771	73	4	S 89827	217	34	13- 516	241	34
R 15023	47	4	S 93392	139	16	13- 516	247	58A
R 15023	49	41	S 219533	75	27	13- 516	283	7
R 15023	49	57	S 219533	83	16	13- 516	395	35
R 15024	47	10	T 28550	249	3	13- 516	457	6
R 15025	47	12	T 29460	257	25	13- 518	147	8A
R 15029	47	13	T 29460	259	25	13- 520	111	18
R 15030	47	19	T 30271	125	18	13- 520	143	7
R 15035	47	18	T 31659	117	27	13- 520	155	2
R 15071	73	5	T 32720	151	19	13- 520	159	6
R 15115	47	28	T 32720	153	18	13- 520	161	6
R 15145	49	45	T 34922	431	4	13- 520	175	8
R 15159	49	76	T 37909	413	42	13- 520	175	14
R 15257	289	16	T 41362	289	15	13- 520	391	12
R 15257	291	17	T 41959	311	7	13- 520	397	44
R 15257	291	32	T 41959	355	9	13- 520	399	6
R 16171	429	7	T 51274	389	16	13- 522	27	8
R 17306	105	2	W 10478	79	19	13- 524	147	8
R 17416	275	14	W 12116	333		13- 524	175	36
R 17416	277	10	W 12133	333		13- 532	147	8B
R 17547	305	9				13- 534	147	7
R 17756	379	40				13- 536	143	8
R 17756	407	60				13- 540	233	34
R 17756	413	37				13- 544	285	2
R 17765	445	53B				13- 548	121	23
R 17820	169	6				13- 548	123	21
R 17820	171	9	5- 8	103	12	13- 6 8	291	7
R 18653	113	8	11- 716	461	5	13- 610	75	9
R 20804	265	4	13- 68	73	23	13- 610	167	3
R 21518	265	11	13- 412	75	28	13- 612	61	22
R 21562	49	52	13- 412	229	41	13- 612	63	19
R 21573	49	65	13- 412	261	18	13- 612	73	26
R 21574	49	64	13- 412	263	18	13- 612	171	13
R 21579	49	40	13- 416	61	11	13- 612	281	35
R 21580	49	43	13- 416	71	7	13- 612	283	14
R 21582	49	44	13- 416	85	33	13- 612	295	6
R 21587	49	47	13- 416	87	19	13- 612	297B	23
R 21590	47	8	13- 416	227	11	13- 612	385	13
R 24323	55	37	13- 420	65	33	13- 612	385	17
R 24323	77	42	13- 428	261	28	13- 612	425	49
R 24323	83	22	13- 428	263	28	13- 612	429	1
R 24323	221	11	13- 432	117	23	13- 612	429	16B
R 24323	411	26	13- 432	225	33	13- 612	435	34
R 26136	47		13- 440	13	5	13- 614	9	13
R 26136	49		13- 512	55	23	13- 614	29	6
R 26136	77	37	13- 512	57	8	13- 614	167	7
R 26136	83	18	13- 512	117	10	13- 614	289	17

HARDWARE PART NUMBERS

5- 8	103	12	13- 6 8	291	7
11- 716	461	5	13- 610	75	9
13- 68	73	23	13- 610	167	3
13- 412	75	28	13- 612	61	22
13- 412	229	41	13- 612	63	19
13- 412	261	18	13- 612	73	26
13- 412	263	18	13- 612	171	13
13- 416	61	11	13- 612	281	35
13- 416	71	7	13- 612	283	14
13- 416	85	33	13- 612	295	6
13- 416	87	19	13- 612	297B	23
13- 416	227	11	13- 612	385	13
13- 420	65	33	13- 612	385	17
13- 428	261	28	13- 612	425	49
13- 428	263	28	13- 612	429	1
13- 432	117	23	13- 612	429	16B
13- 432	225	33	13- 612	435	34
13- 440	13	5	13- 614	9	13
13- 512	55	23	13- 614	29	6
13- 512	57	8	13- 614	167	7
13- 512	117	10	13- 614	289	17

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
13- 616	11	18	13- 624	379	33	13- 820	71	13
13- 616	35	8	13- 624	407	38	13- 820	85	5
13- 616	35	42	13- 624	425	30	13- 820	85	13
13- 616	53	50	13- 624	425	39	13- 820	87	11
13- 616	55	26	13- 624	431	18	13- 820	101	5
13- 616	55	31A	13- 624	435	33	13- 820	103	11
13- 616	59	28	13- 624	437	5	13- 820	223	25
13- 616	61	18	13- 628	55	7	13- 820	297	52
13- 616	63	5	13- 628	57	14	13- 820	391	2
13- 616	85	20	13- 628	143	23	13- 820	407	61
13- 616	89	8	13- 628	147	23	13- 820	413	38
13- 616	91	8	13- 628	281	17	13- 820	425	53
13- 616	93	8	13- 628	291	15	13- 820	441	9
13- 616	113	10	13- 628	407	38	13- 822	221	30
13- 616	115	9	13- 628	431	1	13- 824	23	13
13- 616	139	1	13- 630	169	30	13- 824	55	35
13- 616	143	38	13- 632	9	3	13- 824	59	39
13- 616	149	38	13- 632	291	15	13- 824	77	43
13- 616	169	29	13- 632	291	19A	13- 824	83	5
13- 616	175	30	13- 632	2978	16	13- 824	83	23
13- 616	265	6	13- 632	435	35	13- 824	267	5
13- 616	289	13	13- 636	265	19	13- 824	267	15
13- 616	295	18	13- 636	289	32	13- 824	275	13
13- 616	297B	35	13- 636	295	23	13- 824	277	11
13- 616	401	3	13- 636	2978	42	13- 824	295	12
13- 616	413	31	13- 636	425	35	13- 824	411	88
13- 616	425	44	13- 640	35	9	13- 824	431	31
13- 616	425	60	13- 640	85	26	13- 824	441	8
13- 616	433	28	13- 640	87	7	13- 826	23	3
13- 618	143	23	13- 640	281	16	13- 828	31	6
13- 618	147	23	13- 640	2978	10	13- 828	223	30
13- 620	9	34	13- 644	269	41	13- 828	269	30
13- 620	21	28	13- 644	271	28	13- 828	379	41
13- 620	39	11	13- 644	273	15	13- 828	387	4
13- 620	89	9	13- 644	289	8	13- 832	271	15
13- 620	91	9	13- 644	379	17	13- 832	275	13A
13- 620	93	9	13- 648	121	16	13- 832	379	44
13- 620	117	4	13- 648	123	7	13- 832	423	24
13- 620	121	7	13- 648	269	41	13- 836	23	3
13- 620	269	35	13- 652	53	51	13- 836	73	3
13- 620	291	19	13- 652	55	30	13- 836	277	11A
13- 620	295	23	13- 652	279	10	13- 836	297	51
13- 620	391	7	13- 652	297	38	13- 836	379	45
13- 620	393	38	13- 652	297D	53	13- 836	385	3
13- 620	393	48	13- 656	35	10	13- 836	387	15
13- 620	395	7	13- 656	35	22	13- 836	389	19
13- 620	395	18	13- 656	61	17	13- 840	27	18
13- 620	405	28	13- 656	63	3	13- 840	431	27
13- 620	413	32	13- 660	35	11	13- 848	55	34
13- 620	425	45	13- 664	291	33	13- 848	77	40
13- 620	429	4	13- 668	379	14	13- 848	403	33
13- 620	429	5	13- 672	381	17	13- 852	27	18
13- 620	429	10	13- 672	383	19	13- 852	83	20
13- 620	429	19	13- 680	291	7	13- 864	381	5
13- 620	433	18	13- 720	189	4	13- 868	35	48
13- 622	221	6	13- 720	193	4	13- 888	71	5
13- 624	9	3	13- 720	197	4	13- 888	383	6
13- 624	119	38	13- 720	201	4	13- 924	139	9
13- 624	281	11	13- 720	223	27	13- 928	139	9
13- 624	285	10	13- 724	223	4	13- 1028	403	36
13- 624	289	31	13- 812	23	13	13- 1032	441	14
13- 624	295	28C	13- 812	291	12	13- 1224	131	9
13- 624	297B	9	13- 812	397	57	13- 1232	431	7
13- 624	297D	66	13- 814	101	11	13- 1240	427	71

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
13- 1248	55	12	25- 106	85	29	25- 108	103	14
13- 1264	55	17	25- 106	87	10	25- 108	223	32
13- 1264	139	17	25- 106	113	12	25- 108	267	9
13- 1644	403	19	25- 106	115	11	25- 108	269	34
13- 2056	437	2	25- 106	117	8	25- 108	271	20
13- 2056	439	10	25- 106	119	42	25- 108	275	16
13- 2056	441	2	25- 106	121	11	25- 108	277	14
13-12120	427	65	25- 106	121	19	25- 108	379	46
14- 412	73	17	25- 106	123	11	25- 108	381	88
14- 512	233	37	25- 106	175	32	25- 108	383	98
14- 512	265	12	25- 106	221	9	25- 108	385	8
14- 512	431	22	25- 106	265	9	25- 108	387	19
14- 532	125	10	25- 106	269	39	25- 108	389	23
14- 532	125	33	25- 106	269	47	25- 108	391	5
14- 532	233	42	25- 106	271	32	25- 108	403	35
14- 616	461	3	25- 106	273	20	25- 108	411	8E
14- 840	133	28	25- 106	279	14	25- 108	423	28
25- 104	61	13	25- 106	281	15	25- 108	425	56
25- 104	65	15	25- 106	281	20	25- 108	431	30
25- 104	65	36	25- 106	285	12	25- 108	441	12
25- 104	71	11	25- 106	289	19	25- 109	205	32
25- 104	75	31	25- 106	289	35	25- 109	209	32
25- 104	85	36	25- 106	291	21	25- 109	213	30
25- 104	87	22	25- 106	295	9	25- 109	217	30
25- 104	89	15	25- 106	295	22	25- 114	307	18
25- 104	91	15	25- 106	295	27	25- 115	247	54
25- 104	93	15	25- 106	2978	13	25- 118	133	30
25- 104	117	25	25- 106	2978	20	25- 126	35	40
25- 104	225	36	25- 106	2978	38	25- 144	73	19
25- 104	227	13	25- 106	297	41	25- 144	319	26
25- 104	249	4	25- 106	2978	45	25- 144	321	28
25- 104	261	20	25- 106	2970	56	25- 144	323	44
25- 104	263	20	25- 106	315	13	25- 144	327	29
25- 104	385	12	25- 106	315	30	25- 146	9	24
25- 105	57	11	25- 106	381	20	25- 148	71	6
25- 105	63	10	25- 106	383	22	25- 148	73	6
25- 105	83	12	25- 106	385	21	25- 148	77	48
25- 105	111	20	25- 106	393	41	25- 148	387	7
25- 105	121	28	25- 106	393	51	25- 154	73	19
25- 105	123	25	25- 106	395	9	25- 155	309	3
25- 105	175	11	25- 106	395	20A	25- 155	333	4
25- 105	175	20	25- 106	401	5	25- 155	381	12
25- 105	175	38	25- 106	413	35	25- 155	383	14
25- 105	225	9	25- 106	425	33	25- 155	389	3
25- 105	235	25	25- 106	425	38	25- 156	15	5
25- 105	283	9	25- 106	425	41	25- 156	175	2
25- 105	285	5	25- 106	425	63	25- 156	391	28
25- 105	391	14	25- 106	431	21	25- 156	395	15A
25- 105	395	37	25- 106	433	22	25- 156	395	24
25- 105	397	46	25- 106	433	32	25- 156	397	54
25- 105	399	8	25- 106	435	38	25- 156	399	14
25- 105	457	9	25- 106	437	7	25- 156	401	10
25- 106	9	37	25- 107	13	28	25- 166	11	9
25- 106	35	14	25- 107	15	16	25- 176	257	13
25- 106	35	40	25- 107	223	7	25- 176	259	13
25- 106	53	53	25- 107	461	7	25- 214	73	12
25- 106	55	33	25- 108	23	5	25- 214	175	28
25- 106	57	16	25- 108	59	42	25- 1010	403	38
25- 106	61	20	25- 108	71	15	25- 1010	441	17
25- 106	61	24	25- 108	83	7	25- 1012	23	8
25- 106	63	7	25- 108	85	8	25- 1012	55	15
25- 106	63	22	25- 108	85	16	25- 1012	427	69
25- 106	73	29	25- 108	87	14	25- 1012	427	73
25- 106	85	23	25- 108	101	10	25- 1012	431	9

MODEL 680E CONSTRUCTION KING LOADER BACKHOE
NUMERICAL INDEX

491

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
25- 1020	437	4	28- 1640	341	19	92-	5	123
25- 1020	439	12	28- 1640	343	19	92-	5	143
25- 1020	441	4	28- 2040	365	19	92-	5	143
25- 1110	227	31	28- 2040	367	19	92-	5	147
25- 1310	131	22	28- 2044	357	19	92-	5	149
25- 1314	129	5	28- 2044	359	19	92-	5	151
25- 1314	129	5	28- 2048	349B	18	92-	5	153
25- 1314	129	9	28- 2048	349	18	92-	5	155
25- 1314	129	9	28- 2052	361	19	92-	5	155
25- 1510	395	3	28- 2052	363	19	92-	5	157
25- 1528	405	6	41- 10	207	37	92-	5	157
25- 1918	135	3	41- 10	211	37	92-	5	159
25- 2312	241	38	41- 10	215	38	92-	5	161
25- 2312	245	39	41- 10	219	38	92-	5	175
26- 512	227	2	41- 12	167	11	92-	5	175
26- 614	227	5	41- 51	141	35A	92-	5	175
26- 620	411	24	41- 102	261	9	92-	5	225
26- 624	103	8	41- 102	263	9	92-	5	227
26- 720	223	27A	41- 1011	27	6	92-	5	233
26- 724	221	10	41- 1016	31	4	92-	5	235
26- 728	187	37	41- 1042	11	3	92-	5	251
26- 740	187	37	41- 1052	19	21	92-	5	265
26- 820	411	24	75- 420	389	8	92-	5	283
26- 822	181	1	92- 3	65	5	92-	5	285
26- 824	187	37	92- 3	71	22	92-	5	391
26- 824	205	22	92- 3	77	57	92-	5	395
26- 824	209	22	92- 3	77	59	92-	5	397
26- 824	213	22	92- 3	89	22	92-	5	399
26- 824	217	22	92- 3	91	22	92-	5	431
26- 848	191	26	92- 3	93	22	92-	5	431
26- 848	195	26	92- 3	99	22	92-	5	457
26- 848	199	26	92- 3	231	26	92-	6	9
26- 848	203	25	92- 3	461	11	92-	6	11
26- 928	205	30	92- 4	61	12	92-	6	11
26- 928	209	30	92- 4	65	14	92-	6	11
26- 928	213	28	92- 4	65	35	92-	6	21
26- 928	217	28	92- 4	71	10	92-	6	29
26- 1024	177	23	92- 4	73	18	92-	6	35
26- 1024	181	23	92- 4	75	30	92-	6	35
26- 1024	185	23	92- 4	85	35	92-	6	35
26- 1036	139	12	92- 4	87	21	92-	6	39
26- 1036	377	10	92- 4	89	14	92-	6	53
26- 1040	377	11	92- 4	91	14	92-	6	55
26- 1052	197	22	92- 4	93	14	92-	6	55
26- 1056	191	22	92- 4	117	24	92-	6	55
26- 1056	195	22	92- 4	163	48	92-	6	57
26- 1056	203	19	92- 4	225	35	92-	6	59
26- 1268	373	21B	92- 4	227	12	92-	6	59
26-12108	373	21	92- 4	229	43	92-	6	61
28- 648	141	32	92- 4	241	40	92-	6	61
28- 930	177	30	92- 4	241	53	92-	6	63
28- 930	183	30	92- 4	261	19	92-	6	63
28- 1024	21	34	92- 4	263	19	92-	6	73
28- 1028	129	21	92- 4	385	11	92-	6	73
28- 1028	1298	21	92- 4	459	3	92-	6	75
28- 1028	129	21	92- 5	27	9	92-	6	85
28- 1032	183	30	92- 5	35	26	92-	6	85
28- 1032	185	30	92- 5	55	24	92-	6	87
28- 1240	345	19	92- 5	57	10	92-	6	89
28- 1240	347	19	92- 5	63	9	92-	6	91
28- 1240	369	17	92- 5	83	11	92-	6	93
28- 1240	371	17	92- 5	111	19	92-	6	113
28- 1640	337	19	92- 5	117	11	92-	6	115
28- 1640	339	19	92- 5	121	27	92-	6	117

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	
92-	6	119	41	92-	6	435	36	95-	4
92-	6	121	10	92-	7	223	6	95-	4
92-	6	121	18	92-	7	223	29	95-	4
92-	6	123	10	92-	7	461	6	95-	4
92-	6	139	2	92-	8	23	4	95-	4
92-	6	143	24	92-	8	23	14	95-	4
92-	6	145	39	92-	8	31	7	95-	4
92-	6	147	24	92-	8	55	36	95-	4
92-	6	149	39	92-	8	59	41	95-	5
92-	6	167	8	92-	8	71	14	95-	5
92-	6	175	31	92-	8	77	41	95-	5
92-	6	221	8	92-	8	83	6	95-	5
92-	6	227	6	92-	8	83	21	95-	5
92-	6	245	35	92-	8	85	7	95-	5
92-	6	265	8	92-	8	85	15	95-	5
92-	6	269	38	92-	8	87	13	95-	5
92-	6	269	46	92-	8	101	6	95-	5
92-	6	271	31	92-	8	101	12	95-	5
92-	6	273	19	92-	8	103	13	95-	6
92-	6	279	13	92-	8	133	29	95-	6
92-	6	281	14	92-	8	205	23	95-	6
92-	6	281	18	92-	8	209	23	95-	6
92-	6	281	36	92-	8	213	23	95-	6
92-	6	283	15	92-	8	217	23	95-	6
92-	6	285	11	92-	8	221	31	95-	6
92-	6	289	14	92-	8	223	26	95-	6
92-	6	289	18	92-	8	223	31	95-	6
92-	6	289	34	92-	8	267	8	95-	6
92-	6	291	16	92-	8	267	16	95-	6
92-	6	291	20	92-	8	269	33	95-	6
92-	6	295	8	92-	8	271	19	95-	6
92-	6	295	21	92-	8	275	15	95-	6
92-	6	295	26	92-	8	277	13	95-	6
92-	6	297B	12	92-	8	291	13	95-	6
92-	6	297B	19	92-	8	295	13	95-	6
92-	6	297B	24	92-	8	297B	27	95-	6
92-	6	297B	37	92-	8	297B	32	95-	6
92-	6	297	40	92-	8	381	8A	95-	6
92-	6	297B	44	92-	8	383	9A	95-	6
92-	6	297D	55	92-	8	385	7	95-	6
92-	6	379	34	92-	8	387	18	95-	6
92-	6	381	19	92-	8	389	22	95-	6
92-	6	383	21	92-	8	391	4	95-	6
92-	6	385	14	92-	8	397	58	95-	6
92-	6	385	20	92-	8	403	34	95-	6
92-	6	391	9	92-	8	407	62	95-	6
92-	6	393	40	92-	8	411	8D	95-	6
92-	6	393	50	92-	8	411	25	95-	6
92-	6	395	8	92-	8	413	39	95-	6
92-	6	395	15	92-	8	423	21	95-	6
92-	6	395	20	92-	8	423	27	95-	6
92-	6	401	4	92-	8	425	55	95-	6
92-	6	411	25	92-	8	431	29	95-	6
92-	6	413	34	92-	8	431	32	95-	6
92-	6	425	46	92-	8	441	11	95-	6
92-	6	425	50	92-	9	139	10	95-	6
92-	6	425	62	92-	10	21	21	95-	6
92-	6	429	2	92-	10	227	30	95-	6
92-	6	429	11	92-	10	441	16	95-	6
92-	6	429	16C	92-	12	23	7	95-	6
92-	6	431	2	92-	12	55	14	95-	6
92-	6	431	20	92-	12	373	22	95-	6
92-	6	433	21	92-	12	431	8	95-	6
92-	6	433	31	95-	4	65	13	95-	6

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

493

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	
95-	6	431	12	114-	1	47	6	129-	315
95-	6	431	19	114-	1	49	49	129-	361
95-	6	433	20	114-	5	443	4	129-	409
95-	6	433	30	114-	146	389	2	129-	471
95-	6	435	37	114-	213	257	12	129-	514
95-	5	437	6	114-	213	259	12	129-	514
95-	6	461	3A	116-	701	183	41	129-	530
95-	7	223	28	116-	703	187	41	129-	530
95-	8	59	40	116-	707	179	41	129-	561
95-	8	85	6	116-	707	183	41	129-	563
95-	8	85	14	121-	104	145	43	129-	574
95-	8	87	12	121-	104	149	43	129-	610
95-	8	101	7	121-	123	257	5	129-	724
95-	8	101	13	121-	124	259	5	131-	4
95-	8	223	33	121-	203	145	47	131-	6
95-	8	267	7	121-	203	149	47	131-	6
95-	8	269	32	126-	111	53	40	131-	6
95-	8	277	12	126-	116	9	41	131-	6
95-	8	295	12A	126-	129	21	18	131-	9
95-	8	297B	28	126-	213	241	46	131-	10
95-	8	297B	33	126-	216	245	40	131-	50
95-	8	381	8	126-	227	17	9	131-	52
95-	8	383	9	129-	5	75	13C	131-	94
95-	8	385	4	129-	6	75	16	131-	114
95-	8	387	16	129-	6	91	29	131-	186
95-	8	389	21	129-	7	75	4	131-	186
95-	8	391	3	129-	7	461	12	131-	354
95-	8	411	8C	129-	15	79	26	131-	354
95-	8	423	26	129-	15	79	36	131-	402
95-	8	425	54	129-	16	227	37	131-	414
95-	8	431	33	129-	17	47	17	131-	421
95-	8	435	42	129-	17	443	18	131-	471
95-	10	227	29	129-	17	447	9	131-	471
95-	10	393	56	129-	26	97	6	131-	471
95-	10	397	67	129-	27	71	19	131-	484
95-	10	403	37	129-	37	71	21	131-	607
95-	10	429	8	129-	37	75	25	131-	612
95-	12	131	11A	129-	37	77	60	131-	652
95-	12	139	21	129-	37	79	9	131-	652
95-	12	427	66	129-	101	447	21	131-	652
95-	12	427	72	129-	101	453	43	131-	654
95-	24	407	32B	129-	101	453	50D	131-	903
111-	203	443	19	129-	102	433	15	131-	912
113-	3	233	30	129-	102	443	22	131-	1106
113-	3	451	26	129-	102	447	11	131-	1116
113-	3	453	47B	129-	103	439	21	131-	1138
113-	5	451	21	129-	105	51	22	131-	1138
113-	110	243	1	129-	107	439	17	131-	1138
113-	118	433	12	129-	122	125	12	131-	1138
113-	118	439	7	129-	122	125	35	131-	1180
113-	119	241	56	129-	125	105	10	131-	1180
113-	142	247	63	129-	125	105	22	131-	1202
113-	149	247	59	129-	138	373	23	131-	1205
113-	169	73	17	129-	142	241	60	131-	1205
113-	207	453	36	129-	145	47	34	131-	1235
113-	219	439	18	129-	145	51	20	131-	1235
113-	288	245	34	129-	145	453	54	131-	1236
113-	330	257	3	129-	148	447	22	131-	1236
113-	330	259	3	129-	161	99	18	131-	1251
113-	419	423	11	129-	167	257	21	132-	6
113-	422	133	28	129-	167	259	21	132-	7
113-	424	433	24	129-	169	129	6	132-	7
113-	607	439	15	129-	169	1298	6	132-	25
113-	2611	267	17	129-	169	129	6	132-	25

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
132- 25	389	6	163- 19	37	8	182- 534	443	27
132- 25	395	10	163- 25	157	40	182- 534	445	43
132- 26	251	4	164- 99	257	30	187- 321	111	9
132- 26	391	27	164- 99	259	30	187- 811	75	22
132- 26	391	35	164- 215	79	20	187- 811	91	33
132- 26	395	31	164- 215	79	24	187- 811	93	31
132- 26	397	62	164- 573	297B	31	187- 835	257	1
132- 26	399	12	164- 577	297B	26	187- 835	259	1
132- 26	399	17	164- 591	431	7A	187- 976	79	21
132- 26	401	9	164- 675	373	21A	187- 988	453	59
132- 26	401	13	165- 168	139	5A	187- 994	451	18C
132- 28	213	33	166- 138	23	6	187- 1031	129B	11
132- 28	217	33	169- 99	89	21	187- 1031	129	11
132- 32	27	7	169- 99	91	21	187- 1031	129	11
132- 47	431	13	169- 99	93	21	187- 1031	337	12
132- 48	119	49	169- 143	385	22	187- 1031	339	12
132- 48	221	12	169- 146	53	6	187- 1031	341	12
132- 48	223	8	169- 146	235	17B	187- 1031	343	12
132- 48	379	6	169- 148	109	5	187- 1031	345	12
132- 54	169	37	169- 148	109	15	187- 1031	347	12
132- 56	131	14	173- 26	307	25	187- 1031	349B	12
132- 99	135	4	173- 73	75	14A	187- 1031	349	12
132- 310	257	20	173- 73	101	19	187- 1031	351	11
132- 310	259	20	173- 73	103	16	187- 1031	353	11
132- 331	447	31	173- 74	91	28	187- 1031	357	12
138- 53	395	27A	173- 97	231	25	187- 1031	359	12
138- 59	251	9	173- 274	75	14	187- 1031	361	12
138- 60	127	30	173- 274	227	35	187- 1031	363	12
138- 63	175	6	173- 279	105	8	187- 1031	365	12
138- 96	395	13	173- 279	105	21	187- 1031	367	12
138- 97	173	15	174- 93	61	29	187- 1031	369	11
138- 104	175	22	174- 93	63	27	187- 1031	371	11
138- 127	139	7	175- 56	51	16	187- 1089	53	38
138- 129	447	17	175- 449	47	15	192- 5	75	13B
138- 132	177	15	176- 296	309	4	192- 6	75	15
138- 132	181	15	176- 299	333	5	192- 15	75	12
138- 132	185	15	178- 256	177	3	192- 15	79	25
138- 135	397	64	178- 256	181	3	192- 15	79	35
138- 138	389	12	178- 256	185	3	192- 15	453	47C
138- 321	447	18	178- 630	319	25	192- 16	53	7
138- 2012	307	11	178- 630	321	27	192- 16	227	36
138- 2033	393	53	178- 630	323	43	192- 18	47	16
138- 2039	389	18	178- 630	327	28	192- 18	53	14
139- 64	55	16	178- 830	443	32A	192- 18	75	24
141- 2	73	8	178- 838	443	32B	192- 18	79	8
141- 2	175	25	179- 154	443	35	192- 18	241	49
141- 3	381	13	179- 155	443	15	192- 18	443	17
141- 3	383	15	181- 675	27	2	192- 19	47	7
141- 3	389	5	182- 44	79	33	192- 19	49	50
141- 3	391	34	182- 46	75	13	192- 19	443	5
141- 3	399	16	182- 47	79	37	192- 19	447	20
141- 4	391	26	182- 82	125	22	192- 19	451	22
141- 4	395	30	182- 82	125	26	192- 19	453	50C
141- 4	399	11	182- 84	251	34	192- 20	433	13
141- 4	401	8	182- 125	461	10	192- 20	439	8
151- 500	459	5	182- 202	235	17C	192- 20	443	21
151- 525	463	25C	182- 204	237	36	192- 20	447	10
151- 525	465	28E	182- 208	385	9	192- 21	439	20
151- 525	465	36	182- 208	389	8	192- 23	105	9
151- 526	445	58	182- 208	459	2	192- 23	105	23
163- 4	53	13	182- 516	447	7	192- 23	433	25
163- 4	65	4	182- 519	53	37	192- 25	53	42
163- 4	77	56	182- 527	79	4	192- 25	439	16
163- 11	241	48	182- 527	443	13	192- 53	307	26

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

495

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
192- 106	91	30	195- 515	233	31	213- 4	401	7
192- 110	241	35	195- 518	447	19	214- 3	397	61
192- 110	241	59	195- 518	461	15	214- 253	89	6
192- 110	245	42	195- 518	461	15	214- 253	91	6
192- 110	245	51	195- 521	433	14	214- 253	93	6
192- 110	247	55	195- 521	443	20	214- 253	221	2
192- 110	247	60	195- 521	447	12	214- 253	221	22
192- 110	247	64	195- 525	439	19	214- 253	223	18
192- 113	47	35	195- 545	447	23	214- 254	117	32
192- 113	51	21	195- 2024	145	42	214- 254	223	2
192- 161	139	26	195- 2024	149	42	214- 255	265	2
192- 161	141	34	195- 2026	157	43	214- 256	9	16
193- 4	385	24	195- 2034	295	28D	214- 256	163	45
193- 6	75	3	195- 2034	297D	67	214- 257	121	41
193- 8	79	5	195- 2042	121	26	214- 257	265	2A
193- 9	99	16	195- 2042	123	23	214- 257	275	10
193- 10	9	4	195- 2042	425	32	214- 257	275	24
193- 10	9	14	195- 2051	77	46	214- 257	275	29
193- 10	167	4	195- 2051	397	59	214- 257	277	27
193- 10	169	31	195- 2054	381	6	214- 258	109	1
193- 10	171	14	195- 2054	383	7	214- 258	109	17
193- 25	101	20	195- 2061	431	28	214- 260	267	3
193- 25	103	17	195- 2074	175	16	214- 261	453	46
193- 29	125	11	195- 2091	395	39	214- 262	55	3
193- 29	125	34	195- 2091	397	48	214- 262	61	3
193- 30	9	23	195- 2099	111	14	214- 263	65	10
193- 30	35	39	195- 2122	389	17	214- 264	57	18
193- 37	81	50	195- 2142	403	11A	214- 265	297	48
193- 41	125	27	195- 2151	375	35	214- 265	297D	63
193- 56	21	5	195- 2152	403	14	214- 267	281	31
193- 60	99	19	195- 2152	409	64	214- 267	379	25
193- 70	447	8	195- 2152	409	74	214- 269	279	20
193- 73	445	44	195- 2152	413	48A	214- 273	285	20
193- 528	29	6	195- 2155	375	31	214- 273	289	24
193- 1000	9	7	195- 2155	403	7	214- 273	291	24
193- 1001	99	3	195- 2155	407	35	214- 277	293	38
195- 7	75	13A	195- 2155	407	52	214- 277	297	33
195- 7	79	38	195- 2155	411	16	214- 335	31	22
195- 10	125	28	195- 2167	405	3	214- 351	267	11
195- 21	175	9	195- 2191	381	21	214- 351	275	19
195- 21	265	14	195- 2191	383	23	217- 78	59	35
195- 25	9	5	205- 28	451	6	217- 107	31	11
195- 25	11	8	205- 61	423	10A	217- 109	227	15
195- 25	29	8	211- 7	127	27A	217- 133	221	20
195- 25	35	12	211- 7	127	31	217- 134	31	25
195- 26	57	25E	211- 7	155	31	217- 134	221	3
195- 28	425	37	211- 7	157	28	217- 152	223	16
195- 29	15	15	211- 9	127	24	217- 153	9	30
195- 29	267	18	211- 11	173	11	217- 153	31	27
195- 33	101	17	211- 11	303	19	217- 186	221	23
195- 33	103	23	211- 11	305	19	217- 186	223	19
195- 33	387	5	211- 12	143	19	217- 348	117	30
195- 41	441	15	211- 12	147	19	217- 366	121	42
195- 45	131	15	211- 14	351	20	217- 366	275	21
195- 45	389	11	211- 14	353	20	217- 381	9	30
195- 45	427	68	211- 306	153	20	217- 381	31	27
195- 63	409	90	213- 2	73	9	217- 397	119	50
195- 102	453	42	213- 2	175	26	218- 443	225	4
195- 103	439	9	213- 3	381	11	218- 443	225	20
195- 104	121	17	213- 3	383	13	218- 443	225	32
195- 104	429	20	213- 3	389	4	218- 443	227	20
195- 106	105	25	213- 4	391	25	218- 443	227	25
195- 507	385	23	213- 4	395	29	218- 454	225	10
195- 513	443	16	213- 4	399	13	218- 483	227	32

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
218- 483	237	28	218- 5007	311	12	218- 5010	291	3
218- 533	227	27	218- 5007	317	18	218- 5010	295	3
218- 573	117	15	218- 5007	323	48	218- 5010	297B	3
218- 576	121	5	218- 5007	325	6	218- 5010	299	11
218- 583	123	5	218- 5007	325	15	218- 5010	299	12
218- 583	267	25	218- 5007	327	18	218- 5010	301	11
218- 595	379	32	218- 5007	355	2	218- 5010	301	12
218- 665	121	6	218- 5007	355	2	218- 5012	267	13
218- 665	123	6	218- 5007	379	22	218- 5046	123	15
218- 737	271	13	218- 5007	379	28	218- 5050	267	27
218- 737	273	13	218- 5008	121	3	218- 5050	273	7
218- 739	271	5	218- 5008	121	14	218- 5050	273	25A
218- 739	273	5	218- 5008	121	43	218- 5059	287	7
218- 776	283	18	218- 5008	123	3	218- 5060	121	29
218- 936	237	26	218- 5008	267	23	218- 5060	123	26
218- 1024	221	24	218- 5008	267	28	218- 5060	285	6
218- 1096	223	20	218- 5008	269	48C	218- 5060	297	44
218- 1098	165	7	218- 5008	271	22	218- 5060	297D	60
218- 1576	277	5	218- 5008	275	22	218- 5062	279	15
218- 1577	277	15	218- 5008	275	26	218- 5062	281	28
218- 5002	127	29	218- 5008	277	3	218- 5062	285	16
218- 5002	331	8	218- 5008	277	18	218- 5063	279	2
218- 5005	117	14	218- 5008	277	24	218- 5063	281	2
218- 5005	119	44	218- 5008	279	3	218- 5063	283	2
218- 5005	119	46	218- 5008	281	3	218- 5064	121	2
218- 5005	119	51	218- 5008	281	6	218- 5064	121	13
218- 5005	121	36	218- 5008	283	3	218- 5064	123	2
218- 5005	123	33	218- 5008	289	23B	218- 5064	271	21
218- 5005	303	13	218- 5008	291	27	218- 5064	277	23
218- 5005	305	13	218- 5008	291	30	218- 5064	291	29
218- 5006	117	17A	218- 5008	293	36B	218- 5064	293	40
218- 5006	117	31	218- 5008	293	41	218- 5064	297	31
218- 5006	287	8	218- 5008	297	32B	218- 5064	297D	71
218- 5006	287	13	218- 5008	297	32	218- 5065	121	21
218- 5006	309	10	218- 5008	297D	48	218- 5065	121	40
218- 5006	309	20	218- 5008	297D	72	218- 5065	123	19
218- 5006	311	2	218- 5008	299	9	218- 5065	275	2
218- 5006	333	9	218- 5008	299	10	218- 5065	277	2
218- 5006	355	13	218- 5008	301	9	218- 5069	271	7
218- 5006	355	13	218- 5008	301	10	218- 5069	273	21
218- 5007	121	22	218- 5008	319	27	218- 5069	275	6
218- 5007	121	30	218- 5008	321	29	218- 5069	277	6
218- 5007	121	32	218- 5008	323	45	218- 5071	287	2
218- 5007	121	40A	218- 5008	327	30	218- 5077	267	22
218- 5007	123	20	218- 5008	329	17	218- 5077	271	25
218- 5007	123	27	218- 5009	317	8	218- 5077	273	25
218- 5007	123	29	218- 5009	325	17	218- 5077	289	2
218- 5C07	271	11	218- 5009	333	11	218- 5077	289	21
218- 5007	273	11	218- 5010	123	16	218- 5077	291	2
218- 5007	275	3	218- 5010	271	3	218- 5077	295	2
218- 5007	279	16	218- 5010	271	8	218- 5077	297B	2
218- 5007	279	18	218- 5010	271	26	218- 5105	119	45
218- 5007	281	26	218- 5010	273	3	218- 5107	379	21
218- 5007	281	29	218- 5010	273	8	218- 5108	277	17
218- 5007	285	7	218- 5010	273	22	218- 5108	289	23A
218- 5007	285	14	218- 5010	273	24E	218- 5108	291	26
218- 5007	285	17	218- 5010	273	24C	218- 5108	293	36A
218- 5007	285	23	218- 5010	273	26	218- 5108	297	32A
218- 5007	287	10	218- 5010	275	7	218- 5108	297D	47
218- 5007	297	43	218- 5010	277	7	218- 5110	273	24B
218- 5007	297	45	218- 5010	287	3	218- 5118	289	27
218- 5007	297D	58	218- 5010	289	3	218- 5121	285	13
218- 5007	297D	61	218- 5010	289	22	218- 5121	287	9
218- 5007	311	2	218- 5010	289	28	218- 5121	297	42

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

497

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
218- 5121	297D	57	219- 92	381	4	221- 835	195	18
218- 5124	269	48B	219- 92	383	5	221- 835	197	18
218- 5137	379	27	219- 92	391	24	221- 841	143	3
218- 5146	285	6A	219- 92	397	41A	221- 841	147	3
218- 5146	285	22	219- 92	399	3	221- 843	13	21
218- 5147	273	24D	219- 107	413	61	221- 843	35	6
218- 5152	331	7	221- 3	177	10	221- 844	325	18
218- 5159	325		221- 3	181	10	221- 845	19	18
218- 5210	309	19	221- 3	185	10	221- 846	143	29
218- 5210	311	1	221- 4	143	10	221- 846	147	29
218- 5210	355	12	221- 4	147	10	221- 846	159	4
218- 5220	279	4	221- 12	65	17A	221- 846	161	4
218- 5220	281	4	221- 12	157	39	221- 1011	11	4
218- 5294	281	5	221- 12	159	5	221- 1011	39	21
218- 5351	121	35	221- 12	161	5	221- 1014	225	6
218- 5351	123	32	221- 13	143	4	221- 1014	227	22
218- 5442	117	17	221- 13	147	4	221- 1041	49	42
218- 5576	121	31	221- 25	177	11	221- 1041	49	58
218- 5576	123	28	221- 25	177	33	221- 1056	165	3
218- 5576	271	10	221- 25	181	11	221- 1084	223	11
218- 5576	273	10	221- 25	183	33	221- 1084	225	28
219- 1	131	8	221- 25	185	11	221- 1084	227	15A
219- 1	139	28	221- 25	187	33	221- 1084	235	19
219- 1	141	31	221- 25	203	21	221- 1088	225	13
219- 1	141	36	221- 35	423	15	221- 1088	227	24
219- 1	207	45	221- 51	113	4	221- 1088	231	2
219- 1	211	45	221- 51	115	4	221- 1092	9	31
219- 1	215	45A	221- 53	221	17	221- 1092	89	1
219- 1	219	48	221- 53	223	13	221- 1092	91	1
219- 1	337	21	221- 60	31	26	221- 1092	93	1
219- 1	339	21	221- 84	221	15	221- 1131	225	23
219- 1	345	21	221- 86	41	32	221- 1133	231	19
219- 1	347	21	221- 86	43	34	221- 1138	225	24A
219- 1	349B	20	221- 86	259	7	221- 1139	225	14
219- 1	349	20	221- 158	13	40	221- 1327	225	15
219- 1	351	23	221- 158	89	19	221- 1375	225	38
219- 1	353	23	221- 158	91	19	221- 1401	221	19
219- 1	357	21	221- 158	93	19	221- 1402	225	29
219- 1	359	21	221- 164	165	2	221- 1403	165	11
219- 1	361	21	221- 337	13	41	221- 1411	223	10
219- 1	363	21	221- 337	89	18	221- 1411	223	15
219- 1	365	21	221- 337	91	18	221- 1411	227	16
219- 1	367	21	221- 337	93	18	221- 1412	225	17
219- 1	373	9	221- 402	221	14	221- 1412	225	19
219- 1	373	17	221- 654	143	30	221- 1412	235	16
219- 1	375	33	221- 654	147	30	221- 1414	221	27
219- 1	379	4	221- 654	159	3	221- 1422	225	27A
219- 1	389	24	221- 654	161	3	221- 1424	165	5
219- 1	405	13	221- 655	267	26	221- 1502	225	27
219- 1	405	14B	221- 661	143	25	221- 1662	227	14
219- 1	407	32C	221- 661	147	25	221- 1662	247	62
219- 1	407	45	221- 661	157	10	221- 1691	225	2
219- 1	409	76	221- 661	333	16	221- 1691	227	18
219- 1	413	55	221- 662	299	7	221- 1691	235	9
219- 36	341	21	221- 662	299	8	221- 1843	19	4
219- 36	343	21	221- 662	301	7	221- 1849	19	3
219- 36	403	22	221- 662	301	8	221- 1849	39	2
219- 55	131	4	221- 664	29	2	221- 1849	47	5
219- 55	361	22	221- 676	167	2	221- 1849	225	25
219- 55	405	26	221- 678	183	33A	221- 1849	231	23
219- 86	391	23	221- 678	187	35	221- 1849	249	20
219- 86	397	41	221- 691	221	16	222- 14	65	24
219- 86	401	6	221- 691	223	12	222- 23	41	29
219- 87	425	58	221- 835	191	18	222- 23	43	31

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
222- 23	67		222- 2610	231	13C	321- 1000	465	8
222- 27	65	25	222- 2610	231	17C	321- 1077	463	18
222- 31	27	22	222- 2610	235	4C	321- 1077	465	13
222- 42	41	25	222- 2610	235	8C	321- 1482	463	19
222- 45	39	15	222- 2610	235	14C	321- 1572	411	10
222- 46	69	14	222- 2625	231	13A	321- 1572	463	6
222- 47	67		222- 2625	235	4A	321- 1573	463	1
222- 48	65		222- 2630	231	17A	321- 1751	461	9
222- 48	65		222- 2630	235	14A	321- 1751	461	17
222- 102	37	26	222- 2640	231	9A	321- 2058	411	9
222- 102	37	30	222- 2680	235	8A	321- 2427	413	61
222- 102	41	26	222- 2695	231	5A	321- 2613	463	15
222- 102	41	30	222- 5002	231	10A	321- 2613	465	10
222- 102	43	29	222- 5002	235	1A	321- 2644	13	37
222- 102	43	32	222- 5002	261		321- 2653	465	35
222- 102	67	46	222- 5002	263		321- 2654	379	37
222- 102	241	62	222- 5003	231	14A	321- 2720	463	27
222- 102	241	66	222- 5003	235	11A	321- 2720	465	31
222- 103	39	16	222- 5023	231	6A	321- 2721	463	22
222- 104	65	20	222- 5023	261		321- 2721	465	17
222- 104	65	29	222- 5023	263		321- 2722	463	26
222- 104	67	41	222- 5024	231	2A	321- 2722	465	30
222- 106	27	23	222- 5047	231	4	321- 2724	399	10
222- 112	37	27	222- 5047	231	8	321- 2724	463	30
222- 112	37	31	222- 5047	231	12	321- 2724	465	34
222- 112	41	27	222- 5047	231	16	321- 2725	463	23
222- 112	41	31	222- 5047	235	3	321- 2725	465	18
222- 112	43	30	222- 5047	235	7	321- 2728	463	2
222- 112	43	33	222- 5047	235	13	321- 2729	463	21
222- 112	67	45	222- 5047	261	22	321- 2729	465	16
222- 112	241	63	222- 5047	261	25	321- 2730	463	4
222- 112	241	65	222- 5047	263	22	321- 2731	463	5
222- 113	39	17	222- 5047	263	25	321- 2746	397	60
222- 114	65	19	222- 5060	231	5	321- 2746	463	28
222- 114	65	28	222- 5060	231	9	321- 2746	465	32
222- 114	67	42	222- 5060	231	13	321- 2747	401	15
222- 116	27	24	222- 5060	231	17	321- 2747	463	29
222- 600	57	25A	222- 5060	235	4	321- 2747	465	33
222- 615	63	14	222- 5060	235	8	321- 2785	463	17
222- 617	241		222- 5060	235	14	321- 2785	465	12
222- 618	241		222- 5060	261	23	321- 2797	463	25
222- 650	57	21	222- 5060	261	26	321- 2797	465	20
222- 650	57	25C	222- 5060	263	23	321- 2798	463	24
222- 650	61	5	222- 5060	263	26	321- 2798	465	19
222- 650	61	9	222- 5131	57	22A	321- 2799	463	14
222- 660	57	22	222- 5375	235	5A	321- 2799	465	9
222- 660	57	25D	223- 6	109	7	321- 3054	463	20
222- 660	61	6	223- 10	113	3	321- 3054	465	15
222- 660	61	8	223- 10	115	3	321- 3061	463	3
222- 681	57	19A	223- 56	113	9	321- 3061	465	1
222- 768	163	40	223- 125	77	34A	321- 3069	465	22
222- 1004	447	28	223- 125	79	34C	321- 3087	465	25
222- 1012	27	11	223- 125	83	26B	321- 3088	465	26
222- 1012	27	16	321- 229	463	10	321- 3089	465	27
222- 1034	163	39	321- 229	465	5	321- 3090	465	23
222- 2600	231	5D	321- 230	463	11	321- 3091	465	24
222- 2600	231	9D	321- 230	465	6	321- 3092	465	28
222- 2600	231	13D	321- 246	463	8	321- 3099	465	29
222- 2600	231	17D	321- 246	465	3	321- 3120	413	59
222- 2600	235	4D	321- 663	463	7	321- 3139	413	60
222- 2600	235	8D	321- 663	465	2	321- 3139	463	31
222- 2600	235	14D	321- 704	463	9	321- 3209	463	12
222- 2610	231	5C	321- 704	465	4	321- 3209	465	7
222- 2610	231	9C	321- 1000	463	13	321- 3596	463	25B

MODEL 680E CONSTRUCTION KING LOADER BACKHOE

499

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
321- 3596	465	28A	321- 4901	465	21	353- 550	445	56
321- 3705	465	28B	345- 57	437	10	353- 580	425	438
321- 4127	465	28C	345- 57	457	2	353- 679	451	6A
321- 4145	465	9	345- 84	185	9	355- 62	445	41
321- 4146	465	12	353- 255	425	43A	391- 751	207	53
321- 4408	465	28D	353- 403	85	31	391- 751	211	53
321- 4632	465	28G	353- 403	87	6	391- 751	215	53
321- 4633	465	28F	353- 404	81	45	391- 751	219	47
321- 4901	463	25A	353- 407	81	46			

CASE CORPORATION
700 STATE STREET
RACINE, WI 53404 U.S.A.

Printed in U.S.A.

CASE CANADA CORPORATION
3350 SOUTH SERVICE ROAD
BURLINGTON, ON L7N 3M6 CANADA