

Zwecks prompter Belieferung der Kundschaft aus ihren gut eingerichteten Ersatzteillagern verfügen diese Vertretungen über ein zahlreiches Personal, das in der Fabrik Schulung im Lagern und Ausfolgen von Ersatzteilen erhalten hat. Es liegt in Ihrem Interesse, sich zu vergewissern, daß Ihre Anschrift, die Seriennummer und eine vollständige Beschreibung Ihrer Maschine, einschließlich allem Zubehör und Zusatzapparaten bei Ihrer zuständigen Vertretung vorliegen, so daß Rückfragen sich erübrigen, falls dringende Bestellungen beschleunigt bearbeitet werden müssen.

AUFGABE DER CATERPILLAR-VERTRETUNG. Es ist die Aufgabe der Caterpillar-Vertretung, dafür zu sorgen, daß es für Sie vorteilhaft und einträglich ist, unser Gerät zu erwerben und damit zu arbeiten. Durch ihre Verbindung mit der Zentrale kennt sie stets die neuesten Methoden, solche Maschinen zu benutzen, instand zu halten und zu reparieren, sowie die Einzelteile, die dazu erforderlich sind. Ihr modernes Lager entspricht dem vorausgerechneten Bedarf ihrer Kundschaft, wobei besonderer Nachdruck auf die Teile gelegt wird, die sich erfahrungsgemäß schneller abnutzen. So ist sie in der Lage, diese Produktionsmittel in arbeitsfähigem Zustand zu erhalten und das in ihnen investierte Kapital vor Verlusten zu bewahren.

Bei fast allen Caterpillar-Vertretungen besteht ein Notdienst, Tag und Nacht. Um die Anschrift und Telefonnummer der nächsten Zweigstelle an der Hand zu haben, empfiehlt es sich, sie vorn auf Ihrem Adreß- oder Telefonbuch zu vermerken.

WIR WARREN VOR NACHAHMUNGEN. Die Qualität und Werkarbeit, die den Weltruf der Caterpillar-Geräte begründet haben, findet man nur bei unseren Original-Ersatzteilen.

ESPAÑOL

COMO PEDIR PIEZAS DE REPUESTO. Es necesario indicar la cantidad, el número y el nombre de las piezas que se deseen. Es también importante dar el número de serie de la máquina para la cual se desean las piezas. Se sugiere que usted anote este número de serie de su máquina en el espacio que se ha dejado en la primera página, de manera que lo tenga siempre a mano cuando lo necesite.

Para que el despacho se efectúe con prontitud, es necesario que se dé el nombre correcto del consignatario, así como la dirección, además de los nombres de la provincia, y departamento o estado a que han de enviarse las piezas. Asimismo, debe especificarse el medio a utilizarse, si debe ser hecho como carga, o por expreso, paquete postal o en otra forma.

DONDE PEDIR LAS PIEZAS. Hay más de 400 establecimientos de los Distribuidores CATERPILLAR en los Estados Unidos, y en casi todo el mundo existen otros, similares, estratégicamente ubicados. Estas organizaciones están respaldadas por las extensas facilidades y recursos de Caterpillar Tractor Co.

El personal de los Distribuidores ha recibido su entrenamiento en la fábrica, en el almacenamiento y despacho de partes. Mantienen, además, grandes existencias de partes para asegurar un servicio rápido. Póngase en contacto con su Distribuidor CATERPILLAR para asegurarse de que tiene su nombre y dirección, el número de serie correcto de su máquina y una lista exacta de partes y accesorios. Este registro facilitará el despacho de partes cuando usted las necesite con urgencia.

LO QUE EL DISTRIBUIDOR CATERPILLAR PUEDE HACER POR USTED. Los Distribuidores tienen como objetivo el hacer económico y provechoso para usted poseer y trabajar maquinaria CATERPILLAR. Ellos están en contacto permanente con la fábrica para tener los últimos adelantos en los métodos de reparación y mantenimiento, procedimientos de trabajo y requerimientos de partes. Sus existencias de partes tienen gran movimiento y están siempre al día, incluyendo todas las partes normalmente requeridas para proteger su inversión en maquinaria CATERPILLAR.

Casi todos los Distribuidores ofrecen servicio de emergencia de día y de noche. Para referencia rápida, escriba el nombre y dirección de su Distribuidor local en la carpeta de su escritorio o en la tapa de su libro de teléfono.

SOLO LAS PIEZAS CATERPILLAR DAN EL RESULTADO APETECIDO. Todas las piezas CATERPILLAR han sido fabricadas según el patrón de alta calidad y mano de obra que ha hecho famosos los productos CATERPILLAR.

PORTUGUÊS

COMO FAZER OS PEDIDOS DE PEÇAS. Ponha no pedido a quantidade, o número e o nome de cada peça desejada. É também preciso pôr-se o número de série da máquina para a qual a peça se destina. Escreva o número de série de sua máquina no espaço para o mesmo reservado na página No. 1, para tê-lo à mão quando o precisar.

Para garantir pronta remessa não deixe de pôr o nome correto do consignatário bem como da rua, cidade, estado e país para onde as peças devem ser despachadas, indicando se o despacho deve ser feito como carga regular, encomenda postal via marítima ou aérea (regular ou expressa) ou qualquer outro modo.

PARA ONDE DIRIGIR OS PEDIDOS DE PEÇAS. Os distribuidores "Caterpillar" mantêm mais de 400 estabelecimentos comerciais nos Estados Unidos e em localizações estrategicamente espalhadas por quase todos os países do mundo. Todas essas organizações contam com o apoio e a cooperação de Caterpillar Tractor Co.

Os distribuidores mantêm, sempre, grande estoque de peças para servir os clientes com presteza. E seu pessoal, treinado na fábrica, sabe como lidar com peças. Comunique-se com o distribuidor "Caterpillar" mais próximo para se certificar se ele tem o seu nome e endereço, o exato número de série de sua máquina e uma lista de seus equipamentos e acessórios. O registro desses dados facilitará a remessa de peças quando as pedir com urgência.

O QUE O DISTRIBUIDOR "CATERPILLAR" PODE FAZER PARA LHE SERVIR. Nossos distribuidores têm interesse em tornar econômica e lucrativa a posse e o uso de nossas máquinas. Mantendo constante contato com a fábrica, estão sempre bem informados sobre os métodos mais modernos empregados para manobrá-las, conservá-las e repará-las, bem como sobre tudo que se refere a peças de substituição. Têm em estoque peças para qualquer máquina existente no território a seu cargo e em quantidade suficiente para evitar que as máquinas fiquem paradas.

Quase todos os distribuidores "Caterpillar" têm serviço mecânico de emergência aberto dia e noite. Para uma rápida referência, escreva o nome e o endereço do seu distribuidor no bloco de notas de sua escrevaninha ou na sua lista de telefone.

PEÇAS "CATERPILLAR" SÃO AS UNICAS RECOMENDAVEIS. As peças "Caterpillar" são feitas conforme o padrão de alta qualidade e a técnica de fabricação que tornaram os produtos "Caterpillar" famosos em todo o mundo.

INDEX

Name	Page
Guard	13
Hose and Fitting	47
Hydraulic Air Tank	54
Hydraulic Control Arrangements for:	
Bulldozer	5
Bulldozer and One Implement	10
Bulldozer and Scraper	9
One Implement	11
Scraper	8
Scraper or Two Implements	9
Tool Bar	12
Other Manufacturer's Attachments	12
Hydraulic Cylinder	50
Hydraulic Lines	42
Hydraulic Power Unit	24
Mounting	15
Specifications	56

7F5852 Arrangement—25 Gallons per Minute— Single Valve


For use with Bulldozers on D2 Tractors having

Serial No. 3J1 to 3J8600 and 5J1 to 5J10561 inclusive

Consists of:

- | | | | |
|---|--------|---------------------------------|-----------------|
| I | 7F3983 | Hydraulic Power Unit Group..... | Page 24 |
| I | 7F4275 | Hydraulic Lines Group..... | Shown on insert |
| | | —or— | |
| I | 8F2380 | Hydraulic Lines Group..... | Shown on insert |
| | | —or— | |
| I | 3H397 | Hydraulic Lines Group..... | Shown on insert |
| I | 7F4481 | Hose and Fitting..... | Page 47 |
| | | —or— | |
| I | 1H6458 | Hose and Fitting..... | Shown on insert |
| I | 7F5186 | Mounting Group | Page 16 |
| I | 7F5859 | Guard Group | Page 13 |

7F5852 HYDRAULIC CONTROL ARRANGEMENT



**FOR USE WITH BULLDOZERS MOUNTED ON D2 TRACTORS—
40 INCH & 50 INCH GAUGE**

7F5852 Arrangement—25 Gallons per Minute—Single Valve

For use on D2 Tractors having Serial No. 3J1 to 3J8600 and 5J1 to 5J10561 Inclusive.

Consists of:

I 7F3983	Hydraulic Power Unit Group	Page 24
I 7F4275	Hydraulic Lines Group	Page 42
I 7F4481	Hose and Fitting Group	Page 47
I 7F5186	Mounting Group	Page 16
I 7F5859	Guard Group	Page 13

7F4482 Arrangement—25 Gallons per Minute—Single Valve

For use on D2 Tractors having Serial No. 4U1—Up and 5U1—Up.

Consists of:

I 7F3983	Hydraulic Power Unit Group	Page 24
I 7F4275	Hydraulic Lines Group	Page 42
I 7F4439	Mounting Group	Page 17
I 7F4454	Guard Group	Page 14
I 7F4481	Hose and Fitting Group	Page 47

**FOR USE WITH BULLDOZERS MOUNTED ON D4 TRACTORS—
44 INCH GAUGE**

7F8315 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 4G1 to 4G9999 and 7J1 to 7J5103 Inclusive.

Consists of:

I 7F3949	Guard Group	Page 14
I 7F3950	Hose and Fitting Group	Page 48
I 7F3983	Hydraulic Power Unit Group	Page 24
I 7F5258	Mounting Group	Page 18
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	
	Consisting of:	
8	4F6489 Strip—Tapping	
2	5F6653 Strip	

7F8317 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J5104 to 7J7318 Inclusive.

Consists of:

I 7F3949	Guard Group	Page 14
I 7F3950	Hose and Fitting Group	Page 48
I 7F3983	Hydraulic Power Unit Group	Page 24
I 7F7314	Mounting Group	Page 19
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	
	Consisting of:	
8	4F6489 Strip—Tapping	
2	5F6653 Strip	

7F4424 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

I 7F3949	Guard Group	Page 14
I 7F3950	Hose and Fitting Group	Page 48
I 7F3983	Hydraulic Power Unit Group	Page 24
I 7F4438	Mounting Group	Page 20
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	
	Consisting of:	
8	4F6489 Strip—Tapping	
2	5F6653 Strip	

HYDRAULIC CONTROL ARRANGEMENTS

7F3995 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 6UI—Up.

Consists of:

I 7F3763	Hydraulic Lines Group	Page 43
I 7F3949	Guard Group	Page 14
I 7F3950	Hose and Fitting Group	Page 48
I 7F3983	Hydraulic Power Unit Group	Page 24
I 7F4002	Mounting Group	Page 21

7F8316 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 4G1 to 4G9999 and 7J1 to 7J5103 Inclusive.

Consists of:

I 7F3949	Guard Group	Page 14
I 7F3950	Hose and Fitting Group	Page 48
I 7F4000	Hydraulic Power Unit Group	Page 28
I 7F5258	Mounting Group	Page 18
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	
	Consisting of:	
8	4F6489 Strip—Tapping	
2	5F6653 Strip	

7F8320 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J5104 to 7J7318 Inclusive.

Consists of:

I 7F3949	Guard Group	Page 14
I 7F3950	Hose and Fitting Group	Page 48
I 7F4000	Hydraulic Power Unit Group	Page 28
I 7F7314	Mounting Group	Page 19
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	
	Consisting of:	
8	4F6489 Strip—Tapping	
2	5F6653 Strip	

7F4425 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

I 7F3949	Guard Group	Page 14
I 7F3950	Hose and Fitting Group	Page 48
I 7F4000	Hydraulic Power Unit Group	Page 28
I 7F4438	Mounting Group	Page 20
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	
	Consisting of:	
8	4F6489 Strip—Tapping	
2	5F6653 Strip	

7F3993 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 6UI—Up.

Consists of:

I 7F3763	Hydraulic Lines Group	Page 43
I 7F3949	Guard Group	Page 14
I 7F3950	Hose and Fitting Group	Page 48
I 7F4000	Hydraulic Power Unit Group	Page 28
I 7F4002	Mounting Group	Page 21

HYDRAULIC CONTROL ARRANGEMENTS**ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS**

FOR USE WITH BULLDOZERS MOUNTED ON D4 TRACTORS— 44 INCH GAUGE

5F1302 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive

Consists of:

- | | | | |
|---|--------|------------------------------|-----------------|
| I | 4F8881 | Hydraulic Control Group..... | Shown on insert |
| I | 5F1300 | Mounting Group | Shown on insert |

4F9338 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 6U1—Up

Consists of:

- | | | | |
|---|--------|------------------------------|-----------------|
| I | 4F8881 | Hydraulic Control Group..... | Shown on insert |
| I | 4F8943 | Mounting Group | Shown on insert |

FOR USE WITH BULLDOZERS MOUNTED ON D4 TRACTORS— 60 INCH GAUGE

5F2403 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive

Consists of:

- | | | | |
|---|--------|------------------------------|-----------------|
| I | 4F8881 | Hydraulic Control Group..... | Shown on insert |
| I | 5F2402 | Mounting Group | Shown on insert |

5F2404 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7U1—Up

Consists of:

- | | | | |
|---|--------|------------------------------|-----------------|
| I | 4F8881 | Hydraulic Control Group..... | Shown on insert |
| I | 5F2388 | Mounting Group | Shown on insert |

HYDRAULIC CONTROL ARRANGEMENTS

6F1167 Arrangement

For use with Bulldozers on D2 Tractors having
Serial No. 4U1—Up and 5U1—Up.

Consists of:

- I 6F1130 Mounting Group Shown on insert
- I 6F500 Hydraulic Control Group..... Shown on insert

6F3702 Arrangement

For use with Bulldozers on D2 Tractors having
Serial No. 3J1 to 3J8600 and 5J1 to 5J10561 inclusive.

Consists of:

- I 6F500 Hydraulic Control Group..... Shown on insert
- I 6F3701 Mounting Group Shown on insert

7F4482 Arrangement

25 Gallons per minute—Single Valve

For use with Bulldozers on D2 Tractors having
Serial No. 4U1—Up and 5U1—Up.

Consists of:

- I 7F3983 Hydraulic Control Group..... Page 24
- I 7F4275 Hydraulic Lines Group..... Page 42
- I 7F4439 Mounting Group Page 17
- I 7F4454 Guard Group Page 14
- I 7F4481 Hose and Fitting Group..... Page 47

or

- I H6458 Hose and Fitting Group Shown on insert

HYDRAULIC CONTROL ARRANGEMENTS

**FOR USE WITH BULLDOZERS MOUNTED ON D4 TRACTORS—
60 INCH GAUGE**

7F8314- Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 4G1 to 4G9999 and 7J1 to 7J5103 Inclusive.

Consists of:

I 7F3893	Hose and Fitting Group	Page 48
I 7F3949	Guard Group	Page 14
I 7F3983	Hydraulic Power Unit Group	Page 24
I 7F5258	Mounting Group	Page 18
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	

Consisting of:

8	4F6489	Strip—Tapping
2	5F6653	Strip

7F8318 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J5104 to 7J7318 Inclusive.

Consists of:

I 7F3893	Hose and Fitting Group	Page 48
I 7F3949	Guard Group	Page 14
I 7F3983	Hydraulic Power Unit Group	Page 24
I 7F7314	Mounting Group	Page 19
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	

Consisting of:

8	4F6489	Strip—Tapping
2	5F6653	Strip

7F4423 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

I 7F3893	Hose and Fitting Group	Page 48
I 7F3949	Guard Group	Page 14
I 7F3983	Hydraulic Power Unit Group	Page 24
I 7F4438	Mounting Group	Page 20
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	

Consisting of:

8	4F6489	Strip—Tapping
2	5F6653	Strip

7F3996 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7U1—Up.

Consists of:

I 7F3763	Hydraulic Lines Group	Page 43
I 7F3893	Hose and Fitting Group	Page 48
I 7F3949	Guard Group	Page 14
I 7F3983	Hydraulic Power Unit Group	Page 24
I 7F4002	Mounting Group	Page 21

HYDRAULIC CONTROL ARRANGEMENTS

7F8313 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 4G1 to 4G9999 and 7J1 to 7J5103 Inclusive.

Consists of:

I 7F3893	Hose and Fitting Group	Page 48
I 7F3949	Guard Group	Page 14
I 7F4000	Hydraulic Power Unit Group	Page 28
I 7F5258	Mounting Group	Page 18
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	
	Consisting of:	
8	4F6489 Strip—Tapping	
2	5F6653 Strip	

7F8319 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J5104 to 7J7318 Inclusive.

Consists of:

I 7F3893	Hose and Fitting Group	Page 48
I 7F3949	Guard Group	Page 14
I 7F4000	Hydraulic Power Unit Group	Page 28
I 7F7314	Mounting Group	Page 19
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	
	Consisting of:	
8	4F6489 Strip—Tapping	
2	5F6653 Strip	

7F4426 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

I 7F3893	Hose and Fitting Group	Page 48
I 7F3949	Guard Group	Page 14
I 7F4000	Hydraulic Power Unit Group	Page 28
I 7F4438	Mounting Group	Page 20
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	
	Consisting of:	
8	4F6489 Strip—Tapping	
2	5F6653 Strip	

7F3994 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7U1—Up.

Consists of:

I 7F3763	Hydraulic Lines Group	Page 43
I 7F3893	Hose and Fitting Group	Page 48
I 7F3949	Guard Group	Page 14
I 7F4000	Hydraulic Power Unit Group	Page 28
I 7F4002	Mounting Group	Page 21

FOR USE ON D4 TRACTOR WITH NO. 40 SCRAPER**7F4413 Arrangement—37 Gallons per Minute—Double Valve**

For use on D4 Tractors having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

I 7F3900	Hydraulic Power Unit Group	Page 32
I 7F3959	Hydraulic Lines Group	Page 46
I 7F4438	Mounting Group	Page 20
I 7F4855	Hydraulic Air Tank Group	Page 54

HYDRAULIC CONTROL ARRANGEMENTS

FOR USE WITH BULLDOZERS MOUNTED ON D4 TRACTORS—44 INCH GAUGE

8F9794 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 6U5843—Up

Consists of:

I 7F3763 Hydraulic Lines Group	Page 43
I 7F3949 Guard Group	Page 14
I 7F3950 Hose and Fitting Group	Page 48
I 7F3983 Hydraulic Control Group	Page 24
I 8F9433 Mounting Group	Shown on insert

8F9792 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 6U5843—Up

Consists of:

I 7F3763 Hydraulic Lines Group	Page 43
I 7F3949 Guard Group	Page 14
I 7F3950 Hose and Fitting Group	Page 48
I 7F4000 Hydraulic Control Group	Page 28
I 8F9433 Mounting Group	Shown on insert

FOR USE WITH BULLDOZERS MOUNTED ON D4 TRACTORS—60 INCH GAUGE

8F9789 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7U11952—Up

Consists of:

I 7F3763 Hydraulic Lines Group	Page 43
I 7F3893 Hose and Fitting Group	Page 48
I 7F3949 Guard Group	Page 14
I 7F3983 Hydraulic Control Group	Page 24
I 8F9433 Mounting Group	Shown on insert

8F9793 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7U11952—Up

Consists of:

I 7F3763 Hydraulic Lines Group	Page 43
I 7F3893 Hose and Fitting Group	Page 48
I 7F3949 Guard Group	Page 14
I 7F4000 Hydraulic Control Group	Page 28
I 8F9433 Mounting Group	Shown on insert

FOR USE ON D4 TRACTOR WITH SMALL SCRAPER OR TWO IMPLEMENTS

8F9791 Arrangement—25 Gallons per Minute—Double Valve

For use on D4 Tractors having Serial No. 6U5843—Up and 7U11952—Up

Consists of:

I 7F3984 Hydraulic Control Group	Page 36
I 7F4855 Hydraulic Air Tank Group	Page 54
I 8F8445 Hydraulic Lines Group	Shown on insert
I 8F9433 Mounting Group	Shown on insert

HYDRAULIC CONTROL ARRANGEMENTS

FOR USE ON D4 TRACTOR WITH NO. 40 SCRAPER OR TWO IMPLEMENTS

8F9795 Arrangement—37 Gallons Per Minute—Double Valve

For use on D4 Tractors having Serial No. 6U5843—Up and 7U11952—Up

Consists of:

I 7F3900 Hydraulic Control Group	Page 32
I 7F4855 Hydraulic Air Tank Group	Page 54
I 8F8445 Hydraulic Lines Group	Shown on insert
I 8F9433 Mounting Group	Shown on insert

FOR USE ON D4 TRACTOR WITH BULLDOZER AND NO. 40 SCRAPER

8F9857 Arrangement—37 Gallons per Minute—Double Valve

For use on D4 Tractors—44" Gauge having Serial No. 6U5843—Up

Consists of:

I 7F3763 Hydraulic Lines Group	Page 43
I 7F3949 Guard Group	Page 14
I 7F3950 Hose and Fitting Group	Page 48
I 8F9795 Hydraulic Control Arrangement	Listed above

8F9856 Arrangement—37 Gallons per Minute—Double Valve

For use on D4 Tractors—60" Gauge having Serial No. 7U11952—Up

Consists of:

I 7F3763 Hydraulic Lines Group	Page 43
I 7F3893 Hose and Fitting Group	Page 48
I 7F3949 Guard Group	Page 14
I 8F9795 Hydraulic Control Arrangement	Listed above

FOR USE ON D4 TRACTOR WITH BULLDOZER AND ONE IMPLEMENT

8F9858 Arrangement—28 Gallons per Minute—Single Valve

For use on D4 Tractors—44" Gauge having Serial No. 6U5843—Up

Consists of:

I 8F8436 Hydraulic Lines Group	Shown on insert
I 8F9794 Hydraulic Control Arrangement	Listed on insert

8F9853 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors—44" Gauge having Serial No. 6U5843—Up

Consists of:

I 8F8436 Hydraulic Lines Group	Shown on insert
I 8F9792 Hydraulic Control Arrangement	Listed on insert

8F9854 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors—60" Gauge having Serial No. 7U11952—Up

Consists of:

I 8F8436 Hydraulic Lines Group	Shown on insert
I 8F9789 Hydraulic Control Arrangement	Listed on insert

8F9855 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors—60" Gauge having Serial No. 7U11952—Up

Consists of:

I 8F8436 Hydraulic Lines Group	Shown on insert
I 8F9793 Hydraulic Control Arrangement	Listed on insert

HYDRAULIC CONTROL ARRANGEMENTS

7F3998 Arrangement—37 Gallons per Minute—Double Valve

For use on D4 Tractors having Serial No. 6U1—Up and 7U1—Up.

Consists of:

I 7F3900	Hydraulic Power Unit Group	Page 32
I 7F3959	Hydraulic Lines Group	Page 46
I 7F4002	Mounting Group	Page 21
I 7F4855	Hydraulic Air Tank Group	Page 54

FOR USE ON D4 TRACTOR WITH SMALL SCRAPER OR TWO IMPLEMENTS**7F5741 Arrangement—25 Gallons per Minute—Double Valve**For use on D4 Tractors having Serial No. 7J7319 to 7J9999,
2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

I 7F3959	Hydraulic Lines Group	Page 46
I 7F3984	Hydraulic Power Unit Group	Page 36
I 7F4438	Mounting Group	Page 20
I 7F4855	Hydraulic Air Tank Group	Page 54

7F5740 Arrangement—25 Gallons per Minute—Double Valve

For use on D4 Tractors having Serial No. 6U1—Up and 7U1—Up.

Consists of:

I 7F3959	Hydraulic Lines Group	Page 46
I 7F3984	Hydraulic Power Unit Group	Page 36
I 7F4002	Mounting Group	Page 21
I 7F4855	Hydraulic Air Tank Group	Page 54

FOR USE ON D6 TRACTOR WITH SCRAPER OR TWO IMPLEMENTS**7F5639 Arrangement—37 Gallons per Minute—Double Valve**

For use on D6 Tractors having Serial No. 8U1—Up and 9U1—Up.

Consists of:

I 7F3900	Hydraulic Power Unit Group	Page 32
I 7F4989	Hydraulic Lines Group	Page 45
I 7F5105	Mounting Group	Page 22
I 7F7010	Hydraulic Air Tank Group	Page 54
I 8F2753	Hydraulic Lines Group	Page 44

FOR USE ON D4 TRACTOR WITH BULLDOZER AND NO. 40 SCRAPER**8F858 Arrangement—37 Gallons per Minute—Double Valve**For use on D4 Tractors—44" Gauge having Serial No. 7J7319 to
7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

I 7F3949	Guard Group	Page 14
I 7F3950	Hose and Fitting Group	Page 48
I 7F4413	Hydraulic Control Arrangement	Listed on Page 8
I 8F1938	Hydraulic Lines Group	Page 42
I 5F6654	Mounting Group	

Consisting of:

- 8 4F6489 Strip—Tapping
- 2 5F6653 Strip

8F856 Arrangement—37 Gallons per Minute—Double Valve

For use on D4 Tractors—44" Gauge having Serial No. 6U1—Up.

Consists of:

I 7F3763	Hydraulic Lines Group	Page 43
I 7F3949	Guard Group	Page 14
I 7F3950	Hose and Fitting Group	Page 48
I 7F3998	Hydraulic Control Arrangement	Listed above

HYDRAULIC CONTROL ARRANGEMENTS

8F859 Arrangement—37 Gallons per Minute—Double Valve

For use on D4 Tractors—60" Gauge having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

7F3893	Hose and Fitting Group	Page 48
7F3949	Guard Group	Page 14
7F4413	Hydraulic Control Arrangement	Listed on Page 8
8F1938	Hydraulic Lines Group	Page 42
5F6654	Mounting Group	
	Consisting of:	
8	4F6489 Strip—Tapping	
2	5F6653 Strip	

8F857 Arrangement—37 Gallons per Minute—Double Valve

For use on D4 Tractors—60" Gauge having Serial No. 7U1—Up.

Consists of:

7F3763	Hydraulic Lines Group	Page 43
7F3893	Hose and Fitting Group	Page 48
7F3949	Guard Group	Page 14
7F3998	Hydraulic Control Arrangement	Listed on Page 9

FOR USE ON D4 TRACTOR WITH BULLDOZER AND ONE IMPLEMENT**8F866 Arrangement—25 Gallons per Minute—Single Valve**

For use on D4 Tractors—44" Gauge having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

7F3858	Hydraulic Lines Group	Page 47
7F4424	Hydraulic Control Arrangement	Listed on Page 5

8F864 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors—44" Gauge having Serial No. 6U1—Up.

Consists of:

7F3858	Hydraulic Lines Group	Page 47
7F3995	Hydraulic Control Arrangement	Listed on Page 6

8F862 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors—44" Gauge having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

7F3858	Hydraulic Lines Group	Page 47
7F4425	Hydraulic Control Arrangement	Listed on Page 6

8F860 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors—44" Gauge having Serial No. 6U1—Up.

Consists of:

7F3858	Hydraulic Lines Group	Page 47
7F3993	Hydraulic Control Arrangement	Listed on Page 6

8F867 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors—60" Gauge having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

7F3858	Hydraulic Lines Group	Page 47
7F4423	Hydraulic Control Arrangement	Listed on Page 7

8F865 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors—60" Gauge having Serial No. 7U1—Up.

Consists of:

7F3858	Hydraulic Lines Group	Page 47
7F3996	Hydraulic Control Arrangement	Listed on Page 7

HYDRAULIC CONTROL ARRANGEMENTS

- 8F863 Arrangement—37 Gallons per Minute—Single Valve**
For use on D4 Tractors—60" Gauge having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.
- Consists of:
- I 7F3858 Hydraulic Lines GroupPage 47
 - I 7F4426 Hydraulic Control ArrangementListed on Page 8

- 8F861 Arrangement—37 Gallons per Minute—Single Valve**
For use on D4 Tractors—60" Gauge having Serial No. 7U1—Up.
- Consists of:
- I 7F3858 Hydraulic Lines GroupPage 47
 - I 7F3994 Hydraulic Control ArrangementListed on Page 8

FOR USE ON D2 TRACTOR WITH ONE IMPLEMENT

- 7F5851 Arrangement—25 Gallons per Minute—Single Valve**
For use on D2 Tractors having Serial No. 3J1 to 3J8600 and 5J1 to 5J10561 Inclusive.
- Consists of:
- I 7F3983 Hydraulic Power Unit GroupPage 24
 - I 7F4263 Hydraulic Lines GroupPage 43
 - I 7F5186 Mounting GroupPage 16

- 7F4480 Arrangement—25 Gallons per Minute—Single Valve**
For use on D2 Tractors having Serial No. 4U1—Up and 5U1—Up.
- Consists of:
- I 7F3983 Hydraulic Power Unit GroupPage 24
 - I 7F4263 Hydraulic Lines GroupPage 43
 - I 7F4439 Mounting GroupPage 17

FOR USE ON D4 TRACTOR WITH ONE IMPLEMENT

- 7F8321 Arrangement—25 Gallons per Minute—Single Valve**
For use on D4 Tractors having Serial No. 4G1 to 4G9999 and 7J1 to 7J5103 Inclusive.
- Consists of:
- I 7F3858 Hydraulic Lines GroupPage 47
 - I 7F3983 Hydraulic Power Unit GroupPage 24
 - I 7F5258 Mounting GroupPage 18

- 7F8322 Arrangement—25 Gallons per Minute—Single Valve**
For use on D4 Tractors having Serial No. 7J5104 to 7J7318 Inclusive.
- Consists of:
- I 7F3858 Hydraulic Lines GroupPage 47
 - I 7F3983 Hydraulic Power Unit GroupPage 24
 - I 7F7314 Mounting GroupPage 19

- 7F4422 Arrangement—25 Gallons per Minute—Single Valve**
For use on D4 Tractors having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.
- Consists of:
- I 7F3858 Hydraulic Lines GroupPage 47
 - I 7F3983 Hydraulic Power Unit GroupPage 24
 - I 7F4438 Mounting GroupPage 20

- 7F3997 Arrangement—25 Gallons per Minute—Single Valve**
For use on D4 Tractors having Serial No. 6U1—Up and 7U1—Up.
- Consists of:
- I 7F3858 Hydraulic Lines GroupPage 47
 - I 7F3983 Hydraulic Power Unit GroupPage 24
 - I 7F4002 Mounting GroupPage 21

HYDRAULIC CONTROL ARRANGEMENTS

FOR USE ON D6 TRACTOR WITH ONE IMPLEMENT

7F5107 Arrangement—37 Gallons per Minute—Single Valve

For use on D6 Tractors having Serial No. 8UI—Up and 9UI—Up.

Consists of:

I	7F4000	Hydraulic Power Unit Group	Page 28
I	7F5105	Mounting Group	Page 22
I	8F2753	Hydraulic Lines Group	Page 44

FOR USE WITH TOOL BAR MOUNTED ON D4 TRACTOR

8F3975 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.

Consists of:

I	7F3983	Hydraulic Power Unit Group	Page 24
I	7F4438	Mounting Group	Page 20
I	8F517	Hydraulic Lines Group	Page 44

8F1676 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 6UI—Up and 7UI—Up.

Consists of:

I	7F3983	Hydraulic Power Unit Group	Page 24
I	7F4002	Mounting Group	Page 21
I	8F517	Hydraulic Lines Group	Page 44

FOR USE WITH HT4 INDUSTRIAL LOADER MOUNTED ON D4 TRACTOR

7F3894 Arrangement—37 Gallons per Minute—Double Valve

For use on D4 Tractors having Serial No. 7UI—Up.

Consists of:

I	7F3895	Mounting Group	Page 15
I	7F3900	Hydraulic Power Unit Group	Page 32

FOR USE WITH AFH4 ANGLE FILLER MOUNTED ON D4 TRACTOR

8F48 Arrangement—37 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7UI—Up.

Consists of:

I	4F8661	Hydraulic Cylinder Group—R.H.	Page 50
		or	
I	8F1123	Hydraulic Cylinder Group—R.H.	Page 51
I	7F3949	Guard Group	Page 14
I	7F4000	Hydraulic Power Unit Group	Page 28
I	8F52	Mounting Group	Page 15
2	3B4615	Cotter Pin	
I	5B1797	Pin	
I	5F689	Pin	

FOR USE WITH L2 & LW2 AGRICULTURAL LOADERS MOUNTED ON D2 TRACTORS

7F4994 Arrangement—25 Gallons per Minute—Single Valve

For use on D2 Tractors having Serial No. 4UI—Up and 5UI—Up.

Consists of:

I	7F3983	Hydraulic Power Unit Group	Page 24
I	7F4275	Hydraulic Lines Group	Page 42
I	7F4439	Mounting Group	Page 17
I	7F4454	Guard Group	Page 14
8	3B4508	Lockwasher	
8	S-1595	Cap Screw	

HYDRAULIC CONTROL ARRANGEMENTS

FOR USE WITH L2 & LW2 AGRICULTURAL LOADERS MOUNTED ON D2 TRACTORS

7F5591 Arrangement—26 Gallons per Minute—Single Valve

For use on Tractors having Serial No. 3J1 to 3J8600
and 5J1 to 5J10561 Inclusive


Consists of:

- I 7F3983 Hydraulic Power Unit Group...Shown on Page 24
- I 7F5186 Hydraulic Mounting Group...Shown on Page 16
- I 7F5859 Guard Group.....Shown on Page 13
- I 8F2380 Hydraulic Lines Group.....Shown on insert

—or—

- I 3H397 Hydraulic Lines Group.....Shown on insert


HYDRAULIC CONTROL ARRANGEMENT



37761

3H397 HYDRAULIC LINES GROUP

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



FOR USE WITH L4 & LW4 AGRICULTURAL LOADERS MOUNTED ON D4 TRACTORS

IH7277 Arrangement—37 Gallons per Minute

For use on D4 Tractors having Serial No. 6U5843—Up
and 7U11952—Up

Consists of:

I	7F3763	Hydraulic Lines Group.....	Page 43
I	7F3949	Guard Group	Page 14
I	7F4000	Hydraulic Power Unit Group.....	Page 28
I	8F9433	Hydraulic Control Unit Mounting Group.....	Shown on insert


IH7278 Arrangement—24.5 Gallons per Minute


For use on D4 Tractors having Serial No. 6U5843—Up
and 7U11952—Up

Consists of:


I	7F3763	Hydraulic Lines Group.....	Page 43
I	7F3949	Guard Group	Page 14
I	7F3983	Hydraulic Power Unit Group.....	Page 24
I	8F9433	Hydraulic Control Unit Mounting Group.....	Shown on insert

HYDRAULIC CONTROL ARRANGEMENTS





**3H397 HYDRAULIC LINES GROUP**

Part of 3H4288 Hydraulic Control Arrangement listed on insert

**3H321 HYDRAULIC LINES GROUP**

Part of 3H4293 Hydraulic Control Arrangement listed on insert

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

FOR USE WITH LIGHTWEIGHT TOOL BAR MOUNTED ON D2 TRACTOR

3H4288 Arrangement—25 Gallons per Minute—Single Valve

For use on D2 Tractors having Serial No. 3J1 to 3J8600 and 5J1 to 5J10561 inclusive

Consists of:

- I 7F3983 Hydraulic Control Group.....Page 24
- I 7F5186 Mounting Group.....Page 16
- I 2H6713 Hose and Fitting Group.....shown on insert
- I 3H397 Hydraulic Lines Group.....shown on insert

3H4293 Arrangement—25 Gallons per Minute—Single Valve (Replaces 8F3238)

For use on D2 Tractors having Serial No. 4U1—Up and 5U1—Up

Consists of:

- I 7F3983 Hydraulic Control Group.....Page 24
- I 7F4439 Mounting Group.....Page 17
- I 2H6713 Hose and Fitting Group.....shown on insert
- I 3H321 Hydraulic Lines Group.....shown on insert

HYDRAULIC CONTROL ARRANGEMENTS

FOR USE WITH LIGHTWEIGHT TOOL BAR MOUNTED ON D4 TRACTORS

3H4290 Arrangement—25 Gallons per Minute—Single Valve (Replaces 9F9722)

For use on D4 Tractors having Serial No. 4G1 to 4G9999 and 7J1 to 7J5103 inclusive

Consists of:

I 7F3763 Hydraulic Lines Group.....	Page 43
I 7F3983 Hydraulic Control Group.....	Page 24
I 7F5258 Mounting Group.....	Page 18
I 2H6711 Hose and Fitting Group.....	shown on insert

3H4291 Arrangement—25 Gallons per Minute—Single Valve (Replaces 9F9723)

For use on D4 Tractors having Serial No. 7J5104 to 7J7318 inclusive

Consists of:

I 7F3763 Hydraulic Lines Group.....	Page 43
I 7F3983 Hydraulic Control Group.....	Page 24
I 7F7314 Mounting Group.....	Page 19
I 2H6711 Hose and Fitting Group.....	shown on insert

3H4292 Arrangement—25 Gallons per Minute—Single Valve (Replaces 9F9724)

For use on D4 Tractors having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 inclusive

Consists of:

I 7F3763 Hydraulic Lines Group.....	Page 43
I 7F3983 Hydraulic Control Group.....	Page 24
I 7F4438 Mounting Group.....	Page 20
I 2H6711 Hose and Fitting Group.....	shown on insert

3H4289 Arrangement—25 Gallons per Minute—Single Valve (Replaces 9F9689)

For use on D4 Tractors having Serial No. 6U1 to 6U5842 and 7U1 to 7U11951 inclusive

Consists of:

I 7F3763 Hydraulic Lines Group.....	Page 43
I 7F3983 Hydraulic Control Group.....	Page 24
I 7F4002 Mounting Group.....	Page 21
I 2H6711 Hose and Fitting Group.....	shown on insert

3H4294 Arrangement—25 Gallons per Minute—Single Valve (Replaces 9F6940)


For use on D4 Tractors having Serial No. 6U5843—Up and 7U11952—Up

Consists of:


I 7F3763 Hydraulic Lines Group.....	Page 43
I 7F3983 Hydraulic Control Group.....	Page 24
I 8F9433 Mounting Group.....	shown on insert
I 2H6711 Hose and Fitting Group.....	shown on insert

HYDRAULIC CONTROL ARRANGEMENTS

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS


**9F6991 MOUNTING GROUP**

Part of 9F6995, 9F6997, 9F6996 and 9F6998 Hydraulic Control Arrangements listed on insert

**9F6992 MOUNTING GROUP**


Part of 9F6999, 9F7000, 9F7002 and 9F7001 Hydraulic Control Arrangements listed on insert

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



9F6995 MOUNTING GROUP

Part of 2H3946, 9F7003, 9F7005, 9F7006 and 9F7004 Hydraulic Control Arrangements listed on insert



9F6994 CONTROL GROUP

Part of 9F6995, 9F6997, 9F6999, 9F7001, 9F7003, 9F7005 and 2H3946 Hydraulic Control Arrangements listed on insert

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

FOR USE ON D4 TRACTORS WITH SCRAPERS

2H3945 Arrangement—25 Gallons per Minute—Double Valve

For use on D4 Tractors having Serial Nos. 7U11952—up
and 6U5843—up

Consists of:

- I IH8580 Hydraulic Control Group—Rear.....
.....listed on insert
- I IH8522 Mounting Group.....shown on insert
- I IH8536 Control Group.....shown on insert
- I IH8468 Fitting Group—Single Valve..shown on insert
- I IH8469 Fitting Group—Double Valve..shown on insert
- I IH8541 Tank Group.....shown on insert

HYDRAULIC CONTROL ARRANGEMENTS—Rear Mounted

1-FILLER ----- 9F7174

1-COVER ASSEM. --- 3H5279

CONSISTING OF:


1-COVER ASSEM. --- 9F6341

10-CAP SCREW --- S-1594

10-LOCKWASHER --- 3B4506

1-COVER ----- 3H5276

1-RING ----- 3H5277



35095

2H3944 HYDRAULIC SURGE TANK GROUP—Rear Mounted

Part of 2H3946 Hydraulic Control Arrangement listed on insert

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

FOR USE ON D8 TRACTORS WITH TRAILING AGRICULTURAL
OR INDUSTRIAL EQUIPMENT

9F6995 Arrangement—26 Gallons per Minute—Double Valve

For use on D8 Tractors having Serial Nos. 1H1 to 1H9999
and 8R1 to 8R9999 inclusive and 2U1—up

Consists of:

- I 9F6868 Hydraulic Control Group—Rear.....
.....listed on insert
- I 9F6991 Mounting Group.....shown on insert
- I 9F6994 Control Group.....shown on insert
- I 1H8468 Fitting Group—Single Valve..shown on insert
- I 1H8469 Fitting Group—Double Valve..shown on insert

9F6997 Arrangement—18 Gallons per Minute—Double Valve

For use on D8 Tractors having Serial Nos. 1H1 to 1H9999
and 8R1 to 8R9999 inclusive and 2U1—up

Consists of:

- I 9F6869 Hydraulic Control Group—Rear.....
.....listed on insert
- I 9F6991 Mounting Group.....shown on insert
- I 9F6994 Control Group.....shown on insert
- I 1H8468 Fitting Group—Single Valve..shown on insert
- I 1H8469 Fitting Group—Double Valve..shown on insert

9F6996 Arrangement—26 Gallons per Minute—Single Valve

For use on D8 Tractors having Serial Nos. 1H1 to 1H9999
and 8R1 to 8R9999 inclusive and 2U1—up

Consists of:

- I 9F6870 Hydraulic Control Group—Rear.....
.....listed on insert
- I 9F6991 Mounting Group.....shown on insert
- I 1H8468 Fitting Group—Single Valve..shown on insert

9F6998 Arrangement—18 Gallons per Minute—Single Valve

For use on D8 Tractors having Serial Nos. 1H1 to 1H9999
and 8R1 to 8R9999 inclusive and 2U1—up

Consists of:

- I 9F6988 Hydraulic Control Group—Rear.....
.....listed on insert
- I 9F6991 Mounting Group.....shown on insert
- I 1H8468 Fitting Group—Single Valve..shown on insert

HYDRAULIC CONTROL ARRANGEMENTS—Rear Mounted

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

9F6868 Part of 9F6995, 9F6999, 9F7003 and 2H3946 Hydraulic Control Arrangements

Consists of:

- 1 7F3900 Hydraulic Control Group..Pages 32 through 35 and on insert
- 2 4B4159 Screw
- 4 1D4539 Cap Screw
- 1 4F8842 Cap
- 1 4F8843 Gasket
- 1 5F3489 Strainer Assembly
- 1 5F4721 Seal
- *1 7F3712 Filler
- 1 9F7175 Retainer
- 1 9F7283 Ring
- 1 1H9912 Plate

*Not required when used with Surge Tank

9F6869 Part of 9F6997, 9F7001 and 9F7005 Hydraulic Control Arrangements

Consists of:

- 1 7F3984 Hydraulic Control Group..Pages 36 through 39 and on insert
- 2 4B4159 Screw
- 1 1D4539 Cap Screw
- 1 4F8842 Cap
- 1 4F8843 Gasket
- 1 5F3489 Strainer Assembly
- 1 5F4721 Seal
- *1 7F3712 Filler
- 1 9F7175 Retainer
- 1 9F7283 Ring
- 1 1H9911 Plate

*Not required when used with Surge Tank

9F6870 Part of 9F6996, 9F7000 and 9F7006 Hydraulic Control Arrangements

Consists of:

- 1 7F4000 Hydraulic Control Group..Pages 28 through 31 and on insert
- 2 4B4159 Screw
- 4 1D4539 Cap Screw
- 1 5F4721 Seal
- 1 9F7175 Retainer
- 1 9F7283 Ring
- 1 1H9912 Plate

9F6988 Part of 9F6998, 9F7002 and 9F7004 Hydraulic Control Arrangements

Consists of:

- 1 7F3983 Hydraulic Control Group..Pages 25 through 27 and on insert
- 2 4B4159 Screw
- 4 1D4539 Cap Screw
- 1 5F4721 Seal
- 1 9F7283 Seal
- 1 1H9911 Plate

HYDRAULIC CONTROL GROUPS**ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS**

**FOR USE ON D6 TRACTORS WITH TRAILING AGRICULTURAL
OR INDUSTRIAL EQUIPMENT OR SCRAPER**

2H3946 Arrangement—37 Gallons per Minute—Double Valve

For use on D6 Tractors having Serial Nos. 4R1 to 4R3633, 5R1 to 5R5515, 8U1—up and 9U1—up

Consists of:

- I 9F6868 Hydraulic Control Group—Rear.....Listed on insert
- I 9F6993 Mounting GroupShown on insert
- I 9F6994 Control GroupShown on insert
- I 1H8468 Fitting GroupShown on insert
- I 1H8469 Fitting GroupShown on insert
- I 2H3944 Tank GroupShown on insert

9F7003 Arrangement—37 Gallons per Minute—Double Valve

For use on D6 Tractors having Serial Nos. 4R1 to 4R3633, 5R1 to 5R5515, 8U1—up and 9U1—up

Consists of:

- I 9F6868 Hydraulic Control Group—Rear.....Listed on insert
- I 9F6993 Mounting GroupShown on insert
- I 9F6994 Control GroupShown on insert
- I 1H8468 Fitting Group—Single Valve.....Shown on insert
- I 1H8469 Fitting Group—Double Valve.....Shown on insert

9F7005 Arrangement—25 Gallons per Minute—Double Valve

For use on D6 Tractors having Serial Nos. 4R1 to 4R3633, 5R1 to 5R5515, 8U1—up and 9U1—up

Consists of:

- I 9F6869 Hydraulic Control Group—Rear.....Listed on insert
- I 9F6993 Mounting GroupShown on insert
- I 9F6994 Control GroupShown on insert
- I 1H8468 Fitting Group—Single ValveShown on insert
- I 1H8469 Fitting Group—Double Valve.....Shown on insert

9F7006 Arrangement—37 Gallons per minute—Single Valve

For use on D6 Tractors having Serial Nos. 4R1 to 4R3633, 5R1 to 5R5515, 8U1—up and 9U1—up

Consists of:

- I 9F6870 Hydraulic Control Group—Rear.....Listed on insert
- I 9F6993 Mounting GroupShown on insert
- I 1H8468 Fitting Group—Single ValveShown on insert

9F7004 Arrangement—25 Gallons per Minute—Single Valve

For use on D6 Tractors having Serial Nos. 4R1 to 4R3633, 5R1 to 5R5515, 8U1—up and 9U1—up

Consists of:

- I 9F6988 Hydraulic Control Group—Rear.....Listed on insert
- I 9F6993 Mounting GroupShown on insert
- I 1H8468 Fitting Group—Single Valve.....Shown on insert

HYDRAULIC CONTROL ARRANGEMENTS—Rear Mounted

**FOR USE ON D7 TRACTORS WITH TRAILING AGRICULTURAL
OR INDUSTRIAL EQUIPMENT**

9F6999 Arrangement—26 Gallons per Minute—Double Valve

For use on D7 Tractors having Serial Nos. 7M1 to 7M9999 inclusive and 3T1—up

Consists of:

- I 9F6868 Hydraulic Control Group—
Rear listed on insert
- I 9F6992 Mounting Group shown on insert
- I 9F6994 Control Group shown on insert
- I 1H8468 Fitting Group—Single Valve... shown on insert
- I 1H8469 Fitting Group—Double Valve .. shown on insert

9F7001 Arrangement—18 Gallons per Minute—Double Valve

For use on D7 Tractors having Serial Nos. 7M1 to 7M9999 inclusive and 3T1—up

Consists of:

- I 9F6869 Hydraulic Control Group—
Rear listed on insert
- I 9F6992 Mounting Group shown on insert
- I 9F6994 Control Group shown on insert
- I 1H8468 Fitting Group—Single Valve... shown on insert
- I 1H8469 Fitting Group—Double Valve .. shown on insert

9F7000 Arrangement—26 Gallons per Minute—Single Valve

For use on D7 Tractors having Serial Nos. 7M1 to 7M9999 inclusive and 3T1—up

Consists of:

- I 9F6870 Hydraulic Control Group—
Rear listed on insert
- I 9F6992 Mounting Group shown on insert
- I 1H8468 Fitting Group—Single Valve... shown on insert

9F7002 Arrangement—18 Gallons per Minute—Single Valve

For use on D7 Tractors having Serial Nos. 7M1 to 7M9999 inclusive and 3T1—up

Consists of:

- I 9F6988 Hydraulic Control Group—
Rear listed on insert
- I 9F6992 Mounting Group shown on insert
- I 1H8468 Fitting Group—Single Valve... shown on insert

HYDRAULIC CONTROL ARRANGEMENTS—Rear Mounted

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



Part of 9F3053, 9F3052, 9F3054 Arrangements and 9F5984 Mounting Group
listed on front side of insert

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

FOR USE ON D6 TRACTORS WITH ONE IMPLEMENT

9F5982 Arrangement—37 Gallons per Minute—Single Valve

For use on D6 Tractors having Serial No. 4R1 to 4R955 and 5R1 to 5R1258 inclusive

Consists of:

- I 7F4000 Hydraulic Power Unit Group.....Page 28
- I 8F2753 Hydraulic Lines Group.....Page 44
- I 9F5984 Mounting GroupListed below

9F3053 Arrangement—37 Gallons per Minute—Single Valve

For use on D6 Tractors having Serial No. 4R956—Up and 5R1259—Up

Consists of:

- I 7F4000 Hydraulic Power Unit Group.....Page 28
- I 8F2753 Hydraulic Lines Group.....Page 44
- I 9F3055 Mounting Group.....Shown on reverse side of insert

FOR USE ON D6 TRACTORS WITH TWO IMPLEMENTS

9F5981 Arrangement—37 Gallons per Minute—Double Valve

For use on D6 Tractors having Serial No. 4R1 to 4R955 and 5R1 to 5R1258 inclusive

Consists of:

- I 7F3900 Hydraulic Power Unit Group.....Page 32
- I 8F2753 Hydraulic Lines Group.....Page 44
- I 9F3061 Hydraulic Lines Group.....Shown on insert
- I 9F5978 Hydraulic Surge Tank Group.....Shown on insert
- I 9F5984 Mounting GroupListed below

9F3052 Arrangement—37 Gallons per Minute—Double Valve

For use on D6 Tractors having Serial No. 4R956—Up and 5R1259—Up

Consists of:

- I 7F3900 Hydraulic Power Unit Group.....Page 32
- I 8F2753 Hydraulic Lines Group.....Page 44
- I 9F3055 Mounting Group.....Shown on reverse side of insert
- I 9F3061 Hydraulic Lines Group.....Shown on insert
- I 9F5978 Hydraulic Surge Tank Group.....Shown on insert

FOR USE WITH TOOL BAR MOUNTING ON D6 TRACTOR

9F5983 Arrangement—37 Gallons per Minute—Single Valve

For use on D6 Tractors having Serial No. 4R1 to 4R955 and 5R1 to 5R1258 inclusive

Consists of:

- I 7F4000 Hydraulic Power Unit Group.....Page 28
- I 8F9673 Hydraulic Lines Group.....Shown on insert
- I 9F5984 Mounting GroupListed below

9F3054 Arrangement—37 Gallons per Minute—Single Valve

For use on D6 Tractors having Serial No. 4R956—Up and 5R1259—Up

Consists of:

- I 7F4000 Hydraulic Power Unit Group.....Page 28
- I 8F9673 Hydraulic Lines Group.....Shown on insert
- I 9F3055 Mounting Group.....Shown on reverse side of insert

9F5984 Mounting Group

Part of 9F5982, 9F5981 and 9F5983 Hydraulic Control Arrangements


Consists of:

- I 9F3055 Mounting Group.....Shown on reverse side of insert
- 4 3B4508 Lockwasher
- 2 1F9234 Lug
- 4 S-1595 Cap Screw

HYDRAULIC CONTROL ARRANGEMENTS


ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

INSERT BETWEEN PAGES 12 & 13 IN FORM 30032—PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL



9F3061 HYDRAULIC LINES

Part of 9F5981 and 9F3052 Hydraulic Control Arrangements listed on insert



9F5978 HYDRAULIC SURGE TANK

Part of 9F5981 and 9F3052 Hydraulic Control Arrangements listed on insert

FOR USE ON D4 TRACTORS WITH ONE IMPLEMENT

8F9790 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 6U5843—Up and 7U11952—Up

Consists of:

- I 7F3983 Hydraulic Control GroupPage 24
- I 8F8436 Hydraulic Lines GroupShown on insert
- I 8F9433 Mounting GroupShown on insert

FOR USE WITH TOOL BAR MOUNTED ON D4 TRACTOR

9F4598 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 4G1 to 4G9999 and 7J1 to 7J5103 Inclusive

Consists of:

- I 7F3983 Hydraulic Control GroupPage 24
- I 7F5258 Mounting GroupPage 18
- I 8F9301 Hydraulic Lines GroupShown on insert

9F4599 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J5104 to 7J7318 Inclusive

Consists of:

- I 7F3983 Hydraulic Control GroupPage 24
- I 7F7314 Mounting GroupPage 19
- I 8F9301 Hydraulic Lines GroupShown on insert

8F9796 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors have Serial No. 6U5843—Up and 7U11952—Up

Consists of:

- I 7F3983 Hydraulic Control GroupPage 24
- I 8F9301 Hydraulic Lines GroupShown on insert
- I 8F9433 Mounting GroupShown on insert

FOR USE WITH TOOL BAR MOUNTED ON D6 TRACTOR

9F330 Arrangement—37 Gallons per Minute—Single Valve

For use on D6 Tractors having Serial No. 8U1—Up and 9U1—Up

Consists of:

- I 7F4000 Hydraulic Control GroupPage 28
- I 7F5105 Mounting GroupPage 22
- I 8F9673 Hydraulic Lines GroupShown on insert

HYDRAULIC CONTROL ARRANGEMENTS

FOR USE WITH LIGHTWEIGHT TOOL BAR MOUNTED ON D2 TRACTOR

8F8238 Arrangement—25 Gallons per Minute—Single Valve

For use on D2 Tractors having Serial No. 4U1—Up and 5U1—Up

Consists of:

I 7F3983 Hydraulic Control Group	Page 24
I 7F4275 Hydraulic Lines Group	Page 42
I 7F4439 Mounting Group	Page 17
I 9F3312 Hose and Fitting Group	Shown on insert
I 9F6941 Hose and Fitting Group	Shown on insert

FOR USE WITH LIGHTWEIGHT TOOL BAR MOUNTED ON D4 TRACTOR

9F9722 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 4G1 to 4G9999 and 7J1 to 7J5103 Inclusive

Consists of:

I 7F3763 Hydraulic Lines Group	Page 43
I 7F3983 Hydraulic Control Group	Page 24
I 7F5258 Mounting Group	Page 18
I 9F6941 Hose and Fitting Group	Shown on insert

9F9723 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J5104 to 7J7318 Inclusive

Consists of:

I 7F3763 Hydraulic Lines Group	Page 43
I 7F3983 Hydraulic Control Group	Page 24
I 7F7314 Mounting Group	Page 19
I 9F6941 Hose and Fitting Group	Shown on insert

9F9724 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 7J7319 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive

Consists of:

I 7F3763 Hydraulic Lines Group	Page 43
I 7F3983 Hydraulic Control Group	Page 24
I 7F4438 Mounting Group	Page 20
I 9F6941 Hose and Fitting Group	Shown on insert

9F9689 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 6U1 to 6U5842 and 7U1 to 7U11951 Inclusive

Consists of:

I 7F3763 Hydraulic Lines Group	Page 43
I 7F3983 Hydraulic Control Group	Page 24
I 7F4002 Mounting Group	Page 21
I 9F6941 Hose and Fitting Group	Shown on insert

9F6940 Arrangement—25 Gallons per Minute—Single Valve

For use on D4 Tractors having Serial No. 6U5843—Up and 7U11952—Up


Consists of:

I 7F3763 Hydraulic Lines Group	Page 43
I 7F3983 Hydraulic Control Group	Page 24
I 8F9433 Mounting Group	Shown on insert
I 9F6941 Hose and Fitting Group	Shown on insert

HYDRAULIC CONTROL ARRANGEMENTS

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

INSERT BETWEEN PAGES 12 & 13 IN FORM 30032—
PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL



8F9673 HYDRAULIC LINES GROUP


Part of 9F330 Hydraulic Control Arrangement listed on insert

IH1331 Hydraulic Control Arrangement—37 Gallons per Minute —Single Valve

For use with AFH4 Angle Filler Mounted on D4 Tractors having Serial No. 7U11952—Up

Consists of:

- 1 7F3949 Guard Group Page 14
- 1 7F4000 Hydraulic Power Unit Group Page 28
- 1 8F1123 Hydraulic Cylinder Group—R.H. Page 51
- 1 9F8685 Mounting Group Shown below
- 2 3B4617 Cotter Pin
- 1 5B1797 Pin
- 1 5F689 Pin



9F8685 MOUNTING GROUP

Part of IH1331 Hydraulic Control Arrangement

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

FOR USE WITH L2 & LW2 AGRICULTURAL LOADERS MOUNTED ON
D2 TRACTORS


7F5591 Arrangement—26 Gallons per Minute—Single Valve

For use on Tractors having Serial No. 3J1 to 3J8600 and
5J1 to 5J10561 Inclusive.

Consists of:

- I 7F3983 Hydraulic Power Unit Group.....Page 24
- I 7F5186 Hydraulic Mounting GroupPage 16
- I 7F5859 Guard GroupPage 13
- I 8F2380 Hydraulic Lines GroupShown below

HYDRAULIC CONTROL ARRANGEMENT



8F2380 HYDRAULIC LINES GROUP

Part of 7F5591 Hydraulic Control Arrangement

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

FOR USE WITH TOOL BAR MOUNTED ON D6 TRACTOR


8F2826 Arrangement—25 Gallons per Minute—Single Valve

For use on D6 Tractors having Serial No. 8U1—Up and
9U1—Up

Consists of:

- I 7F3983 Hydraulic Power Unit Group Page 24
- I 7F5105 Mounting Group Page 22
- I 8F2754 Hydraulic Lines Group Shown Below

HYDRAULIC CONTROL ARRANGEMENT



8F2754 HYDRAULIC LINES GROUP


Part of 8F2826 Hydraulic Control Arrangement

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

**FOR USE WITH L4 & LW4 AGRICULTURAL LOADERS
MOUNTED ON D4 TRACTORS**


- 7F5592 Arrangement—25 Gallons per Minute—Single Valve**
For use on D4 Tractors having Serial No. 4G1 to 4G9999, 7J1 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.
Consists of:
- I 7F3763 Hydraulic Lines GroupPage 43
 - I 7F3949 Guard GroupPage 14
 - I 7F3983 Hydraulic Power Unit GroupPage 24
 - I 7F4438 Mounting GroupPage 20
- 7F5234 Arrangement—25 Gallons per Minute—Single Valve**
For use on D4 Tractors having Serial No. 6U1—Up and 7U1—Up.
Consists of:
- I 7F3763 Hydraulic Lines GroupPage 43
 - I 7F3949 Guard GroupPage 14
 - I 7F3983 Hydraulic Power Unit GroupPage 24
 - I 7F4002 Mounting GroupPage 21
- 7F5593 Arrangement—37 Gallons per Minute—Single Valve**
For use on D4 Tractors having Serial No. 4G1 to 4G9999, 7J1 to 7J9999, 2T1 to 2T9999 and 5T1 to 5T7411 Inclusive.
Consists of:
- I 7F3763 Hydraulic Lines GroupPage 43
 - I 7F3949 Guard GroupPage 14
 - I 7F4000 Hydraulic Power Unit GroupPage 28
 - I 7F4438 Mounting GroupPage 20
- 7F5235 Arrangement—37 Gallons per Minute—Single Valve**
For use on D4 Tractors having Serial No. 6U1—Up and 7U1—Up.
Consists of:
- I 7F3763 Hydraulic Lines GroupPage 43
 - I 7F3949 Guard GroupPage 14
 - I 7F4000 Hydraulic Power Unit GroupPage 28
 - I 7F4002 Mounting GroupPage 21

HYDRAULIC CONTROL ARRANGEMENTS




7F5859 GUARD GROUP

Part of 7F5852 Hydraulic Control Arrangement listed on Page 5


**7F4454 GUARD GROUP**

Part of 7F4482 and 7F4994 Hydraulic Control Arrangements listed on Pages 5 and 12


**7F3949 GUARD GROUP**

Part of Hydraulic Control Arrangements listed on Pages 5 through 10, 12 and 13


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

**7F3895 MOUNTING GROUP**

Part of 7F3894 Hydraulic Control Arrangement listed on Page 12


**8F52 MOUNTING GROUP**

Part of 8F48 Hydraulic Control Arrangement listed on Page 12




Part of 7F5852 and 7F5851 Hydraulic Control Arrangements listed on Pages 5 and 11

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




5F2402 MOUNTING GROUP—First Type
Part of 5F2403 Hydraulic Control Arrangement listed on insert




5F2402 MOUNTING GROUP—Second Type
Part of 5F2403 Hydraulic Control Arrangement listed on insert

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




4F8943 MOUNTING GROUP

Part of 4F9338 Hydraulic Control Arrangement listed on insert




ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

INSERT BETWEEN PAGES 16 & 17 IN FORM 30032—PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL



5FI300 MOUNTING GROUP—First Type
Part of 5FI302 Hydraulic Control Arrangement listed on insert


ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



5F1300 MOUNTING GROUP—Second Type


Part of 5F1302 Hydraulic Control Arrangement listed on insert

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

**7F3895 MOUNTING GROUP—Third Type**


Part of 7F3894 Hydraulic Control Arrangement listed on Page 12


INSERT BETWEEN PAGES 14 & 15 IN FORM 30032—
PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL




7F3895 MOUNTING GROUP—Second Type

Part of 7F3894 Hydraulic Control Arrangement listed on Page 12






6F1130 MOUNTING GROUP (First Type)
Part of 6F1167 Hydraulic Control Arrangement listed on insert




6F1130 MOUNTING GROUP—Second Type
Part of 6F1167 Hydraulic Control Arrangement listed on insert

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



6F3701 MOUNTING GROUP—First Type
Part of 6F3702 Hydraulic Control Arrangement listed on insert



Part of 7F4482, 7F4480, 7F4994 and 8F5238 Hydraulic Control Arrangements listed on Pages 5, 11 and 12 and on insert
7F3620 Valve Group parts are shown on Page 23

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

500.37

020200-5F7751

8F3249

437.12

300

125th 5F7754


→ 177.78

new Jiffy Stone

40th 5F4408


625

NT 108



7F4439 MOUNTING GROUP


Part of 7F4482, 7F4480 and 7F4994 Hydraulic Control Arrangements listed on Pages 5, 11 and 12
7F3620 Valve Group parts are shown on Page 23




7F528 MOUNTING GROUP

Part of Hydraulic Control Arrangements listed on Pages 5 through 8 and 11

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



7F5258 MOUNTING GROUP—Second Type
Part of Hydraulic Control Arrangements listed on Pages 5 through 8 and 11
7F3620 Valve Group parts are shown on Page 23




7F5258 MOUNTING GROUP—Third Type

Part of Hydraulic Control Arrangements listed on Pages 5 through 8 and 11
7F3620 Valve Group parts are shown on Page 23


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

INSERT BETWEEN PAGES 18 & 19 IN FORM 30032—PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL




7F7314 MOUNTING GROUP—Second Type

Part of Hydraulic Control Arrangements listed on Pages 5 through 8 and 11
7F3620 Valve Group parts are shown on Page 23




ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



7F314 MOUNTING GROUP

Part of Hydraulic Control Arrangements listed on Pages 5 through 8 and 11
7F3620 Valve Group parts are shown on Page 23



7F4438 MOUNTING GROUP

of Hydraulic Control Arrangements listed on Pages 5 through 9 and 11 through 13


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

PRINTED IN U.S.A.

123000 AGIAS

1944 71 147 3-54


NO. 44 HYDRAULIC CONTROL—PARTS CATALOG—FORM 30032—INSERT BETWEEN PAGES 20 & 21



8F9433 MOUNTING GROUP—Third Type

Part of 8F9789, 8F9790, 8F9791, 8F9792, 8F9793, 8F9794, 8F9795, 8F9796 and 9F6940 Hydraulic

Controls listed on insert. 7F3620 Valve Group parts are shown on Page 23




7F4002 MOUNTING GROUP—Second Type

Part of Hydraulic Arrangements listed on Pages 6 through 9 and 11 through 13
 7F3620 Valve Group parts are shown on Page 23

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS


INSERT BETWEEN PAGES 20 & 21 IN FORM 30032—PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL



7F4438 MOUNTING GROUP—Second Type


Part of Hydraulic Control Arrangements listed on Pages 5 through 9, and 11 through 13
7F3620 Valve Group parts are shown on Page 23


INSERT BETWEEN PAGES 20 & 21 IN FORM 30032—PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL



8F9433 MOUNTING GROUP


Part of 8F9789, 8F9790, 8F9791, 8F9792, 8F9793, 8F9794, 8F9795, 8F9796 and 9F6940 Hydraulic Control Arrangements listed on insert 7F3620 Valve Group parts are shown on Page 23





7F4002 MOUNTING GROUP

Part of Hydraulic Control Arrangements listed on Pages 6 through 9 and 11 through 13
7F3620 Valve Group parts are shown on Page 23



7F5105 MOUNTING GROUP

Hydraulic Control Arrangements listed in Part 9 and 12


Part

33

FOM


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS


PARTS CATALOG INSERT



7F3620 VALVE GROUP—Second Type

Part of Mounting Groups shown on Pages 16 through 21





2-YOKE.....5F8501

6-CUP ASSEM.....6F4342
(PLAIN NEEDLE)

2-CROSS ASSEM.....6F4343

2-PLUG.....2B4602
(1 IN EACH CROSS ASSEM.)2-CUP ASSEM.....6F4341
(LUB. NEEDLE)

2-PLUG.....2B4602

1-CENTER.....5F8500

8-LOCK RING.....5F2476

25899

6F4339 UNIVERSAL JOINT
Part of 7F5105 Mounting Group

1-LEVER.....7F3617

-OR-

1-LEVER.....8F2466

1-KEY.....JB8705

1-BODY GROUP.....7F6029

CONSISTING OF:

1-STEM.....NOT SERVICED

1-BODY.....NOT SERVICED

6-SEAL.....4F7952

4-LOCKWASHER...3B4508

4-CAP SCREW.....S-1621

2-BUSHING.....4F4392
(PART OF ASSEM. 7F3702)

4-LOCKWASHER...3B4506

4-CAP SCREW.....7F3425

S-1588-CAP SCREW.....1

7F3615-COVER.....1

-OR-

8F2467-COVER.....1

4F9653-SEAL.....2

6F4855-SEAL.....1

S-1621-CAP SCREW.....4

3B4508-LOCKWASHER...4

7F3412-COVER.....3

3B4508-LOCKWASHER...4

S-1621-CAP SCREW.....4


3B8489-FITTING.....1

7F3702-BASE ASSEM.....1

28673


7F3620 VALVE GROUP

Part of Mounting Groups shown on Pages 16 through 21



7F3983 HYDRAULIC POWER UNIT GROUP—Part One

Hydraulic Power Unit Serial No. 9W1 to 9W363 inclusive
 Part of Hydraulic Control Arrangements listed on Pages 5 through 7 and 11 through 13



25145


6F500 HYDRAULIC CONTROL GROUP—Side View


Hydraulic Control Serial No. 4W1 to 4W484 inclusive

Part of 6F1167 and 6F3702 Hydraulic Control Arrangements listed on insert

Additional parts are shown on reverse side of insert

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE





27028


6F500 HYDRAULIC CONTROL GROUP—Side View (Second Type)

Effective with Hydraulic Control Serial No. 4W485

Part of 6F1167 and 6F3702 Hydraulic Control Arrangements listed on insert

Additional parts are shown on reverse side of insert

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



27029


6F500 HYDRAULIC CONTROL GROUP—Rear View (Second Type)

Effective with Hydraulic Control Serial No. 4W485

Part of 6F1167 and 6F3702 Hydraulic Control Arrangements listed on insert

6F4377 Valve parts are shown on insert. Additional parts are shown on front side of insert

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



25345

▲ FOR SHIPPING & STORAGE ONLY


4F8881 HYDRAULIC CONTROL GROUP—Side View (First Type)

Hydraulic Control Serial No. 7V5001 to 7V6741 inclusive

Part of Hydraulic Control Arrangements listed on insert

Additional parts are shown on reverse side of insert

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




4F8881 HYDRAULIC CONTROL GROUP—Rear View (First Type)

Hydraulic Control Serial No. 7V5001 to 7V6741 inclusive

Part of Hydraulic Control Arrangements listed on insert

5F3996 Valve parts are shown on insert

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




27026

▲ FOR SHIPPING & STORAGE ONLY

4F8881 HYDRAULIC CONTROL GROUP—Side View (Second Type)

Effective with Hydraulic Control Serial No. 7V6742
 Part of Hydraulic Control Arrangements, listed on insert
 Additional parts are shown on reverse side of insert

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




4F8881 HYDRAULIC CONTROL GROUP—Rear View (Second Type)

Effective with Hydraulic Control Serial No. 7V6742

Part of Hydraulic Control Arrangements listed on insert

6F4377 Valve parts are shown on insert


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




7F3983 HYDRAULIC POWER UNIT GROUP—Part Two

Hydraulic Power Unit Serial No. 9W1 to 9W363 inclusive

Part of Hydraulic Control Arrangements listed on Pages 5 through 7 and 11 through 13. 6F7441 and 7F4307 Valve parts are shown on Page 40




7F983 HYDRAULIC POWER UNIT GROUP—Part One
Effective with Hydraulic Power Unit Serial No. 9W364
Control Assembly Serial No. 9W364




7F3983 HYDRAULIC CONTROL GROUP—Part Two (Third Type)

Effective with Hydraulic Control Serial No. 9W526

Part of Hydraulic Control Arrangements listed on Pages 5 through 7 and 11 through 13. 6F7441 and 7F4307 Valve parts are shown on Page 40




INSERT BETWEEN PAGES 26 & 27 IN FORM 30032—PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL



7F983 HYDRAULIC CONTROL GROUP—Part One (Fourth Type)

Effective with Hydraulic Control Serial No. 9W1611

Part of Hydraulic Control Arrangements listed on Pages 5 through 7 and 11 through 13 and on insert




7F3983 HYDRAULIC CONTROL GROUP—Part Two (Fourth Type)

Effective with Hydraulic Control Serial No. 9W1611


Part of Hydraulic Control Arrangements listed on Pages 5 through 7 and 11 through 13 and on insert. 6F7441 and 9F1384 Valve parts are shown on insert.


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



7F3983 HYDRAULIC POWER UNIT GROUP—Part Two
 Effective with Hydraulic Power Unit Serial No. 9W364


Part of Hydraulic Control Arrangements listed on Pages 5 through 7 and 11 through 13. 6F7441 and 7F4307 Valve parts are shown on Page 40






7F4000 HYDRAULIC POWER UNIT GROUP—Part Two
Hydraulic Power Unit Serial No. 6W5001 to 6W6047 inclusive

Part of Hydraulic Control Arrangements listed on Pages 6, 8, 12 and 13. 6F7441 and 7F4307 Valve parts are shown on Page 40




28827


7F4000 HYDRAULIC POWER UNIT GROUP-Part One
Effective with Hydraulic Power Unit Serial No. 6W5048



7F4000 HYDRAULIC CONTROL GROUP—Part Two (Third Type)
Effective with Hydraulic Control Serial No. 6W6478

Part of Hydraulic Control Arrangements listed on Pages 6, 8, 12 and 13. 6F7441 and 7F4307 Valve parts are shown on Page 40






7F4000 HYDRAULIC CONTROL GROUP—Part One (Fourth Type)

Effective with Hydraulic Control Serial No. 6W8314

Part of Hydraulic Control Arrangements listed on Pages 6, 8, 12 and 13




7F4000 HYDRAULIC CONTROL GROUP—Part Two (Fourth Type)

Effective with Hydraulic Control Serial No. 6W8314


Part of Hydraulic Control Arrangements listed on Pages 6, 8, 12 and 13
6F7441 and 9F1384 Valve parts are shown on insert

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




7F4000 HYDRAULIC POWER UNIT GROUP—Part Two
Effective with Hydraulic Power Unit Serial No. 6W6048

Part of Hydraulic Control Arrangements listed on Pages 6, 8, 12 and 13. 6F7441 and 7F4307 Valve parts are shown on Page 40




7F3900 HYDRAULIC POWER UNIT GROUP—Part One
 Hydraulic Power Unit, Serial No. 7W1 to 7W607 inclusive




7F3900 HYDRAULIC POWER UNIT GROUP—Part Two

Hydraulic Power Unit Serial No. 7W1 to 7W607 inclusive. Part of 7F4413, 7F3998, 7F5639 and 7F3894 Hydraulic Control Arrangements listed on Pages 8, 9 and 12. 6F7441 and 7F3879 Valve parts are shown on Pages 40 and 41



7F3900 HYDRAULIC POWER UNIT GROUP—Part One
Effective with Hydraulic Power Unit Serial No. 7W608


INSERT BETWEEN PAGES 33 & 34 IN FORM 30032—PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL




7F3900 HYDRAULIC CONTROL GROUP—Part Two (Fifth Type)

Effective with Hydraulic Control Serial No. 7W4598

Part of 7F4413, 7F3998, 7F5639 and 7F3894 Hydraulic Control Arrangements listed on Pages 8, 9 and 12. 6F7441 and 9F1383 Valve parts are shown on insert. Additional parts are shown on insert



CROSS OUT ILLUSTRATION 30937 AND 30950 ON INSERT 152 AND INSERT 151
PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL




7F3900 HYDRAULIC CONTROL GROUP—Part One (Fourth Type)

Serial No. 7W1832 to 7W4597 inclusive

Part of 7F4413, 7F3998, 7F5639 and 7F3894 Hydraulic Control Arrangements listed on Pages 8, 9 and 12

Additional parts are shown on reverse side of insert




7F3900 HYDRAULIC CONTROL GROUP—Part Two (Fourth Type)

Serial No. 7W1832 to 7W4597 inclusive

Part of 7F4413, 7F3998, 7F5639 and 7F3894 Hydraulic Control Arrangements
listed on Pages 8, 9 and 12

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS


INSERT BETWEEN PAGES 34 & 35 IN FORM 30032—PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL




7F3900 HYDRAULIC CONTROL GROUP—Part Two (Third Type)

Effective with Hydraulic Control Serial No. 7W764

Part of 7F4413, 7F3998, 7F5639 and 7F3894 Hydraulic Control Arrangements listed on Pages 8, 9 and 12. 6F7441 and 7F3879 Valve parts are shown on Pages 40 and 41




INSERT BETWEEN PAGES 34 & 35 IN FORM 30032—PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL



7F3900 HYDRAULIC CONTROL GROUP—Part One (Fourth Type)

Effective with Hydraulic Control Serial No. 7W1832

Part of 7F4413, 7F3998, 7F5639 and 7F3894 Hydraulic Control Arrangements listed on Pages 8, 9 and 12




7F3900 HYDRAULIC CONTROL GROUP—Part Two (Fourth Type)

Effective with Hydraulic Control Serial No. 7W1832


Part of 7F4413, 7F3998, 7F5639 and 7F3894 Hydraulic Control Arrangements listed on Pages 8, 9 and 12. 6F7441 and 9F1383 Valve parts are shown on insert

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



7F3900 HYDRAULIC POWER UNIT GROUP—Part Two


Effective with Hydraulic Power Unit Serial No. 7W608. Part of 7F4413, 7F3998, 7F5639 and 7F3894 Hydraulic Control Arrangements listed on Pages 8, 9 and 12. 6F7441 and 7F3879 Valve parts are shown on Pages 40 and 41



7F3984 HYDRAULIC POWER UNIT GROUP—Part Two

Hydraulic Power Unit Serial No. 8W5001 to 8W5007 inclusive

Part of 7F5741 and 7F5740 Hydraulic Control Arrangements listed on Page 9. 6F7441 and 7F3879 Valve parts are shown on Pages 40 and 41




28828

7F3984 HYDRAULIC POWER UNIT GROUP—Part One

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS


INSERT BETWEEN PAGES 38 & 39 IN FORM 30032—PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL




7F3984 HYDRAULIC CONTROL GROUP—Part Two (Third Type)

Effective with Hydraulic Control Serial No. 8W5013

Part of 7F5741 and 7F5740 Hydraulic Control Arrangements listed on Page 9. 6F7441 and 7F3879 Valve parts are shown on Pages 40 and 41




INSERT BETWEEN PAGES 38 & 39 IN FORM 30032—PARTS CATALOG FOR NO. 44 HYDRAULIC CONTROL



7F3984 HYDRAULIC CONTROL GROUP—Part One (Fourth Type)

Effective with Hydraulic Control Serial No. 8W5044

Part of 7F5741 and 7F5740 Hydraulic Control Arrangements listed on Page 9




30938

7F3984 HYDRAULIC CONTROL GROUP—Part Two (Fourth Type)

Effective with Hydraulic Control Serial No. 8W5044


Part of 7F5741 and 7F5740 Hydraulic Control Arrangements listed on Page 9. 6F7441 and 9F1383 Valve parts are shown on insert

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




7F3984 HYDRAULIC POWER UNIT GROUP—Part Two
Effective with Hydraulic Power Unit Serial No. 8W5008

Part of 7F5741 and 7F5740 Hydraulic Control Arrangements listed on Page 9. 6F7441 and 7F3879 Valve parts are shown on Pages 40 and 41


**6F7441 VALVE ASSEMBLY**

Part of 7F3983, 7F4000, 7F3900 and 7F3984 Hydraulic Power Unit Groups
shown on Pages 25, 27, 29, 31, 33, 35, 37 and 39


**7F4307 VALVE GROUP**

Part of 7F3983 and 7F4000 Hydraulic Power Unit Groups
shown on Pages 25, 27, 29 and 31 and on insert

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS


**6F7441 VALVE ASSEMBLY**

Part of 7F3983, 7F4000, 7F3900 and 7F3984 Hydraulic Control Groups shown on Pages 25, 27, 29, 31, 33, 35, 37, 39 and on insert

**9F1384 VALVE GROUP**

Effective with Serial No. 6W8314 and 9W1611


Part of 7F3983 and 7F4000 Hydraulic Control Groups shown on insert



9F1383 VALVE GROUP

Effective with Serial No. 7W1832 and 8W5044

Part of 7F3900 and 7F3984 Hydraulic Control Groups shown on insert 183




7F5200 FLOAT VALVE CHANGEOVER GROUP


Hydraulic Control Serial No. 4W1 to 4W484 and 7V5001 to 7V6741 inclusive

6F4377 Valve Group parts are shown on insert


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS


**5F3996 CONTROL VALVE GROUP**

Part of 4F8881 Hydraulic Control Group shown on insert


**6F4377 CONTROL VALVE GROUP**

Part of 4F8881 Hydraulic Control Group shown on insert




**7F3879 VALVE GROUP**

Serial No. 7W1 to 7W356 and 8W5001 to 8W5006 inclusive. Part of 7F3900 and 7F3984 Hydraulic Power Unit Groups shown on Pages 33, 35, 37 and 39


**7F3879 VALVE GROUP**

Effective with Serial No. 7W357 and 8W5007. Part of 7F3900 and 7F3984 Hydraulic Power Unit Groups shown on Pages 33, 35, 37 and 39

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE


**7F4275 HYDRAULIC LINES GROUP**

Part of 7F5852, 7F4482 and 7F4994 Hydraulic Control Arrangements
listed on Pages 5 and 12


**8F1938 HYDRAULIC LINES GROUP**

Part of Hydraulic Control Arrangements listed on Pages 5 through 10


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

**7F3763 HYDRAULIC LINES GROUP—Second Type**


Part of Hydraulic Control Arrangements listed on Pages 6 through 10 and 13

**7F3763 HYDRAULIC LINES GROUP**


Part of Hydraulic Control Arrangements listed on Pages 6 through 10 and 13

**7F4263 HYDRAULIC LINES GROUP**

Part of 7F5851 and 7F4480 Hydraulic Control Arrangements listed on Page 11


**8F2753 HYDRAULIC LINES GROUP**

Part of 7F5639 and 7F5107 Hydraulic Control Arrangements listed on Pages 9 and 12

**8F517 HYDRAULIC LINES GROUP**

Part of 8F3975 and 8F1676 Hydraulic Control Arrangements listed on Page 12


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



28584

7F4989 HYDRAULIC LINES GROUP

Part of 7F5639 Hydraulic Control Arrangement listed on Page 9



28583


7F3959 HYDRAULIC LINES GROUP


Part of 7F4413, 7F3998, 7F5741 and 7F5740 Hydraulic Control Arrangements listed on Pages 8 and 9

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS


Part of 7F4413, 7F3998, 7F5741 and 7F5740 Hydraulic Control Arrangements listed on Pages 8 and 9
7F3858 Hydraulic Lines Group parts are shown on Page 47

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




**8F8445 HYDRAULIC LINES GROUP**

Part of 8F9795 and 8F9791 Hydraulic Control Arrangements listed on insert
8F8436 Hydraulic Lines Group parts are shown on reverse side of insert



8F8436 HYDRAULIC LINES GROUP


Part of 8F9790, 8F9853, 8F9854, 8F9855, 8F9858 Hydraulic Control Arrangements and 8F8445 Hydraulic Lines Group shown on insert



8F9301 HYDRAULIC LINES GROUP


Part of 8F1676, 8F3975, 8F9796, 9F4598 and 9F4599 Hydraulic Control Arrangements listed on Page 12 and on insert


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




8F9301 HYDRAULIC LINES GROUP—Second Type

Part of 8F1676, 8F9796, 9F4598 and 9F4599 Hydraulic Control Arrangements listed on Page 12 and on insert




**7F3858 HYDRAULIC LINES GROUP**

Part of Hydraulic Control Arrangements listed on Pages 10 and 11 and
7F3959 Hydraulic Lines Group shown on Page 46


**7F4481 HOSE AND FITTING GROUP**

Part of 7F5852 and 7F4482 Hydraulic Control Arrangements listed on Page 5

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

**7F3950 HOSE AND FITTING GROUP**

Part of Hydraulic Control Arrangements listed on Pages 5, 6 and 9

**7F3893 HOSE AND FITTING GROUP**

Part of Hydraulic Control Arrangements listed on Pages 7, 8 and 10

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS


PARTS CATALOG INSERT

3H 6170
FLANGE5F7054 SEAL
(.740" DIA.)5F1678 SEAL
(.990" DIA.)3H6171
FLANGE

{1-COUPLING ASSEM._2H9272
1-COUPLING ASSEM._2H9271
(PARTS OF ASSEM. 2H 9262)



2H 9262 COUPLING ASSEM.

5F6916
CLAMP2H 9264
STEM2H9091
UNION3H6275
FITTING3H 6274
PLATE1H5278
FLANGE2H 9089
SLEEVE6F 4216 HOSE (1/2" DIA.)
(20FT. REEL)






37335

MISCELLANEOUS HYDRAULIC FITTINGS—1/2 Inch For Agricultural Usage



I-FITTING GROUP_3H1691

CONSISTING OF:

- 2-FLANGE_3H 166
- 4-CAP SCREW_1A2469
- 4-LOCKWASHER_3B4508
- 2-RING_5F9657

5F 6371
UNION5F2107
CLAMP5F 2108
STEM1K 7119
STEM


3H 8506-COUPLING ASSEM.

5F2046
FLANGE3H 6276
FLANGE8F 3217
ELBOW9F 9141
ELBOW5F1678
SEAL6F 5295 HOSE (3/4" DIA.)
(20FT. REEL)


37336


MISCELLANEOUS HYDRAULIC FITTINGS—3/4 Inch For Agricultural Usage

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

**9F3312 HOSE AND FITTING GROUP**


Part of 8F8238 Hydraulic Control Arrangement listed on insert

**9F6941 HOSE AND FITTING GROUP**Part of 9F6940, 9F9689, 9F9722, 9F9723 and 9F9724
Hydraulic Control Arrangements listed on insert**ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE**



9F7936 HOSE AND FITTING GROUP


For use with 9F1724 and 9F1725 Cylinder Groups shown on insert
For use on Agricultural Hydraulic Control and Cylinder mounted on D2 or D4 Tractor



9F7937 HOSE AND FITTING GROUP


For use with 9F1724 and 9F1725 Cylinder Groups shown on insert
For use on Agricultural Hydraulic Control and Cylinder mounted on D6 Tractor


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




IH6458 HOSE AND FITTINGS GROUP

Part of 7F4482 Hydraulic Control Arrangement listed on insert




**7F4706 HOSE AND FITTING GROUP**

For use on Agricultural Hydraulic Power Unit and Cylinder mounted on D2 or D4 Tractor

**7F4707 HOSE AND FITTING GROUP**


For use on Agricultural Hydraulic Power Unit and Cylinder mounted on D6 Tractor

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




4F8661 HYDRAULIC CYLINDER GROUP—Right Hand
Part of 8F48 Hydraulic Control Arrangement listed on Page 12

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




8F1123 HYDRAULIC CYLINDER GROUP—Right Hand
 Part of 8F48 Hydraulic Control Arrangement listed on Page 12



4F6349 HYDRAULIC CYLINDER GROUP--5" x 8"


For use with Agricultural Implements

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



9F1725 HYDRAULIC CYLINDER GROUP—5" x 8"


For use with Agricultural Implements




30876

9F1724 HYDRAULIC CYLINDER GROUP—5" x 12"
 For use with Agricultural Implements


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



4F6466 HYDRAULIC CYLINDER GROUP—5" x 12"
For use with Agricultural Implements


**7F4855 HYDRAULIC AIR TANK GROUP**

Part of 7F4413, 7F3998, 7F5741 and 7F5740 Hydraulic Control Arrangements listed on Pages 8 and 9


**7F7010 HYDRAULIC AIR TANK GROUP**

Part of 7F5639 Hydraulic Control Arrangement listed on Page 9


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

**7F4855 HYDRAULIC AIR TANK GROUP—Second Type**

Part of 7F4413, 7F3998, 7F5741 and 7F5740 Hydraulic Control Arrangements
listed on Pages 8 and 9

**7F7010 HYDRAULIC AIR TANK GROUP—Second Type**

Part of 7F5639 Hydraulic Control Arrangements listed on Page 9



7F4855 HYDRAULIC AIR TANK GROUP—Third Type

Part of 7F4413, 7F3998, 7F5741, 7F5740, 8F9791 and 8F9795 Hydraulic Control Arrangements listed on Pages 8 and 9 and on insert

MEMORANDA

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

SPECIFICATIONS

(SUBJECT TO CHANGE WITHOUT NOTICE)

For use with tractor model.....	D2	D4	D6
Weight, shipping (approximate) in pounds.....	365	365	365
(Includes pump, housing, valve, control lever and lines)			

CAPACITIES

Pump housing: Liquid required for operating.....	14 qt.	14 qt.	14 qt.
Pump, output in gallons per minute			
With narrow pump cartridge.....	27	25	—
With wide pump cartridge.....	—	37	37
(Based on full load governed engine revolutions per minute)	1525	1400	1400
(When developing pressure of pounds per square inch)	1000	1000	1000
Relief valve set to by-pass full flow of pump at pounds per square inch.....	1200	1200	1200
Maximum recommended working pressure, pounds per square inch.....	1000	1000	1000

MACHINE SERIAL NUMBER PLATE LOCATION

Serial number plate is located on the left hand side of the rear face of the Hydraulic Control tank assembly.

FRANÇAIS

REDACTION DES COMMANDES DE PIÈCES. Pour chaque pièce, indiquer la quantité, le numéro et la désignation. Le numéro de série de la machine à laquelle les pièces sont destinées est également indispensable. Nous vous conseillons d'inscrire le numéro de série de votre machine à la première page de ce catalogue, dans l'espace réservé à cet effet, de façon à le trouver facilement en toutes circonstances.

Pour obtenir une livraison rapide, nous vous prions d'indiquer très exactement le nom du destinataire et son adresse complète: rue, numéro, ville, département, en stipulant, par exemple: petite ou grande vitesse, colis postal, ou tout autre mode d'expédition.

PASSATION DES COMMANDES. Le réseau des Distributeurs Caterpillar couvre le monde entier avec ateliers et dépôts dans la plupart des grands centres. Toute cette organisation repose, en outre, sur l'expérience et les moyens techniques de la Caterpillar Tractor Co.

Les Distributeurs Caterpillar disposent d'un personnel formé à l'usine, parfaitement au courant de tous les problèmes que soulèvent le stockage et la distribution de pièces de rechange. On trouve toujours chez eux un assortiment complet de pièces, ce qui leur permet de servir rapidement les usagers. Mettez-vous en rapport avec le Distributeur Caterpillar le plus proche, assurez-vous qu'il connaît votre nom et votre adresse, le numéro de série de votre machine et les accessoires qui l'équipent. Ces renseignements lui seront utiles, surtout pour les dépannages urgents.

DISTRIBUTEURS CATERPILLAR. Les Distributeurs Caterpillar sont au service de l'utilisateur pour lui faciliter la parfaite utilisation de son matériel. Par leurs rapports constants avec l'usine, ils sont toujours au courant des toutes dernières méthodes de réparation, d'entretien, d'emploi du matériel et de remplacement des pièces. Ils veillent, en particulier, à ce que leur stock de pièces réponde par sa composition aux besoins éventuels de tous les propriétaires de matériel Caterpillar, quel que soit l'âge de leur machine, pour réduire au strict minimum les arrêts toujours très coûteux.

Presque tous nos Distributeurs ont une permanence de jour et de nuit pour les appels urgents. Afin d'éviter toute perte de temps, ayez toujours à portée de la main le nom et l'adresse de votre Distributeur Caterpillar.

RIEN NE SAURAIT SE SUBSTITUER À LA PIÈCE AUTHENTIQUE CATERPILLAR. La qualité et la construction soignée qui ont fait la réputation mondiale du matériel Caterpillar se retrouvent dans toutes les pièces d'origine.

ITALIANO

MODO DI ORDINARE LE PARTI DI RICAMBIO. Vi preghiamo di indicare con precisione la quantità, il numero e la denominazione di ogni parte richiesta. È altresì importante precisare il numero di serie della macchina sulla quale dovrà essere montata la parte. Vi consigliamo di scrivere il numero di serie della Vostra macchina nello spazio predisposto a questo scopo nella prima pagina di questo catalogo parti.

Per assicurare la pronta consegna, Vi preghiamo di non mancare di fornire il nome del destinatario, correttamente scritto, come pure l'indirizzo, cioè la strada, la città, la provincia e lo stato dove le parti dovranno essere spedite, indicando se la spedizione dovrà essere effettuata per ferrovia, per mare, per espresso, per pacco postale o per altro mezzo.

DOVE SI ORDINANO LE PARTI. I vari Distributori CATERPILLAR hanno organizzato oltre 400 depositi di parti di ricambio negli Stati Uniti e simili depositi si trovano convenientemente situati in quasi tutti i paesi del mondo. Questi depositi usufruiscono del vantaggio delle adeguate facilitazioni e delle forti risorse della CATERPILLAR TRACTOR CO. Il personale dei Distributori viene istruito dalla fabbrica per il mantenimento degli assortimenti e per la consegna delle parti. Vasti depositi vengono continuamente riforniti per assicurare la pronta consegna. MetteteVi in comunicazione con il Distributore CATERPILLAR più vicino a Voi ed assicurateVi che egli abbia il Vostro nome e indirizzo, l'esatto numero di serie della Vostra macchina ed una larga disponibilità di accessori vari. In questa maniera faciliterete la consegna delle parti quando ne avrete urgente necessità.

CIÒ CHE PUÒ FARE PER VOI IL DISTRIBUTORE CATERPILLAR. I Distributori CATERPILLAR hanno principalmente lo scopo di rendere economico e vantaggioso per Voi il possesso e l'uso dei macchinari CATERPILLAR. Essi sono costantemente in comunicazione con la fabbrica e perciò al corrente dei miglioramenti introdotti nei sistemi di riparazione, di manutenzione e di impiego delle macchine, nonché nella richiesta di parti di ricambio.

I loro assortimenti sono efficienti e continuamente aggiornati. Essi comprendono tutti i pezzi che normalmente sono richiesti per garantire il capitale da Voi impiegato in macchinari CATERPILLAR.

Quasi tutti i Distributori CATERPILLAR offrono giorno e notte servizio per casi urgenti.

Per rapidità di riferimento, segnate il nome e l'indirizzo del Vostro rivenditore locale sulla rubrica della Vostra scrivania o nella testata della vostra guida telefonica.

SOLTANTO LE PARTI CATERPILLAR GARANTISCONO LA FAMA DELLA MARCA CATERPILLAR. Le parti di ricambio CATERPILLAR vengono costruite con i materiali e con i sistemi di lavorazione che hanno resi famosi in tutto il mondo i prodotti CATERPILLAR.

DEUTSCH

WIE MAN ERSATZTEILE BESTELLT. Bitte übersehen Sie nicht, bei jedem Ersatzteilposten die Anzahl, Nummer und Bezeichnung genau anzugeben. Ebenso wichtig ist es, die Seriennummer der Maschine aufzuführen, auf die die Teile passen sollen. Wir möchten Ihnen empfehlen, diese Seriennummer in dem dafür vorgesehenen Rechteck auf der ersten Seite dieses Katalogs einzutragen, damit sie stets schnell zu finden ist.

Um alle Zeitverluste bei der Lieferung zu vermeiden, ist es ratsam, den vollen Namen, sowie den Staat, das Land, die Stadt, die Straße und die Hausnummer des jeweiligen Empfängers genau anzugeben, wobei am besten auch die Verschiffungsart (Fracht, Eilgut, Postpaket, usw.) ausdrücklich vorzuschreiben ist.

WO MAN ERSATZTEILE BESTELLT. In fast allen Ländern der Welt bestehen Caterpillar-Vertretungen. Diese Firmen stehen in enger Fühlung mit der Hauptfabrik, bei der sie in vielen Fragen Rat- und weitgehende Unterstützung finden.

No. 44 HYDRAULIC CONTROL

HOW TO ORDER PARTS

Please be sure to furnish the quantity, part number and name of each part wanted. It is also important to give the serial number of the machine for which the parts are intended. Location of serial number plates may be determined by referring to the "Specifications" page of this parts catalog. It is suggested that you write the serial number of your machine in this space so that it will be readily available when you need it.

**THIS PARTS CATALOG FOR
MACHINE SERIAL NUMBER**

.....

To insure prompt delivery, please don't overlook furnishing the correct name of the consignee, also the street address, town, county and state to which the parts are to be shipped, and indicate whether shipment is to be made by freight, express, parcel post or by other means.

WHERE TO ORDER PARTS

Caterpillar dealers maintain over 400 stores in the United States, and similar establishments are located strategically in nearly all countries throughout the world. These organizations are backed by the extensive facilities and resources of Caterpillar Tractor Co.

Dealer personnel are factory trained in the stocking and issuing of parts, and large stocks are constantly maintained to insure prompt service. Contact your nearest Caterpillar dealer to make sure that he has your name and address, the correct serial number of your machine, and an accurate list of accessories and attachments. This record will facilitate the issuance of parts when you need them in a hurry.

WHAT THE CATERPILLAR DEALER CAN DO FOR YOU

Caterpillar dealers are in the business of making it economical and profitable for you to own and operate Caterpillar machinery. They are in constant touch with the factory for new developments in repair and maintenance methods, operating procedures, and parts requirements. Their parts stocks are active and up-to-date, including all parts normally required to protect your investment in Caterpillar machinery.

Nearly all Caterpillar dealers offer 24-hour emergency service. For quick reference, write the name and address of the local dealer on your desk pad or the front of your phone book.

ONLY CATERPILLAR PARTS GIVE CATERPILLAR PERFORMANCE

The same quality and craftsmanship that has made Caterpillar products famous throughout the world is built into all Caterpillar replacement parts.

REPRINT PUBLISHED APRIL 1953