

PARTS BOOK

FORM 34469
REPLACES
FORM 33297

B.M.S.

CATERPILLAR NO. 8A, NO. 8C NO. 8S & NO. 8U BULLDOZERS

SERIAL NUMBERS

28E1 — UP

29E1 — UP

30E1 — UP

71F1 — UP

Caterpillar Tractor Co., General Offices, Peoria, Illinois. • Caterpillar Americas Co., Peoria, Illinois. • Caterpillar Overseas S.A., Geneva. • Caterpillar of Australia Pty. Ltd., Melbourne. • Caterpillar Brasil S.A., São Paulo. • Caterpillar Tractor Co. Ltd., Glasgow. • Caterpillar of Canada Ltd., Toronto. • Caterpillar France S.A., Grenoble.

No. 8A, No. 8C, No. 8S & No. 8U BULLDOZERS

HOW TO ORDER PARTS

Please be sure to furnish the quantity, part number and name of each part wanted. It is also important to give the serial number of the machine for which the parts are intended. Location of serial number plates may be determined by referring to the "Specifications" page of this parts book. It is suggested that you write the serial number of your machine in this space so that it will be readily available when you need it.

**THIS PARTS BOOK FOR
MACHINE SERIAL NUMBER**

.....

To insure prompt delivery, please don't overlook furnishing the correct name of the consignee, also the street address, town, county and state to which the parts are to be shipped, and indicate whether shipment is to be made by freight, express, parcel post or by other means.

WHERE TO ORDER PARTS

Caterpillar dealers maintain over 400 stores in the United States, and similar establishments are located strategically in nearly all countries throughout the world. These organizations are backed by the extensive facilities and resources of Caterpillar Tractor Co.

Dealer personnel are factory trained in the stocking and issuing of parts, and large stocks are constantly maintained to insure prompt service. Contact your nearest Caterpillar dealer to make sure that he has your name and address, the correct serial number of your machine, and an accurate list of accessories and attachments. This record will facilitate the issuance of parts when you need them in a hurry.

WHAT THE CATERPILLAR DEALER CAN DO FOR YOU

Caterpillar dealers are in the business of making it economical and profitable for you to own and operate Caterpillar machinery. They are in constant touch with the factory for new developments in repair and maintenance methods, operating procedures, and parts requirements. Their parts stocks are active and up-to-date, including all parts normally required to protect your investment in Caterpillar machinery.

Nearly all Caterpillar dealers offer 24-hour emergency service. For quick reference, write the name and address of the local dealer on your desk pad or the front of your phone book.

ONLY CATERPILLAR PARTS GIVE CATERPILLAR PERFORMANCE

The same quality and craftsmanship that has made Caterpillar products famous throughout the world is built into all Caterpillar replacement parts.

REVISION PUBLISHED SEPTEMBER 1962

FRANCAIS

COMMENT FAIRE UNE COMMANDE DE PIÈCES DE RECHANGE. Avant tout, soyez certain de fournir correctement la quantité, le numéro et le nom de chaque pièce désirée. Il est important encore d'indiquer le numéro de série de la machine pour laquelle les pièces sont destinées. L'endroit de la plaque au numéro de série peut être trouvé en étudiant la page des "Spécifications" de ce catalogue de pièces de rechange. Nous recommandons que vous inscrivez de numéro de série de votre machine dans l'espace réservé à cet effet à la page 1 de ce catalogue de pièces de rechange. Ainsi vous ne manquerez pas de le trouver aussitôt que vous en aurez besoin.

Afin d'assurer prompt livraison, ne manquez pas d'indiquer le nom correct du destinataire, son adresse, la rue, la ville, le département, le pays où les pièces en question devront être envoyées, tout en indiquant aussi comment la livraison devra être effectuée: par fret, express, colis postal ou par d'autres moyens.

OU COMMANDER LES PIÈCES DE RECHANGE. Les agences de distribution CATERPILLAR comprennent plus de 400 magasins aux Etats-Unis et des établissements similaires sont situés stratégiquement dans la plupart des pays du monde entier. Ces établissements ont l'appui des facilités et ressources extensives de la CATERPILLAR Tractor Co.

Le personnel de vente a reçu son training à l'usine pour ce qui regarde les stocks et la distribution des pièces de rechange et de vastes stocks sont constamment maintenus à jour pour assurer un service prompt. Mettez-vous en rapport avec l'agent CATERPILLAR le plus près de chez vous pour être sûr qu'il a votre nom et adresse, le numéro de série correct de votre machine et une liste précise des accessoires et pièces d'attache. Ce dossier facilitera la livraison de pièces de rechange quand vous en aurez besoin d'urgence.

CE QUE L'AGENT-DISTRIBUTEUR CATERPILLAR PEUT FAIRE POUR VOUS. Les agents-distributeurs CATERPILLAR sont dans les affaires pour rendre économiques et lucratives pour vous et la possession et l'opération des machines CATERPILLAR. Ils sont constamment en contact avec l'usine, afin d'être au courant de nouveaux développements dans les méthodes de réparations et d'entretien, les procédés d'opération, ainsi que pour leurs besoins de pièces de rechange. Leurs stocks de pièces de remplacement sont actifs et au jour, y-inclus toutes les pièces normalement nécessaires pour protéger vos fonds engagés dans les machines CATERPILLAR.

La plupart des agents CATERPILLAR vous offrent un service d'urgence de 24 heures. Afin d'obtenir des renseignements sans délai, soyez certain d'avoir le nom et l'adresse de votre agent sur place dans un carnet sur votre bureau ou à la première page de votre annuaire de téléphone.

SEULES LES PIÈCES DE RECHANGE CATERPILLAR VOUS DONNENT LA PRODUCTION CATERPILLAR. La même qualité et la main-d'oeuvre qui ont rendu fameux dans le monde entier les produits CATERPILLAR, sont construits dans toutes les pièces de rechange CATERPILLAR.

ITALIANO

MODO DI ORDINARE PEZZI. Si prega di essere sicuri d'indicare la quantità, il numero ed il nome di ogni pezzo desiderato. Ed è altresì importante riferire il numero di serie della macchina per la quale sono destinati i pezzi. Il collocamento delle placche contenenti i numeri di serie si può determinare col riferire alla pagina di specificazioni in questo catalogo di pezzi. Si suggerisce di scrivere il numero di serie della vostra macchina nello spazio provvisto a questo scopo sulla prima pagina di questo catalogo di pezzi.

Per assicurare pronta consegna, si prega di non mancare di fornire il nome del consegnatario correttamente scritto, come pure l'indirizzo, cioè la strada, città, contea e lo stato dove saranno spediti i pezzi, indicando se la spedizione sarà fatta per carico, espresso, pacco postale o per altro mezzo.

DOVE SI ORDINANO PEZZI. I rivenditori CATERPILLAR mantengono più di 400 magazzini negli Stati Uniti, e simili stabilimenti si trovano convenientemente collocati in quasi tutti i paesi del mondo. Questi stabilimenti godono l'appoggio delle estese facilitazioni e forti risorse della ditta CATERPILLAR Tractor Co.

Il personale rivenditore viene istruito, alla fabbrica, nel mantenimento degli assortimenti e rilascio dei pezzi, e si mantengono assortimenti, grossi per assicurare pronta consegna. Mettetevi in comunicazione col rivenditore e mantenuti al corrente, compresi tutti i pezzi che normalmente sono necessari per proteggere il vostro capitale di serie della vostra macchina ed una lista accurata di accessori ed attacchi. Così si rende più facile il rilascio di pezzi quando ne avrete di bisogno in fretta.

CIO CHE PUO FARE PER VOI IL RIVENDITORE CATERPILLAR. I rivenditori CATERPILLAR sono lì all'unico scopo di rendere economici e vantaggiosi per voi il possedere e manovrare macchinari CATERPILLAR. Egli sono costantemente in comunicazione colla fabbrica per essere ed essere di corrente delle nuove migliorie effettuate nei modi di riparazione e mantenimento, nei metodi d'operazione, e dello sviluppo in richiedimenti di pezzi. I loro assortimenti sono attivi e mantenuti al corrente, compresi tutti i pezzi che normalmente sono necessari per proteggere il vostro capitale di macchinari CATERPILLAR.

Quasi tutti i rivenditori CATERPILLAR offrono un servizio d'emergenza giorno e notte. Per riferimento istantaneo, appuntate il nome e l'indirizzo del vostro rivenditore locale sul taccuino della vostra scrivania o in avanti della vostra guida del telefono.

SOLTANTO I PEZZI CATERPILLAR DANNO RISULTATI DEGNI DELLA MARCA CATERPILLAR. La medesima qualità e lavorazione che hanno reso famosi i prodotti CATERPILLAR dappertutto il mondo si trovano in tutti i pezzi macchinari CATERPILLAR.

DEUTSCH

WIE MAN ERSATZTEILE BESTELLT. Vor allem muss die Qualität, die Teilnummer und Benennung jedes einzelnen gewünschten Teiles angegeben werden. Ausserdem ist es notwendig, die Seriennummer der Maschine, für welche die einzelnen Teile bestimmt sind, bekannt zu geben. Die Tabelle, wo die Seriennummern zu finden ist, ist in diesem Teilkatalog unter dem Titel "Spezifikationen" enthalten. Es ist ratsam, die Seriennummer der Maschine an Seite 1 dieses Teilkataloges an der zu diesem Zwecke bestimmten Stelle zu vermerken. Solcherart wird sie stets zu finden sein, so oft sie benötigt wird.

Um eine prompte Lieferung zu bewerkstelligen, muss der Name des Bestellers fehlerfrei, genau angegeben werden, namentlich die Strasse, die Stadt, die Provinz, das Land, mit einem Worte der Wohnort wohin die bestellten Maschinenteile gesandt werden sollen. Bei dieser Gelegenheit darf man nicht vergessen mitzuteilen, ob die Waren per Fracht, Express, im Postpaket oder anders zugesandt werden sollen.

WO MAN ERSATZTEILE ZU BESTELLEN HAT. CATERPILLAR-Vertreter haben über 400 Verkaufsstellen in den Vereinigten Staaten allein zu verwalten. Ähnliche Unternehmungen sind in den meisten Ländern der Welt strategisch verteilt. Diese Organisationen funktionieren mit der grössten Leichtigkeit unter der Ägide der ausgezeichneten Hilfsquellen der CATERPILLAR Tractor Co.

Das Verkaufspersonal hat Fabrikserziehung erhalten in Einlagerung und Ausfolgung von Ersatzteilen. Reichliche Vorräte sind überall vorhanden, um eine prompte Bedienung zu sichern. Treten Sie mit Ihrem nächsten CATERPILLAR Vertreter in Verbindung, überzeugen Sie sich, dass er Ihren Namen und Ihre Adresse kennt, als auch die genaue Seriennummer Ihrer Maschine. Er muss eine sorgfältig zusammengestellte Liste der Maschinenteile und Ansatzteile besitzen. Diese Liste wird die Herausgabe erleichtern, besonders wenn es sich um eine eilige Lieferung handelt.

WAS DER CATERPILLAR VERTRETER FÜR SIE TUN KANN. Es ist die Aufgabe des CATERPILLAR Vertreters, den Besitz und Gebrauch der CATERPILLAR Maschinerie für Sie möglichst wirksam und einträglich zu gestalten. Der Vertreter hält eine ständige Verbindung mit der Fabrik aufrecht, er beobachtet und benützt die neuesten Fortschritte und Erfindungen gleichviel ob es sich um Reparatur, Instandhalten, Gebrauchsverfahren und Bedarf an Maschinenteilen handelt. Die Lagerbestände sind aktiv und stets modern, um den normalen Arbeitsgang aufrecht erhalten zu können, Ihre Kapitalanlagen an CATERPILLAR Maschinen zu schützen und zu sichern.

Beinahe alle CATERPILLAR Vertreter halten einen 24-stündigen Notfalldienst aufrecht. Um eine schnelle Information bereit zu haben, schreiben Sie den Namen und die Adresse Ihres nächstliegenden CATERPILLAR Vertreters in Ihr Notizbüchlein an Ihrem Schreibtisch oder auf den Deckel Ihres Telefonbuches.

NUR CATERPILLAR MASCHINENTEILE GEBEN CATERPILLAR VOLLENDUNG. Jene Qualität und jene tadellose Ausführung, die den Weltruf der CATERPILLAR Erzeugnisse sicherten, ist in allen CATERPILLAR Maschinen und Ansatzteilen enthalten.

ESPAÑOL

CÓMO DEBEN PEDIRSE LAS PIEZAS. Es preciso que se especifique la cantidad y se dé el número y el nombre de las piezas que se necesiten. Es también importante dar el número de la serie a que pertenece la máquina para la cual se piden las piezas. Para saber dónde están las placas con el número de la serie, consúltese la página de este catálogo de piezas en que se dan las "Especificaciones". Sería conveniente que insertara Ud. el número de la serie de su máquina en el espacio que se ha dejado para este objeto en la página uno de este catálogo; de esta manera lo tendrá siempre a la mano cuando la necesite.

Para que el despacho se efectúe con prontitud, es necesario que se dé el nombre correcto del consignatario, así como la dirección y los nombres de la ciudad y la provincia, departamento o estado a que han de enviarse las piezas. Debe especificarse, asimismo, si el despacho hay que hacerlo por flete, expreso, paquete postal u otro conducto.

DONDE PUEDEN CONSEGUIRSE LAS PIEZAS. Hay más de 400 tiendas en los EE. UU. en que se venden los tractores y los accesorios "CATERPILLAR". Establecimientos semejantes a éstos están situados en lugares estratégicos en casi todos los países del mundo. Estas organizaciones cuentan con el ayuda y las extensas facilidades y la cooperación de la CATERPILLAR Tractor Co.

El personal de las tiendas mencionadas ha recibido su preparación en la fábrica en lo que se refiere a piezas y accesorios. Las tiendas mantienen siempre una gran existencia de estos últimos, lo que les permite prestar un servicio rápido. Póngase Ud. en contacto con el agente de la CATERPILLAR más cercano y procure darle su nombre y dirección, así como el número de la serie de su máquina, y averiguar se aquél tiene una lista exacta de accesorios y conexiones. Esto le facilitará el conseguir las piezas cuando las necesite con urgencia.

LO QUE PUEDEN HACER POR UD. LOS AGENTES DE LA CATERPILLAR. Los agentes de la CATERPILLAR tienen por mira el hacer económico y provechoso el uso y el funcionamiento de las máquinas CATERPILLAR; están siempre en constante comunicación con la fábrica, para estar así al corriente de los últimos métodos que se emplean para hacer reparaciones y para la conservación y el funcionamiento de las máquinas y la selección de las piezas que se requieran. Las existencias que mantienen dichos agentes son completas en todo sentido e incluyen todas aquellas piezas que se consideran esenciales para proteger la inversión que Ud. ha hecho en máquinas CATERPILLAR.

Casi todos los agentes de la CATERPILLAR ofrecen un servicio de emergencia de 24 horas. Para cuando se presente el caso, procure Ud. tener siempre a la mano, en su escritorio, el nombre y la dirección del agente.

SOLO LAS PIEZAS CATERPILLAR DAN EL RESULTADO APETECIDO. Todas las piezas CATERPILLAR han sido fabricadas según el patrón de alta calidad y mano de obra que ha hecho famosos los productos CATERPILLAR.

PORTUGUES

COMO ENCOMENDAR PECAS AVULSAS. É indispensável indicar a quantidade, o número e o nome de cada peça que desejar. É também importante dar o número de série da máquina a que a nova peça se destina. As chapas que trazem os números de série podem ser localizadas pela página "Especificações" deste catálogo. Sugurimos que V.S. escreva o número de série de sua máquina no espaço reservado para este fim na página número 1 do catálogo e assim te-lo-á pronto quando precisar.

Afim de assegurar pronta entrega, tenha o cuidado de indicar a nome exato do consignatário, com endereço completo incluindo rua a número, cidade, provincia ou estado e país para onde as peças devem ser despachadas, indicando também se o despacho deve ser feito por carga, correio expreso, ou outro meio de transporte.

PARA ONDE DIRIGIR A ENCOMENDA DE PECAS. Os distribuidores de CATERPILLAR mantêm mais de 400 casas nos Estados Unidos a estabelecimentos semelhantes estão localizados em pontos convenientes de quase todos os países do mundo. Todas estas organizações gozam das inúmeras vantagens e recursos da CATERPILLAR Tractor Co.

Todo o pessoal distribuidor tem experiência industrial em armazenamento e distribuição de peças e grandes estoques são sempre mantidos afim de assegurar serviço pronto. Entre em contacto com o distribuidor de CATERPILLAR que lhe ficar mais próximo e providencie para que e uma lista precisa dos acessórios e peças correspondentes. Esta relação facilitará o fornecimento de peças quando V.S. tiver necessidade urgente delas.

O QUE O DISTRIBUIDOR DE CATERPILLAR PODE FAZER PARA SERVIR V.S. A função dos distribuidores de CATERPILLAR é tornar económico e proveitoso para V.S. possuir e operar maquinário CATERPILLAR. Constantemente em contacto com a fábrica a respeito de novos processos de concerto e manutenção do maquinário, de técnicas de funcionamento e de características das peças, mantêm um estoque ativo, incluindo sempre os últimos tipos e todas as peças normalmente necessárias para que V.S. tire o máximo proveito do capital aplicado em maquinário CATERPILLAR.

Quase todos os nossos distribuidores mantêm serviço de emergência para fornecimento dentro de 24 horas. Afim de ter sempre à mão as referências, escreva no bloco de sua escrevaninha, ou na primeira página de sua lista de telefones, o nome e endereço de seu distribuidor.

56 PECAS CATERPILLAR PODEM OFERECER FUNCIONAMENTO CATERPILLAR. A mesma qualidade e técnica de manufatura que tornam os produtos CATERPILLAR famosos no mundo inteiro caracterizam as peças avulsas CATERPILLAR.

INDEX

Name	Page
Blade—No. 8A	14
Blade—No. 8C	13
Blade—No. 8S	6
Blade—No. 8U	11
Brace-Arm—No. 8A	15
Brace—No. 8S & No. 8U	10
Bracket-Cylinder	48
Bracket-Sheave	36
Cable and Guard	23
Cable Cutter	51
C-Frame—No. 8A	22
Cylinder-Hydraulic	39
Hitch-Sheave	38
Push Arm—No. 8S & No. 8U	10
Push Cup	49
Sheaves	35
Specifications	52
Trunnion	48

INDEX ALPHABÉTIQUE

Désignation	Page
Bras de Bulldozer N° 8S et N° 8U	10
Câbles et protecteurs	23
Caractéristiques	52
Châssis en U pour N° 8A	22
Cisaille à câble	51
Lame N° 8A	14
Lame N° 8C	13
Lame N° 8S	6
Lame N° 8U	11
Palonnier de moufle	38
Plaques-support et tourillons de vérin	48
Poulies et moufles	35
Support de moufles	36
Tampon de poussée	49
Tirant de réglage pour N° 8A	15
Tirant de réglage pour N° 8S et N° 8U	10
Tourillons	48
Vérins hydrauliques	39

ÍNDICE


Nombre	Página
Abrazadera—Cilindro	48
Abrazadera—Polea	36
Bastidor "U" No. 8A	22
Brazo de Empuje—No. 8S y No. 8U	10
Cable y Protección	23
Caja de Empuje	49
Cilindro Hidráulico	39
Enganche—Polea	38
Especificaciones	52
Hoja No. 8A	14
Hoja No. 8C	13
Hoja No. 8S	6
Hoja No. 8U	11
Muñón	48
Poleas	35
Tirante—Brazo—No. 8A	15
Tirante—No. 8S y No. 8U	10

ÍNDICE


Nomenclatura	Página
Armação C—N° 8A	22
Braço—N° 8A	15
Braço—N° 8S e N° 8U	10
Braço lateral—N° 8S e N° 8U	10
Cabo e protetor	23
Chapa de empuxo	49
Cilindro hidráulico	39
Cortador de cabos	51
Engate da roldana	38
Especificações	52
Lâmina—N° 8A	14
Lâmina—N° 8C	13
Lâmina—N° 8S	6
Lâmina—N° 8U	11
Munhão	48
Roldanas	35
Suporte da roldana	36
Suporte do cilindro	48

INHALTSVERZEICHNIS


Bezeichnung	Seite
Hydraulik-Zylinder	39
Montagezapfen	44
Rollenträgeraufhängung	36
Rollenträgergelenke	38
Schild Nr. 8A	14
Schild Nr. 8C	13
Schild Nr. 8S	6
Schild Nr. 8U	11
Schubarm Nr. 8A	15
Schubarm Nr. 8S & 8U	10
Schublagerböcke	49
Seil und Seilschutz	23
Seilkappvorrichtung	51
Seilrollenträger	35
Streben Nr. 8A	15
Streben 8S & 8U	10
Technische Daten	52
U-Rahmen Nr. 8A	22
Zylinderdrehzapfen	48



ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




3J2105 BLADE GROUP

No. 8S Bulldozer Serial No. 29E2609 to 29E3661 inclusive



4J2210 BLADE GROUP
Effective with No. 8S Bulldozer Serial No. 29E3662

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




55234


2J2447 PUSH ARM AND BRACE GROUP

No. 8S Bulldozer Serial No. 29E1 to 29E1947 and No. 8U Bulldozer Serial No. 30E1 to 30E390 inclusive

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




3J2641 PUSH ARM GROUP
No. 8S Bulldozer Serial No. 29E1948 to 29E3661 and No. 8U Bulldozer Serial No. 30E391 to 30E828 inclusive
For D8 Tractors equipped with rear mounted counterweight equipment



PUSH ARM


Effective with No. 8S Bulldozer Serial No. 29E3662—Up and No. 8U Bulldozer Serial No. 30E829—Up
For D8 Tractors equipped with rear mounted counterweight equipment



03503


3J2099 PUSH ARM AND BRACE GROUP

No. 8S Bulldozer Serial No. 29E1948 to 29E3661 and No. 8U Bulldozer Serial No. 30E391 to 30E828 inclusive
 For D8 Tractors equipped with Seven Roller Track Roller Frames




4J2140 PUSH ARM AND BRACE GROUP

Effective with No. 8S Bulldozer Serial No. 29E3662—Up and No. 8U Bulldozer Serial No. 30E829—Up
 For D8 Tractors equipped with Seven Roller Track Roller Frames




ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




3J2107 BLADE GROUP

No. 8S Bulldozer Serial No. 30E391 to 30E537 inclusive




3J2107 BLADE GROUP

No. 8S Bulldozer Serial No. 30E538 to 30E828 inclusive




4J2189 BLADE GROUP
Effective with No. 8U Bulldozer Serial No. 30E829



3J2788 BLADE GROUP


Effective with No. 8C Bulldozer Serial No. 71F1



2J2458 BLADE GROUP


Effective with No. 8A Bulldozer Serial No. 28EI

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




63714

2J2456 ARM AND BRACE GROUP
 No. 8A Bulldozer Serial No. 28E1 to 28E673 inclusive




2J2456 ARM AND BRACE GROUP

No. 8A Bulldozer Serial No. 28E674 to 28E1641, 28E1664 and 28E1706 inclusive




2J2456 ARM AND BRACE GROUP

No. 8A Bulldozer Serial No. 28E1642 to 28E1663, 28E1665 to 28E1705 and 28E2250 inclusive



3J3841 ARM AND BRACE GROUP
 Effective with No. 8A Bulldozer Serial No. 28E2251




3J3516 C-FRAME AND BRACE GROUP—Second Type


Effective with No. 8A Bulldozer Serial No. 28E1

3J6606 C-Frame Group and 3J6562 Brace Group parts are shown on Pages 18B, 18C and 18D

Note: For use where extreme load conditions are encountered




3J6606 C-FRAME GROUP—First Type
Part of 3J3516 C-Frame and Brace Group shown on Page 18A



66510

3J6606 C-FRAME GROUP—Second Type
Part of 3J3516 C-Frame and Brace Group shown on Page 18A


18D CATERPILLAR NO. 8A, NO. 8C, NO. 8S & NO. 8U BULLDOZERS



3J6562 BRACE GROUP

Part of 3J3516 C-Frame and Brace Group shown on Page 18A


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



3J3516 C-FRAME AND BRACE GROUP


Effective with No. 8A Bulldozer Serial No. 28E1

Note: For use where extreme load conditions are encountered




3J2791 C-FRAME GROUP
Effective with No. 8C Bulldozer Serial No. 71F1

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




2J2457 C-FRAME GROUP


No. 8A Bulldozer Serial No. 28E1 to 28E2250 inclusive



3J3840 C-FRAME GROUP
No. 8A Bulldozer Serial No. 28E2251 to 28E2741 inclusive




3J3840 C-FRAME GROUP
Effective with No. 8A Bulldozer Serial No. 28E2742



2J2468 CABLE AND GUARD GROUP—First Type

For use with Rear Cable Control
For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

Only separate parts serviced. When complete Group is required order 3J4060 shown on Page 25




2J2468 CABLE AND GUARD GROUP—Second Type

For use with Rear Cable Control

For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

Only separate parts serviced. When complete Group is required order 3J4060 shown on Page 25




3J3990 CABLE AND GUARD GROUP

For use with 128 Cable Control


For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up. NO. 8C BULLDOZER REQUIRES THE USE OF 2M9626 FRONT GUARD ASSEMBLY for use with 126 Cable Control

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




3J4060 CABLE AND GUARD GROUP


For use with Rear Cable Control
For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up



3J2870 SHEAVE, CABLE AND HITCH GROUP—Eight Part Line—First Type
 Effective with No. 8S Bulldozer Serial No. 29E1649—Up and No. 8U Bulldozer Serial No. 30E343—Up
 For use with Front Cable Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up
 Only separate parts serviced. When complete Group is required order 3J4040 shown on Page 26B




3J2870 SHEAVE, CABLE AND HITCH GROUP—Eighth Part Line—Second Type
 Effective with No. 8S Bulldozer Serial No. 29E1649—Up and No. 8U Bulldozer Serial No. 30E343—Up
 For use with Front Cable Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up
 Only separate parts serviced. When complete parts is required order 3J4040 shown on Page 26B



33J4040 SHEAVE, CABLE AND HITCH GROUP—Eight Part Line

REAR CABLE AND TWIN GROUP—Bulldozer Serial No. 30E343—Up
Effective with No. 8S Bulldozer Serial No. 29E1649—Up and No. 8U Bulldozer Serial No. 30E343—Up
For use with Front Cable Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




3J2871 SHEAVE, CABLE AND HITCH GROUP—Eight Part Line—First Type


Effective with No. 8S Bulldozer Serial No. 29E1649—Up and No. 8U Bulldozer Serial No. 30E343—Up

For use with Rear Cable Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

Only separate parts serviced. When complete Group is required order 3J4041 shown on Page 29




3J2871 SHEAVE, CABLE AND HITCH GROUP—Eight Part Line—Second Type
 Effective with No. 8S Bulldozer Serial No. 29E1649—Up and No. 8U Bulldozer Serial No. 30E343—Up
 For use with Rear Cable Control, For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up
 Only separate parts serviced. When complete Group is required order 3J4041



3J4041 SHEAVE, CABLE AND HITCH GROUP—Eight Part Line


Effective with No. 8S and No. 8U Bulldozer Serial No. 29E1649—Up and 30E343—Up

For use with Rear Cable Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up



3J2872 SHEAVE, CABLE AND HITCH GROUP—Eight Part Line—First Type

Effective with No. 8A Bulldozer Serial No. 28E1—Up
 For use with Rear Cable Control; For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up
 Only separate parts serviced. When complete Group is required order 3J4042 shown on Page 30B




3J2872 SHEAVE, CABLE AND HITCH GROUP—Eight Part Line—Second Type

Effective with No. 8A Bulldozer Serial No. 28E1—Up

For use with Rear Cable Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

Only separate parts serviced. When complete Group is required order 3J4042 shown on Page 30B




3J4042 SHEAVE, CABLE AND HITCH GROUP—Eight Part Line

Effective with No. 8A Bulldozer Serial No. 28EI—Up

For use with Rear Cable Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



3J2873 SHEAVE, CABLE AND HITCH GROUP—Eight Part Line—First Type


Effective with No. 8A Bulldozer Serial No. 28E1—Up
For use with Front Cable Control, For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up
Only separate parts serviced. When complete Group is required order 3J4043 shown on Page 33

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



3J2873 SHEAVE, CABLE AND HITCH GROUP—Eight Part Line—Second Type

For use with Front Cable Control. For D8 Tractors Serial No. 28E1—Up
Effective with No. 8A Bulldozer Serial No. 28E1—Up
Only separate parts serviced. When complete Group is required order 3J4043





3J4043 SHEAVE, CABLE AND HITCH GROUP—Eight Part Line

Effective with No. 8A Bulldozer Serial No. 28E1


For use with Front Cable Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE






4H1094 SHEAVE GROUP—Six Part Line—Second Type
For use with Front or Rear Cable Control
For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up



3J3988 SHEAVE GROUP—Six Part Line

For use with Front or Rear Cable Control
For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up


NOTE: NO. 8C BULLDOZER REQUIRES THE USE OF 2M9626 FRONT GUARD ASSEMBLY



2J620 SHEAVE BRACKET GROUP

For use with Rear Cable Control

For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up
NO. 8C BULLDOZER REQUIRES THE USE OF 2M9626 FRONT GUARD ASSEMBLY




2J619 SHEAVE BRACKET GROUP

For use with Front Cable Control

For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




3J6045 SHEAVE HITCH GROUP

Effective with No. 8C Bulldozer Serial No. 71F1

For use with Front or Rear Cable Control


For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up



4H2647 SHEAVE HITCH GROUP


No. 8S Bulldozer Serial No. 29E1 to 29E3661 inclusive and No. 8U Bulldozer Serial No. 30E1 to 30E828 inclusive. For use with Front or Rear Cable Control
 For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



4J2244 SHEAVE HITCH GROUP


Effective with No. 8S Bulldozer Serial No. 29E3662—Up and No. 8U Bulldozer Serial No. 30E829—Up. For use with Front or Rear Cable Control For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up



4H1209 SHEAVE HITCH GROUP

Effective with No. 8A Bulldozer Serial No. 28E1—Up and No. 8C Bulldozer Serial No. 71F1—Up. For use with Front or Rear Cable Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up. No. 8C Bulldozer requires the use of 2M9626 Front Guard Assembly


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




2J2470 HYDRAULIC CYLINDER GROUP—2 Required

Effective with No. 8A, No. 8S and No. 8U Bulldozer Serial No. 28E1—Up, 29E1—Up and 30E1—Up
For use with Hydraulic Control, For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE


**3J2189 HYDRAULIC CYLINDER GROUP—6" x 46"—2 Required—First Type**

Effective with No. 8A, No. 8S and No. 8U Bulldozer Serial No. 28E1—Up, 29E1—Up and 30E1—Up
 For use with Hydraulic Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up




3J2189 HYDRAULIC CYLINDER GROUP—6" x 46"—2 Groups Required—Second Type

Effective with No. 8A Bulldozer Serial No. 28E1—Up, No. 8S Bulldozer Serial No. 29E1—Up and No. 8U Bulldozer Serial No. 30E1—Up
For use with Hydraulic Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up



3J2189 HYDRAULIC CYLINDER GROUP—6" x 46"—2 Groups Required—Third Type

Effective with No. 8A Bulldozer Serial No. 28E1—Up, No. 8S Bulldozer Serial No. 29E1—Up and No. 8U Bulldozer Serial No. 30E1—Up
For use with Hydraulic Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up




3J4871 HYDRAULIC CYLINDER GROUP—7 1/4" x 48 1/2"

Effective with No. 8C Bulldozer Serial No. 71F1


For use with Hydraulic Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




3J2039 HYDRAULIC CYLINDER GROUP—6 1/2" x 33 1/2"
Part of 3J2060 Bulldozer Conversion Group shown on Page 45

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




2J3894 HYDRAULIC TILTBOILER CYLINDER GROUP
For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



3J2060 BULLDOZER CONVERSION GROUP


For use with Hydraulic Control
For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up
3J2039 Hydraulic Cylinder Group parts are shown on Page 43



3J1989 CYLINDER BRACKET GROUP—First Type


Effective with No. 8A, No. 8S and No. 8U Bulldozer Serial No. 28E1—Up, 29E1—Up and
30E1—Up. For use with Hydraulic Control
For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



3J1989 CYLINDER BRACKET GROUP—Second Type


Effective with No. 8A, No. 8S and No. 8U Bulldozer Serial No. 28E1—Up, 29E1—Up and 30E1—Up. For use with Hydraulic Control
For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up



3J1989 CYLINDER BRACKET GROUP—Third Type

Effective with No. 8A, No. 8S and No. 8U Bulldozer Serial No. 28E1—Up, 29E1—Up and 30E1—Up. For use with Hydraulic Control
For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




3J2441 TRUNNION GROUP—Second Type

Effective with No. 8C Bulldozer Serial No. 71F1

For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

NO. 8C BULLDOZER REQUIRES THE USE OF 2M9626 FRONT GUARD ASSEMBLY




3J5195 CYLINDER BRACKET GROUP

Effective with No. 8C Bulldozer Serial No. 71F1

For use with Hydraulic Control

For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up




3J2441 TRUNNION GROUP

Effective with No. 8C Bulldozer Serial No. 71F1


For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

NO. 8C BULLDOZER REQUIRES THE USE OF 2M9626 FRONT GUARD ASSEMBLY
ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



2J2451 CYLINDER BRACKET GROUP


Effective with No. 8A, No. 8S and No. 8U Bulldozer Serial No. 28E1—Up, 29E1—Up and 30E1—Up. For use with Hydraulic Control. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up




2J584 BULLDOZER TRUNNION GROUP

Effective with No. 8A, No. 8S and No. 8U Bulldozer Serial No. 28E1—Up, 29E1—Up and 30E1—Up. For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




2J4292 PUSH CUP GROUP
Effective with No. 8A Bulldozer Serial No. 28E1




2J5460 PUSH CUP GROUP
Effective with No. 8S Bulldozer Serial No. 29E1

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




2J9070 PUSH CUP GROUP
Effective with No. 8S Bulldozer Serial No. 29E1




3J1012 C-FRAME GROUP—Tandem Pusher
For D8 Tractors Serial No. 35A1—Up, 36A1—Up and 46A1—Up

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



2J8801 CABLE AND REEL GROUP



1J9698 CABLE CUTTER

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

MEMORANDA

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

MEMORANDA

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

SPECIFICATIONS

(SUBJECT TO CHANGE WITHOUT NOTICE)

	No. 8A	No. 8C	No. 8S	No. 8U
Weight, shipping (approx.) in pounds				
Equipped for use with:				
Front Cable Control	9,984	9,700	7,970	8,750
Rear Cable Control	9,770	8,800	7,756	8,536
Hydraulic Control	10,654	9,400	8,731	9,527

CABLE

Size	1/2"	1/2"	1/2"	1/2"
Length, for use with				
Front Cable Control	52'	73'	52'	52'
Rear Cable Control	80'	92 1/2'	80'	80'

BLADE

Length	15' 2"	9' 11 3/4"	12' 9"	13' 5"
Height	43 5/8"	59 3/4"	52 3/8"	52 3/8"
Maximum lift above ground:				
Cable controlled	53 1/8"	32"	53 1/4"	55"
Hydraulically controlled	52 1/2"	32"	54 1/4"	54 1/4"
Maximum blade				
pitch adjustment			11°	11°
Maximum blade				
tilting adjustment	17"		31"	31"

MACHINE SERIAL NUMBER PLATE LOCATION

Serial number plate is located on the right-hand side of the rear face of the moldboard.

No. 24, No. 80, No. 81 & No. 82 BUILDERS 28E, 29E, 30E & 31E SERIES

CATERPILLAR

Diesel Engines - - - - Tractors - - - - Motor Graders
- - - - - Earthmoving Equipment - - - - -

THERE IS A CATERPILLAR DEALER NEAR YOU

Caterpillar, Cat and Traxcavator are registered trade marks
of Caterpillar Tractor Co.

PRINTED IN U.S.A.

FORM 34469