


LETOURNEAU



EQUIPMENT

MODEL J6 CARRYALL SCRAPER

PARTS CATALOG

LETOURNEAU
EQUIPMENT
COMPANY

Form PC-190

MODEL

J6

CARRYALL SCRAPER

J6 CARRYALL SCRAPER


E-1223 DUMP CABLE 1/2 x 6 x 19=300 FOOT SPOOL

From left drum on Power Control Unit enter cable in swivel sheave housing.....**B**
Then over inside sheave in housing.....**G**
Then down and around apron sheave in housing.....**J**
Then up to top A-Frame housing.....**L**
Then back and around sheave in housing.....**M**
Then down and around sheave in housing.....**P**
Then back and around bottom sheave in housing.....**Q**
Then forward and around sheave in housing.....**Q**
Then back and enter top of housing.....**Q**

Then across tailgate and around top sheave in housing.....**N**
Then forward and around sheave in housing.....**K**
Then back and around bottom sheave in housing.....**N**
Then forward and dead end cable on bottom of sheave housing.....**K**

E-1220 SPRING BOX CABLE 1/2 x 6 x 19=15 FEET LONG


From Right Drum on Power Control Unit, enter cable at Swivel Sheave Housing.....**A**
Then up and enter slot.....**C**
Then up and around inside sheave in housing.....**H**
Then forward and enter top of housing.....**D**
Then back and enter bottom of outside sheave in housing.....**H**
Then forward and around top Pushbeam Sheave Housing.....**F**
Then back to inside sheave in housing.....**G**
Then forward to bottom of housing.....**E**
Then enter cable in hole above outside sheave in housing.....**G**
Then Dead end at cable wedge.....**I**
On the top of housing.....**G**



CABLE THREADING DIAGRAM

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS


J6 CARRYALL SCRAPER



BODY

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS

PRINTED IN U.S.



279


APRON

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS

PRINTED IN U.S.A.




PRINTED IN U.




YOKE

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS



PUSHBEAM



FRONT AXLE TONGUE

INSERT IN MISCELLANEOUS SECTION OF MASTER PARTS CATALOG

DRAWBAR UNIVERSAL ASSEMBLIES

TRACTOR SIZE		ASSEM. NO.		FORGING NO.												BLOCK						NUT		BOLT		COTTER			
		PART NO.		A	B	C	D	E	F	PART NO.		G	H	I	J	K	PART NO.		L	M	PART NO.		N	O	PART NO.		P	Q	

UNIVERSAL NUT ASSEMBLY--D-6192 2 BOLT-----C-1685
 2 NUT-----C-1524
 2 LOCKWASHER-----C-1540



C-1561 COTTER KEY-----I
 C-59 NUT-----I


D4, D6, D7, & D8 TRACTOR

DRAWBAR UNIVERSAL ASSEMBLIES

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS


PRINTED IN U. S. A.

1012



9.75 X 20 SINGLE WHEEL GROUP

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS



9.75 X 20 DUAL WHEEL GROUP

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS