

STEERING CLUTCHES

29		28	12			25	24	23	22	21	20	19	18	17	11 15 15	13		10	9	æ	7	6	ъ	4		ω	2 -	ITEM
Ų		•			_		, T			• 100000		_						Ū							_	~		
* * * * * * * * * * * * * * * * * * * *	921402	645236	919128	904208	642448 921573		040475	623004	623929	623003	623008	623007	623932	035793	663245 663117 630052	623516	052119 023756	623879	059035	623878	059048	623876	623877	048209	650622	# 1 # 300 M 4c	623927 650813	PART NO.
2	2	N	NN	1 66	NN	2	6	2	N	N	2	2	2	N	NNN	2	⊔ ∞ 4	18	2	18	N	30	30	N	Ν.	2	20	QTY.
UNION, bulkhead (See STEERING CONTROL VALVE AND LINES)	excluding #6082) ELBOW, adjustable, 90°, flare type, 1/2" tube, 3/4"NF (Includes washer, nut and O-RING 921349)	HOSE, oil pressure (See HOSE PARTS)(Effective with tractor #6081,	#6081, including #6082) CONNECTOR, flare type, 1/2" tube, 1/2"NPT male	CAPSCREW, 1/2"NC x 1-3/8" LOCKWASHER, 1/2"	73.	RING, collector (Used prior to tractor #6081 including #6082. Order 1 each RING 642448, HOSE 645236, PLUG 921573, ELBOW 921402)	G, throwout bearing ring	RING, sealing, actuating piston, inner	PISTON, actuating	RING, sealing, actuating piston, outer	CUP, clutch throwout bearing	CONE ASSEMBLY, clutch throwout bearing	SLEEVE, throwout	PIN, hub retaining washer	WASHER ASSEMBLY, hub retaining (Includes item 17) CAPSCREW, thin-hd., 1"NF x 1-3/4" LOCK, capscrew (Used prior to tractor #8264)	HUB, driving	CAPSCREW, plate (drilled-hd., 1/2"NF x 6-1/2") WIRE, locking, 1/16" x 26"	SPACER, throwout plate	PLATE, throwout	SPRING, pressure	PLATE, pressure	DISC, friction (steel)(Use as req'd)	DISC, friction (bimetallic)	PLATE, back (Used prior to tractor #7912)	HUB, steering clutch (Effective with tractor #7912)	HUB, steering clutch (Used prior to tractor $\#7912$. Order HUB 650622 and discard item 4)	CLUTCH ASSEMBLY (Consists of items 3 thru 12) BOLT, self-locking, 5/8"NC x 1-7/8"	DESCRIPTION