

MODEL T REAR DOUBLE DRUM POWER CONTROL UNIT

SERIAL NO. _____

PARTS CATALOG

FOR MODEL T

POWER CONTROL UNIT


REAR DOUBLE DRUM

EFFECTIVE WITH SERIAL NUMBER

SHORT DRUM CASE P 13099 STE & UP
STANDARD DRUM CASE P 12429 TE & UP
LONG DRUM CASE P 12949 LTE & UP

D8 NECK N 5095 T8B & UP
D7 NECK N 5584 T7B & UP
NEW D7 NECK N 5443 TD7B & UP
DL NECK N 5463 T6B & UP
D4 NECK N 5599 T4B & UP
CAT. 60 NECK N 5651 T60B & UP

MODEL T PCU




PC-235

942

CASE GROUP

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS

PRINTED IN U. S. A.




PC-235

995

NECK ASSEMBLY

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS

PRINTED IN U. S. A.



NOTE:


LEFT AND RIGHT ARE DETERMINED BY STANDING IN BACK OF THE TRACTOR AND LOOKING FORWARD.

733

SHORT CABLE DRUM GROUP

EFFECTIVE WITH SERIAL NO P13099 STE & UP

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS




LEFT AND RIGHT DETERMINED BY STANDING IN BACK OF TRACTOR AND LOOKING FORWARD

STANDARD CABLE DRUM GROUP

EFFECTIVE WITH SERIAL NO P12429 TE & UP
ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS

MODEL T PCU




LEFT AND RIGHT DETERMINED BY STANDING IN BACK OF TRACTOR AND LOOKING FORWARD

723

LONG DRUM CABLE DRUM GROUP

EFFECTIVE WITH SERIAL NO P-9910 LTB& P12949 LTE & UP


ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS



724

DOUBLE DECKER GROUP E-4283

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS




Gears and bearings for this neck group see Page 2

725

D8 NECK GROUP

EFFECTIVE WITH SERIAL NO N5095 T8B & UP
ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS




Gears and bearings for this neck group see page 2

726

D7 NECK GROUP

EFFECTIVE WITH SERIAL NO N5584 T7B & UP
ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS




Gears and bearings for this neck group see page 2

727

NEW D7 NECK GROUP

EFFECTIVE WITH SERIAL NO N5443 TD7B & UP
ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS




Gears and bearings for this neck group see page 2

728

D6 NECK GROUP

EFFECTIVE WITH SERIAL NO N 5463 T 6B & UP
ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS




Gears and bearings for this neck group see page 2

729

D4 NECK GROUP

EFFECTIVE WITH SERIAL NO N5599 T4B & UP
ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS




Gears and bearings for this neck group see page 2

CAT 60 NECK GROUP

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS


PRINTED IN U



Gears and bearings for this neck group see page 2

MODEL SO NECK GROUP
EFFECTIVE WITH SERIAL NO. N-5563-TSOB & UP
ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS

INSERT AFTER PAGE 13, FORM PC-235, MODEL T PCU




PC-235

994

MODEL L & HD14 NECK GROUP H-8131
EFFECTIVE WITH SERIAL NO. N5611TLB & UP
ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS

14A

MODEL T PCU




EFFECTIVE WITH SERIAL NO N7741 TLB, N7917 TLB, N7918 TLB AND N8029 TLC & UP

MODEL L & HD14 NECK GROUP R-171

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS

PRINTED IN U. S. A.


INSERT AFTER PAGE 14, FORM PC-235, MODEL T PCU



PC-235


1007

NEW D6 NECK GROUP H-9549
EFFECTIVE WITH SERIAL NO N7089 TD6B & UP
ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS



MODEL HD10 NECK GROUP H-9666
 EFFECTIVE WITH SERIAL NO. N5641 TH10B & UP
 ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS


INSERT AFTER PAGE 16 FORM PC-235 MODEL T PCU



PC-235

1000

MODEL TDI8 NECK GROUP H-9536
EFFECTIVE WITH SERIAL NO. N5660 TT18B & UP
ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS




PC-235

1139

MODEL TDI4 NECK GROUP R-116
 EFFECTIVE WITH SERIAL NO. N4662 TT14B & UP
 ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS

PRINTED IN U. S. A.


INSERT AFTER PAGE 18 FORM PC-235 MODEL T PCU



PC-235

1158

MODEL CG CLETRAC NECK GROUP
EFFECTIVE WITH SERIAL NO. N8609 TCB & UP
ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS



PC-235


1182

CABLE CUTTER ASSEMBLY H-3150

ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS

PRINTED IN U.S.A

INSERT AFTER PAGE 20, FORM PC 235, MODEL T PCU



PC-235

1142

MODEL TF NECK GROUP R-2360
 EFFECTIVE WITH SERIAL NO. N10187 TFB & UP
 ALWAYS GIVE MACHINE NUMBER WHEN ORDERING PARTS

LETOURNEAU
MODEL T REAR DOUBLE DRUM
POWER CONTROL UNIT
PARTS CATALOG
WESTINGHOUSE

LeTourneau-Westinghouse Company

(A Subsidiary of Westinghouse Airbrake Company)

Peoria · Illinois U. S. A.